WSM

WORKSHOP MANUAL

DIESEL ENGINE

03 SERIES

Kubota

MidWestTech | Kubota 03 Series Diesel Engine Service Manual | Publication 01092

Order the manual at mid-west-tech.com >

CONTENTS

SAFETY INSTRUCTIONS ——— 1
SPECIFICATIONS ——— 7
PERFORMANCE CURVES ——— 13
DIMENSIONS ——— 16

M. MECHANISM

F. FEATURE ——— M-1
1. ENGINE BODY ——— M-3
[1] CYLINDER BLOCK M-3
[2] CYLINDER HEAD M-3
[3] CRANK SHAFT M-5
[4] PISTON AND PISTON RINGS M-5
[5] CONNECTING ROD M-5
[6] CAMSHAFT M-7
[7] FLYWHEEL M-7
[8] ROCKER ARM M-7
2. LUBRICATING SYSTEM ——— M-9
[1] GENERAL M-9
[2] OIL PUMP M-11
[3] RELIEF VALVE M-11
[4] OIL FILTER CARTRIDGE M-13
[5] OIL PRESSURE SWITCH M-13
3. COOLING SYSTEM ——— M-15
[1] GENERAL M-15
[2] WATER PUMP M-15
[3] THERMOSTAT M-17
[4] RADIATOR M-17
[5] RADIATOR CAP M-17
4. INTAKE/EXHAUST SYSTEM ——— M-19
[1] AIR CLEANER M-19
[2] MUFFLER M-19
5. FUEL SYSTEM ——— M-21
[1] GENERAL M-21
[2] INJECTION PUMP M-21
[3] INJECTION NOZZLE M-27
[4] FUEL FILTER M-27
[5] FUEL LIFT PUMP M-29
[6] GOVERNOR M-31
6. ELECTRICAL SYSTEM ——— M-35
[1] CHARGING SYSTEM M-35

S. DISASSEMBLING AND SERVICING

G. GENERAL ——— S-1
[1] ENGINE IDENTIFICATION S-1
[2] GENERAL PRECAUTIONS S-3
[3] TIGHTENING TORQUES S-5
[4] TROUBLESHOOTING S-8
[5] SERVICING SPECIFICATIONS S-16
[6] MAINTENANCE CHECK LIST S-32
[7] CHECK AND MAINTENANCE S-35
[8] SPECIAL TOOLS S-45
1. ENGINE BODY ——— S-53
CHECKING AND ADJUSTING S-53
DISASSEMBLING AND ASSEMBLING S-55
[1] DRAINING WATER AND OIL S-55
[2] EXTERNAL COMPORNENTS S-55
[3] CYLINDER HEAD AND VALVES S-57
[4] GEAR CASE S-59
[5] PISTON AND CONNECTING ROD S-67
[6] FLYWHEEL AND CRANKSHAFT S-71
SERVICING S-73
[1] CYLINDER HEAD S-73
[2] TIMING GEAR AND CAMSHAFT S-81
[3] PISTON AND CONNECTING ROD S-85
[4] CRANKSHAFT S-89
[5] CYLINDER BORE S-97
2. LUBRICATING SYSTEM ——— S-99
CHECKING S-99
SERVICING S-99
[1] OIL PUMP S-99
3. COOLING SYSTEM ——— S-101
CHECKING S-101
[1] FAN BELT S-101
[2] RADIATOR S-101
DISASSEMBLING AND ASSEMBLING S-103
4. FUEL SYSTEM ——— S-105
CHECKING AND ADJUSTING S-105
[1] INJECTION PUMP S-105
[2] INJECTION NOZZLE S-107
DISASSEMBLING AND ASSEMBLING S-109
[1] INJECTION PUMP S-109
[2] INJECTION NOZZLE S-109
5. ELECTRICAL SYSTEM ——— S-111
CHECKING S-111
[1] STARTER S-111
[2] GLOW PLUG S-111
[3] ALTERNATOR AND REGULATOR S-113
DISASSEMBLING AND ASSEMBLING S-123
[1] STARTER S-123
[2] ALTERNATOR S-125
SERVICING S-133
[1] STARTER S-133
[2] ALTERNATOR S-137

MidWestTech | Kubota 03 Series Diesel Engine Service Manual | Publication 01092 Order the manual at mid-west-tech.com >