Maintenance and Repair Parts Manual

Snorkel

UNO 41D/G

engine powered diesel - gasoline LPG fuel

ATTENTION:

Always give the unit serial and model number when ordering parts.

This information is found on the serial number placard.

Be sure to order all parts by their part number, and if possible, specify routing of shipment.

All correspondence relative to this unit, such as field reports, discrepancy reports, requests for service information, etc., should be directed to:

OmniQuip Snorkel INTERNATIONAL

P.O. Box 1160
St. Joseph, MO 64502-1160

Attention: Service Department

P/N 0152874
January, 1998

MidWestTech | Snorkel UNO41D, UNO41G Articulating Boom Lift Maintenance and Repair... Order the manual at mid-west-tech.com >

Maintenance Information

Manual Organization 1
Maintenance 1
Repair parts and illustrations 1
Hydraulics 1
Electrical 1
Options 1
Parts index - Page locator 1
Parts drawings 2
General specifications 3
OSHA, ANSI and CSA Standards 3
Maintenance schedules 4
Daily maintenance (operator's inspection) 4
90 day or 150 hour maintenance (trained service technician) 5
Yearly or 500 hour maintenance (trained service technician) 5
Lubrication information 6
Lubrication illustration 6
Lubricants 6
Pressure gun application 6
Rotation bearing 6
Rotation gear teeth and pinion 6
Tie rods 6
Swing drive 6
Power wheel 7
Hydraulic oil reservoir 7
Engines 7
Door hinges and latches 7
Platform rotation gear box 7
Return Filter 7
Suction strainer 8
Pump drive shaft Kubota units only 8
Batteries 8
Preventive inspection maintenance 90 day or 150 hour checklist 9
Torque chart 11

Section 1. - Repair Parts

Chassis and Turntable Mounting 1-2
Swing Drive Installation 1-4
Steering Installation 1-6
Steer Yoke Installation 1-8
Drive Installation 1-10
Drive Installation illustration 1-11
Power Wheel 1-12
Booms Installation 1-14
Upper Boom and Hose Carrier Assembly 1-16
Upper Boom and Hose Carrier Assembly illustration 1-17
Boom Assembly, Upper illustration 1-18
Boom Assembly, Upper 1-19
Hose Carrier Assembly 1-20
Hose Carrier Assembly illustration 1-21
Extend Cylinder Assembly illustration 1-22
Extend Cylinder Assembly 1-23
Cylinder Assembly, Lower Boom Lift 1-24
Cylinder Assembly, Master Level 1-25
Cylinder Assembly, Middle Boom Lift 1-26
Cylinder Assembly, Slave Level 1-27
Cylinder Assembly, Upper Boom Lift 1-28
Platform Installation 1-29
Platform Installation illustration 1-31
Platform Rotation Gear Box, Morse 1-32
Platform Rotation Gear Box, Safeguard 1-34
Chassis Cowling Installation, Kohler 1-36
Chassis Cowling Installation, Kubota 1-38
Turntable Cowling Installation 1-40
Fuel Tank Installation 1-42
Hydraulic Oil Reservoir Installation 1-43
Engine Installation, Kohler 1-44
Engine Installation, Kohler illustration 1-45
Engine Assembly, Kohler illustration 1-46
Engine Assembly, Kohler 1-47
Engine Installation, Kubota Gas 1-48
Engine Installation, Kubota Gas illustration 1-49
Engine Assembly, Kubota Gas illustration 1-50
Engine Assembly, Kubota Gas 1-51
Throttle and Choke Installation, Kubota Gas 1-53
Air Cleaner Installation, Kubota Gas 1-54
Engine Installation, Kubota Diesel 1-56
Engine Installation, Kubota Diesel illustration 1-57
Engine Assembly, Kubota Diesel illustration 1-58
Engine Assembly, Kubota Diesel 1-59
Tire and Wheel Installation 1-61
Placards and Decals Installation 1-62

MidWestTech | Snorkel UNO41D, UNO41G Articulating Boom Lift Maintenance and Re... Order the manual at mid-west-tech.com >

Table of Contents

Section 2. - Hydraulics

Hydraulic Schematic illustration . . . 2-3
Chassis Hydraulic Equipment, Kohler . . . 2-5
Chassis Hydraulic Equipment, Kohler illustration . . . 2-7
Chassis Hydraulic Hoses, Kohler illustration . . . 2-8
Chassis Hydraulic Hoses, Kohler . . . 2-9
Chassis Hydraulic Equipment, Kubota . . . 2-10
Chassis Hydraulic Equipment, Kubota illustration . . . 2-11
Chassis Hydraulic Hoses, Kubota illustration . . . 2-12
Chassis Hydraulic Hoses, Kubota . . . 2-13
Hydraulic Equipment, Turntable . . . 2-14
Hydraulic Hose Installation, Turntable . . . 2-16
Package Valve Assembly, Rexroth . . . 2-18
Package Valve Assembly, Rexroth illustration . . . 2-19
Package Valve Assembly, Vickers illustration . . . 2-20
Package Valve Assembly, Vickers . . . 2-21
Control Valve Package, Rexroth . . . 2-22
Control Valve Package, Vickers . . . 2-24
Add-on Valve Section, Rexroth . . . 2-26
Add-on Valve Section, Vickers . . . 2-27
Control Valve, Drive . . . 2-28
Cylinder Assembly, Lower Boom Lift . . . 2-29
Cylinder Assembly, Extension . . . 2-30
Cylinder Assembly, Master Level . . . 2-31
Cylinder Assembly, Middle Boom Lift . . . 2-32
Cylinder Assembly, Slave Level . . . 2-33
Cylinder Assembly, Steering . . . 2-34
Cylinder Assembly, Upper Boom Lift . . . 2-35
Dual Counterbalance Valve . . . 2-36
Flow Divider/Combiner . . . 2-37
Pressure Switch . . . 2-38
Solenoid Valve, Sense Line Dump & Drive Shift . . . 2-39
Swing drive, Gear Products manufacture . . . 2-40

Section 3. - Electrical

Wiring Code and Function . . . 3-3
Wiring Schematic, Kohler Gas illustration . . . 3-5
Wiring Schematic, Kubota Diesel illustration . . . 3-6
Wiring Schematic, Kubota Gas illustration . . . 3-7
Chassis Electrical, Kohler Gas . . . 3-8
Chassis Electrical, Kubota Gas illustration . . . 3-9
Chassis Electrical, Kubota Diesel illustration . . . 3-10
Chassis Electrical, Kubota Diesel . . . 3-11
Chassis Electrical, Kubota Gas . . . 3-12
Chassis Electrical, Kubota Gas illustration . . . 3-13
Turntable Electrical illustration . . . 3-14
Turntable Electrical . . . 3-15
Wiring Box Assembly, Kohler Gas . . . 3-16
Wiring Box Assembly, Kohler Gas illustration . . . 3-17
Wiring Box Assembly, Kubota Diesel illustration . . . 3-18
Wiring Box Assembly, Kubota Diesel . . . 3-19
Wiring Box Assembly, Kubota Gas . . . 3-21
Wiring Box Assembly, Kubota Gas illustration . . . 3-23
Wiring Box Panel Assembly, Gasoline illustration . . . 3-24
Wiring Box Panel Assembly, Gasoline . . . 3-25
Wiring Box Panel Assembly, Diesel . . . 3-26
Wiring Box Panel Assembly, Diesel illustration . . . 3-27
Platform Control Box, Kohler illustration . . . 3-28
Platform Control Box, Kohler . . . 3-29
Platform Control Box, Kubota . . . 3-31
Platform Control Box, Kubota illustration . . . 3-33
Relay Panel Assembly . . . 3-35
Solenoid Switch Assembly, Kubota Diesel . . . 3-36
Engine Gauge Panel, Kohler Gas . . . 3-38
Engine Gauge Panel, Kubota Diesel . . . 3-40
Engine Gauge Panel, Kubota Gas . . . 3-42
Boom Switch Assembly . . . 3-44
Foot Switch Assembly, Kohler . . . 3-45
Foot Switch Assembly, Kubota . . . 3-46
Electric Fuel Pump Assembly . . . 3-47
Controller Assembly, Drive . . . 3-48
Power to Platform, 110 Volt DC . . . 3-50

Section 4. - Options

Air Line to Platform . . . 4-2
Air Line to Platform Installation illustration . . . 4-3
Dual Fuel Installation, Kubota illustration . . . 4-4
Dual Fuel Installation, Kubota . . . 4-5

MidWestTech | Snorkel UNO41D, UNO41G Articulating Boom Lift Maintenance and Re... Order the manual at mid-west-tech.com >

LP Fuel Only Installation, Kubota 4-6
LP Fuel Only Installation, Kubota
illustration 4-7
Warning Light Installation
illustration 4-8
Warning Light Installation 4-9
Driving Lights 4-10
Driving Lights
illustration 4-11
Platform Work Lights
illustration 4-12
Platform Work Lights 4-13
Operator Horn 4-14
Drive Motion Alarm 4-15
Self Closing Platform Gate 4-16
Spark Arrestor, Kubota 4-17
Tow Package 4-18
Tow Package
illustration 4-19
Hydraulic AC Generator Installation
illustration 4-20
Hydraulic AC Generator Installation 4-21
Hydraulic AC Generator Assembly 4-22
Tool Tray 4-24

MidWestTech | Snorkel UNO41D, UNO41G Articulating Boom Lift Maintenance and Re... Order the manual at mid-west-tech.com >

MidWestTech | Snorkel UNO41D, UNO41G Articulating Boom Lift Maintenance and Repair Parts Manual | Publication 0152874

Order the manual at mid-west-tech.com >

Snorkel

TITLE WIRING BOX ASSEMBLY
KOHLER GAS
SNORKELIFT UNO 41D/41G

DWG. 0150884

