Operator's Manual

Snorkel

UNO

33D/G 41D/G

engine powered
diesel
gasoline
LPG



P/N 0163088
August, 1999

OmniQuip Snorkel INTERNATIONAL

MidWestTech | Snorkel UNO33D, UNO33G, UNO41D, UNO41G Articulating Boom Lift Oper... Order the manual at mid-west-tech.com >

Table of Contents

Chapter 1. Introduction

Safety Alerts 1-1
Notes 1-1
Options 1-1
Operation 1-1
Maintenance 1-2
Manual of Responsibilities 1-2
Additional Information 1-2

Chapter 2. Specifications

Component Identification—UNO 33 2-1
Component Identification—UNO 41 2-2
Working Envelope—UNO 33 2-3
Working Envelope—UNO 41 2-4
General Specifications—UNO 33 2-5
General Specifications—UNO 41 2-6
Engine Specifications 2-7
Engine Oil Viscosity 2-7

Chapter 3. Safety

Electrocution Hazards 3-1
  Minimum Safe Approach Distance 3-1
Prestart Inspection 3-2
Work Place Inspection and Practices 3-2
Operation 3-2
Tip-Over and Falling Hazards 3-3
Electrical System 3-3
Hydraulic System 3-3
Engine and Fuel Handling Precautions 3-4
Placards and Decals 3-4

Chapter 4. Safety Devices

Emergency Stop Controls 4-1
Emergency Power System 4-1
Emergency Lowering Knobs 4-1
Ground Controls Switch 4-1
Platform Foot Switch 4-2
Guardrails 4-2
Lanyard Anchors 4-2
Ground Fault Circuit Interrupter 4-2
Tilt Alarm 4-2
Engine Protection Systems 4-2
  High Engine Temperature Alarm 4-3
  Low Oil Pressure Alarm 4-3
Horn 4-3
Drive Motion Alarm 4-3
Flashing Light 4-3
Driving Lights 4-3
Platform Work Lights 4-3

Chapter 5. Gauges

Engine Air Filter Gauge 5-1
Engine Temperature Gauge 5-1
Ammeter 5-1
Hour Meter 5-1
Fuel 5-1
Engine Oil 5-2
Hydraulic Fluid Filter Gauge 5-2
Hydraulic Fluid Level and Temperature Gauge 5-2

Chapter 6. Controls

Chassis Controls 6-1
  Battery Disconnect Switch 6-1
Lower Controls 6-1
  Master Switch 6-1
  Start Assist Button 6-1
  Emergency Stop Button 6-1
  Selector Switch 6-2
  Ground Controls Switch 6-2
  Boom Speed Knob 6-2
  Turntable Swing Switch 6-2
  Bottom Boom Switch 6-2
  Middle Boom Switch 6-2
  Top Boom Switch 6-2
  Boom Extension Switch 6-2
  Platform Level Switch 6-2
  Emergency Power Switch 6-2
Upper Controls 6-3
  Anti-Restart Master Switch 6-3
  Start Assist Button 6-3
  Emergency Stop Button 6-3
  Boom Speed Knob 6-4
  Turntable Swing Switch 6-4
  Bottom Boom Switch 6-4
  Middle Boom Switch 6-4
  Top Boom Up/Down Switch 6-4
  Top Boom Extend/Retract Switch 6-4
  Level Switch 6-4
  Horn Button 6-4
  Steer Switch 6-4
  Drive Joystick 6-4
  Drive Range Switch 6-4
  Engine/Emergency Power Switch 6-4
  Platform Foot Switch 6-5
  Machine/Generator Switch 6-5
  Dual Fuel 6-5
  Driving and Platform Work Lights 6-5

Chapter 7. Prestart Inspection

Operator's Manual 7-2
Engine 7-2
  Oil Level 7-2
  Coolant 7-2
  Radiator 7-2
  Fuel Tank 7-2
  Fuel Line 7-3
  Air Filter 7-3

MidWestTech | Snorkel UNO33D, UNO33G, UNO41D, UNO41G Articulating Boom Lift... Order the manual at mid-west-tech.com >

Table of Contents

Charging System 7-4
Cold Weather Start Kit 7-4
Electrical System 7-4
Emergency Power Battery 7-4
Battery Fluid Level 7-4
Battery Terminals 7-4
Cables and Wiring Harness 7-4
Hydraulic System 7-5
Fluid Level 7-5
Fluid Filter 7-5
Hoses, Tubes, and Fittings 7-5
Tires and Wheels 7-5
Air Filled 7-6
Foam Filled 7-6
Lower Control Station 7-6
Operating Controls 7-6
Emergency Stop 7-6
Emergency Power 7-7
Emergency Lowering 7-7
Level Sensor 7-8
Flashing Light 7-8
Structures 7-8
Weldments 7-8
Slide Pads 7-8
Fasteners 7-9
Upper Control Station 7-9
Guardrail System 7-9
Lanyard Anchors 7-9
Operating Controls 7-9
Emergency Stop 7-10
Emergency Power 7-10
Horn 7-10
Electrical Power Outlet 7-10
Air Line 7-11
Driving and Work Lights 7-11
Platform Control Cover 7-11
Drive Motion Alarm 7-11
Tow Kit 7-11
Placards and Decals 7-11
UNO 33 7-12
UNO 41 7-13

Chapter 8. Operation

Cold Weather Start-Up 8-1
Engine Cold Weather Start Kit 8-1
Hydraulic System Cold Weather Warm-Up . 8-1
Preparing for Operation 8-1
Lower Controls 8-1
Upper Controls 8-2
Boom Operation 8-3
Driving and Steering 8-3
Drive Speeds 8-4
Platform Rotation 8-4
Electrical Power Outlet 8-4
AC Generator 8-5
Dual Fuel 8-5
Air Line 8-5

Chapter 9. Stowing and Transporting

Stowing 9-1
Transporting 9-1
Driving 9-1
Winching 9-2
Lifting With a Forklift 9-2
Hoisting 9-3
Securing for Transport 9-3

Chapter 10. Emergency Operation

Emergency Power System 10-1
Lower Controls 10-1
Upper Controls 10-1
Emergency Lowering 10-2
Towing 10-3

Chapter 11. Troubleshooting

Troubleshooting Chart 11-1

Appendix A. Glossary

MidWestTech | Snorkel UNO33D, UNO33G, UNO41D, UNO41G Articulating Boom Lift... Order the manual at mid-west-tech.com >