# Operator's Manual

Snorkel

UNO 4x4

33D/G 41D/G

engine powered
diesel
gasoline
LPG




P/N 0153089
April, 2000

OmniQuip Snorkel. INTERNATIONAL

MidWestTech | Snorkel UNO33D, UNO33G, UNO41D, UNO41G (4x4) Articulating Boom Lift... Order the manual at mid-west-tech.com >

# Table of Contents


## Chapter 1. Introduction

Safety Alerts . . . . . 1-1
Notes . . . . . 1-1
Options . . . . . 1-1
Operation . . . . . 1-1
Maintenance . . . . . 1-2
Manual of Responsibilities . . . . . 1-2
Additional Information . . . . . 1-2

## Chapter 2. Specifications

Component Identification—UNO 33 . . . . . 2-1
Component Identification—UNO 41 . . . . . 2-2
Working Envelope—UNO 33 . . . . . 2-3
Working Envelope—UNO 41 . . . . . 2-4
General Specifications—UNO 33 . . . . . 2-5
General Specifications—UNO 41 . . . . . 2-6
Engine Specifications . . . . . 2-7
Engine Oil Viscosity . . . . . 2-7

## Chapter 3. Safety

Electrocution Hazards . . . . . 3-1
  Minimum Safe Approach Distance . . . . . 3-1
Prestart Inspection . . . . . 3-2
Work Place Inspection and Practices . . . . . 3-2
Operation . . . . . 3-2
Tip-Over and Falling Hazards . . . . . 3-3
Electrical System . . . . . 3-3
Hydraulic System . . . . . 3-3
Engine and Fuel Handling Precautions . . . . . 3-4
Placards and Decals . . . . . 3-4

## Chapter 4. Safety Devices

Emergency Stop Controls . . . . . 4-1
Emergency Power System . . . . . 4-1
Emergency Lowering Knobs . . . . . 4-1
Ground Controls Switch . . . . . 4-1
Platform Foot Switch . . . . . 4-2
Guardrails . . . . . 4-2
Lanyard Anchors . . . . . 4-2
Ground Fault Circuit Interrupter . . . . . 4-2
Tilt Alarm . . . . . 4-2
Engine Protection Systems . . . . . 4-2
  High Engine Temperature Alarm . . . . . 4-3
  Low Oil Pressure Alarm . . . . . 4-3
Horn . . . . . 4-3
Drive Motion Alarm . . . . . 4-3
Flashing Light . . . . . 4-3
Driving Lights . . . . . 4-3
Platform Work Lights . . . . . 4-3

## Chapter 5. Gauges

Engine Air Filter Gauge . . . . . 5-1
Engine Temperature Gauge . . . . . 5-1
Ammeter . . . . . 5-1
Hour Meter . . . . . 5-1
Fuel . . . . . 5-1
Engine Oil . . . . . 5-2
Hydraulic Fluid Filter Gauge . . . . . 5-2
Hydraulic Fluid Level and Temperature Gauge 5-2

## Chapter 6. Controls

Chassis Controls . . . . . 6-1
  Battery Disconnect Switch . . . . . 6-1
Lower Controls . . . . . 6-1
  Master Switch . . . . . 6-1
  Preheat Button . . . . . 6-1
  Emergency Stop Button . . . . . 6-1
  Selector Switch . . . . . 6-1
  Ground Controls Switch . . . . . 6-1
  Boom Speed Knob . . . . . 6-2
  Turntable Swing Switch . . . . . 6-2
  Bottom Boom Switch . . . . . 6-2
  Middle Boom Switch . . . . . 6-2
  Top Boom Switch . . . . . 6-2
  Boom Extension Switch . . . . . 6-2
  Platform Level Switch . . . . . 6-2
  Emergency Power Switch . . . . . 6-2
Upper Controls . . . . . 6-2
  Anti-Restart Master Switch . . . . . 6-3
  Preheat Button . . . . . 6-3
  Emergency Stop Button . . . . . 6-3
  Boom Speed Knob . . . . . 6-3
  Turntable Swing Switch . . . . . 6-3
  Bottom Boom Switch . . . . . 6-3
  Middle Boom Switch . . . . . 6-4
  Top Boom Up/Down Switch . . . . . 6-4
  Top Boom Extend/Retract Switch . . . . . 6-4
  Level Switch . . . . . 6-4
  Horn Button . . . . . 6-4
  Steer Switch . . . . . 6-4
  Drive Joystick . . . . . 6-4
  Drive Range Switch . . . . . 6-4
  Engine/Emergency Power Switch . . . . . 6-4
  Platform Foot Switch . . . . . 6-4
  Machine/Generator Switch . . . . . 6-5
  Dual Fuel . . . . . 6-5
  Driving and Platform Work Lights . . . . . 6-5

## Chapter 7. Prestart Inspection

Operator's Manual . . . . . 7-2
Engine . . . . . 7-2
  Oil Level . . . . . 7-2
  Coolant . . . . . 7-2
  Radiator . . . . . 7-2
  Fuel Tank . . . . . 7-2
  Fuel Line . . . . . 7-3
  Air Filter . . . . . 7-3




MidWestTech | Snorkel UNO33D, UNO33G, UNO41D, UNO41G (4x4) Articulating Boom... Order the manual at mid-west-tech.com >

# Table of Contents


Charging System . . . . . 7-4
Cold Weather Start Kit . . . . . 7-4
Electrical System . . . . . 7-4
Emergency Power Battery . . . . . 7-4
Battery Fluid Level . . . . . 7-4
Battery Terminals . . . . . 7-4
Cables and Wiring Harness . . . . . 7-4
Hydraulic System . . . . . 7-5
Fluid Level . . . . . 7-5
Fluid Filter . . . . . 7-5
Hoses, Tubes, and Fittings . . . . . 7-5
Tires and Wheels . . . . . 7-5
Air Filled . . . . . 7-6
Foam Filled . . . . . 7-6
Lower Control Station . . . . . 7-6
Operating Controls . . . . . 7-6
Emergency Stop . . . . . 7-6
Emergency Power . . . . . 7-7
Emergency Lowering . . . . . 7-7
Level Sensor . . . . . 7-8
Flashing Light . . . . . 7-8
Structures . . . . . 7-8
Weldments . . . . . 7-8
Slide Pads . . . . . 7-8
Fasteners . . . . . 7-9
Upper Control Station . . . . . 7-9
Guardrail System . . . . . 7-9
Lanyard Anchors . . . . . 7-9
Operating Controls . . . . . 7-9
Emergency Stop . . . . . 7-10
Emergency Power . . . . . 7-10
Horn . . . . . 7-10
Electrical Power Outlet . . . . . 7-10
Air Line . . . . . 7-11
Driving and Work Lights . . . . . 7-11
Platform Control Cover . . . . . 7-11
Drive Motion Alarm . . . . . 7-11
Tow Kit . . . . . 7-11
Placards and Decals . . . . . 7-11
UNO 33 . . . . . 7-12
UNO 41 . . . . . 7-13

**Chapter 8. Operation**

Cold Weather Start-Up . . . . . 8-1
Engine Cold Weather Start Kit . . . . . 8-1
Hydraulic System Cold Weather Warm-Up . 8-1
Preparing for Operation . . . . . 8-1
Lower Controls . . . . . 8-1
Upper Controls . . . . . 8-2
Boom Operation . . . . . 8-3
Driving and Steering . . . . . 8-3
Drive Speeds . . . . . 8-4
Platform Rotation . . . . . 8-4
Electrical Power Outlet . . . . . 8-4
AC Generator . . . . . 8-5
Dual Fuel . . . . . 8-5
Air Line . . . . . 8-5

**Chapter 9. Stowing and Transporting**

Stowing . . . . . 9-1
Transporting . . . . . 9-1
Driving . . . . . 9-1
Winching . . . . . 9-2
Hoisting . . . . . 9-2
Securing for Transport . . . . . 9-3

**Chapter 10. Emergency Operation**

Emergency Power System . . . . . 10-1
Lower Controls . . . . . 10-1
Upper Controls . . . . . 10-1
Emergency Lowering . . . . . 10-2
Towing . . . . . 10-3

**Chapter 11. Troubleshooting**

Troubleshooting Chart . . . . . 11-1

**Appendix A. Glossary**




MidWestTech | Snorkel UNO33D, UNO33G, UNO41D, UNO41G (4x4) Articulating Boom... Order the manual at mid-west-tech.com >