800
Terratrac
Crawler Tractor

Parts Catalog

1032

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

-A-

Accelerator..... 97
Adapter-hydraulic pump..... 11
Air Cleaner..... 51
Ammeter..... 95
Angledozer-hydraulic..... 221
Angledozer-mechanical..... 213

-B-

Balancer Assy. - Lanchester..... 29
Battery..... 69
Battery Box..... 181
Bearings - engine..... 21
Bracket - pump mtg..... 7
Brake - hydraulic..... 125
Brake Lines..... 143
Brake Pedals..... 133
Brake Mounts - transmission..... 113
Brush Guard..... 187
Brush Screen..... 187
Bulldozer - hydraulic..... 231
Bulldozer - mechanical..... 209
Bumper - front..... 7

-C-

Camshaft - engine..... 23
Clamp-on Grousers..... 173
Clutch - hydraulic..... 123
Cold Starting - engine..... 99
Connecting Rods - engine..... 21
Control Levers..... 137
Control Tower..... 137
Control Valve
Control Valve-transmission 295,297
Counterweight..... 193
Cowl & Dash..... 179
Crankshaft - engine..... 21
Cylinder - dozer angling..... 221
Cylinder - dozer lift..... 209
Cylinder - dozer strut..... 231
Cylinder - Terraload'r hyd. dump... 197
Cylinder - Terraload'r hyd. lift... 197
Cylinder - Scarifier..... 249

-D-

Decals..... 191
Digging Teeth - Terraload'r..... 197
Drawbar..... 189

-E-

Electrical System..... 69
Engine Cooling System..... 65
Engine - external parts..... 9
Engine - crankshaft & pistons..... 21
Engine - fuel injection..... 37

-E-

Engine - fuel system..... 61
Engine - gaskets..... 15
Engine - head & camshaft..... 23
Engine - injection pump..... 39
Engine - oil pump & balancer..... 27
Engine Control..... 97
Exhaust Pipe..... 51

-F-

Fan..... 47
Fan Belt..... 47
Fenders..... 181
Filter - engine oil..... 55
Filter - final stage fuel..... 61
Filter - full flow..... 59
Filter - hydraulic tank..... 185
Filter - primary fuel..... 61
Filter - secondary fuel..... 61
Filter - transmission hyd..... 155
Final Drive..... 129
Floor Mat..... 179
Floor Plate..... 179
Flywheel Assy. Engine..... 21
Flywheel Housing..... 11
Frame - main..... 157
Frame Assy. - engine..... 7
Fuel Injection Lines..... 37
Fuel Lines..... 61
Fuel Tank..... 181

-G-

Gaskets - engine..... 15
Gauge Stick - hydraulic..... 115
Gauge Stick - oil..... 13
Generator..... 81
Grease Gun..... 191
Grousers..... 173
Guard Assy. - bottom..... 7

-H-

Head Assy. - cylinder..... 23
Head Lights..... 93
Heat Indicator..... 95
Hood - engine..... 187
Hook - pull..... 7
Hour Meter..... 95
Hydraulic System - dual pull behind... 261
Hyd. system - hyd. angledozer..... 225
Hyd. system - hyd. bulldozer..... 235
Hyd. system - mech. bulldozer & angledozer..... 217
Hyd. system - primaries for dozers.... 243
Hyd. system - primaries for Terraloadr 205
Hyd. system - scarifier & hyd. angle-dozer..... 259
Hyd. system - scarifier & hyd. bulldozer..... 255

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

-H-

Hyd. system - scarifier & mech. dozer..... 257
Hyd. system - scarifier & Terraload'r. 253
Hyd. system - Terraload'r..... 201
Hydraulic Tank..... 181
Hydraulics - standard tractor..... 143

-I-

Idler Guards..... 175
Ignition Switch..... 95
Injection Pump - fuel..... 39

-J-

Journal Kit - universal..... 107

-K-

Knocker - tree..... 269

-L-

Lever & Valve Kits..... 265
Light Housing - tail..... 181
Light Switch..... 95
Liner - cylinder..... 9

-M-

Manifold..... 51
Master Cylinder - brake..... 183
Mounts - engine..... 7
Muffler..... 51

-O-

Oil Filter - engine..... 55
Oil Filter - transmission..... 155
Oil Lines - engine lube..... 55
Oil Pan..... 27
Oil Pressure Gauges..... 95
Oil Pump - engine..... 27

-P-

Parking Brake..... 137
Pistons - engine..... 21
Pre-cleaner..... 53
Pressure Switch..... 95
Pulley - fan..... 47

-P-

Pump - water..... 47
Pump Assy. - allied equipment..... 287
Pump - converter..... 101
Pump - fuel injection..... 39
Pump - trans. hyd..... 285

-R-

Radiator..... 65
Radiator - tropical..... 67
Radiator Guard..... 187
Radiator Hoses..... 65
Rain Cap..... 51
Rake - brush..... 271
Range Shift Lever..... 137
Recoil Spring Housing..... 161
Relief Valve - Terraload'r..... 283
Ring Gear - flywheel..... 21
Rings - piston..... 21
Ripper..... 251
Rock Guards..... 175

-S-

Seat Assy..... 181
Seat Cushions..... 181
Scarifier..... 249
Shroud - radiator..... 187
Side Panels - engine..... 179
Solenoid Switch..... 95
Sprocket - tractor drive..... 157
Starter..... 87
Starter Switch..... 87
Support - engine..... 7

-T-

Tail Lights..... 93
Tank - hydraulic..... 181
Tank - fuel..... 181
Tappets - valve..... 23
Terraload'r..... 197
Thermostat..... 65
Throttle - hand..... 97
Tool Box..... 181
Tools & Equipment..... 191
Torsion Bar..... 157
Torque Converter..... 101
Track Chain..... 171
Track Frame..... 161
Track Front Idler..... 169
Track Rollers..... 165
Track Shoes..... 173
Track Support Idler..... 167
Transmission - brake shaft parts..... 121
Transmission - clutch shaft parts..... 119
Transmission - drive & 2 speed shift. 117
Transmission - external parts..... 113
Transmission Control - hyd..... 133
Transmission Control - tower..... 137

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

-U-

Universal Shaft..... 107

-V-

Valve - hyd. angledozer..... 225
Valve - hyd. bulldozer..... 235
Valve - mechanical dozers..... 217
Valve - scarifier & hyd. angle dozer comb..... 259
Valve - scarifier & hyd. bulldozer comb. 255
Valve - scarifier & mech. dozers comb.. 257
Valve - scarifier & Terraload'r comb... 253
Valve - trans.control..... 295, 297
Valve Guides - engine..... 23
Valve Levers - trans.control..... 137
Valve Sections - hydraulic..... 305
Valves - engine..... 23
Voltage regulator..... 81

-W-

Water Pump..... 47
Wiring Harness..... 69

MidWestTech | Case 800 Terratrac Crawler Tractor Parts Catalog | Publication 1032 Order the manual at mid-west-tech.com >