Lull

Operators and Safety Manual

Models
522 & 522/4
622 & 622/4
824

10709977
(was) P09977

ANSI

JLG

MidWestTech | Lull 522, 522/4, 622, 622/4, 824 Telehandler Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

FLUID PRESSURES

TRANSMISSION PRESSURE

REFER TO TRANSMISSION SERVICE MANUAL

HYDRAULIC PRESSURE

	522	622	824
BOOM LIFT & EXTEND RELIEF	2600	2900	2900
CARRIAGE TILT VALVE SECTION - UP	2000	2000	2000
CARRIAGE TILT VALVE SECTION - DOWN	2100	2550	2550

STEERING HYDRAULIC PRESSURE

	522	622	824
AFTER SERIAL NUMBER 101	2000	2000	2000

BRAKE PRESSURE

	522	622	824
BEFORE SERIAL NUMBER 133		1800	
AFTER SERIAL NUMBER 132		1100	
BEFORE SERIAL NUMBER 348		1100	
AFTER SERIAL NUMBER 347		700	
AFTER SERIAL NUMBER 101	700		800

DIFFERENTIAL LOCK PRESSURE

	522	622	824
AFTER SERIAL NUMBER 101	275		275
AFTER SERIAL NUMBER 348		275	

MidWestTech | Lull 522, 522/4, 622, 622/4, 824 Telehandler Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >