MidWestTech | Lull 644B, 6K, 844C, 8K, 1044C, 10K Telehandler Parts Manual | Publicatio...

Order the manual at mid-west-tech.com >

Lull

# Illustrated Parts Manual

## Models
## 644B, 6K, 844C,
## 8K, 1044C &
## 10K

**P/N - 1100820**

*Revised*
*April 24, 2009*

ISO9001

JLG



# TABLE OF CONTENTS


## Using this book
## Serial Number Locations
## Section 1 — Drive Train

Drive Train Group Assembly . . . . . 1.1.1
Drive Train Group Assembly . . . . . 1.1.2
Front Drive Shaft Assembly . . . . . 1.2.1
Drive Train Group Assembly . . . . . 1.1.3
Front Drive Shaft Assembly . . . . . 1.2.2
Rear Drive Shaft Assembly . . . . . 1.3.1
Rear Drive Shaft Assembly . . . . . 1.3.2
Differential Carrier Assembly - Front Axle (PS 7036) . . . . . 1.4.1
Differential Carrier Assembly - Rear Axle (PS 7036) . . . . . 1.5.1
Steer Axle Shafts & Knuckle Assembly (PS 7036) . . . . . 1.6.1
Steer Axle Shafts & Knuckle Assembly (PS 7036) . . . . . 1.6.2
Wheel End Assembly - With Wet Disc Brakes (PS 7036) . . . . . 1.7.1
Wheel End Assembly - With Wet Disc Brakes (PS 7036) . . . . . 1.7.2
Drive Flange Assembly (PS 7036) . . . . . 1.8.1
Tie Rod & Steer Cylinder Mounting Assembly (PS 7036) . . . . . 1.9.1
Steer Cylinder Assembly (PS 7036) . . . . . 1.10.1
Steer Cylinder Assembly (PS 7036) . . . . . 1.10.1.1
Differential Carrier Assembly - Front Axle (PS 8036) . . . . . 1.14.1
Differential Carrier Assembly - Rear Axle (PS 8036) . . . . . 1.15.1
Steer Axle Shafts & Knuckle Assembly (PS 8036) . . . . . 1.16.1
Wheel End Assembly - With Wet Disc Brakes (PS 8036) . . . . . 1.17.1
Wheel End Assembly - With DRY Disc Brakes (PS 8036) . . . . . 1.17.2
Drive Flange Assembly (PS 8036) . . . . . 1.18.1
Tie Rod & Steer Cylinder Mounting Assembly (PS 8036) . . . . . 1.19.1
Steer Cylinder Assembly (PS 8036) . . . . . 1.20.1
Converter & Flex Plate (3WG 100) . . . . . 1.24.1
Gearbox Housing (3WG 100) . . . . . 1.25.1
Input Group (3WG 100) . . . . . 1.26.1
Clutch Pack, Forward, 1st Gear (3WG 100) (1 of 2) . . . . . 1.27.1
Clutch Pack, Forward, 1st Gear (3WG 100) (2 of 2) . . . . . 1.27.1
Clutch Pack, Reverse, 2nd Gear (3WG 100) (1 of 2) . . . . . 1.28.1
Clutch Pack, Reverse, 2nd Gear (3WG 100) (2 of 2) . . . . . 1.28.1
Clutch Pack, 3rd Gear (3WG 100) (1 of 2) . . . . . 1.29.1
Clutch Pack, 3rd Gear (3WG 100) (2 of 2) . . . . . 1.29.1
Output Group (3WG 100) . . . . . 1.30.1
Power Take-Off & Filter (3WG 100) . . . . . 1.31.1
Gearshift System (3WG 100) . . . . . 1.32.1
Control Valve (3WG 100) . . . . . 1.33.1
Oil Tubes & Dipstick (3WG 100) . . . . . 1.34.1
Converter & Flex Plate (4WG 100) . . . . . 1.38.1
Gearbox Housing (4WG 100) . . . . . 1.39.1
Input Group & Layshaft (4WG 100) . . . . . 1.40.1
Clutch Pack, Forward, 1st Gear (4WG 100) (1 of 2) . . . . . 1.41.1
Clutch Pack, Forward, 1st Gear (4WG 100) (2 of 2) . . . . . 1.41.1
Clutch Pack, Reverse, 2nd Gear (4WG 100) (1 of 2) . . . . . 1.42.1
Clutch Pack, Reverse, 2nd Gear (4WG 100) (2 of 2) . . . . . 1.42.1
Clutch Pack, 3rd Gear (4WG 100) (1 of 2) . . . . . 1.43.1
Clutch Pack, 3rd Gear (4WG 100) (2 of 2) . . . . . 1.43.1
Clutch Pack, 4th Gear (4WG 100) (1 of 2) . . . . . 1.44.1
Clutch Pack, 4th Gear (4WG 100) (2 of 2) . . . . . 1.44.1
Output Group (4WG 100) . . . . . 1.45.1
Power TakE-Off & Filter (4WG 100) . . . . . 1.46.1
Gearshift System (4wg 100) . . . . . 1.47.1
Control Valve (4WG 100) . . . . . 1.48.1
Oil Tubes & Dipstick (4WG 100) . . . . . 1.49.1
Transmission Oil Cooler Assembly . . . . . 1.53.1
Transmission Oil Cooler Assembly . . . . . 1.53.1.1
Park Brake Assembly . . . . . 1.54.1
Park Brake Cylinder Mounting & Linkage Assembly . . . . . 1.55.1
Park Brake Cylinder Mounting & Linkage Assembly . . . . . 1.55.1.1

## Section 2 — Power Plant




MidWestTech | Lull 644B, 6K, 844C, 8K, 1044C, 10K Telehandler Parts Manual | Publication 1100820

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


Engine Mounting & Fuel Lines (Deere 4039D) . . . . . 2.1.1
Exhaust Assembly (Deere 4039D) . . . . . 2.2.1
Air Cleaner Assembly (Deere 4039D) . . . . . 2.3.1
Radiator Group Assembly (Deere 4039D) . . . . . 2.4.1
Throttle Group Assembly (Deere 4039D) . . . . . 2.5.1
Throttle Group Assembly (Deere 4039D) . . . . . 2.5.1.1
Engine Mounting & Fuel Lines (Deere 4039T) . . . . . 2.6.1
Exhaust Assembly (Deere 4039T) . . . . . 2.7.1
Air Cleaner Assembly (Deere 4039T) . . . . . 2.8.1
Radiator Group Assembly (Deere 4039T) . . . . . 2.9.1
Throttle Group Assembly (Deere 4039T) . . . . . 2.10.1
Throttle Group Assembly (Deere 4039T) . . . . . 2.10.1.1
Engine Mounting & Fuel Lines (Deere 4045T 100 hp) . . . . . 2.11.1
Exhaust Assembly (Deere 4045T 100 hp) . . . . . 2.12.1
Air Cleaner Assembly (Deere 4045T 100 hp ) . . . . . 2.13.1
Radiator Group Assembly (Deere 4045T 100 hp) . . . . . 2.14.1
Throttle Group Assembly (Deere 4045T 100 hp) . . . . . 2.15.1
Engine Mounting & Fuel Lines (Deere 4045T 115 hp) . . . . . 2.16.1
Exhaust Assembly (Deere 4045T 115 hp) . . . . . 2.17.1
Air Cleaner Assembly (Deere 4045T 115 hp) . . . . . 2.18.1
Radiator Group Assembly (Deere 4045T 115 hp) . . . . . 2.19.1
Throttle Group Assembly (Deere 4045t 115 hp) . . . . . 2.20.1
Throttle Group Assembly (Deere 4045T 115 hp) . . . . . 2.20.1.1
Engine Mounting & Fuel Lines (Deere 6068D) . . . . . 2.21.1
Exhaust Assembly (Deere 6068D) . . . . . 2.22.1
Air Cleaner Assembly (Deere 6068D) . . . . . 2.23.1
Radiator Group Assembly (Deere 6068D) . . . . . 2.24.1
Throttle Group Assembly (Deere 6068D) . . . . . 2.25.1
Engine Mounting & Fuel Lines (Cummins 4B3.9) . . . . . 2.26.1
Engine Mounting & Fuel Lines (Cummins 4B3.9) . . . . . 2.26.1.1
Exhaust Assembly (Cummins 4B3.9) . . . . . 2.27.1
Air Cleaner Assembly (Cummins 4B3.9) . . . . . 2.28.1
Radiator Group Assembly (Cummins 4B3.9) . . . . . 2.29.1
Radiator Group Assembly (Cummins 4B3.9) . . . . . 2.29.1.1
Throttle Group Assembly (Cummins 4B3.9) . . . . . 2.30.1
Throttle Group Assembly (Cummins 4B3.9) . . . . . 2.30.1.1
Engine Mounting & Fuel Lines (Cummins 4BT3.9) . . . . . 2.31.1
Engine Mounting & Fuel Lines (Cummins 4BT3.9) . . . . . 2.31.1.1
Exhaust Assembly (Cummins 4BT3.9) . . . . . 2.32.1
Air Cleaner Assembly (Cummins 4BT3.9) . . . . . 2.33.1
Air Cleaner Assembly (Cummins 4BT3.9) . . . . . 2.33.1.1
Radiator Group Assembly (Cummins 4BT3.9) . . . . . 2.34.1
Radiator Group Assembly (Cummins 4BT3.9) . . . . . 2.34.1.1
Throttle Group Assembly (Cummins 4BT3.9) . . . . . 2.35.1
Throttle Group Assembly (Cummins 4BT3.9) . . . . . 2.35.1.1
Throttle Group Assembly (Cummins 4BT3.9) . . . . . 2.35.1.2
Engine Mounting & Fuel Lines (Cummins 6B5.9) . . . . . 2.36.1
Exhaust Assembly (Cummins 6B5.9) . . . . . 2.37.1
Air Cleaner Assembly (Cummins 6B5.9) . . . . . 2.38.1
Radiator Group Assembly (Cummins 6B5.9) . . . . . 2.39.1
Throttle Group Assembly (Cummins 6b5.9) . . . . . 2.40.1
Throttle Group Assembly (Cummins 6B5.9) . . . . . 2.40.1.1
Engine Mounting & Fuel Lines (Deere 4045D) . . . . . 2.41.1
Exhaust Assembly (Deere 4045D) . . . . . 2.42.1
Air Cleaner Assembly (Deere 4045D) . . . . . 2.43.1
Radiator Group Assembly (Deere 4045D) . . . . . 2.44.1
Throttle Group Assembly (Deere 4045D) . . . . . 2.45.1


## Section 3 — Frame and Operator's Compartment


Main Frame Assembly . . . . . 3.1.1
Main Frame Assembly . . . . . 3.1.1.1
Main Frame Assembly . . . . . 3.1.2
Main Frame Assembly . . . . . 3.1.3
Main Frame Assembly . . . . . 3.1.3.1
Main Frame Assembly . . . . . 3.1.4
Operator's Compartment Assembly . . . . . 3.2.1
Operator's Compartment Assembly . . . . . 3.2.1.1




MidWestTech | Lull 644B, 6K, 844C, 8K, 1044C, 10K Telehandler Parts Manual | Publication 1100820

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


Operator's Compartment Assembly . . . . . 3.2.2
Operator's Compartment Assembly . . . . . 3.2.2.1
Instrument Panel Assembly . . . . . 3.3.1
Instrument Panel Assembly . . . . . 3.3.1.1
Instrument Panel Assembly . . . . . 3.3.1.2
Steer Column Assembly . . . . . 3.4.1
Outrigger Assembly . . . . . 3.5.1


## Section 4 — Boom and Transfer Carriage


Transfer Carriage/Boom Cradle Assembly . . . . . 4.1.1
Transfer Carriage/Boom Cradle Assembly . . . . . 4.1.2
Outer Boom Assembly (2-Section) . . . . . 4.2.1
Outer Boom Assembly (2-Section) . . . . . 4.2.1.1
Inner Boom Assembly (2-Section) . . . . . 4.3.1
Outer Boom Assembly (3-Section) . . . . . 4.4.1
Outer Boom Assembly (3-Section) . . . . . 4.4.1.1
Outer Boom Assembly (3-Section) . . . . . 4.4.1.2
Outer Boom Assembly (3-Section) . . . . . 4.4.1.3
Middle Boom Assembly (3-Section) . . . . . 4.5.1
Middle Boom Assembly (3-Section) . . . . . 4.5.1.1
Middle Boom Assembly (3-Section) . . . . . 4.5.1.2
Middle Boom Assembly (3-Section) . . . . . 4.5.1.3
Middle Boom Assembly (3-Section) . . . . . 4.5.1.4
Middle Boom Assembly (3-Section) . . . . . 4.5.1.5
Inner Boom Assembly (3-Section) . . . . . 4.6.1
Inner Boom Assembly (3-Section) . . . . . 4.6.1.1
Outer Boom Assembly (4-Section) . . . . . 4.7.1
Outer Boom Assembly (4-Section) . . . . . 4.7.1.1
Outer Boom Assembly (4-Section) . . . . . 4.7.1.2
Outer Boom Assembly (4-Section) . . . . . 4.7.1.3
Rear Middle Boom Assembly (4-Section) . . . . . 4.8.1
Rear Middle Boom Assembly (4-Section) . . . . . 4.8.1.1
forward Middle Boom Assembly (4-Section) . . . . . 4.9.1
Forward Middle Boom Assembly (4-Section) . . . . . 4.9.1.1
Forward Middle Boom Assembly (4-Section) . . . . . 4.9.1.2
Inner Boom Assembly (4-Section) . . . . . 4.10.1
Quick Attach Group Assembly (Weldment Type) . . . . . 4.11.1
Quick Attach Group Assembly (Cast Type) . . . . . 4.11.1.1
Quick Attach Group Assembly (Cast Type) . . . . . 4.11.1.2


## Section 5 — Boom and Transfer Hydraulics


Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.1
Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.1.1
Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.2
Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.2.1
Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.3
Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.3.1
Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.4
Hoist & Rear Carriage Tilt Hydraulic circuit . . . . . 5.1.4.1
Rear Carriage Tilt Cylinder Assembly . . . . . 5.2.1
Rear Carriage Tilt Cylinder Assembly . . . . . 5.2.1.1
Rear Carriage Tilt Cylinder Assembly . . . . . 5.2.2
Hoist Cylinder Assembly . . . . . 5.3.1
Hoist Cylinder Assembly . . . . . 5.3.2
Transfer Hydraulic Circuit . . . . . 5.4.1
Transfer Hydraulic Circuit . . . . . 5.4.1.1
Transfer Cylinder Assembly . . . . . 5.5.1
Transfer Cylinder Assembly . . . . . 5.5.1.1
Boom Hydraulic Circuit (2-Section) . . . . . 5.6.1
Boom Hydraulic Circuit (2-Section) . . . . . 5.6.1.1
Boom Hydraulic Circuit (2-Section) . . . . . 5.6.2
Boom Hydraulic Circuit (2-Section) . . . . . 5.6.2.1
Boom Extension Cylinder Assembly (2-Section) . . . . . 5.7.1
Boom Extension Cylinder Assembly (2-Section) . . . . . 5.7.1.1
Boom Hydraulic Circuit (3-Section) . . . . . 5.8.1
Boom Hydraulic Circuit (3-Section) . . . . . 5.8.1.1




MidWestTech | Lull 644B, 6K, 844C, 8K, 1044C, 10K Telehandler Parts Manual | Publication 1100820

Order the manual at mid-west-tech.com >