TEREX®

Service Manual

AL5
AL5 with Tier 4
AL5000

Part No. 116476
Rev B
April 2015

MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publication 116476

Order the manual at mid-west-tech.com >

Table of Contents

Introduction	**Introduction**	**ii**
	Important Information	ii
	Serial Number Legend	3
Section 1	**Safety Rules**	**iv**
	General Safety Rules	iv
Section 2	**Specifications**	**1**
	Machine Specifications	1
	Performance Specifications	1
	Performance Specifications	1
	Machine Specifications	2
	Machine Specifications	3
	Machine Specifications	4
	Isuzu 4LE2 Engine	5
	Isuzu 4LE2-T Engine	6
	Machine Torque Specifications	7
	SAE and Metric Fasteners Torque Charts	8
Section 3	**Scheduled Maintenance Procedures**	**9**
	Introduction	9
	Pre-Delivery Preparation Report	12
	Maintenance Inspection Report	13

MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publica... Order the manual at mid-west-tech.com >

Table of Contents

Checklist A Procedures **15**
A-1 Inspect the Manuals and Decals 15
A-2 Perform Pre-operation Inspection 16
A-3 Perform Function Tests 16
A-4 Perform Engine Maintenance 17
A-5 Perform Coupler Maintenance 17
A-6 Test the Brakes (if equipped) 18
A-7 Torque the Wheel Lug Nuts 18
A-8 Check the Tires and Wheels 19
A-9 Inspect the Engine Air Filter 19
A-10 Perform Generator Maintenance 20
A-11 Perform Engine Maintenance 21
A-12 Perform Engine Maintenance 21
A-13 Inspect the Cable and Cable Pulleys 22
A-14 Perform Engine Maintenance 23
A-15 Perform Engine Maintenance 23
A-16 Perform Generator Maintenance 24
A-17 Drain the Fuel Filter/Water Separator 24
A-18 Adjust the Brakes (if equipped) 26

Checklist B Procedures **27**
B-1 Inspect the Engine Start Battery 27
B-2 Inspect the Electrical Wiring 28
B-3 Torque the Wheel Lug Nuts 29
B-5 Perform Engine Maintenance 29
B-5 Perform Jack Maintenance 30
B-6 Inspect and Lubricate the Winch 30
B-7 Lubricate the T-bolt 31
B-8 Inspect and Adjust the Brakes (if equipped) 31
B-9 Inspect the Suspension 33
B-10 Perform Engine Maintenance 34

MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publica... Order the manual at mid-west-tech.com >

Table of Contents

Checklist C Procedures **35**
C-1 Perform Engine Maintenance 35
C-2 Clean the Light Assemblies 35
C-3 Grease the Wheel Bearings 36
C-4 Inspect the Electric Brake Magnets 37
C-5 Perform Engine Maintenance 39
C-6 Perform Generator Maintenance 39

Checklist D Procedures **40**
D-1 Perform Engine Maintenance 40
D-2 Perform Generator Maintenance 40
D-3 Perform Coupler Maintenance 41

Checklist E Procedures **42**
E-1 Inspect the Cable and Cable Pulleys 42
E-2 Perform Engine Maintenance 43
E-3 Perform Engine Maintenance 43
E-4 Perform Generator Maintenance 44
E-5 Perform Generator Maintenance 44
E-6 Perform Generator Maintenance 45

Section 4 **Repair Procedures** **46**
Introduction 46

Lighting **48**
1-1 How to Remove a Lamp 48
1-2 How to Check Line Voltage 48
1-3 How to Check the Open Circuit Voltage [Terex SM] 49

MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publica... Order the manual at mid-west-tech.com >

Specifications

Machine Specifications

Total lighting wattage	4 x 1000 watts
Fuel capacities	
Single tank	30 gallons 114 liters
Large tank (option)	60 gallons 227 liters
Tires and wheels	
Tire size	ST205/75D15
Load range	C
Lug nut torque, dry	90 ft-lbs 122 Nm
Lug nut torque, lubricated	67.5 ft-lbs 91.5 Nm

Performance Specifications

Tongue weight, maximum	
With fuel (single tank)	150 lbs 68 kg
With fuel (large tank)	130 lbs 59 kg
Run time	
Single tank	50 hours
Large tank	100 hours

For operational specifications, refer to the Operator's Manual.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.

Generator Options

Marathon 8 kW 201CSA5412	
Generator rpm @ full load	60Hz, 1800 rpm
Temperature, ambient maximum	104° F 40° C
Power	8 kW
Marathon 8 kW 201CSA5420	
Generator rpm @ full load	60 Hz, 1800 rpm
Temperature, ambient maximum	104° F 40° C
Power	8 kW
Marathon 12 kW 281CSL1513	
Generator rpm @ full load	60 Hz, 1800 rpm
Temperature, ambient maximum	104° F 40° C
Power	12 kW
Marathon 20 kW 334CSA3028	
Generator rpm @ full load	60 Hz, 1800 rpm
Temperature, ambient maximum	104° F 40° C
Power	20 kW

For operational specifications, refer to the Operator's Manual.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.

MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publica... Order the manual at mid-west-tech.com >

Diagnostics



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.
- ☑ Unless otherwise specified, perform each procedure with the machine in the following configuration:
  - Machine parked on a firm, level surface
  - Mast in the stowed position
  - Key switch in the off position with the key removed
  - The red Emergency Stop button in the off position on the electrical control box
  - Wheels chocked
  - Light switches in the off position
  - All external AC power supply disconnected from the machine

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.
- ☑ Read each appropriate fault code thoroughly. Attempting short cuts may produce hazardous conditions.
- ☑ Be aware of the following hazards and follow generally accepted safe workshop practices.


⚠WARNING Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.


⚠DANGER High voltage. Exposure to electrical wires or electrical current will result in death or serious injury. Turn off all power when not needed for testing. Use extreme caution when working with high voltage electrical components.

⚠CAUTION Burn hazard. Beware of hot engine components. Contact with hot engine components may cause severe burns. Use caution when working around lamps or a hot engine.

MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publica... Order the manual at mid-west-tech.com >


Trailer Wiring Diagram - AUS Models





MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publication 116476 Order the manual at mid-west-tech.com >

Electrical Wiring Schematic ANSI / CSA Models



MidWestTech | Terex Genie AL5, AL5 Tier 4, AL5000 Light Tower Service Manual | Publication 116476
Order the manual at mid-west-tech.com >