# 1090 Tractor

## Parts Catalog

1225

MidWestTech | Case 1090 Tractor Parts Catalog | Publication 1225

Order the manual at mid-west-tech.com >

## Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

## Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

## Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

## Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

## Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

| REF. | PART NO. | DESCRIPTION | REQ'D |
|---|---|---|---|
| | A 55159 | CYLINDER ASSY. - rear steering | 1 |
| 28 | A 56208 | SOCKET ASSY. rear cylinder | 1 |
| 29 | NSS | PLUG - adjusting, socket assy | 1 |
| 30 | NSS | SEAT - socket ball | 2 |
| 31 | NSS | SPRING - socket | 1 |
| 32 | NSS | SEAT - socket spring | 1 |
| 33 | G 45175 | CLAMP ASSY. - socket assy. | 1 |
| | 16- 836 | BOLT - 1/2" x 2-1/4" N.F. hex. | 1 |
| 34 | 132- 104 | PIN - cotter, 3/16" x 3" | UAR |
| 35 | A 55889 | STUD - ball, socket & cylinder | 2 |
| 36 | 13- 410 | BOLT - 1/4" x 5/8" N.C., hex | 4 |
| 37 | 92- 4 | LOCKWASHER - 1/4" SAE | 4 |

**NOTE** NSS IN PART NO. COLUMN INDICATES THIS PART IS NOT SERVICED SEPARATELY.
UAR IN AMT. REQ'D COLUMN INDICATES THIS PART IS USED AS REQUIRED.

## Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.


Order the manual at mid-west-tech.com >

# CASE 1090 AGRI-KING TRACTORS

## ALPHABETICAL INDEX

### ENGINE SECTION


Air Intake and Exhaust Section
- Air Cleaner ..... 19,21
- Manifold ..... 25
- Muffler ..... 25
- Pre-Cleaner ..... 21

Cold Weather Starting Aids
- Block Heater ..... 87
- Ether Starting Kit ..... 23
- Manifold Heater ..... 25-65

Cooling Section
- Oil Cooler ..... 15
- Radiator Baffles ..... 13
- Radiator ..... 11
- Water Manifold and Thermostat ..... 17
- Water Pump and Attaching Parts ..... 17

Engine Section
- Camshaft ..... 29
- Connecting Rods and Bearings ..... 35
- Crankshaft and Bearings ..... 33
- Cylinder Block ..... 31
- Cylinder Head Cover ..... 27
- Cylinder Head ..... 27
- Engine Gasket Kits ..... 41
- Flywheel ..... 33
- Manifolds ..... 25
- Pistons and Rings ..... 35
- Rocker Shaft and Arms ..... 29
- Timing Gear Cover ..... 61
- Timing Gear ..... 61
- Valve Train ..... 29

Fuel Section
- Fuel Injection Filter System ..... 53-57
- Fuel Injection Pump and Drive ..... 61
- Fuel Injection System ..... 49
- Fuel Injection Nozzle ..... 51
- Fuel Lines ..... 45
- Fuel Tank ..... 45
- Throttle Linkage ..... 43

Lubrication Section
- Oil Filter ..... 39
- Oil Pan ..... 39
- Oil Pump ..... 37


MidWestTech | Case 1090 Tractor Parts Catalog | Publication 1225 Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## BASIC TRACTOR SECTION


Axle Section
- Front Axle
  - Tread 60 to 80" ..... 113
- Rear Axle
  - Tread to 96" ..... 179
  - Tread to 118" ..... 181
- Tie Rods ..... 115

Brake Section
- Controls ..... 183
- Differential ..... 171
- Hoses and Lines ..... 99
- Oil Filter ..... 101-101B
- Parking Brake ..... 173-175
- Valve ..... 185

Cab Section
- Acoustical Covers ..... 323-325
- Air Conditioner ..... 365-367
- Blower ..... 361
- Compressor
  - Tecumseh ..... 369
  - York ..... 371
- Compressor Clutch ..... 369-371
- Door ..... 311-313
- Electrical Wiring ..... 357-371
- Glass ..... 375-377
- Headliner ..... 327-329
- Instrument Panel ..... 345,351
- Insulation ..... 319-321
- Lights ..... 357-359
- Mirrors ..... 373
- Platform ..... 309
- Plenum
  - Air Conditioner ..... 339-341
  - Blower ..... 331-333
  - Heater ..... 335-337
- Protective Frame and Canopy ..... 299
- Radio Kit ..... 363
- Sheet Metal ..... 301-307
- Windows ..... 375-377
- Windshield Wiper ..... 357-359



Order the manual at mid-west-tech.com >