snorkel

S2255RTE
S2755RTE



CE

OPERATOR'S MANUAL

ANSI/CSA/CE/AS/NZS
Replaces November 2022

Part Number 15382-1
August 2024 Rev F
Original Instructions

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Publication... Order the manual at mid-west-tech.com >

Table of Contents

Electrical Danger ..... Inside Front Cover
Proposition 65 Warning ..... Inside Front Cover
Danger Symbols ..... Inside Front Cover
Lanyard Anchor Points ..... Inside Front Cover
Safety Rules ..... Inside Front Cover

Chapter 1 – Introduction

Aerial Platform Features 1
Options 1
Operator's Manual 1
Safety Alerts 1
Operation 1
Maintenance 2
Manual of Responsibilities – ANSI 2
MEWP Safe Use – AS/NZS 2
AS/NZS 1418.10 Commissioning 2
Additional Information 2

Chapter 2 – Specifications

Component Identification 3
General Specifications – S2255RTE 4
General Specifications – S2755RTE 5

Chapter 3 – Safety

Electrocution Hazards 7
Minimum Safe Approach Distance – ANSI 7
Minimum Safe Approach Distance – AS/NZS 7
Platform Capacity 8
Manual Force 8
Wind Speeds 8
Prestart Inspection 8
Work Place Inspection and Practices 8
Operation 9
Tip-Over and Falling Hazards 9
Electrical System 10
Hydraulic System 10
Placards and Decals 10
General Safety Rules 10

Chapter 4 – Safety Devices

Safety Device Information 13
Emergency Stop Switches 13
- Upper Controls 13
- Lower Controls 13

Alarms 13
- Lowering 13
- Drive (reverse) 14
- Drive (forward) 14

Load Sensing System 14
Level Sensor 14
Dual Tilt Limits 14
Primary Fall Restraint System 14
Safety Prop 15
Swinging Gate 15
Interlock Switch 15
Bubble Level 15
Operator Horn 15
Stabilisers 15
Rough Terrain Scissor Interlock Test 16
Enable Switch (Lower Controls Only) 16
RCD/ELCB Outlet (Option) 16
Electrical Power Outlet (Option 16
Flashing Light 16
Fall Restraint Lanyard Anchor Points 16

Chapter 5 – Gauges and Displays

Diagnostic Center Display 19
Platform Overload/Lift Enable Lights 19
Warning Light 19
Hydraulic Oil Tank 19

Chapter 6 – Batteries

General Maintenance 21
Charging 21

Chapter 7 – Controls

Battery Disconnect 23
Lower Controls 23
- Emergency Stop Button 23
- Control Selector 23
- Ground Operation Switch 23
- Platform Raise/Lower Switch 23
- Lift Indicator Light 24
- Platform Overload Indicator Light 24

Upper Controls 24
- Emergency Stop Button 24
- Drive/Lift Selector Switch 24
- Joystick 24
- Interlock Switch 25
- Steer Switch 25
- Drive Range Switch 25
- Horn Button 25
- Battery Condition/State Of Charge Indicator 25
- Stabiliser Manual Switches 25
- Auto Level/Stow Switch 25
- Lift Indicator Light 25
- Drive Indicator Light 25
- Warning Light 25
- Platform Overload Indicator Light 25

Chapter 8 – Prestart Inspection

Operator's Manual 27
Electrical System 27
- Battery Terminals 27
- Battery Charger 27

Safety Prop 28
Cables and Wiring Harness 28
Hydraulic System 28
- Fluid Level 28
- Hoses, Tubes, and Fittings 29
- Free-Wheeling Valve 29

Diagnostic Center Display 29
Tires and Wheels 29
Lower Control Station 29
- Operating Controls 30
- Emergency Stop 30
- Lowering Alarm 30

Stabiliser Interlock Test 30
- Stabiliser Locked Out When Platform Elevated . 30
- Elevation Locked Out When Axles Not Stowed . 30
- Elevation Locked Out When Axles Tilted 31

Emergency Lowering System 31
Structures 31

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Public... Order the manual at mid-west-tech.com >

Weldments 31
Rollers and Slide Blocks 32
Fasteners 32
Upper Control Station 32
Guardrail System 32
Platform Extension 32
Operating Controls 33
Emergency Stop 34
Horn Button 34
Lowering Alarm 34
Drive Alarm 34
Electrical Power Outlet 34
Flashing Light 34
Placards and Decals 35
Prestart Inspection Checklist 38

Chapter 9 – Operation

Preparing for Operation 39
Lower Controls 39
Upper Controls 39
Platform 40
Raising and Lowering 40
Lowering Interrupt – CE/AS/NZS 40
Overload Protection 40
Extending 41
Fold Down Guardrails 41
Driving and Steering 42
Drive Range Switch 42
Drive Speeds 42
Drive/Lift Pothole Protector Interlock 42
Drive/Lift Level Sensor Interlock 43
Electrical Power Outlet 43
After Use Each Day 43
Stabilisers 43
Operating The Stabilisers Manually 43
To Set The Stabilsers 43
To Raise The Stabilsers 44
Operating The Auto Level System 44
Setting The Stabilisers Automatically 44
Raising The Stabilisers Automatically 45
The Risk Of Operating Outriggers On Slopes 45
Snorkel OnSite 46

Chapter 10 – Stowing and Transporting

Stowing 47
Transporting 47
Lifting With a Forklift 47
Winching 47
Driving 48
Hoisting 48
Securing for Transport 49
Storage 49

Chapter 11 – Emergency Operation

Emergency Lowering 51
Towing 51

Chapter 12 – Troubleshooting

Troubleshooting Chart 53

Appendix A – Glossary

Appendix B – Inspection Checklists

Limited Warranty

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Public... Order the manual at mid-west-tech.com >

General Specifications – S2755RTE

SPECIFICATIONS		S2755RTE	
Normal working height	Wheels	9.9m	32' 6"
	Stabilisers	10.4m	34' 1"
Platform floor height	Wheels	7.9m	25' 11"
	Stabilisers	8.4m	27' 7"
Rollout deck size		1.2m	47"
Drive speed	Below 2.4m	0 to 5.2kph	0 to 3.3mph
	Above 2.4m	0 to 0.64kph	0 to 0.4mph
Safe working load (Rollout deck NOT extended)	Main deck	300kg	750lb
Safe working load (Rollout deck extended)	Main deck	180kg	396lb
	Rollout deck	120kg	265lb
Platform size		2.73 x 1.4m	8' 11" x 4' 7"
Stowed height	Hand rails up	2.5m	8' 3"
	Hand rails folded down	1.75m	5' 8"
Overall length		3.3m	11' 0"
Overall width		1.45m	4' 9"
Gradeability		35%	
Lift time		24 - 29 seconds	
Lower time		40 - 42 seconds	
Turning radius	Inner	2.5m	8.2'
	Outer	4.75m	15.6'
Maximum wind speed	12.5m/s	45kph	28mph
Insulation rating		Nil	
Tyres	Poly filled loader lug	23" x 8.9" x 12"	
Overall weight		2750kg	6063lb
Ground clearance	Minimum	140mm	5.5"
	Mid cabinet	260mm	10.2"
Maximum sound level at platform		86db	
Maximum outrigger load		1470kg	3240lb
Maximum wheel load		1470kg	3240lb
Maximum chassis inclination		4 ° sideways up to 5.5m +0.6m/-0.3m 2 ° sideways above 5.5m 4 ° fore & aft	
Maximum manual force		400N	

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Public... Order the manual at mid-west-tech.com >

⚠Danger

Pinch points may exist between moving components. Death or serious injury will result from becoming trapped between components, buildings, structures, or other obstacles. Make sure all personnel stand clear while operating the aerial platform.

- Controls to position the platform are located on the lower control box on the chassis and on the upper control box in the platform.
- Controls to drive the aerial platform are located on the upper control box only.

Battery Disconnect

The battery disconnect switch is at the rear of the platform, on the left side of the battery box (refer to Figure 7.1).



Figure 7.1 – Rear of Chassis

The battery disconnect switch removes electrical power from all electrically controlled functions when in the off position.

- Place the switch in the on position to operate any electrically controlled function.

⚠Caution

Only authorized personnel should operate the aerial platform. Unqualified personnel may cause injury to coworkers or property damage. Lock the battery disconnect switch in the off position before leaving the aerial platform unattended.

- Lock the battery disconnect switch in the off position to prevent unauthorized use of the aerial platform.

Lower Controls

The lower controls (refer to Figure 7.2) are located at the right rear of the chassis. Only platform functions can be operated from the lower controls.




Figure 7.2 – Lower Controls

The following are located on the lower control panel:

- Emergency stop button
- Control selector
- Ground operation switch
- Platform raise/lower switch
- Platform overload protection light
- Lift Indicator light

Emergency Stop Button

The emergency stop is a two-position red push button.

- Push the button inward to disconnect power to all control circuits.
- Pull the button outward to restore power.

Control Selector

Insert the key into the control selector

- In the middle position, aerial platform functions will not operate from the lower or upper controls. The upper controls will not operate while the control selector is in the lower position.
- Turn the switch to the upper controls position to operate the aerial platform functions from the upper controls, or turn the switch to the lower controls position to operate the aerial platform functions from the lower controls.

Ground Operation Switch

- Hold the switch downward continually in the lower controls position to enable the platform raise/lower switch functions.

Platform Raise/Lower Switch

The platform raise/lower switch is used to raise or lower the platform. The switch is spring returned to the center off position.

- Hold the switch upward to raise the platform.
- Hold the switch downward to lower the platform.
- An alarm will sound as the platform lowers.

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Public... Order the manual at mid-west-tech.com >

Annual Maintenance – Every 500 Hours

Item	Procedure	Information	P/F/R
Frequent Maintenance Checklist	Complete Frequent Maintenance		
Hydraulic System			
Hydraulic fluid condition	Drain, flush, and clean hydraulic system. Refill with new fluid.	Above 10°F (-12°C) ISO VG32 Below 10°F (-12°C) ISO VG15	
Return filter	Replace	Refer to Parts Manual for filter part number	
System pressures	Check system relief pressure	System Relief Pressure 3,200 to 3,300 psi (220 to 228 bar)	

Maintenance Table Key: P = Pass, F = Fail, R = Repaired

Performed by: _____ Date: _____

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Public... Order the manual at mid-west-tech.com >

SAFETY RULES

⚠Warning

All personnel shall carefully read, understand and follow all safety rules and operating instructions before operating or performing maintenance on any Snorkel aerial work platform.

Electrocution Hazard	Tip Over Hazard	Collision Hazard	Fall Hazard
			
THIS MACHINE IS NOT INSULATED!	**NEVER** elevate the platform or drive the machine while elevated unless the machine is on a firm, level surface.	**NEVER** position the platform without first checking for overhead obstructions or other hazards.	**NEVER** climb, stand, or sit on platform guardrails or midrail.

USE OF THE AERIAL WORK PLATFORM: This aerial work platform is intended to lift persons, their tools and materials used for the job. It is designed for repair, assembly, stockpicking jobs, etc., and assignments at workplaces above head height (ceilings, cranes, roof structures, buildings, shelving, etc.). All other uses of the aerial work platform are prohibited and the rules below must be adhered to!

THIS AERIAL WORK PLATFORM IS NOT INSULATED! Refer to applicable national standards for safe approach distances.

Exceeding the specified permissible maximum load **is prohibited!** See "Platform Capacity" for details.

The use and operation of the aerial work platform as a lifting tool or a crane **is prohibited!**

NEVER exceed the manual force allowed for this machine. See "Manual Force" for details.

DISTRIBUTE all platform loads evenly on the platform.

NEVER operate the machine without first surveying the work area for stationary or moving obstacles and surface hazards such as holes, drop-offs, bumps, curbs, or debris, and avoiding them. **NEVER** strike or bump into stationary or moving obstacles while driving or raising, lowering, or extending the platform.

USE THREE POINTS OF SUPPORT when entering or exiting the platform. Grasp the handrails, not the doors, with one hand on each side. Use two hands and one foot on the step when climbing into and out of the platform.

PLATFORM passengers should watch their hands and fingers for pinch points while holding on the guardrails while the platform is moving.

OPERATE machine only on surfaces capable of supporting wheel loads.

NEVER operate the machine when wind speeds exceed this machine's wind rating. See "Beaufort Scale" for details.

Do not operate the aerial platform in windy or gusty conditions. Do not add anything to or take anything into the aerial platform that will increase the wind loading such as billboards, banners, flags, etc.

IN CASE OF EMERGENCY push EMERGENCY STOP switch to deactivate all powered functions.

IF ALARM SOUNDS while platform is elevated, STOP, carefully lower platform. Move machine to a firm, level surface.

Climbing up the railing of the platform, standing on or stepping from the platform onto buildings, steel or prefab concrete structures, etc., **is prohibited! NEVER** exit or enter the platform when it is elevated.

Dismantling the entry gate or other railing components **is prohibited!** Always make certain that the entry gate is closed!

It is prohibited to keep the entry gate in an open position when the platform is raised!

To extend the height or the range by placing of ladders, scaffolds or similar devices on the platform **is prohibited!**

NEVER perform service on machine while platform is elevated without blocking elevating assembly.

INSPECT the machine thoroughly for cracked welds, loose or missing hardware, hydraulic leaks, loose wire connections, and damaged cables or hoses before using.

VERIFY that all labels are in place and legible before using.

NEVER use a machine that is damaged, not functioning properly, or has damaged or missing labels.

To bypass any safety equipment **is prohibited** and presents a danger for the persons on the aerial work platform and in its working range.

NEVER charge batteries near sparks or open flame. Charging batteries emit explosive hydrogen gas.

Modifications to the aerial work platform **are prohibited** or permissible only at the approval by **Snorkel**.

AFTER USE, secure the work platform from unauthorized use by turning the keyswitch off and removing key.

The driving of MEWP's on the public highway is subject to national traffic regulations.

Certain inherent risks remain in the operation of this machine despite utilizing proper design practices and safeguarding.

Care must be taken to ensure that the machines meets the requirements of stability during use, transportation, assembly, dismantling when out of service, testing, or foreseeable breakdowns.

In the event of an accident or breakdown see "Emergency Lowering." Do not operate the aerial platform if it is damaged or not functioning properly. Qualified maintenance personnel must correct the problem before putting the aerial platform back into service.

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Public... Order the manual at mid-west-tech.com >




Figure 1 – Minimum Safe Approach Distance

Platform Capacity

The maximum unrestricted rated load capacity and the maximum number of occupants for the aerial platform are stated on machine decals, placards, and in the machine specifications in this manual.

⚠Danger

The aerial platform can tip over if it becomes unstable. Death or serious injury will result from a tip-over accident. Do not exceed the capacity values indicated on the machine decals, placards, and in the machine specifications in this manual.

Manual Force

Manual force is the force applied by the occupants to objects such as walls or other structures outside the work platform.

⚠Danger

The aerial platform can tip over if it becomes unstable. Death or serious injury will result from a tip-over accident. Do not exceed the maximum allowable manual force indicated on the machine decals, placards, and in the machine specifications in this manual.

The maximum allowable manual force is limited to 45 lbs (200 N) of force per occupant, with a maximum of 90 lbs (400 N) for all occupants.

Wind Speeds

Do not add anything to the aerial platform that will increase the wind loading such as billboards, banners, flags, etc.

⚠Danger

The aerial platform can tip over if it becomes unstable. Death or serious injury will result from a tip-over accident. Do not operate the machine in wind speeds of 28 mph (12.5 m/s) or greater.

Do not operate the aerial platform in windy conditions with wind gusts or steady wind speeds of 28 mph (12.5 m/s) or greater. Refer to Figure 2.

Prestart Inspection

Perform a prestart inspection before each shift as described in Chapter 8. Do not use the aerial platform on the job unless you are trained and authorized to do so.

Work Place Inspection and Practices

Do not use the aerial platform as a ground connection when welding.

- The welding ground clamp must be attached to the same structure that is being welded.
- Electrical current flow can be very intense, causing serious internal damage to some components.

Inspect the area before and during aerial platform use. The following are some potential hazards that may be in the work place:

- Debris
- Slopes
- Drop-offs or holes
- Bumps and floor obstructions
- Overhead obstructions
- Unauthorized persons
- High voltage conductors
- Wind and weather conditions
- Inadequate surface and support to withstand load forces applied by the aerial platform in all operating configurations

Before using the aerial platform in any hazardous (classified) location, make certain it is approved and of the type required by ANSI/NFPA 505 for use in that particular location.

Know and understand the job site traffic-flow patterns and obey the flagmen, road signs and signals.

BEAUFORT RATING	WIND SPEED				GROUND CONDITIONS
	m/s	km/h	ft/s	mph	
3	3,4~5,4	12,25~19,4	11.5~17.75	7.5~12.0	Papers and thin branches move, flags wave.
4	5,4~8,0	19,4~28,8	17.75~26.25	12.0~18	Dust is raised, paper whirls up, and small branches sway.
5	8,0~10,8	28,8~38,9	26.25~35.5	18~24.25	Shrubs with leaves start swaying. Wave crests are apparent in ponds or swamps.
6	10,8~13,9	38,9~50,0	35.5~45.5	24.5~31	Tree branches move. Power lines whistle. It is difficult to open an umbrella.
7	13,9~17,2	50,0~61,9	45.5~56.5	31.~38.5	Whole trees sway. It is difficult to walk against the wind.

Figure 2 – Beaufort Scale

MidWestTech | Snorkel S2255RTE, S2755RTE Scissor Lift Operator's Manual | Public... Order the manual at mid-west-tech.com >