snorkel

SR9244
SR1054



OPERATOR'S and MAINTENANCE MANUAL

Open Cab
Deutz Stage 4
Manufactured January 2021 and after

Part Number 159-0079-000
January 2021

Order the manual at mid-west-tech.com >

Table of contents

1. GENERAL INFORMATION 9
1.1 PRELIMINARY INFORMATION 10
1.1.1 DOCUMENT IDENTIFICATION 10
1.1.2 SYMBOLS USED IN THE MANUAL 10
1.1.3 MANUAL OWNERSHIP 10
1.1.4 VALIDITY 10
1.1.5 THE IMPORTANCE OF THE MANUAL 11
1.1.6 RECIPIENTS OF THE MANUAL 11
1.1.7 SAFE-KEEPING OF THE MANUAL 11
1.1.8 TERMINOLOGY USED 11
1.2 THE MANUFACTURER 12
1.3 THE DEALER 12
1.4 OPERATOR TRAINING 13
1.4.1 DRIVING ABILITY 13
1.5 MACHINE IDENTIFICATION 13
1.5.1 TECHNICAL NAME 13
1.5.2 IDENTIFICATION PLATE 14
1.6 NOISE 15
1.7 VIBRATION 15
1.8 TECHNICAL SPECIFICATIONS 16
1.8.1 MACHINE MASS 16
1.8.2 MACHINE SIZE 17
1.8.3 BRAKING SYSTEMS 18
1.8.4 TRANSMISSION 18
1.8.5 STEERING 18
1.8.6 HYDRAULIC SERVICES SYSTEM 19
1.8.7 DIFFERENTIAL AXLES 19
1.8.8 DIESEL ENGINE 19
1.8.9 COOLING SYSTEM 19
1.8.10 TIRES 19
1.8.11 DRIVER CABIN 20
1.9 REGULATORY REFERENCES 21

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >

2 SAFETY 23
2.1 INTENDED USE OF THE MACHINE 24
2.2 UNINTENDED USE 24
2.3 LIMITS OF USE 25
2.4 GENERAL REGULATIONS FOR USE 26
2.5 WORKING ON SITE 26
2.6 MANEUVERING ON UNEVEN GROUND 28
2.7 MANEUVERING ON A TRANSVERSAL SLOPE 28
2.8 MANEUVERING ON A LONGITUDINAL SLOPE 29
2.9 IN CASE OF TIPPING OVER 29
2.10 PREPARING TO DRIVE 30
2.10.1 ACCESS TO THE DRIVER CABIN 30
2.10.2 ADJUSTING THE DRIVER'S SEAT 31
2.10.3 TILTING THE SEAT 32
2.10.4 SAFETY BELTS 32
2.10.5 ADJUSTING THE STEERING WHEEL 33
2.11 SAFETY DECALS 34
2.12 LOAD CHART 36
2.12.1 STABILITY CONDITIONS 37
2.13 ANTI-TIP SYSTEM 38
2.14 TRANSPORTING THE MACHINE 39
2.14.1 LOADING AND UNLOADING WITH RAMPS 39
2.14.2 LOADING AND UNLOADING WITH A CRANE 39
2.15 GENERAL SAFETY WARNINGS 40
2.16 CHECKING ENGINE START UP 41
2.17 MOVEMENT IN REVERSE DRIVE 42
2.18 REFUELLING THE MACHINE 42
2.19 FUEL QUALITY (DIESEL) 43
2.20 STORING THE MACHINE 43
2.21 MACHINE DEMOLITION 43
2.22 USING THE MACHINE 44
2.22.1 DRIVING ABILITY 44
2.22.2 RESPONSIBLE USE 44
2.22.3 RESPONSIBLE DRIVING 44

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >

2.23 ROAD CIRCULATION 45
2.23.1 BEFORE MOVING 45
2.23.2 FORWARD DRIVE 45
2.23.3 REVERSE DRIVE 45
2.23.4 PARKING 46
3 CONTROLS AND GENERAL REGULATIONS 47
3.1 DESCRIPTION OF THE CONTROLS 48
3.1.1 CONTROL LEVERS ON THE STEERING COLUMN 48
3.1.1.1 LEFT LEVER OF THE STEERING WHEEL (STALK) 48
3.1.1.2 LEVER ON THE RIGHT OF THE STEERING WHEEL 49
3.2 DESCRIPTION OF THE RIGHT FRONT DASHBOARD 50
3.2.1 ON BOARD COMPUTER 50
3.2.1.1 MAIN PAGE 52
3.2.1.2 MACHINE'S FORWARD MOVEMENT AND STREET MODE 53
3.2.1.3 BOOM LIFTED MODE 55
3.2.1.4 AGRI MODE (OPTIONAL) 56
3.2.1.5 LMC SWITCH OFF 57
3.2.1.6 MENU PAGE 58
3.2.1.7 LANGUAGE PAGE 59
3.2.1.8 CONFIGURATION PAGE 59
3.2.1.9 SOFTWARE VERSION PAGE 60
3.2.1.10 ENGINE PAGE 61
3.2.1.11 SCR PARAMETERS PAGE 62
3.2.1.12 DIESEL REGENERATION PAGE 63
3.2.1.13 IAS – IDLE AUTO STOP PAGE (OPTIONAL) 66
3.2.1.14 ENGINE ERRORS PAGE 68
3.2.1.15 VEHICLE ERRORS PAGE 69
3.2.1.16 INPUTS PAGE 70
3.2.1.17 FNR MODE PAGE 72
3.2.1.18 OIL CONSTANT FLOW (OPTIONAL) 73
3.2.1.19 SAFETY WARNINGS 74
3.2.2 RIGHT FRONT DASHBOARD 79
3.2.3 FIRST RIGHT SIDE DASHBOARD 79
3.3 SECOND RIGHT SIDE DASHBOARD 80

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >

3.1.1.2 LEVER ON THE RIGHT OF THE STEERING WHEEL

Lights control (works with option road lights)

Rotate the lever by holding it from the knurled part until the desired symbol of the rotating part is aligned with the horizontal line of the fixed part. 3 positions are possible:

- Position 0 = lights off
- Position 1 = parking lights on
- Position 2 = low beam lights on



High beam lights

To activate the high beam lights, push the lever forward until it stops in position. The command only works when the ignition is on.

Hazard lights

Pull the lever until it stops. The control works even when the ignition is off.



Direction indicators

Activate the indicators as follows:

a- push the lever up to indicate a left turn

b- push the lever down to indicate a right turn

Windscreen wiper (only for closed cab)

Press the crown at the end of the lever to activate the water spraying circuit to wash the front windshield.



Horn

Sound the horn by pressing the central button at the end of the lever.

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >

		FREQUENCY		FREQUENCY OF SCHEDULED MAINTENANCE					
GROUP	TYPE OF VERIFICATION	DAILY	WEEKLY	FIRST INTERVENTION (250 HOURS)	EVERY 500 HOURS	EVERY 1000 HOURS	EVERY 1500 HOURS	EVERY 2000 HOURS	EVERY 3000 HOURS
ENGINE AIR FILTER	Clean the air filter		X	WHEN SIGNALLED FROM THE COMPUTER ON BOARD					
	Replace the filter primary cartridge					X			
	Replace the secondary filter cartridge					X			
AXLES	Change the axle oil *			X		X			
	Clean the magnetic oil drain plug*			X		X			
	Adjust the negative and service brake *			X		X			
	Greasing		X	X					
GEARBOX	Change the gearbox oil*			X		X			
	Clean the magnetic oil drain plug*			X		X			
	Clean the oil vent *			X		X			
	Greasing		X	X					
HYDRAULIC SYSTEM	Check the hydraulic oil level	X							
	Check the oil leaks from the hydraulic circuit	X							
	Change the hydraulic oil*						X		
	Replace the immersed suction hydraulic oil filter *						X		
	Replace the return hydraulic oil filter *				X				
	Replace the hydrostatic pump filter cartridge*			X	X				
	Verify the torque of the clamps and hydraulic pipes*					X			
	Replace the oil tank air vent filter			Cleaning	x				
VARIOUS	Safety decals inspection	X							
	Check tires pressure	X							
	Check the electrical system operation	X							
	Verify the torque of the tire nuts		X						
	Verify the torque of the boom slider screws*			X		X			
	Replace the boom sliders*							X	
	Verify the cardan shaft cross joint screw torque		X						

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >

5.28 CHECKING THE TIRE PRESSURE AND TORQUE OF THE NUTS

Periodically check the torque of the nuts (1) of the 4 wheels and the tire pressure. Inflation can pose some risk and it is best to use a gun fitted with an extension pipe so as to be positioned at a safe distance and protected from a possible explosion.

To adjust tire pressure and/or replace the tires, refer to the "tires" paragraph in the "general information, chap.1" section.



CHARACTERISTICS	THREAD	TORQUE [Nm]
Wheel nut with integrated ball collar 	M18X1.5 mm M20X1.5 mm M22X1.5 mm	460 630 740
Flat collar wheel nut with separate safety ball washer 	M18X1.5 mm M20X1.5 mm M22X1.5 mm	360 450 550
Wheel nut with captive screw with separate hole 	M18X1.5 mm M20X1.5 mm M22X1.5 mm	360 500 650

To adjust the inflation pressure, refer to the following table and the tire installed on the machine:


TIRE MODEL AND DIMENSIONS	BRAND	PRESSURE [bar]	LOAD INDEX
405/70-20 MPT-01 TL 14PR	MITAS	3.5	149B
405/70-20 MPT800 14PR	CEAT	3.5	149B
405/70-20 4L R1	CAMSO	5.5	158 A8
405/70-24 MPT-01 TL 14PR	MITAS	4.0	152B
405/70-24 MPT-04 TL 14PR	MITAS	4.0	151D
405/70-24 MPT800 14PR	CEAT	4.0	152B

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >

4.5 LEVELING THE MACHINE



Handling loads and namely lifting or other operations that need to be conducted with the boom partially or completely extended are particularly dangerous if they are carried out with the machine NOT positioned on flat ground (check the flatness with the level in the cabin on the right behind the joystick and with the electronic angle sensor that shows the value of the side angle of the machine respecting the ground in the main page display).



To level the machine:

Act on the figertip lever positioned between the main joystick and the bubble level (par. 3.7);

A hydraulic cylinder connected to the chassis lowers or lifts the chassis according to the command given.

The Y box in the main page indicates the side inclination of the machine.

This inclination is detected and measured by specific position sensors.

The machine is levelled when the angle value is near the **0 value.**

The machine leveling control is inhibited under the following conditions:

- machine on outriggers
- rear axle in locked mode
- boom angle over 50 degrees

The machine leveling system has an electronic safety control that automatically decreases the speed of the leveling movement when the boom is raised; furthermore, it is always possible to level the machine towards the 0 degree position while the dangerous movement that could overturn the machine is automatically limited.

4.5.1 MACHINE LEVELING ON WHEELS

When operating with outriggers raised, it is important to check the side levelling before operating the machine.

If this is higher than 1.0°, the machine will automatically prevent boom lifting up to the maximum limit of 70°, limiting it to approximately 60°.

It is therefore advisable, in order to fully make use of machine operation, to level it before performing lifting operations.

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >

2.10.3 TILTING THE SEAT



Press the lever (G) completely to tilt the backrest forward to access the rear compartment where the accessories supplied are housed together with the instruction booklet of the machine and the various equipment installed. The side arm rests can be tilted freely.

The windscreen wiper water tank (H) is found on the left side of the seat (with a level indicator).



Attention! The seat is fitted with a sensor that is activated when the operator sits and enables the engine to start.

2.10.4 SAFETY BELTS



In case of an accident, the properly fastened safety belt offers good protection. The risk of injury is reduced and the chances of survival are increased.
Adjust the driver's seat before fastening the safety belt. Hold the tongue and slowly pull the belt over the pelvis. Insert the tongue (1) into the buckle (2) of the seat until you hear it click. Try to pull the safety belt to make sure it is engaged in the buckle.
Adjust the belt by pulling the flap of the belt with your left hand to tighten it across your body. If the belt is too tight, unhook it and lengthen the left side accordingly and repeat the coupling operation.
Release belt by pressing the red button (3). The tongue is expelled.



The belt is adjusted correctly when it is positioned on your pelvis without causing particular discomfort while driving. Using the belt increases the level of operator safety and reduces the risk of accidents. The driver cabin has been designed to support the weight of the machine in case of tipping over (ROPS). Therefore, the safety belt must always be fastened to avoid being thrown out of the cabin and/or being crushed in case of possible tipping over.

MidWestTech | Snorkel SR9244, SR1054 - Deutz Stage 4, Open Cab Telehandler Oper... Order the manual at mid-west-tech.com >