


OPERATING MANUAL (ANSI/CSA)

ARTICULATING BOOMS

MODEL SJ63AJ

159765AF-A August 2014

SKYJACK

MidWestTech | Skyjack SJ63AJ Articulating Boom Lift Operating Manual | Publication 1597... Order the manual at mid-west-tech.com >

Table of Contents

Section 1 - About Your Aerial Platform 5
Read and Heed 5
Safety Rules 6

Section 2 - Familiarization 13
2.1 Familiarization of Articulated Boom Series 13
2.2 Component Identification 14
2.3 Visual & Daily Maintenance Inspections 20
2.4 Function Tests 28
2.5 Winching and Towing Procedure 41
2.6 Emergency Lowering Procedures 43

Section 3 - Operation 45
3.1 General 45
3.2 Major Components 46
3.3 Major Assemblies 47
3.4 Serial Number Nameplate 47
3.5 Component Identification 48
3.6 Component Identification (Optional Equipment/Attachments) 49
3.7 Operator's Responsibility 51
3.8 Start Operation 52
3.9 Refueling Procedure 58
3.10 Loading/Unloading 60
3.11 Chassis Tilt 62

Section 3 - Diagrams 63

Section 4 - Tables 65
Table 4.1 Standard and Optional Features 65
Table 4.2a Specifications and Features 66
Table 4.2b Specifications and Features 67
Table 4.3 Owner's Annual Inspection Record 68
Table 4.4 Tire/Wheel Specifications 69
Table 4.5 Maximum Platform Capacities 69
Table 4.6 Floor Loading Pressure 70
Table 4.7 Maintenance and Inspection Schedule 71
Table 4.8 Operator's Checklist 72

Section 5 - Labels 73

MidWestTech | Skyjack SJ63AJ Articulating Boom Lift Operating Manual | Publication 1597... Order the manual at mid-west-tech.com >

3.0 Operation

This section provides the necessary information needed to operate the aerial platform. It is important that the user reads and understands this section before operating the aerial platform.

3.1 General

In order for this aerial platform to be in good working condition, it is important that the operator meets the necessary qualifications and follow the maintenance and inspection schedule referred to in this section.

3.1-1 Operator Qualifications

- Only trained and authorized personnel shall be permitted to operate an aerial platform.
- Safe use of this aerial platform requires the operator to understand the limitations and warnings, operating procedures and operator's responsibility for maintenance. Accordingly, the operator must understand and be familiar with this operating manual, its warnings and instructions, and all warnings and instructions on the aerial platform.
- The operator must be familiar with employer's work rules and related government regulations and be able to demonstrate the ability to understand and operate this make and model of aerial platform in the presence of a qualified person.

3.1-2 Operator's Responsibility for Maintenance

⚠ WARNING

Maintenance must be performed by trained and competent personnel who are familiar with mechanical procedures.

Death or serious injury could result from the use of an aerial platform that is not properly maintained or kept in good working condition.

- The operator must be sure that the aerial platform has been properly maintained and inspected before using it.
- The operator must perform all the daily inspections and function tests found in Table 4.7, even if the operator is not directly responsible for the maintenance of this aerial platform.

3.1-3 Maintenance and Inspection Schedule

- The inspection points covered in Table 4.7 indicate the areas of the aerial platform to be maintained or inspected and at what intervals the maintenance and inspections are to be performed.
- The actual operating environment of the aerial platform may affect the maintenance schedule.

⚠ WARNING

Use original or manufacturer-approved parts and components for the aerial platform.

3.1-4 Owner's Inspections

It is the responsibility of the owner to arrange daily, quarterly (or 150 hours) and annual inspections of the aerial platform. Refer to Table 4.7 for recommended maintenance and inspection areas and intervals. A record of annual inspection is kept on a label located close to the base control console on the cowling. Refer to Table 4.3 in this manual.

NOTE

Inspection scheduling requirements may vary. Owners must comply with local standards and regulations.

MidWestTech | Skyjack SJ63AJ Articulating Boom Lift Operating Manual | Publication 1597... Order the manual at mid-west-tech.com >

3.8-9 To Operate Using Emergency Power Switch at Base Control Console

This is a momentary-type switch. This switch allows all functions except the drive function to operate in the event of engine malfunction. Refer to Section 2.6 for the emergency lowering procedure.

NOTE
The emergency power unit has a three-minute duty cycle.

CAUTION
Do not use emergency power unit continuously for more than three minutes.

3.8-10 To Activate Platform Control Console

1. In engine compartment, turn main power disconnect switch to "I" on position.
2. On base control console, turn base/off/platform key switch to "" platform position.
3. On base control console, pull out "" emergency stop button.

WARNING
Ensure that you maintain three points of contact to mount/dismount the platform.

WARNING
DO NOT operate any control on operator's control console without proper fall protection secured to the designated location in the platform. Failure to avoid this hazard could result in death or serious injury.

4. Enter platform and close gate.
5. Attach body harness lanyards of each occupant to platform lanyard rings.
6. On platform control console, pull out "" emergency stop button.
7. Push and hold "" start position from start/on/off switch until engine starts.

WARNING
DO NOT over crank the starter. If engine fails to start after multiple attempts, consult "Troubleshooting Information," in the Service and Maintenance Manual.

NOTE
Engine will not start if you are pressing down on the footswitch.

8. Select desired engine RPM using throttle switch: "" high or "" low.

WARNING
- **DO NOT** drive or steer the aerial platform when the platform position does not allow you a clear view of the base.
- Your area of operation should be cordoned from other personnel or equipment.

MidWestTech | Skyjack SJ63AJ Articulating Boom Lift Operating Manual | Publication 1597... Order the manual at mid-west-tech.com >

Table 4.2b Specifications and Features

MODEL				SJ 63AJ
Engine - Deutz	Engine Type			Deutz D2011L04i
	RPM Settings			1600 Low / 2100 / 2675 High
	Gross Intermittent HP			48 kW / 65 Hp
	Horsepower @ 2000 rpm (intermittent)			48 kW / 65 Hp
	Fuel Type			Diesel
	Fuel Tank Capacity			31.7 gal. (120 L)
	Standard Oil Factory Fill	Ambient Temperature Limits	0°F to 115°F (-18°C to +45°C)	SAE 15W-40 API CF/CG/CH-6
	Cold Lube Oil Option		-20°F to 90°F (-29°C to +32°C)	SAE 5W-40 API CF/CG/CH-6
	Arctic Lube Oil Option		-40°F to 115°F (-40°C to +45°C)	SAE 0W-40 API CF/CG/CH-6
	Approved Alternates		-	See Engine Manual
	Lube Oil Sump Capacity			2.64 gal. (10.0 L)
Engine - GM (ANSI/CSA Only)	Engine Type			3.0L GM Dual Fuel
	RPM Settings			902 Low / 1600 / 2675 High
	Gross Intermittent HP			48 kW / 62 Hp
	Horsepower @ 2000 rpm (intermittent)			47 kW / 60 Hp
	Fuel Type - Dual			Gasoline/Propane
	Fuel Tank Capacity			31.7 gal. (120 L)
	Standard Oil Factory Fill	Ambient Temperature Limits	-40°F to 115°F (-40°C to +45°C)	SAE 5W-30 API SL
	Approved Alternates		-	See Engine Manual
	Lube Oil Capacity			1.19 gal. (4.5 L)
	Standard Coolant	Ambient Temperature Limits	-20°F to 115°F (-29°C to +45°C)	GM 50/50 Extended Life Coolant
	Arctic Coolant Option		-40°F to 115°F (-40°C to +45°C)	GM 60/40 Extended Life Coolant
	Coolant Capacity			3.0 gal. (11.4 L)
Hydraulic Oil	Hydraulic Cooler Option	Ambient Temperature Limits	100°F to 115°F (+38°C to +45°C)	Oil cooler option recommended
	Standard Oil Factory Fill		-15°F to 100°F (-26°C to +38°C)	Shell Tellus T46
	Arctic Oil Option		-40°F to 100°F (-40°C to +38°C)	Esso/Mobil UNIVIS HVI 26 Petro-Canada HYDREX EXTREME
	Approved Alternates		-15°F to 100°F (-26°C to +38°C)	Mobilfluid 424, Esso UNIVIS N46, Chevron Rycon MV
			-40°F to 80°F (-40°C to +27°C)	Mobil DTE 13M, Esso UNIVIS N22 Petro-Canada HYDREX MV Arctic 15
	Hydraulic Tank Capacity			30.4 gal. (115 L)

1203AA_AW8

MidWestTech | Skyjack SJ63AJ Articulating Boom Lift Operating Manual | Publication 1597... Order the manual at mid-west-tech.com >

3.9 Refueling Procedure

This section provides the operator with the procedure on how to refuel the engine with regular fuel and install the propane cylinder.

IMPORTANT

Before using the aerial platform ensure there is enough fuel to finish the job.

⚠ WARNING

Follow all local and national regulations for propane handling.

⚠ WARNING

Failure to heed the following safety precautions could result in death or serious injury:

- **Use extreme caution while refueling aerial platforms.**
- **Ensure engine and all systems are turned off before refueling.**
- **Refuel aerial platform only in a well ventilated area away from open flame and other sources of ignition, authorized by your employer and supervisor.**
- **Liquid propane gas fuel is a gas that is heavier than air. It settles in low spots. Any flame or spark could cause a fire that could cause serious injury.**
- **When changing liquid propane gas cylinder, check all connections for damage or missing parts. Never try to start an aerial platform if you smell gas.**
- **For gasoline engine models, use only unleaded gasoline with an octane rating 87 or higher.**

⚠ WARNING

Do not smoke in an area where aerial platforms are stored or refueled.

3.9-1 Regular Fuel

1. Ensure engine and all systems are turned off and emergency stop buttons are depressed.
2. Open fuel compartment door and remove fuel cap.
3. Carefully pour fuel into tank ensuring that no spillage occurs.
4. Securely replace fuel cap.
5. Ensure there are no leaks in the fuel system.
6. Wipe up any spilled fuel.
7. Dispose of rags in an approved container.

Protection of Environment from Chemical Dangers

⚠ WARNING

Gasoline, diesel fuel, engine oil and hydraulic fluid are chemicals, which can contaminate the environment. If they are spilled during filling and reach the water, they can cause damage to the environment, e.g., death of fish. For such damage, the party responsible is liable! Therefore, gasoline, diesel fuel, engine oil or hydraulic fluid must not get into the sewage system, streams, rivers or other surface water. For that reason, immediately remove the dripped off or spilled gasoline, diesel fuel, engine oil or hydraulic fluid with appropriate means and dispose of these means according to the regulations.

MidWestTech | Skyjack SJ63AJ Articulating Boom Lift Operating Manual | Publication 1597... Order the manual at mid-west-tech.com >

Safety Precautions

Know and understand the safety precautions before going on to next section.

WARNING

Failure to heed the following safety precautions could result in tip over, falling, crushing, or other hazards leading to death or serious injury.

- **KNOW** all national, state or territorial/provincial and local rules which apply to your aerial platform and jobsite.
- **TURN** main power disconnect switch "◯" off when leaving the aerial platform unattended. Remove the key to prevent unauthorized use of the aerial platform.
- **WEAR** all the protective clothing and personal safety devices issued to you or called for by job conditions.
- **DO NOT** wear loose clothing, dangling neckties, scarves, rings, wristwatches or other jewelry while operating this aerial platform .



- **AVOID** entanglement with ropes, cords or hoses.



- **AVOID** falling. Stay within the boundaries of the guardrails.



- **DO NOT** raise the aerial platform or operate elevated in windy or gusty conditions that exceed the limits specified in Section 4, Table 4.5.



- **DO NOT** increase the lateral surface area of the platform. Increasing the area exposed to the wind will decrease aerial platform stability. Avoid tenting.



- **DO NOT** elevate the aerial platform if it is not on a firm, level surface.
- **DO NOT** drive elevated near depressions or holes of any type, loading docks, debris, drop-offs and surfaces that may affect the stability of the aerial platform.



- **DO NOT** elevate or drive elevated on a slope. Elevated driving must be done on a firm, level surface.



- **If operation in areas with holes or drop-offs is absolutely necessary,** elevated driving shall not be allowed. Position the aerial platform horizontally only with the platform fully lowered. After ensuring that all 4 wheels or outriggers (if equipped) have contact with a firm, level surface, the aerial platform can be elevated. After elevation, the drive function must not be activated.



- **DO NOT** drive elevated on a soft or uneven surface.



- **DO NOT** ascend or descend a grade steeper than 45%. Boom elevated driving must only be done on firm, level surfaces.



MidWestTech | Skyjack SJ63AJ Articulating Boom Lift Operating Manual | Publication 1597... Order the manual at mid-west-tech.com >