
SKYJACK

OPERATION MANUAL

SJ63 AJ+

ARTICULATING BOOMS



213211ACA
September 2021
ANSI/CSA

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >

Table of Contents

Section 1 – About this Mobile Elevating Work Platform (MEWP) 9

1.1 Read and heed 9

1.1-1 Mobile Elevating Work Platform (MEWP) definition 9

1.1-2 Purpose of equipment 9

1.1-3 Use of equipment 9

1.1-4 Operation manual 9

1.1-5 Operator 9

1.1-6 Service policy and warranty 9

1.1-7 Ownership of MEWP 9

1.1-8 Optional equipment 9

1.1-9 Scope of this manual 10

1.2 Primary assemblies 11

1.3 Serial number nameplate 12

1.4 Maintenance responsibility 13

1.4-1 Operator 13

1.4-2 Maintenance and inspection schedule 13

1.4-3 Owner 13

Section 2 – General Safety Precautions 15

2.1 Electrocution hazards 15

2.1-1 Minimum distance from electrical conductors 15

2.2 Safety instructions 16

2.3 Fall-protection 19

2.4 Worksite inspection 19

Section 3 – Familiarization 21

3.1 Overview of the MEWP 22

3.2 Manual storage box 23

3.3 Control functions 23

3.3-1 Main power disconnect switch 23

3.3-2 Footswitch 23

3.3-3 Base control console 24

3.3-4 Platform control console 26

3.4 Features and devices 29

3.4-1 Lowered travel position and elevated travel position 29

3.4-2 Drive speed 30

3.4-3 Drive direction 30

3.4-4 Tilt switch 30

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >

3.4-5 Function restrictions when the MEWP is tilted . . . 30
3.4-6 Platform load sensing system . . . 31
3.4-7 Overload status . . . 32
3.4-8 Brake-release system . . . 33
3.4-9 Secondary guarding electrical (SGE) . . . 33
3.4-10 Drive-bypass valve . . . 34
3.4-11 AC power socket on the platform . . . 34
3.4-12 Motion alarm . . . 34
3.4-13 Differential lock switch . . . 34
3.4-14 Turret transportation lock . . . 34
3.5 Optional equipment and attachments . . . 35
3.5-1 Flashing amber light . . . 35
3.5-2 Welder . . . 35
3.5-3 Cold or arctic weather package . . . 36
3.5-4 Tool Tray . . . 36
3.5-5 Glazier . . . 36
3.5-6 Pipe Rack . . . 37
3.5-7 Elevate™ telematics - access control unit . . . 37

Section 4 – Inspections Before Operation . . . 39
4.1 Operator's responsibility . . . 39
4.2 Visual and daily maintenance inspections . . . 40
4.2-1 Labels . . . 40
4.2-2 Electrical . . . 40
4.2-3 Limit switches . . . 40
4.2-4 Hydraulic . . . 40
4.2-5 Engine compartment . . . 41
4.2-6 Control compartment . . . 43
4.2-7 Base . . . 45
4.2-8 Platform assembly . . . 47
4.2-9 Boom assembly . . . 48
4.2-10 Optional equipment . . . 49
4.3 Function tests . . . 50
4.3-1 Do a test of the main power disconnect switch . . . 50
4.3-2 Do a test of the base keyswitch and the emergency-stop button and light . . . 50
4.3-3 Do a test of the start/function enable/emergency power switch and all the boom and platform functions . . . 51
4.3-4 Do a test of the platform self-leveling . . . 51
4.3-5 Do a test of the platform capacity zone indicator lights . . . 51
4.3-6 Do a test of the emergency power unit . . . 52
4.3-7 Do a test of the off/base/platform switch . . . 52
4.3-8 Do a test of the positive air shut-off switch (optional equipment) . . . 53
4.3-9 Do a test of the emergency-stop button and emergency-stop light on the platform . . . 54

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >

4.3-10 Do a test of the load sensing module self-check . . . 54
4.3-11 Do a test of the footswitch and all the boom and platform functions . . . 55
4.3-12 Do a test of the platform capacity zone indicator lights . . . 55
4.3-13 Do a test of the secondary guarding electrical (SGE) . . . 56
4.3-14 Do a test of the engine start/on/off switch . . . 57
4.3-15 Do a test of the emergency power unit . . . 58
4.3-16 Do a test of the manual platform-leveling . . . 58
4.3-17 Do a test of the steer function . . . 58
4.3-18 Do a test of the drive function . . . 59
4.3-19 Do a test of the brakes . . . 59
4.3-20 Do a test of the horn . . . 59
4.3-21 Do a test of the elevated travel speed . . . 60
4.3-22 Do a test of the differential lock switch . . . 60
4.3-23 Do a test of the oscillating cylinders . . . 61
4.4 Operator's checklist . . . 62

Section 5 – Operation . . . 65
5.1 Energize the base control console . . . 65
5.2 Rotate the platform with the base control console . . . 66
5.3 Rotate the turret with the base control console . . . 66
5.4 Move the jib up and down with the base control console . . . 66
5.5 Raise or lower the riser with the base control console . . . 66
5.6 Raise or lower the main boom with the base control console . . . 66
5.7 Extend or retract the boom with the base control console . . . 67
5.8 Make the platform level with the base control console . . . 67
5.9 Operate with the emergency power switch at the base control console . . . 67
5.10 Energize the platform control console . . . 67
5.11 Drive forward or rearward . . . 68
5.12 Steer . . . 68
5.13 Move the jib up and down with the platform control console . . . 68
5.14 Move the riser up and down with the platform control console . . . 69
5.15 Extend or retract the boom with the platform control console . . . 69
5.16 Make the platform level with the platform control console . . . 69
5.17 Rotate the platform with the platform control console . . . 69
5.18 Raise or lower the main boom with the platform control console . . . 69
5.19 Operate the horn . . . 69
5.20 Rotate the turret with the platform control console . . . 69
5.21 Operate with the emergency power switch at the platform control console . . . 70
5.22 Engage or disengage the differential lock switch . . . 70
5.23 MEWP shutdown . . . 70
5.24 Generator (optional equipment) . . . 70
5.25 Glazier Tray (optional equipment) . . . 70
5.26 Pipe Rack (optional equipment) . . . 70

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >

1.4 Maintenance responsibility

1.4-1 Operator

Before the beginning of each shift, do all the daily inspections and function tests. Refer to *Section 4*.

1.4-2 Maintenance and inspection schedule

Refer to the service manual for frequent, periodic, and annual inspections.

The actual operating environment of the MEWP may affect the maintenance schedule.

IMPORTANT

Only use original or manufacturer-approved parts and components for the MEWP.

NOTE

Refer to the Skyjack web site (www.skyjack.com) for machine registration and the latest service bulletins before you do frequent/periodic or annual inspections.

1.4-3 Owner

The owner is responsible for maintenance inspections and repairs. Refer to the service manual for the recommended maintenance and inspection areas and intervals. Keep a record of the annual inspection on the label on the cowling of the control compartment. Refer to *Section 7.3* in this manual.

⚠ WARNING

Only trained and qualified/competent personnel, who understand the mechanical procedures, may do maintenance on the MEWP. The use of a MEWP that is not properly maintained or in the correct working condition could result in death or serious injury.

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >

5.21 Operate with the emergency power switch at the platform control console

This switch enables all of the functions, with the exception of drive, if there is an engine malfunction. Refer to *Section 6.1* for the emergency-lowering procedure.

5.22 Engage or disengage the differential lock switch

1. Move the **differential lock** switch forward and release it to lock or unlock the differential.

5.23 MEWP shutdown

1. Select a reasonably well-protected location to park the MEWP. This location must have a firm, level surface, clear of obstructions, and traffic.
2. Fully retract the boom and lower the platform.
3. Push the **emergency-stop** button on the platform control console.
4. Exit the platform.
5. Turn the **off**/**base**/**platform key** switch to the off position and remove the key.
6. Push the **emergency-stop** button on the base control console.
7. Turn the **main power disconnect** switch to the off position.
8. If it is necessary, put a cover on the platform control console to prevent damage to the warning labels and controls in hostile environments.

5.24 Generator (optional equipment)

To start the generator:

1. Make sure the engine is on.
2. Turn the **generator on**/**off** switch to the on position.

To restore normal operation:

3. Turn the **generator on**/**off** switch to the off position.

5.25 Glazier Tray (optional equipment)

The glazier tray attaches to the kickplate of the platform. Refer to the glazier operation manual for the correct operation and maintenance.

1. Turn the capacity derate switch, and check that the capacity derate light turns on.

5.26 Pipe Rack (optional equipment)

The pipe rack attaches to the kickplate of the platform. Refer to the glazier operation manual for the correct operation and maintenance.

1. Turn the capacity derate switch, and check that the capacity derate light turns on.

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >

7.7 Maximum platform capacities (evenly distributed)

SJ63 AJ+		
	Regular Platform Capacity	**Derated Platform Capacity***
High-capacity zone	454 kg (1000 lb)	454 kg (1000 lb)
	3 persons (maximum number of personnel)	1 person (maximum number of personnel)
	400 N (manual side force)	200 N (manual side force)
Low-capacity zone	300 kg (660 lb)	272 kg (600 lb)
	2 persons (maximum number of personnel)	1 person (maximum number of personnel)
	400 N (manual side force)	200 N (manual side force)
Wind rating	12.5 m/s (28 mph)	
Tilt cutout setting (side-to-side x front-to-back)	5 degrees x 5 degrees	

1957AA

***NOTE:** Refer to *Section 3* for the capacity derate switch operation.

7.8 Floor loading pressure

Model		Weights				Pressures			
		MEWP Weight		Max Weight per Wheel**		LCP***		OFL***	
		kg	lb	kg	lb	kPa	psi	kPa	psf
SJ63 AJ+	Min*	10680	23550	3000	6600	792	115	14	292
	Max*	11136	24550	5445	12000	1064	154	14.6	304

1958AA

* **Min:** Minimum MEWP weight (Unloaded platform, no options/attachments)
Max: Maximum MEWP weight (Platform loaded to capacity with options/attachments)

** **Wheel Load** is the weight that can be experienced on one wheel.
Note: *This is more than 25% of the machine weight due to possible weight distribution over the machine and platform.*

*** **LCP:** Local Concentrated Pressure is a measure of how hard the MEWP presses on the area in direct contact with the floor/tire.
OFL: Overall Floor Load (Pressure) is a measure of the average load the MEWP imparts on the whole surface directly underneath the chassis. This has been calculated by dividing the MEWP weight by the overall floor area occupied by the MEWP (on wheels).

Note: *The floor covering (e.g., tile, carpet, etc.) or the structure (e.g., beams) of the operating surface must be able to withstand more than the values indicated above.*

NOTE

The **LCP** *or* **OFL** *that an individual surface can withstand varies from structure to structure and is generally determined by the engineer or architect for that particular structure.*

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >



DO NOT drive elevated near depressions or holes of any type, loading docks, debris, drop-offs or surfaces that may affect the stability of the MEWP.

IF OPERATION IN AREAS WITH HOLES OR DROP-OFFS IS ABSOLUTELY NECESSARY, elevated driving shall not be allowed. Position the MEWP horizontally only with the platform fully-lowered. After ensuring that all 4 wheels have contact with a firm, level surface, the platform can be raised. After elevation, the drive function must not be activated.



DO NOT drive elevated on a soft or uneven surface.

DO NOT raise the platform if it is not on a firm, level surface.



DO NOT ascend or descend grades greater than the maximum inclines listed in *Section 7.4*. Ascending or descending slopes must only be done when fully lowered.



DO NOT operate a MEWP that has ladders, scaffolding, or other devices on it to increase the platform size or work height.



DO NOT exceed the maximum side force on the platform capacity label when elevated (refer to*Section 7.7*).



DO NOT use the MEWP as a crane.



DO NOT step on the boom arm assembly.



DO NOT sit, stand, or climb on the guardrails.









DO NOT collide or crush. Be aware of obstructions, personnel, or other possible hazards around the MEWP when elevating, lowering, or driving. Keep all body parts inside the platform when elevating or driving. Be aware of blind spots when operating the MEWP.

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21...
Order the manual at mid-west-tech.com >

5.27 Cold or arctic weather package (optional equipment) 71

Section 6 – Additional Procedures 73

6.1 Use the emergency-lowering function 73

6.1-1 At the base control console: 73

6.1-2 At the platform control console: 73

6.2 Chassis tilt recovery 74

6.2-1 Platform uphill 74

6.2-2 Platform downhill 74

6.3 Release the brakes manually 75

6.4 Winch and tow the MEWP 76

6.5 Refuel 77

6.5-1 Refuel the MEWP with diesel or gasoline 77

6.5-2 Replace the propane cylinder (optional equipment) 78

6.6 Move the MEWP for transport 79

6.6-1 Lock the turret 79

6.6-2 Hoist the MEWP 80

6.6-3 Tie down the MEWP 81

Section 7 – Technical Diagrams and Specifications 83

7.1 Technical diagrams 84

7.1-1 Reach diagram - SJ63 AJ+ 84

7.1-2 Dimensions - SJ63 AJ+ 85

7.2 Standard and optional equipment 87

7.3 Owner's annual inspection record 88

7.4 Specifications 89

7.5 Environment 90

7.6 Tire/wheel specifications 90

7.7 Maximum platform capacities (evenly distributed) 91

7.8 Floor loading pressure 91

Section 8 – Labels 93

8.1 Engine side 94

8.2 Engine compartment 97

8.3 Front and rear sides 99

8.4 Controls side 100

8.5 Control compartment 106

8.6 Platform 109

8.7 Platform control console 115

Section 9 – Unique Skyjack Features 119

MidWestTech | Skyjack SJ63 AJ+ Articulating Boom Lift Operation Manual | Publication 21... Order the manual at mid-west-tech.com >