SKYJACK

# PARTS MANUAL

## SJ60 AJ+

ARTICULATING BOOM



**238272AFA**
January 26 2026
ANSI/CSA, CE, AS

MidWestTech | Skyjack SJ60 AJ+ Articulating Boom Lift Parts Manual | Publication 238272... Order the manual at mid-west-tech.com >

# Table of Contents


**Foreword** . . . . . 7

General . . . . . 7
Parts Ordering Information . . . . . 7
Method of Listing . . . . . 7
Quantities . . . . . 7
How To Order Repair Parts . . . . . 7
Recommended Service Parts . . . . . 8

**Section 1 – Platform** . . . . . 11

1.1 Platform with Drop Bars . . . . . 12
1.2 Platform with Swing Gate . . . . . 14
1.3 Railings . . . . . 16
1.4 Rotary Actuator Mount with Load Cell . . . . . 18
1.5 Drop Bar Gate . . . . . 20
1.6 Swing Gate . . . . . 22
1.7 Platform Control Box . . . . . 24
1.8 Boom / Turret Controller . . . . . 28
1.9 Drive / Steer Controller . . . . . 30
1.10 Riser Controller . . . . . 32
1.11 Platform Terminal Strip . . . . . 33
1.12 SGE . . . . . 34
1.13 Footswitch . . . . . 35
1.14 Power to Platform - CE & AS . . . . . 36
1.15 Power to Platform - ANSI/CSA . . . . . 38

**Section 2 – Boom** . . . . . 39

2.1 Riser . . . . . 40
2.2 Main Boom . . . . . 42
2.3 Fly Boom . . . . . 44
2.4 Upper Pivot . . . . . 46
2.5 Cable Track . . . . . 48
2.6 Jib . . . . . 50
2.7 Jib Manifold . . . . . 52
2.8 Limit Switches . . . . . 54
2.9 Rotary Actuator . . . . . 56

**Section 3 – Cylinders** . . . . . 57

3.1 Riser Cylinder . . . . . 58
3.2 Lift Cylinder . . . . . 59





MidWestTech | Skyjack SJ60 AJ+ Articulating Boom Lift Parts Manual | Publication 238272... Order the manual at mid-west-tech.com >

| Index No. | Skyjack Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 153773 | 1 | LOWER RISER |
| 2 | 153862 | 2 | PIN, (1-3/4" diameter x 6-3/8") |
| 3 | 153861 | 2 | PIN, (1-1/2" diameter x 6-15/16") |
| 4 | 162045 | 3 | BOLT, Hex head patch (5/8"-11 x 1-1/2" G8) |
| 5 | 149015 | 2 | BOLT, Hex head patch (5/8"-11 x 1-1/4" G8) |
| 6 | 700782 | 8 | WASHER, Flat hardened (5/8") |
| 7 | 146898 | 7 | PIN, Keeper (5/8") |
| 8 | 101564 | 16 | BUSHING, Fiberglide (1-3/4" ID x 1-1/2") |
| 9 | 153752 | 1 | SECOND RISER |
| 10 | 153844 | 8 | BUSHING, CJS 3224 (2" ID x 1-1/2") |
| 11 | 153745 | 1 | THIRD RISER |
| 12 | 153782 | 1 | COVER, Third riser |
| 13 | 103995 | 2 | WASHER, Flat (1/4") |
| 14 | 115649 | 2 | NUT, Hex lock (1/4"-20 G5, nylon) |
| 15 | 231505 | 2 | CLAMP, Hose |
| 16 | 218003 | 2 | UPPER RISER |
| 17 | 159853 | 2 | PIN, (1-3/4" diameter x 6-7/32") |
| 18 | 159860 | 2 | PIN, Keeper (5/8" short) |
| 19 | 153753 | 2 | LINK |
| 20 | 154076 | 1 | LOWER PIVOT |
| 21 | 153937 | 2 | PAD, Bumper |
| 22 | 153944 | 1 | PAD, Wear |
| 23 | 125959 | 2 | WASHER, Flat hardened (3/8") |
| 24 | 139193 | 2 | BOLT, Hex head patch (3/8"-16 x 7/8" G8) |
| 25 | 104606 | 2 | NUT, Hex lock (3/8"-16 G5, nylon) |
| 26 | 159859 | 2 | BOLT, Hex head (3/8"-16 x 4-1/4" G8) |
| 27 | 148944 | 3 | BOLT, Hex head patch (5/8"-11 x 1-3/4" G8) |
| 28 | 154078 | 2 | SCREW, Button head cap (3/8"-16 x 1/2") |
| 29 | 103949 | 4 | SCREW, Button head cap (3/8"16 x 1") |
| 30 | 162133 | 2 | WELDMENT, Pin (1-1/2" diameter, 8" long) |
| 31 | 153689 | 1 | PIN (1-3/4" dia x 13-3/4" lg) |
| 32 | 153869 | 2 | PIN (1-3/4" dia x 9-1/4" lg) |
| 33 | 153927 | 2 | PIN (2" dia x 12" lg) |
| 34 | (Ref.) | 2 | RISER CYLINDER<br>*(For components, refer to 3.1 Riser Cylinder)* |



MidWestTech | Skyjack SJ60 AJ+ Articulating Boom Lift Parts Manual | Publication 238272... Order the manual at mid-west-tech.com >

| Index No. | Skyjack Part No. | Qty. | Description |
|---|---|---|---|
| 1 | 146176 | 1 | FRONT AXLE |
| | (Ref.) | 1 | • CENTRAL HOUSING - Front Axle<br>*(For components, refer to 5.3 Central Housing - Front Axle)* |
| | (Ref.) | 1 | • DIFFERENTIAL - Front Axle<br>*(For components, refer to 5.4 Differential - Front Axle)* |
| | (Ref.) | 1 | • STEERING - Front Axle<br>*(For components, refer to 5.5 Steering - Front Axle)* |
| | (Ref.) | 1 | • TRUNNION<br>*(For components, refer to 5.6 Trunnion - Front Axle)* |
| 2 | 231443 | 2 | PLATE, Oscillation |
| 3 | 131705 | 2 | FITTING, Straight (08ORBM-04JICM) |
| 4 | 149195 | 1 | FITTING, Straight (04JICM-04BSPPM) |
| 5 | 139126 | 1 | SEAL, British bonded (04BSPPM) |
| 6 | 171913 | 2 | BOLT, Hex head (M14 x 2 x 35 mm, cl 10.9 zp) |
| 7 | 700782 | 2 | WASHER, Flat hardened (5/8") |
| 8 | 702194 | 4 | WASHER, Flat hardened (3/4") |
| 9 | 700575 | 4 | NUT, Torque lock (3/4"-10, gr C) |
| 10 | 146773 | 4 | BOLT, Hex head (3/4"-10 x 5", gr 8) |
| 11 | 153602 | 2 | PLATE, Wear pad |



MidWestTech | Skyjack SJ60 AJ+ Articulating Boom Lift Parts Manual | Publication 238272... Order the manual at mid-west-tech.com >

# 7.3 Engine Fuse Box - Kubota D1305

| Index No. | Skyjack Part No. | Qty. | Description |
|---|---|---|---|
| - | 236168 | 1 | FUSE BOX |
| 1 | 198654 | 1 | • COVER, Fuse box - bottom |
| 2 | 198646 | 1 | • BLOCK, Fuse box - dual ISO relay |
| 3 | 198647 | 1 | • BLOCK, Fuse box - ISO relay, 6 fuses |
| 4 | 198651 | 1 | • COVER, Fuse box - top |
| 5 | 198652 | 1 | • BRACKET, Fuse box - RH |
| 6 | 198653 | 1 | • BRACKET, Fuse box - LH |
| 7 | 198649 | 1 | • SPACER, Half module - mini fuse |
| 8 | 198650 | 1 | • SPACER, ISO relay |
| 9 | 170626 | 2 | • FUSE, ATM - 10A |
| 10 | 198727 | 1 | • FUSE, ATM - 30A |
| 11 | 198725 | 1 | • FUSE, ATM - 5A |
| 12 | 127131 | 3 | • RELAY, 12V 40 AMP |
| 13 | 198657 | 4 | • TERMINAL, Female - ISO relay (14/16 AWG) (not shown) |
| 14 | 198658 | 4 | • TERMINAL, Female - ISO relay (18/20 AWG) (not shown) |
| 15 | 198662 | 1 | • TERMINAL, Female - mini fuse (18/20 AWG) (not shown) |
| 16 | 198661 | 5 | • TERMINAL, Female - mini fuse (14/16 AWG) (not shown) |
| 17 | 198648 | 1 | • SPACER, Half module - ISO relay |
| 18 | 198655 | 4 | • TERMINAL, Female - ISO relay (10/12 AWG) (not shown) |
| 19 | 198660 | 2 | • TERMINAL, Female - mini fuse (10/12 AWG) (not shown) |
| 20 | (Ref.) | 1 | • LABEL, Fuse box<br>*(For components, refer to 10.6 Labels - Engine Compartment)* |



MidWestTech | Skyjack SJ60 AJ+ Articulating Boom Lift Parts Manual | Publication 238272... Order the manual at mid-west-tech.com >