KOBELCO

PARTS CATALOG

HYDRAULIC EXCAVATOR

SK130 IV
SK130LC IV

Applicable:SK130 IV LPU0201~
Applicable: SK130LC IV YPU2001~

2421R417D1-01 06/99

MidWestTech | Kobelco SK130 IV, SK130LC IV Hydraulic Excavator Parts Catalog | Publication 2421R417D1

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00. GENERAL MAINTENANCE

FILTER LIST 004-49-1
HYDRAULIC SERVICE COMPONENTS 005-01-1
HYDRAULIC LINE WRENCHES 005-01-2
KOBELCO OILS AND LUBRICANTS 005-01-2
KOBELCO PAINTS 005-01-2
KOBELCO WIRING HARNESS MASTER REPAIR KIT 005-01-3

0. UPPER GROUP

UPPER FRAME ASSY0 011-49-1
UPPER FRAME ASSY REWORK (NIBBLER, BREAKER) 014-60-1
UPPER FRAME ASSY REWORK (NIBBLER, BREAKER GUARDS) 014-61-1
UPPER FRAME ASSY REWORK (DOZER, EXTRA, BREAKER) 014-72-1
UPPER FRAME ASSY REWORK (MIRROR) 014-75-1
COUNTERWEIGHT ASSEMBLY 015-49-1
SWING MOTOR ASSEMBLY 025-49-1
HYDRAULIC TANK ASSEMBLY 041-49-1
FUEL TANK ASSEMBLY 045-49-1

1. CAB & SHEET METAL GROUP

CAB INSTALLATION 051-49-1
CAB ASSEMBLY 055-49-1
FLOOR PLATE ASSEMBLY (1/97~5/98) 064-49-1
FLOOR PLATE ASSEMBLY (5/98~) 065-49-1
SEAT GROUP 071-49-1
SEAT ASSEMBLY 074-49-1
MACHINERY COVERS & SHEET METAL (GUARD ASSY) 081-49-1
COVER ASSEMBLY (ENGINE HOOD) 101-49-1
UNDER COVER ASSEMBLY 115-49-1

2. CONTROL GROUP

CONTROLS, OPERATORS 121-49-1
CONTROL BOX ASSEMBLY 124-49-1
CONTROL LINES 161-49-1
CONTROL LINES (BOOM SAFETY, BOOM & ARM SAFETY) 161-51-1
CONTROL LINES (NIBBLER & BREAKER) 161-60-1
CONTROL LINES (EXTRA & BREAKER) 161-62-1
CONTROL LINES (BREAKER) 161-63-1
CONTROL LINES (DOZER, EXTRA & BREAKER) 161-71-1
CONTROL LINES (DOZER) 161-72-1
CONTROL LINES (EXTRA) 161-73-1
CONTROL LINES (DOZER & EXTRA) 161-74-1
CONTROL LINES (BOOM SAFETY ~7/1/98) 161-75-1
CONTROL LINES(BOOM , BOOM & ARM SAFETY ~7/1/98) 161-76-1
CONTROL LINES (BOOM, BOOM & ARM SAFETY 7/1/98~) 161-77-1

MidWestTech | Kobelco SK130 IV, SK130LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

FOOT PEDAL & CONTROL LEVER ASSEMBLY 201-49-1

3. UPPER HYDRAULICS GROUP

UPPER HYDRAULICS 221-49-1
UPPER HYDRAULICS (EC) 221-50-1
UPPER HYDRAULICS (NA,SA)(BOOM, BOOM & ARM SAFETY) 221-51-1
UPPER HYDRAULICS (EC)(BOOM, BOOM & ARM SAFETY) 221-52-1
UPPER HYDRAULICS (NIBBLER & BREAKER) 221-60-1
UPPER HYDRAULICS (EXTRA & BREAKER) 221-62-1
UPPER HYDRAULICS (BREAKER) 221-63-1
UPPER HYDRAULICS (REWORK, DOZER) 221-72-1
UPPER HYDRAULICS (EXTRA) 221-73-1
UPPER HYDRAULICS (DOZER & EXTRA) 221-74-1
UPPER HYDRAULICS (DOZER, EXTRA & BREAKER) 222-72-1

4. ENGINE INSTALLATION & CONTROL GROUP

POWER PLANT ASSEMBLY 291-49-1
ENGINE ASSEMBLY 295-49-1
POWER TAKE-OFF ASSEMBLY (HYDRAULIC PUMP) 301-49-1
RADIATOR & COOLER ASSEMBLY 321-49-1
ENGINE THROTTLE CONTROL ASSEMBLY (STEPPING MOTOR) 371-49-1
INSTRUMENT PANEL ASSEMBLY 381-49-1
CONTROLLER INSTALLATION 384-49-1
CONTROLLER ASSEMBLY (TYPICAL VIEW) 384-49-2
CONTROLLER ASSEMBLY 385-49-1
CLUSTER GAUGE ASSEMBLY 386-49-1
FUSE BOX ASSEMBLY 387-49-1
HEATER & DEFROSTER INSTALLATION (RED DOT R-1550) 392-49-1
HEATER ASSEMBLY (RED DOT R-1550) 393-49-1
CONTROL PANEL ASSEMBLY (RED DOT R-1550) 394-49-1
HEATER INSTALLATION 395-49-1
HEATER AND HEATER AIR CONDITIONER ASSEMBLY (RED DOT R-1550) ... 398-49-1
AIR CONDITIONER KIT INSTALLATION (RED DOT R-1550) 399-49-1

5. ELECTRICAL COMPONENTS

ELECTRICAL WIRING ASSEMBLY 411-49-1
HARNESS ASSEMBLY (INSTRUMENT PANEL) 415-49-1
HARNESS ASSEMBLY (CONTROLLER) 416-49-1
BATTERY ASSEMBLY 421-49-1
LAMP ASSEMBLY (COMPLETE MACHINE) 423-49-1
SWING FLASHER ASSEMBLY (RED) 427-49-1
REAR LAMP ASSEMBLY (CLEAR) 428-49-1

MidWestTech | Kobelco SK130 IV, SK130LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

6. LOWER GROUP

LOWER INSTALLATION [SHORT CRAWLER(SC)] 441-50-1
LOWER INSTALLATION (SC-DOZER) 441-72-1
LOWER INSTALLATION (LONG CRAWLER) 444-49-1
LOWER INSTALLATION (DOZER-LONG CRAWLER) 444-72-1
LOWER INSTALLATION, REWORK (SC-TRACK GUIDE ASSY) 445-50-1
LOWER INSTALLATION, REWORK (LC-TRACK GUIDE ASSY) 446-49-1
IDLER ASSY 451-49-1
LOWER ROLLER ASSY 461-49-1
UPPER ROLLER ASSY 467-49-1
IDLER ADJUSTER ASSY 471-49-1
IDLER ADJUSTER ASSY 471-50-1
LOWER HYDRAULIC LINES [SHORT CRAWLER (SC)] 491-50-1
LOWER HYDRAULIC LINES (SC-DOZER) 491-72-1
LOWER HYDRAULIC LINES [LONG CRAWLER(LC)] 494-49-1
LOWER HYDRAULIC LINES (LC-DOZER) 494-72-1
CRAWLER TRACK INSTALLATION (SHORT CRAWLER) 511-50-1
CRAWLER TRACK INSTALLATION (LONG CRAWLER) 516-49-1

7. FRONT ATTACHMENT GROUP

BOOM ASSY, 4.6M (NA & EC) 621-49-1
BOOM ASSY, 4.6M (SA) 621-57-1
BOOM ASSY, 4.6M (NIBBLER & BREAKER) 621-60-1
BOOM ASSY, 4.6M (EXTRA & BREAKER) 621-62-1
BOOM ASSY, 4.6M (EXTRA) 621-73-1
BOOM ASSY, 4.6M (BOOM SAFETY ~5/98) 622-49-1
BOOM ASSY, 4.6M [(BOOM SAFETY ~5/98) N&B or BREAKER] 622-60-1
BOOM ASSY, 4.6M [(BOOM SAFETY ~5/98) E&B] 622-62-1
BOOM ASSY, 4.6M [(BOOM SAFETY ~5/98) EXTRA] 622-73-1
BOOM ASSY, 4.6M [(BOOM SAFETY ~5/98) ALL] 622-80-1
BOOM ASSY, 4.6M (BOOM & ARM SAFETY ~5/98) 623-49-1
BOOM ASSY, 4.6M [(BOOM & ARM SAFETY ~5/98) N&B or BKR] 623-60-1
BOOM ASSY, 4.6M [(BOOM & ARM SAFETY ~5/98) E&B] 623-62-1
BOOM ASSY, 4.6M [(BOOM & ARMSAFETY ~5/98) EXTRA] 623-73-1
BOOM ASSY, 4.6M [(BOOM & ARMSAFETY 5/98~) ALL] 623-80-1
ARM ASSY, 3.0M 631-49-1
BUCKET ASSY 641-49-1

8. MACHINE OPTIONS

FUEL PUMP ASSEMBLY 701-50-1
VANDALISM GUARD ASSEMBLY, CAB 711-49-1
VANDALISM PROTECTION GROUP 712-49-1
SEAT BELT ASSEMBLY 721-49-1
BREAKER FLOW CONTROL 771-50-1
AUTO WARM-UP SYSTEM 780-49-1
AUTO WARM-UP SYSTEM (NIBBLER & BREAKER) 781-49-1
FAN INSTALLATION 794-49-1

MidWestTech | Kobelco SK130 IV, SK130LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >