KOBELCO

PARTS CATALOG

EXCAVATOR

SK200 IV
SK200LC IV

Applicable:
SK200 IV YNU0501~
SK200LC IV YQU3101~

Issued 06-1999
2421R418D1-01 NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00. GENERAL MAINTENANCE

FILTER LIST 004-49-1
HYDRAULIC SERVICE COMPONENTS 005-01-1
HYDRAULIC LINE WRENCHES 005-01-2
KOBELCO OILS AND LUBRICANTS 005-01-2
KOBELCO PAINTS 005-01-2
KOBELCO WIRING HARNESS MASTER REPAIR KIT 005-01-3

0. UPPER GROUP

UPPER FRAME ASSEMBLY 011-49-1
UPPER FRAME (REWORK FOR BREAKER OR NIBBLER & BREAKER) 014-60-1
UPPER FRAME (REWORK FOR EXTRA & BREAKER OR EXTRA) 014-73-1
UPPER FRAME (REWORK FOR LEFT LOWER MIRROR MOUNT) 014-75-1
COUNTERWEIGHT ASSEMBLY (CAST) 015-49-1
ADDITIONAL COUNTERWEIGHT KIT (ASSEMBLY FABRICATED) 015-52-1
SWING MOTOR ASSEMBLY 025-49-1
HYDRAULIC TANK ASSEMBLY 041-49-1
FUEL TANK ASSEMBLY 045-49-1

1. CAB & SHEET METAL GROUP

CAB INSTALLATION 051-49-1
CAB ASSEMBLY 055-49-1
MIRROR INSTALLATION (FRAME) 059-50-1
FLOOR PLATE ASSEMBLY 064-49-1
SEAT GROUP 071-49-1
SEAT ASSEMBLY 074-49-1
GUARD ASSYEMBLY 081-49-1
COVER ASSEMBLY (ENGINE HOOD) 101-49-1
UNDER COVER ASSEMBLY 115-49-1

2. CONTROL GROUP

CONTROLS, OPERATORS 121-49-1
CONTROL BOX ASSEMBLY 124-49-1
REWORK, REMOTE CONTROL (NIBBLER & BREAKER) 161-60-1
REWORK, REMOTE CONTROL (BREAKER) 161-63-1
REWORK, REMOTE CONTROL (EXTRA) 161-73-1
REWORK, REMOTE CONTROL (EXTRA & BREAKER) 161-62-1
REWORK, REMOTE CONTROL (BUCKET CUT SYSTEM) 165-49-1
FOOT PEDAL & CONTROL LEVER ASSEMBLY 201-49-1
REMOTE CONTROL ASSY (WRIST CONTROL, PILOT LINES) 161-49-1
REWORK REMOTE CONTROL ASSY (BOOM, BOOM & ARM SAFETY) 161-49-1

MidWestTech | Kobelco SK200 IV, SK200LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

3. UPPER HYDRAULICS GROUP

UPPER HYDRAULICS (N.A. & S.A.) STANDARD 221-49-1
UPPER HYDRAULICS (EC) STANDARD 221-50-1
UPPER HYDRAULICS REWORK (BOOM, BOOM & ARM SAFETY) 221-53-1
REWORK UPPER HYDRAULICS (NIBBLER & BREAKER) 221-60-1
REWORK, UPPER HYDRAULICS (BREAKER) 221-63-1
REWORK,UPPER HYDRAULICS (EXTRA) 221-73-1
REWORK UPPER HYDRAULICS (EXTRA & BREAKER) 221-62-1
SWING PRIORITY KIT 224-49-1

4. ENGINE INSTALLATION & CONTROL GROUP

ENGINE INSTALLATION 291-49-1
ENGINE ASSEMBLY 295-49-1
ENGINE INSTALLATION 298-49-1
POWER TAKE-OFF ASSEMBLY (HYDRAULIC PUMP) 301-49-1
AIR CLEANER ASSEMBLY 318-49-1
RADIATOR & COOLER ASSEMBLY 321-49-1
ENGINE THROTTLE CONTROL ASSEMBLY (STEPPING MOTOR) 371-49-1
INSTRUMENT PANEL ASSEMBLY 381-49-1
CONTROLLER INSTALLATION 384-49-1
CONTROLLER ASSEMBLY (TYPICAL VIEW) 385-49-2
CONTROLLER ASSEMBLY 385-49-1
CLUSTER GAUGE ASSEMBLY 386-49-1
FUSE BOX ASSEMBLY 387-49-1
HEATER & DEFROSTER INSTALLATION (RED DOT R-1550) 392-49-1
HEATER ASSEMBLY (RED DOT R-1550) 393-49-1
CONTROL PANEL ASSEMBLY (RED DOT R-1550) 394-49-1
HEATER INSTALLATION 395-49-1
HEATER AND HEATER AIR CONDITIONER ASSEMBLY (RED DOT R-1550) 398-49-1
AIR CONDITIONER KIT INSTALLATION (RED DOT R-1550) 399-49-1

5. ELECTRICAL COMPONENTS

ELECTRICAL WIRING ASSEMBLY 411-49-1
HARNESS ASSEMBLY (INSTRUMENT PANEL) 415-49-1
HARNESS ASSEMBLY (CONTROLLER) 416-49-1
BATTERY ASSEMBLY 421-49-1
LAMP ASSEMBLY (COMPLETE MACHINE) 423-49-1
SWING FLASHER ASSEMBLY (RED) 427-49-1
REAR LAMP ASSEMBLY (CLEAR) 428-49-1

6. LOWER GROUP

CROSS REFERENCE TABLE 441-00-1

LOWER INSTALLATION

STANDARD CRAWLER - (SC) 441-50-1
LONG CRAWLER - (LC) 444-49-1
HIGH & WIDE LONG CRAWLER (HWLC) 450-49-1
IDLER ASSEMBLY 451-49-1
LOWER ROLLER ASSEMBLY 461-49-1
UPPER ROLLER ASSEMBLY 467-49-1
STANDARD DUTY 451-49

MidWestTech | Kobelco SK200 IV, SK200LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

IDLER ADJUSTER ASSEMBLY 471-49-1
PROPEL MOTOR ASSEMBLY 481-49-1
LOWER HYDRAULICS
STANDARD CRAWLER - (SC) 491-50-1
LONG CRAWLER - (LC) 494-49-1
HIGH & WIDE LONG CRAWLER- (HWLC) 499-49-1
CRAWLER TRACK INSTALLATION
STANDARD CRAWLER - (SC) 511-50-1
LONG CRAWLER - (LC) 516-49-1

7. FRONT ATTACHMENT GROUP
BOOM ASSEMBLY, 5.6M (N.A.,E.C.) 621-49-1
BOOM ASSEMBLY, 5.6M (SA.) 621-57-1
BOOM ASSEMBLY, 5.6M (NIBBLER & BREAKER OR BREAKER) 621-60-1
BOOM ASSEMBLY, 5.6M (EXTRA & BREAKER) 621-62-1
BOOM ASSEMBLY, 5.6M (EXTRA) 621-73-1
BOOM ASSEMBLY, 5.6M (BOOM SAFETY) 622-49-1
BOOM ASSEMBLY, 5.6M NIBBLER & BREAKER OR BREAKER(BOOM SAFETY) 622-60-1
BOOM ASSEMBLY, 5.6M EXTRA & BREAKER(BOOMSAFETY) 622-62-1
BOOM ASSEMBLY, 5.6M EXTRA(BOOM SAFETY) 622-73-1
BOOM ASSEMBLY, 5.6M (BOOM & ARM SAFETY) 623-49-1
BOOM ASSEMBLY, 5.6M NIBBLER & BREAKER OR BREAKER(BOOM & ARM SAFETY) ... 623-60-1
BOOM ASSEMBLY, 5.6M EXTRA & BREAKER (BOOM & ARM SAFETY) 623-62-1
BOOM ASSEMBLY, 5.6M EXTRA (BOOM & ARM SAFETY) 623-73-1
ARM ASSEMBLY, 2.94M (N.A. STANDARD) 631-49-1
ARM ASSEMBLY, 2.94M (EC) STANDARD 631-50-1
ARM ASSEMBLY, 2.94M (S.A.) STANDARD 631-57-1
ARM ASSEMBLY, 2.94M (NIBBLER & BREAKER) 631-57-1
ARM ASSEMBLY, 2.94M (EXTRA & BREAKER) 631-62-1
ARM ASSEMBLY, 2.94M (BREAKER) 631-63-1
ARM ASSEMBLY, 2.94M (EXTRA) 631-73-1
BUCKET ASSEMBLY, STANDARD 641-49-1
HENDRIX BUCKETS FOR LATIN AMERICA 641-50

8. MACHINE OPTIONS

FUEL PUMP ASSEMBLY 701-57-1
VANDALISM GUARD ASSEMBLY, CAB 711-49-1
VANDALISM PROTECTION GROUP 712-49-1
SEAT BELT ASSEMBLY 721-49-1
REWORK, CONTROL (VARIABLE LOADING MODE) 733-49-1
REWORK, CONTROL (AUTO WARM-UP SYSTEM) 780-49-1
FAN INSTALLATION 794-49-1
MIRROR INSTALLATION 795-57-1
TRAVEL ALARM ASSEMBLY 798-49-1
RADIO INSTALLATION (LEFT CONTROL BOX - EUROPE) 799-49-1
REWORK, LOW FRAME (BELLY PAN KIT) 801-49-1

MidWestTech | Kobelco SK200 IV, SK200LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

KOBELCO

PARTS CATALOG

EXCAVATOR

SK200 IV
SK200LC IV

Applicable:
SK200 IV YNU0501~
SK200LC IV YQU3101~

Issued 06-1999
2421R418D1-01 NA

Order the manual at mid-west-tech.com >