KOBELCO

PARTS CATALOG

HYDRAULIC EXCAVATOR

SK210 IV
SK210LC IV

SK210 IV . . . YNU0501~
SK210LC IV . YQU3101~

Issued 06-1999
2421R418D2-01 NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00. GENERAL MAINTENANCE

FILTER LIST 004-49-1
HYDRAULIC SERVICE COMPONENTS 005-01-1
HYDRAULIC LINE WRENCHES 005-01-2
KOBELCO OILS AND LUBRICANTS 005-01-2
KOBELCO PAINTS 005-01-2
KOBELCO WIRING HARNESS MASTER REPAIR KIT 005-01-3

0. UPPER GROUP

UPPER FRAME ASSEMBLY 011-49-1
UPPER FRAME (REWORK FOR BREAKER OR NIBBLER & BREAKER) 014-60-1
UPPER FRAME (REWORK FOR EXTRA & BREAKER OR EXTRA) 014-73-1
UPPER FRAME (REWORK FOR LEFT LOWER MIRROR MOUNT) 014-75-1
COUNTERWEIGHT ASSEMBLY (CAST) 015-49-1
ADDITIONAL COUNTERWEIGHT KIT (ASSEMBLY FABRICATED) 015-52-1
SWING MOTOR ASSEMBLY 025-49-1
HYDRAULIC TANK ASSEMBLY 041-49-1
FUEL TANK ASSEMBLY 045-49-1

1. CAB & SHEET METAL GROUP

CAB INSTALLATION 051-49-1
CAB ASSEMBLY 055-49-1
MIRROR INSTALLATION (FRAME) 059-50-1
FLOOR PLATE ASSEMBLY 064-49-1
SEAT GROUP 071-49-1
SEAT ASSEMBLY 074-49-1
GUARD ASSYEMBLY 081-49-1
COVER ASSEMBLY (ENGINE HOOD) 101-49-1
UNDER COVER ASSEMBLY 115-49-1

2. CONTROL GROUP

CONTROLS, OPERATORS 121-49-1
CONTROL BOX ASSEMBLY 124-49-1
REWORK, REMOTE CONTROL (NIBBLER & BREAKER) 161-60-1
REWORK, REMOTE CONTROL (BREAKER) 161-63-1
REWORK, REMOTE CONTROL (EXTRA) 161-73-1
REWORK, REMOTE CONTROL (EXTRA & BREAKER) 161-62-1
REWORK, REMOTE CONTROL (BUCKET CUT SYSTEM) 165-49-1
FOOT PEDAL & CONTROL LEVER ASSEMBLY 201-49-1
REMOTE CONTROL ASSY (WRIST CONTROL, PILOT LINES) 161-49-1
REWORK REMOTE CONTROL ASSY (BOOM, BOOM & ARM SAFETY) 161-49-1

MidWestTech | Kobelco SK210 IV, SK210LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

3. UPPER HYDRAULICS GROUP

UPPER HYDRAULICS (N.A. & S.A.) STANDARD 221-49-1
UPPER HYDRAULICS (EC) STANDARD 221-50-1
UPPER HYDRAULICS REWORK (BOOM, BOOM & ARM SAFETY) 221-53-1
REWORK UPPER HYDRAULICS (NIBBLER & BREAKER) 221-60-1
REWORK, UPPER HYDRAULICS (BREAKER) 221-63-1
REWORK,UPPER HYDRAULICS (EXTRA) 221-73-1
REWORK UPPER HYDRAULICS (EXTRA & BREAKER) 221-62-1
SWING PRIORITY KIT 224-49-1

4. ENGINE INSTALLATION & CONTROL GROUP

ENGINE INSTALLATION 291-49-1
ENGINE ASSEMBLY 295-49-1
ENGINE INSTALLATION 298-49-1
POWER TAKE-OFF ASSEMBLY (HYDRAULIC PUMP) 301-49-1
AIR CLEANER ASSEMBLY 318-49-1
RADIATOR & COOLER ASSEMBLY 321-49-1
ENGINE THROTTLE CONTROL ASSEMBLY (STEPPING MOTOR) 371-49-1
INSTRUMENT PANEL ASSEMBLY 381-49-1
CONTROLLER INSTALLATION 384-49-1
CONTROLLER ASSEMBLY (TYPICAL VIEW) 385-49-2
CONTROLLER ASSEMBLY 385-49-1
CLUSTER GAUGE ASSEMBLY 386-49-1
FUSE BOX ASSEMBLY 387-49-1
HEATER & DEFROSTER INSTALLATION (RED DOT R-1550) 392-49-1
HEATER ASSEMBLY (RED DOT R-1550) 393-49-1
CONTROL PANEL ASSEMBLY (RED DOT R-1550) 394-49-1
HEATER INSTALLATION 395-49-1
HEATER AND HEATER AIR CONDITIONER ASSEMBLY (RED DOT R-1550) 398-49-1
AIR CONDITIONER KIT INSTALLATION (RED DOT R-1550) 399-49-1

5. ELECTRICAL COMPONENTS

ELECTRICAL WIRING ASSEMBLY 411-49-1
HARNESS ASSEMBLY (INSTRUMENT PANEL) 415-49-1
HARNESS ASSEMBLY (CONTROLLER) 416-49-1
BATTERY ASSEMBLY 421-49-1
LAMP ASSEMBLY (COMPLETE MACHINE) 423-49-1
SWING FLASHER ASSEMBLY (RED) 427-49-1
REAR LAMP ASSEMBLY (CLEAR) 428-49-1

6. LOWER GROUP

CROSS REFERENCE TABLE 441-00-1

LOWER INSTALLATION

STANDARD CRAWLER - (SC) 441-50-1
LONG CRAWLER - (LC) 444-49-1
HIGH & WIDE LONG CRAWLER (HWLC) 450-49-1
IDLER ASSEMBLY 451-49-1
LOWER ROLLER ASSEMBLY 461-49-1
UPPER ROLLER ASSEMBLY 467-49-1
STANDARD DUTY 451-49

MidWestTech | Kobelco SK210 IV, SK210LC IV Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >