
SKYJACK

OPERATING MANUAL

SJ85 AJ

ARTICULATING BOOMS



266536AAA
July 2026
ANSI/CSA

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266...

Order the manual at mid-west-tech.com >

Table of Contents

Section 1 – About This Mobile Elevating Work Platform (MEWP) 9

1.1 Read and Heed 9

1.1-1 Mobile elevating work platform (MEWP) definition 9

1.1-2 Purpose of equipment 9

1.1-3 Use of equipment 9

1.1-4 Manual 9

1.1-5 Operator 9

1.1-6 Service policy and warranty 9

1.1-7 Ownership of machine 9

1.1-8 Optional accessories 9

1.1-9 Scope of this manual 10

1.2 Major Assemblies 11

1.2-1 Base 11

1.2-2 Turret 11

1.2-3 Boom assembly 11

1.2-4 Platform 11

1.3 Serial Number Nameplate 13

1.4 Responsibility for Maintenance 13

1.4-1 Operator's responsibility for maintenance 13

1.4-2 Maintenance and inspection schedule 13

1.4-3 Owner's inspections 13

Section 2 – Operator Safety 15

2.1 Electrocution Hazard 15

2.2 Safety Precautions 16

2.3 Fall Protection 18

2.4 Jobsite Inspection 19

Section 3 – Familiarization 21

3.1 Component Identification 22

3.2 Manual Storage Box 23

3.3 Control Functions 23

3.3-1 Main power disconnect switch 23

3.3-2 Footswitch 23

3.3-3 Base control console 24

3.3-4 Platform control console 26

3.4 Features and Devices 29

3.4-1 Lowered travel position and elevated travel position 29

3.4-2 Drive speed 30

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >

3.4-3 Drive direction . . . 30
3.4-4 Tilt switch . . . 30
3.4-5 Function restrictions when tilted . . . 30
3.4-6 Platform load sensing system . . . 30
3.4-7 Overload status . . . 31
3.4-8 Brake release system . . . 32
3.4-9 Secondary guarding electrical (SGE) . . . 32
3.4-10 Drive bypass valve . . . 33
3.4-11 Differential lock switch . . . 33
3.4-12 Turret transportation lock . . . 33
3.4-13 All motion alarm . . . 33
3.5 Optional Equipment and Attachments . . . 34
3.5-1 AC outlet on platform (if equipped) . . . 34
3.5-2 Work light (if equipped) . . . 34
3.5-3 Flashing amber light (if equipped) . . . 34
3.5-4 LanyardGo . . . 34
3.5-5 Welder (if equipped) . . . 35
3.5-6 Cold weather start (if equipped) . . . 35
3.5-7 Arctic weather package (if equipped) . . . 35
3.5-8 Elevate telematics - access control unit (if equipped) . . . 36

Section 4 – Pre-operation . . . 39
4.1 Operator's Responsibility . . . 39
4.2 Visual & Daily Maintenance Inspections . . . 40
4.2-1 Labels . . . 40
4.2-2 Electrical . . . 40
4.2-3 Limit switches . . . 40
4.2-4 Hydraulic . . . 40
4.2-5 Engine compartment . . . 41
4.2-6 Control compartment . . . 43
4.2-7 Base . . . 44
4.2-8 Platform assembly . . . 46
4.2-9 Boom assembly . . . 47
4.2-10 Optional equipment/attachments . . . 48
4.3 Function Tests . . . 49
4.3-1 Testing main power disconnect switch . . . 49
4.3-2 Base control console . . . 49
4.3-3 Testing base emergency stop button and base emergency stop light . . . 49
4.3-4 Testing start/function enable/emergency power switch and all boom and platform functions . . . 50
4.3-5 Testing platform self-leveling . . . 50
4.3-6 Testing platform capacity zone indicator lights . . . 51
4.3-7 Testing emergency power . . . 51
4.3-8 Testing off/base/platform switch . . . 52
4.3-9 Testing positive air shutoff (if equipped) . . . 52

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >

4.3-10 Platform control console . . . 53
4.3-11 Testing platform emergency stop button and platform emergency stop light . . . 53
4.3-12 Verifying load sensing module self-check . . . 53
4.3-13 Testing footswitch and all boom and platform functions . . . 54
4.3-14 Testing boom lowering cutout switch . . . 54
4.3-15 Testing platform capacity zone indicator lights . . . 54
4.3-16 Testing secondary guarding electrical (SGE) . . . 55
4.3-17 Testing engine start/on/off switch . . . 56
4.3-18 Testing emergency power . . . 56
4.3-19 Testing manual platform leveling . . . 57
4.3-20 Testing steering . . . 57
4.3-21 Testing driving function . . . 57
4.3-22 Testing brakes . . . 57
4.3-23 Testing driving speed . . . 58
4.3-24 Testing horn . . . 58
4.3-25 Testing differential lock switch . . . 58
4.3-26 Do a test of the LanyardGo (if equipped) . . . 58
4.3-27 Testing oscillating axles . . . 59
4.4 Operator's Checklist . . . 60

Section 5 – Operation . . . 61

5.1 Start Operation . . . 62
5.1-1 Activating base control console . . . 62
5.1-2 Rotating platform using base control console . . . 62
5.1-3 Rotating turret using base control console . . . 62
5.1-4 Moving jib up and down using base control console . . . 62
5.1-5 Moving riser up and down using base control console . . . 62
5.1-6 Raising or lowering main boom using base control console . . . 62
5.1-7 Extending or retracting fly boom using base control console . . . 62
5.1-8 Leveling platform using base control console . . . 63
5.1-9 Operating using emergency power switch at base control console . . . 63
5.1-10 Activating platform control console . . . 63
5.1-11 Driving forward or reverse using platform control console . . . 63
5.1-12 Steering using platform control console . . . 64
5.1-13 Moving jib up and down using platform control console . . . 64
5.1-14 Moving riser up and down using platform control console . . . 64
5.1-15 Extending or retracting fly boom using platform control console . . . 64
5.1-16 Leveling platform using platform control console . . . 64
5.1-17 Rotating platform using platform control console . . . 64
5.1-18 Raising or lowering main boom using platform control console . . . 64
5.1-19 Sounding horn . . . 64
5.1-20 Rotating turret using platform control console . . . 64
5.1-21 Operating with emergency power switch at platform control console . . . 64
5.1-22 Engaging differential lock switch . . . 65

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >

5.1-22 Engaging differential lock switch

1. Depress and hold footswitch.
2. On platform control console, push differential lock switch forward to the locked position and then release.

5.1-23 Disengaging differential lock switch

1. Ensure path of intended motion is clear.
2. Depress and hold footswitch.
3. Pull differential lock switch backward to the unlocked position and then release.

NOTE

To disengage differential lock mechanism, it may be necessary to release drive torque. This can be accomplished by operating drive (alternating directions) and/or steer functions (alternating directions).

5.1-24 Shutdown procedure

1. Select a reasonably well-protected parking location with a firm, level surface, clear of obstructions and traffic.
2. Completely retract boom and lower platform.
3. Push in emergency stop button on platform control console and on base control console.
4. Turn base/off/platform key switch to off position. Remove key.
5. Turn main power disconnect switch to off position.
6. If necessary, cover platform control console to protect warning labels and operating controls from hostile environments.

5.1-25 Hydraulic generator (if equipped)

To start hydraulic generator:

1. Ensure engine is running.
2. On platform control console, turn generator on/off switch to on position.

To restore normal operation:

1. On platform control console, turn generator on/off switch to off position.

NOTE

An engine shut down will turn the generator off. All functions are disabled while the generator switch is on.


5.1-26 LanyardGo (optional equipment)

1. Attach the body-harness lanyard to the LanyardGo anchorage point.
2. The MEWP functions become active.
3. The light on the platform control console turns green.
4. The light at the bottom of the LanyardGo turns green.

NOTE

When the body-harness lanyard is not attached to the LanyardGo anchorage point:

- *The MEWP functions do not operate,*
- *The light ❶ on the platform control console turns red,*
- *The light ❷ at the bottom of the LanyardGo turns red to alert the personnel on the ground.*



MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >

7.5 Specifications and Features-B

Model	SJ85 AJ
Electromagnetic Compatibility (EMC)	Meets EN13309:2010 requirements
Hazardous Location Rating	MEWP not rated for hazardous locations
Operating Temperatures	
Standard	-20°C (-4°F) to +40°C (+104°F)
Cold Weather Package	Below -10°C (+14°F)
Arctic Weather Package	Below -18°C (0°F)

1745AA_ANSI

7.6 Tire/Wheel Specifications

SJ85 AJ	
Tire Size	Outrigger R4 18-625
	0.47 m x 1.05 m (18.7 in x 41.2 in)
Type	Foam-filled
Tire Ply Rating	16
Wheel Nuts Torque	373 Nm

1746AA_ANSI


7.7 Maximum Platform Capacities


SJ85 AJ	
Total Capacity (High)	340 kg (750 lb)
	3 Persons
Total Capacity (Low)	227 kg (500 lb)
	2 Persons
Maximum Wind	12.5 m/s
Maximum Side Force	400 N
Tilt Cutout Setting	5 degrees x 5 degrees

1747AA_ANSI

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >

Control compartment (continued)



Description	Label Pictorial
3 Grease points maintenance Refer to service and maintenance manual for lubricating MEWP.	
4 Hydraulic oil Replace hydraulic fluid with approved type (see service manual).	
5 Hydraulic oil level Indicates minimum/maximum oil level.	
6 Warning - Maintenance support Do not enter the space beneath the work platform or extending structure during maintenance unless a means of structure support is in place. Refer to service manual for instructions regarding machine power isolation and structure support during maintenance.	

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >



DO NOT ascend or descend a grade steeper than 45% (4WD). Boom elevated driving must only be done on firm, level surfaces.



DO NOT operate an MEWP that has ladders, scaffolding or other devices mounted on it to increase its size or work height. It is prohibited.



DO NOT exert horizontal (manual) force on MEWP that exceeds the limits specified in *Section 7.7*.



DO NOT use the MEWP as a crane. It is prohibited.



DO NOT climb on boom arm assembly. It is prohibited.



DO NOT sit, stand or climb on the guardrails. It is prohibited.



AVOID overhead obstructions. Be aware of overhead obstructions or other possible hazards around MEWP when lifting or driving.



AVOID crushing hazards. Be aware of crushing hazards when lifting or driving. Keep all body parts inside the MEWP.



BE AWARE of blind spots when operating the MEWP.

ENSURE that there are no personnel or obstructions in the path of travel, including blind spots.



DO NOT lower the platform unless the area below is clear of personnel and obstructions.



DO NOT use boom to push, pull other objects or to lift the chassis.



DO NOT raise the MEWP while it is on a truck, forklift or other device or vehicle.

STUNT driving and horseplay are prohibited.



DO NOT use with improperly inflated/damaged tires or wheels. Refer to *Section 4.2-7*.



DO NOT alter or disable limit switches or other safety devices.

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >

5.1-23 Disengaging differential lock switch . . . 65
5.1-24 Shutdown procedure . . . 65
5.1-25 Hydraulic generator (if equipped) . . . 65
5.1-26 LanyardGo (optional equipment) . . . 65
5.1-27 Arctic weather package (if equipped) . . . 66

Section 6 – Additional Procedures . . . 67

6.1 Emergency Lowering Procedure . . . 67
6.2 Chassis Tilt Recovery . . . 68
6.2-1 Platform uphill . . . 68
6.2-2 Platform downhill . . . 68
6.3 Release the brakes manually . . . 69
6.4 Winch and tow the MEWP . . . 70
6.5 Refueling Procedure . . . 71
6.5-1 Refuelling (gasoline or diesel) . . . 71
6.5-2 Propane . . . 71
6.6 Loading/Unloading . . . 72
6.6-1 Loading and tie-down . . . 72
6.6-2 Locking the turret . . . 73
6.6-3 Lifting . . . 73

Section 7 – Technical Diagrams & Specifications . . . 75

7.1 Technical Diagrams . . . 76
7.2 Standard and Optional Equipment . . . 79
7.3 Owner's Annual Inspection Record . . . 80
7.4 Specifications and Features-A . . . 81
7.5 Specifications and Features-B . . . 82
7.6 Tire/Wheel Specifications . . . 82
7.7 Maximum Platform Capacities . . . 82
7.8 Floor Loading Pressure . . . 83
7.8-1 Locally concentrated pressure (LCP) . . . 83
7.8-2 Overall uniform pressure (OUP) . . . 83

Section 8 – Labels . . . 85

8.1 SJ85 AJ Labels . . . 86
8.1-1 Engine side . . . 86
8.1-2 Front side . . . 91
8.1-3 Control side . . . 92
8.1-4 Platform . . . 96
8.1-5 Control compartment . . . 98
8.1-6 Rear side . . . 102
8.1-7 Platform control console . . . 105

Section 9 – Unique Skyjack Features . . . 109

MidWestTech | Skyjack SJ85 AJ Articulating Boom Lift Operating Manual | Publication 266... Order the manual at mid-west-tech.com >