Operation & Safety Manual

Original Instructions
Keep this manual with machine at all times.

Telehandler Personnel Work Platform

31200160

Revised
April 10, 2017

An Oshkosh Corporation Company

MidWestTech | Lull Personnel Work Platform Telehandler Operator's Manual | Publication 3... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Revision Log

Read This First

Telehandler Operator and Platform Occupant Qualifications ..... b
Modifications ..... b

Table of Contents

Section 1 - General Safety Practices

1.1 Hazard Classification System 1-1
Safety Alert System and Safety Signal Words 1-1
1.2 General Precautions 1-2
1.3 Operation Safety 1-3
Electrical Hazards 1-3
Tip Over Hazard 1-4
Load Falling Hazard 1-6
Pinch Points and Crush Hazards 1-7
Fall Hazard 1-9
Chemical Hazards 1-11

Section 2 - Pre-Operation and Inspection

2.1 Pre-Operation Check and Inspection 2-1
2.2 Safety Decals - JLG Supplied Personnel Work Platform 2-2
Quick Switch Mounted 2-2
Fork Mounted 2-4
2.3 Walk-Around Inspection 2-5
2.4 Warm-Up and Operational Checks 2-6
Warm-Up Check 2-6
Operational Check 2-6

Section 3 - Operation

3.1 Platform Operation 3-1
Lifting/Lowering Personnel 3-1
Removable Rail 3-2
3.2 Use of the Capacity Chart 3-3
Example 3-3
3.3 Loading and Securing for Transport 3-5

MidWestTech | Lull Personnel... Order the manual at mid-west-tech.com >

Section 4 - Types of Personnel Work Platforms

4.1 Approved Personnel Work Platforms 4-1
Quick Switch Mounted - JLG Supplied 4-1
Fork Mounted 4-1
4.2 Unapproved Personnel Work Platforms 4-2
4.3 Platform Installation 4-3
Quick Switch Mounted - JLG Supplied 4-3
Fork Mounted 4-4

Section 5 - Emergency Procedures

5.1 Emergency Lowering of Boom 5-1
5.2 Incident Notification 5-1

Section 6 - Specifications

6.1 Product Specifications - JLG Supplied Personnel Work Platform 6-1
Performance 6-1
Dimensions of Platform 6-1

Index

Inspection, Maintenance and Repair Log

MidWestTech | Lull Personnel... Order the manual at mid-west-tech.com >

SECTION 2 - PRE-OPERATION AND INSPECTION

2.1 PRE-OPERATION CHECK AND INSPECTION

Note: *Complete all required maintenance before operating unit.*

⚠ WARNING

FALL HAZARD. Use extreme caution when checking items beyond your normal reach. Use an approved ladder.

A pre-operation check & inspection of the telehandler is to be completed first. Refer to the Operation & Safety Manual supplied with telehandler.

The pre-operation check & inspection, performed at beginning of each work shift or at each change of operator, should include the following:

1. **Cleanliness -** Check all surfaces for foreign objects.
2. **Structure -** Inspect the platform structure for dents, damage, weld or parent metal cracks or other discrepancies.
3. **Safety Decals -** Ensure all safety decals are legible and in place. Clean or replace as required. See page 2-2 for details.
4. **Operation & Safety Manual -** Operation & Safety manual located in platform manual holder.
5. **Walk-Around Inspection -** See page 2-5 for details.
6. **Operational Check -** Once the walk-around inspection is complete, perform a warm-up and operational check (see page 2-6) in an area free of overhead and ground level obstructions.

⚠ WARNING

If the telehandler does not operate properly, immediately bring machine to a stop, lower boom and platform to ground and stop engine. Determine cause and correct before continued use.

MidWestTech | Lull Personnel... Order the manual at mid-west-tech.com >

3.2 USE OF THE CAPACITY CHART

Example

A contractor owns a model xxxxx telehandler with a 48" Carriage. He knows his fork mounted platform may be used with his model/attachment since it follows the requirements set forth in *"Approved Personnel Work Platforms"* on page 4-1.

The contractor knows the platform's capacity of 1,000 lb (454 kg) can handle the occupant's weight of 450 lb (204 kg) and the load also being lifted of 150 lb (68 kg). The contractor also knows the platform weighs 400 lb (181 kg).

The following are examples with various conditions the contractor may encounter and whether or not the platform may be lifted.

	Load Weight (including platform, load & personnel)	Distance	Height	OK to Lift
1	1000 lb (454 kg)	20 ft (6,1 m)	10 ft (3,0 m)	Yes
2	1000 lb (454 kg)	28 ft (8,5 m)	16 ft (4,9 m)	NO
3	1000 lb (454 kg)	22 ft (6,7 m)	24 ft (7,3 m)	NO
4	1000 lb (454 kg)	8 ft (2,4 m)	30 ft (9,1 m)	Yes

MidWestTech | Lull Personnel... Order the manual at mid-west-tech.com >

Serial Number _____

Date	Comments

Order the manual at mid-west-tech.com >