Illustrated Parts Manual

Models
G5-19A
&
G6-23A

31200194

Revised
August 24, 2017

An Oshkosh Corporation Company

MidWestTech | JLG G5-19A, G6-23A Telehandler Parts Manual | Publication 31200194

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 9

FIGURE 1-1. FRAME SHROUDING AND TRIM 10
FIGURE 1-2. FRAME SHROUDING AND TRIM, FENDER INSTALLATION 14
FIGURE 1-3. AXLE INSTALLATION G5-19A 16
FIGURE 1-4. AXLE INSTALLATION G6-23A 18

SECTION 2 - BOOM 21

FIGURE 2-1. FIRST BOOM SECTION G5-19A 22
FIGURE 2-2. FIRST BOOM SECTION G6-23A 24
FIGURE 2-3. SECOND BOOM SECTION G5-19A 26
FIGURE 2-4. SECOND BOOM SECTION G6-23A 28
FIGURE 2-5. QUICK SWITCH ASSEMBLY 30
FIGURE 2-6. HYDRAULIC QUICK SWITCH ASSEMBLY 32

SECTION 3 - ATTACHMENTS 35

FIGURE 3-1. CARRIAGE ASSEMBLY 36
FIGURE 3-2. CARRIAGE ASSEMBLY 38
FIGURE 3-3. BUCKETS 40
FIGURE 3-4. FOUR IN ONE BUCKET 42
FIGURE 3-5. FORK MOUNTED HOOK 44
FIGURE 3-6. TRUSS BOOM 46
FIGURE 3-7. MANURE BUCKET 48
FIGURE 3-8. FORK 50
FIGURE 3-9. SIDE SHIFT CARRIAGE 52
FIGURE 3-10. SIDE TILT CARRIAGE 54
FIGURE 3-11. FORK POSITION/SIDE SHIFT CARRIAGE 56
FIGURE 3-12. FORK MOUNTED PLATFORM 60
FIGURE 3-13. UNIVERSAL HITCH ATTACHMENT 62

SECTION 4 - ENGINE AND ATTACHING PARTS 65

FIGURE 4-1. ENGINE ASSEMBLY 66
FIGURE 4-2. DEUTZ ENGINE 70
FIGURE 4-3. FUEL TANK AND LINES 74
FIGURE 4-4. RADIATOR ASSEMBLY 76
FIGURE 4-5. AIR CLEANER INSTALLATION 78
FIGURE 4-6. EXHAUST INSTALLATION 80

SECTION 5 - DRIVE TRAIN 83

FIGURE 5-1. FRONT AXLE 84
FIGURE 5-2. FRONT AXLE - HOUSING G5-19A 86
FIGURE 5-3. FRONT AXLE - HOUSING G6-23A 88
FIGURE 5-4. FRONT AXLE - HOUSING AND STEERING CYLINDER G5-19A 90
FIGURE 5-5. FRONT AXLE - HOUSING AND STEERING CYLINDER G6-23A 92
FIGURE 5-6. FRONT AXLE - BEVEL GEAR SET 94
FIGURE 5-7. FRONT AXLE - DIFFERENTIAL 96
FIGURE 5-8. FRONT AXLE - DOUBLE U-JOINT G5-19A 98
FIGURE 5-9. FRONT AXLE - DOUBLE U-JOINT G6-23A 100
FIGURE 5-10. FRONT AXLE - BRAKES G5-19A 102
FIGURE 5-11. FRONT AXLE - BRAKES G6-23A 104
FIGURE 5-12. FRONT AXLE - WHEEL HUB AND FINAL REDUCTION G5-19A 106
FIGURE 5-13. FRONT AXLE - WHEEL HUB AND FINAL REDUCTION G6-23A 108
FIGURE 5-14. FRONT AXLE - TRANSMISSION HOUSING 110
FIGURE 5-15. FRONT AXLE - LOWER AND UPPER SHAFT G5-19A 112
FIGURE 5-16. FRONT AXLE - LOWER AND UPPER SHAFT G6-23A 114
FIGURE 5-17. REAR AXLE 116
FIGURE 5-18. REAR AXLE - HOUSING 118
FIGURE 5-19. REAR AXLE - SWIVEL HOUSING AND STEERING CYLINDER G5-19A 120
FIGURE 5-20. REAR AXLE - SWIVEL HOUSING AND STEERING CYLINDER G6-23A 122
FIGURE 5-21. REAR AXLE - BEVEL GEAR SET 124
FIGURE 5-22. REAR AXLE - DIFFERENTIAL G5-19A 126

MidWestTech | JLG G5-19A, G6-23A Telehandler Parts Manual | Publication 31200194 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 5-23. REAR AXLE - DIFFERENTIAL G6-23A....128
FIGURE 5-24. REAR AXLE - DOUBLE U-JOINT G5-19A....130
FIGURE 5-25. REAR AXLE - DOUBLE U-JOINT G6-23A....132
FIGURE 5-26. REAR AXLE - WHEEL HUB AND FINAL REDUCTION G5-19A....134
FIGURE 5-27. REAR AXLE - WHEEL HUB AND FINAL REDUCTION G6-23A....136
FIGURE 5-28. DRIVE SHAFT....138
FIGURE 5-29. TIRES AND RIMS....140

SECTION 6 - CAB....143

FIGURE 6-1. CAB ASSEMBLY....144
FIGURE 6-2. CAB INTERIOR ASSEMBLY....148
FIGURE 6-3. SEAT ASSEMBLY....150
FIGURE 6-4. CAB WINDOWS....152
FIGURE 6-5. CAB DOOR ASSEMBLY....154
FIGURE 6-6. WIPER ASSEMBLY G6-23A....156
FIGURE 6-7. AIR CIRCULATION INSTALLATION....158
FIGURE 6-8. TOOL BOX ASSEMBLY (OPTIONAL)....162
FIGURE 6-9. FIRE EXTINGUISHER INSTALLATION (OPTIONAL) (G6-23A)....164

SECTION 7 - CONTROLS....167

FIGURE 7-1. BOOM JOYSTICK....168
FIGURE 7-2. STEERING COLUMN AND ATTACHING PARTS....170
FIGURE 7-3. ACCELERATOR PEDAL ASSEMBLY....172
FIGURE 7-4. BRAKE PEDAL ASSEMBLY....174

SECTION 8 - HYDRAULIC CIRCUITS....177

FIGURE 8-1. SUPPLY CIRCUIT....178
FIGURE 8-2. DUMP CIRCUIT....182
FIGURE 8-3. FRONT DRIVE CIRCUIT G5-19A....186
FIGURE 8-4. FRONT DRIVE CIRCUIT G6-23A....188
FIGURE 8-5. STEER SELECT....190
FIGURE 8-6. SERVICE/PARK BRAKE....192
FIGURE 8-7. LIFT CYLINDER....194
FIGURE 8-8. EXTEND/RETRACT CYLINDER G5-19A....196
FIGURE 8-9. EXTEND/RETRACT CYLINDER G6-23A....198
FIGURE 8-10. TILT AND TILT COMPENSATING CYLINDER G5-19A....200
FIGURE 8-11. TILT AND TILT COMPENSATING CYLINDER G6-23A....202
FIGURE 8-12. AUXILIARY FUNCTION....204
FIGURE 8-13. REAR HYDRAULIC OUTLET....206

SECTION 9 - HYDRAULIC COMPONENTS....209

FIGURE 9-1. LIFT CYLINDER G5-19A....210
FIGURE 9-2. LIFT CYLINDER G6-23A....212
FIGURE 9-3. EXTEND/RETRACT CYLINDER G5-19A....214
FIGURE 9-4. EXTEND/RETRACT CYLINDER G6-23A....216
FIGURE 9-5. TILT CYLINDER G5-19A....218
FIGURE 9-6. TILT CYLINDER G6-23A....220
FIGURE 9-7. COMPENSATING CYLINDER G5-19A....222
FIGURE 9-8. COMPENSATING CYLINDER G6-23A....224
FIGURE 9-9. FORK LOCKING CYLINDER....226
FIGURE 9-10. FORK LOCKING CYLINDER ASSAMBLY....228
FIGURE 9-11. MAIN CONTROL VALVE (G5-19A Prior to SN 1160003034; G6-23A Prior to SN 1160003516)....230
FIGURE 9-12. MAIN CONTROL VALVE (G5-19A SN 1160003034 to Present; G6-23A SN 1160003516 to Present)....232
FIGURE 9-13. FRONT DRIVE MOTOR G5-19A....234
FIGURE 9-14. FRONT DRIVE MOTOR G6-23A....236
FIGURE 9-15. HYDROSTATIC TRANSMISSION PUMP....238
FIGURE 9-16. HYDRAULIC TANK ASSEMBLY....240
FIGURE 9-17. IMPLEMENT PUMP....242
FIGURE 9-18. AUXILIARY DIVERTER VALVE....244

SECTION 10 - ELECTRICAL....247

MidWestTech | JLG G5-19A, G6-23A Telehandler Parts Manual | Publication 31200194 Order the manual at mid-west-tech.com >

FIGURE 10-1. ELECTRICAL INSTALLATION 248
FIGURE 10-2. ENGINE HARNESS (G5-19A Prior to SN 1160002222; G6-23A Prior to SN 1160002234) 252
FIGURE 10-3. ENGINE HARNESS (G5-19A SN 1160002222 to Present; G6-23A SN 1160002234 to Present) 254
FIGURE 10-4. REAR CHASSIS HARNESS (G5-19A Prior to SN 1160001709; G6-23A Prior to SN 1160001708) 256
FIGURE 10-5. REAR CHASSIS HARNESS (G5-19A SN 1160001709 to Present; G6-23A SN 1160001708 to Present) 258
FIGURE 10-6. FRONT CHASSIS HARNESS 260
FIGURE 10-7. PWM VALVE CONTROLLER ASSEMBLY 262
FIGURE 10-8. ROOF HARNESS 264
FIGURE 10-9. MAIN HARNESS 266
FIGURE 10-10. GROUND HARNESS 270
FIGURE 10-11. BUCKET SHAKE SWITCH (OPTIONAL) 272
FIGURE 10-12. OIL TEMPERATURE GAUGE INSTALLATION G6-23A (OPTIONAL) 274

SECTION 11 - DECALS 277

FIGURE 11-1. FRAME AND BOOM DECALS 278
FIGURE 11-2. CAB DECALS 282
FIGURE 11-3. MACHINE DECALS, G5-19A 284
FIGURE 11-4. MACHINE DECALS, G6-23A 286

SECTION 12 - OPTIONS 289

FIGURE 12-1. CAB WORKLIGHT INSTALLATIONS 290
FIGURE 12-2. BOOM WORKLIGHT INSTALLATION 292
FIGURE 12-3. ROTATING BEACON INSTALLATION 294
FIGURE 12-4. AIR CONDITIONER INSTALLATION (G5-19A Prior to SN 1160004784; G6-23A Prior to SN 1160004665) 296
FIGURE 12-5. AIR CONDITIONER INSTALLATION (G5-19A SN 1160004784 to Present; G6-23A SN 1160004665 to Present) 298
FIGURE 12-6. DRAW BAR COUPLING INSTALLATION 300
FIGURE 12-7. DUAL BOOM AUX HYDRAULIC, MANUAL 302
FIGURE 12-8. DUAL BOOM AUX HYDRAULIC, ELECTRICAL 304
FIGURE 12-9. OPTION HARNESS 306
FIGURE 12-10. UPPER CAB ELECTRICAL INSTALLATION (G5-19A Prior to SN 1160003034; G6-23A Prior to SN 1160003240) 308
FIGURE 12-11. UPPER CAB ELECTRICAL INSTALLATION (G5-19A SN 1160003034 to Present; G6-23A SN 1160003240 to Present) 310
FIGURE 12-12. PINTLE HITCH INSTALLATION 312
FIGURE 12-13. DUMP VALVE INSTALLATION 314
FIGURE 12-14. BOOM AUXILIARY ELECTRIC 316

SECTION 13 - RECOMMENDED SPARE PARTS 319

FIGURE 13-1. RECOMMENDED SPARE PARTS 320

PART NUMBER INDEX 323

MidWestTech | JLG G5-19A, G6-23A Telehandler Parts Manual | Publication 31200194 Order the manual at mid-west-tech.com >

FIGURE 6-3. SEAT ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
1	3980047	1	OPERATOR SEAT, MECHANICAL, (includes items 14 thru 26)	
2	0200843	1	ARM	
3	8004672	1	LOWER JOYSTICK COVER	
4	21011032	2	NUT	
5	3767375	1	FOAM PAD	
6	4569078	2	SPACER TUBE	
7		Ref	HEX HD CAPSCREW	
8		Ref	HEX HD CAPSCREW	
9		Ref	HEX HD CAPSCREW	
10		Ref	WASHER	
11	7029515	4	NUT	
12		Ref	NUT	
13		Ref	HEX HD CAPSCREW	
14	70020223	1	BACK COVER KIT	
15	70020224	1	BACK CUSHION KIT, (includes item 14)	
16	70020225	1	SEAT COVER KIT	
17	70020226	1	SEAT CUSHION KIT, (includes item 16)	
18	70020216	1	SUSPENSION ASSY KIT	
19	70020217	1	DAMPER ASSY KIT	
20	70020218	1	INDICATOR/ADJUSTER AND BUMP STOP	
21	70020219	1	STUD ASSY	
22	70020220	1	HANDLE ASSY KIT	
23	70020221	1	SUSPENSION COVER KIT	
24	70020222	1	FORE AND AFT ADJUSTER KIT	
25	1001006731	1	SEAT BELT, 3 IN RETRACTABLE, (not illustrated)	
26	8004762	1	UPPER JOYSTICK COVER	

MidWestTech | JLG G5-19A, G6-23A Telehandler Parts Manual | Publication 31200194 Order the manual at mid-west-tech.com >

FIGURE 8-10. TILT AND TILT COMPENSATING CYLINDER G5-19A

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
51	2142733	2	CONNECTOR	
105		Ref	MAIN CONTROL VALVE, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
123	2142216	2	SWIVEL NUT RUN TEE	
124	2143017	2	ELBOW, 90	
126	2754307	2	HOSE ASSY	
201	0700815	5	HEX HD CAPSCREW, 8-1.25X35MM	
202	0700817	1	HEX HD CAPSCREW, 8-1.25X45MM	
218	874960	5	COVER PLATE	
219	1309435	1	COVER PLATE	
221	1321128	7	CLAMP	
222	1321133	2	STACKING BOLT	
223	1321134	2	LOCKING PLATE	
224		Ref	TILT CYLINDER, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
227	2141621	4	CONNECTOR	
228	2143017	2	ELBOW, 90	
233	2754113	2	HOSE ASSY	
234	2754122	NLA	HOSE ASSY, (no longer available, use 1001111491 for replacement)	
234	1001111491	1	HOSE ASSY	
251	4569029	1	TUBE ASSY	
252	4569042	1	TUBE ASSY	
253	4569047	1	TUBE ASSY	
254	4569053	1	TUBE ASSY	
289	1321086	1	CLAMP	
312		Ref	COMPENSATION CYLINDER, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	

MidWestTech | JLG G5-19A, G6-23A Telehandler Parts Manual | Publication 31200194 Order the manual at mid-west-tech.com >

FIGURE 9-16. HYDRAULIC TANK ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
1		Ref	CONNECTOR, (See HYDRAULIC CIRCUITS SECTION for Breakdown)	
2	2120194	1	HYDRAULIC FILTER	
2	2120195	1	ELEMENT	
2	7029364	1	PRESSURE SWITCH	
2	7028909	1	CONNECTOR	
2	7029948	2	O-RING	
3	0761012	4	HEX HD CAPSCREW, 10X25, GR8.8	
4	2120206	1	BREATHER	
5		Ref	ELBOW, 90, (See HYDRAULIC CIRCUITS SECTION for Breakdown)	
6	8005248	1	FLUID LEVEL GUAGE	
7		Ref	RUN TEE, (See HYDRAULIC CIRCUITS SECTION for Breakdown)	
8	3460451	1	HYDRAULIC TUBE	
9	1120587	1	FILLER CAP	
10	0760810	4	HEX HD CAPSCREW, 8-1.25X20MM, GR8.8	
11	3960603	1	SEAL	
12	2171948	1	PLUG	
13	2142503	2	FITTING CAP	
14	7029949	1	O-RING	
15	2180874	1	SPACER	

MidWestTech | JLG G5-19A, G6-23A Telehandler Parts Manual | Publication 31200194 Order the manual at mid-west-tech.com >