Illustrated Parts Manual

Models
3614RS
4017RS

SN 1160007024 to SN 1160008790
SN E160000001 to SN E160000496

P/N
31200939

May 27, 2020 - Rev N

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 19

FIGURE 1-1. FRAME INSTALLATION - 3614RS 20
FIGURE 1-2. FRAME INSTALLATION - 3614RS 22
FIGURE 1-3. FRAME INSTALLATION - 3614RS (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 24
FIGURE 1-4. FRAME INSTALLATION - 4017RS (74KW) 26
FIGURE 1-5. FRAME INSTALLATION - 4017RS (74KW) 28
FIGURE 1-6. FRAME INSTALLATION - 4017RS (55KW) 30
FIGURE 1-7. FRAME INSTALLATION - 4017RS (55KW) 32
FIGURE 1-8. FRAME INSTALLATION - 4017RS (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 34
FIGURE 1-9. FRAME INSTALLATION (HIGH CAB) - 4017RS (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 36
FIGURE 1-10. ENCLOSURE GROUP INSTALLATION 38
FIGURE 1-11. MIRROR INSTALLATION - 3614RS 40
FIGURE 1-12. MIRROR INSTALLATION - 4017RS 42
FIGURE 1-13. REAR MIRROR INSTALLATION 44
FIGURE 1-14. MIRROR ASSEMBLY 46
FIGURE 1-15. BOOM PROP INSTALLATION 48
FIGURE 1-16. WHEEL CHOCK INSTALLATION 50
FIGURE 1-17. COUNTERWEIGHT INSTALLATION - 3614RS 52
FIGURE 1-18. COUNTERWEIGHT INSTALLATION - 4017RS 54
FIGURE 1-19. HOOD ASSEMBLY 56
FIGURE 1-20. SOUND SUPPRESSION INSTALLATION (LCAD, AFRICA AND MID EAST, PAC RIM) 58
FIGURE 1-21. SOUND SUPPRESSION INSTALLATION (EU, GERMANY, FRANCE, UK AND IRELAND) 60
FIGURE 1-22. SOUND SUPPRESSION INSTALLATION (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 62
FIGURE 1-23. CHASSIS COVER PLATE INSTALLATION - 3614RS 64
FIGURE 1-24. CHASSIS COVER PLATE INSTALLATION - 4017RS 66
FIGURE 1-25. LICENSE PLATE INSTALLATION 68
FIGURE 1-26. RETRIEVAL HITCH 70
FIGURE 1-27. HYDRAULIC TANK INSTALLATION 72
FIGURE 1-28. PAD LOCK 74
FIGURE 1-29. HITCH PIN ASSEMBLY 76

SECTION 2 - BOOM 79

FIGURE 2-1. BOOM INSTALLATION - 3614RS (NO AUXILIARY HYDRAULICS) 80
FIGURE 2-2. BOOM INSTALLATION - 3614RS (AUXILIARY HYDRAULICS) 82
FIGURE 2-3. BOOM INSTALLATION - 4017RS (NO AUXILIARY HYDRAULICS) 84
FIGURE 2-4. BOOM INSTALLATION - 4017RS (AUXILIARY HYDRAULICS) 86
FIGURE 2-5. BOOM ASSEMBLY - 3614RS (NO AUXILIARY HYDRAULICS) 88
FIGURE 2-6. BOOM ASSEMBLY - 3614RS (AUXILIARY HYDRAULICS) 90
FIGURE 2-7. BOOM ASSEMBLY - 4017RS (NO AUXILIARY HYDRAULICS) 92
FIGURE 2-8. BOOM ASSEMBLY - 4017RS (AUXILIARY HYDRAULICS) 96
FIGURE 2-9. EXTEND CHAIN ASSEMBLY - 3614RS 100
FIGURE 2-10. EXTEND CHAIN ASSEMBLY (1) - 4017RS 102
FIGURE 2-11. EXTEND CHAIN ASSEMBLY (2) - 4017RS 104
FIGURE 2-12. RETRACT CHAIN ASSEMBLY - 3614RS 106
FIGURE 2-13. RETRACT CHAIN ASSEMBLY (1) - 4017RS 108
FIGURE 2-14. RETRACT CHAIN ASSEMBLY (2) - 4017RS 110
FIGURE 2-15. COVER PLATE INSTALLATION - 3614RS 112
FIGURE 2-16. COVER PLATE INSTALLATION - 4017RS 114
FIGURE 2-17. FIRST BOOM SECTION - 3614RS 116
FIGURE 2-18. FIRST BOOM SECTION - 4017RS 118
FIGURE 2-19. SECOND BOOM SECTION - 3614RS 120
FIGURE 2-20. SECOND BOOM SECTION - 4017RS 122
FIGURE 2-21. THIRD BOOM SECTION - 3614RS 124
FIGURE 2-22. THIRD BOOM SECTION - 4017RS 126
FIGURE 2-23. FOURTH BOOM SECTION - 4017RS 128
FIGURE 2-24. HOSE SUPPORT ASSEMBLY - 4017RS 130
FIGURE 2-25. MANUAL QUICK ATTACH 132
FIGURE 2-26. HYDRAULICS INSTALLATION - 3614RS (NO AUXILIARY HYDRAULICS) 134
FIGURE 2-27. HYDRAULICS INSTALLATION - 3614RS (AUXILIARY HYDRAULICS) 136
FIGURE 2-28. HYDRAULICS INSTALLATION - 4017RS 138

MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31200939 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-29. HYDRAULICS ASSEMBLY - 4017RS 140
FIGURE 2-30. HYDRAULICS INSTALLATION - 4017RS (AUXILIARY HYDRAULICS) 142
FIGURE 2-31. AUXILIARY LINES INSTALLATION 144
FIGURE 2-32. BOOM BRUSH INSTALLATION - 3614RS 146
FIGURE 2-33. BOOM BRUSH INSTALLATION - 4017RS 148
FIGURE 2-34. BOOM BRUSH BRACKET ASSEMBLY (1) 150
FIGURE 2-35. BOOM BRUSH BRACKET ASSEMBLY (2) 152
FIGURE 2-36. BOOM BRUSH BRACKET ASSEMBLY (3) 154
FIGURE 2-37. BOOM BRUSH BRACKET ASSEMBLY (4) - 3614RS 156
FIGURE 2-38. BOOM BRUSH BRACKET ASSEMBLY (5) - 3614RS 158
FIGURE 2-39. BOOM BRUSH BRACKET ASSEMBLY (6) 160
FIGURE 2-40. BOOM BRUSH BRACKET ASSEMBLY (7) - 4017RS 162
FIGURE 2-41. BOOM BRUSH BRACKET ASSEMBLY (8) - 4017RS 164
FIGURE 2-42. BOOM BRUSH BRACKET ASSEMBLY (9) - 4017RS 166
FIGURE 2-43. BOOM BRUSH BRACKET ASSEMBLY (10) - 4017RS 168
FIGURE 2-44. BOOM BRUSH BRACKET ASSEMBLY (11) - 4017RS 170

SECTION 3 - ATTACHMENTS 173

FIGURE 3-1. CARRIAGE 174
FIGURE 3-2. FORKS 176
FIGURE 3-3. FORKS TINES 178
FIGURE 3-4. BUCKET 1.8M³ 180
FIGURE 3-5. BUCKET 0.9M³ 182
FIGURE 3-6. MULTI-PURPOSE BUCKET (SN 1160007024 through 1160008687) 184
FIGURE 3-7. MULTI-PURPOSE BUCKET (SN 1160008687 through 1160008790) 186
FIGURE 3-8. TRUSS BOOM (1000 KG) 188
FIGURE 3-9. TRUSS BOOM (4000 KG) 190
FIGURE 3-10. INSTALLATION, CARRIAGE FORK POSITIONING 192
FIGURE 3-11. INSTALLATION, FORK AND HOOK - 3614RS 194
FIGURE 3-12. INSTALLATION, FORK AND HOOK - 4017RS 196
FIGURE 3-13. 4 TON FORK HOOK 198
FIGURE 3-14. STANDARD CARRIAGE INSTALLATION WITH LIFT LUG - 3614RS 200
FIGURE 3-15. STANDARD CARRIAGE INSTALLATION WITH LIFT LUG - 4017RS 202
FIGURE 3-16. 4T FORK AND HOOK CARRIAGE 204
FIGURE 3-17. MANITOU CARRIAGE INSTALLATION - 3614RS 206
FIGURE 3-18. MANITOU CARRIAGE INSTALLATION - 4017RS 208
FIGURE 3-19. MANITOU COUPLER INSTALLATION 210
FIGURE 3-20. MANITOU CARRIAGE 212
FIGURE 3-21. JCB CARRIAGE INSTALLATION - 3614RS 214
FIGURE 3-22. JCB CARRIAGE INSTALLATION - 4017RS 216
FIGURE 3-23. JCB COUPLER INSTALLATION 218
FIGURE 3-24. JCB COUPLING 220
FIGURE 3-25. JCB FORK ASSEMBLY 222
FIGURE 3-26. SIDE SHIFT CARRIAGE INSTALLATION - 3614RS 224
FIGURE 3-27. SIDE SHIFT CARRIAGE INSTALLATION - 4017RS 226
FIGURE 3-28. SIDE SHIFT CARRIAGE ASSEMBLY (SN 1160007024 through 1160008687) 228
FIGURE 3-29. SIDE SHIFT CARRIAGE ASSEMBLY (SN 1160008687 through 1160008790) 230
FIGURE 3-30. FORK TRANSPORT LATCH INSTALLATION 232
FIGURE 3-31. HOMOLOGATION INSTALLATION - 3614RS (GERMANY) 234
FIGURE 3-32. HOMOLOGATION WARNING PANEL INSTALLATION - 3614RS (GERMANY) 236
FIGURE 3-33. REFLECTIVE PLATES INSTALLATION (FORKS) 238
FIGURE 3-34. REFLECTIVE PLATES INSTALLATION (BUCKET) (ITALY) 240
FIGURE 3-35. BUCKET GUARD ACCESSORY (ITALY) 242

SECTION 4 - ENGINE AND ATTACHING PARTS 245

FIGURE 4-1. ENGINE AND TRANSMISSION INSTALLATION (ULS) - 74KW (SN 1160007024 through 1160007354) 246
FIGURE 4-2. ENGINE AND TRANSMISSION INSTALLATION (ULS) - 74KW (SN 1160007354 through 1160008518) 248
FIGURE 4-3. ENGINE AND TRANSMISSION INSTALLATION (LS) - 74KW (SN 1160007024 through 1160007354) 250
FIGURE 4-4. ENGINE AND TRANSMISSION INSTALLATION (LS) - 74KW (SN 1160007354 through 1160008518) 252
FIGURE 4-5. TRANSMISSION INSTALLATION (ULS) - 74KW (SN 1160008519 through 1160008790) 254
FIGURE 4-6. ENGINE AND TRANSMISSION INSTALLATION (ULS) - 55KW (SN E160000001 through E160000342, Excluding E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 256
FIGURE 4-7. ENGINE AND TRANSMISSION INSTALLATION (ULS) - 55KW (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 258
FIGURE 4-8. ENGINE MOUNTING INSTALLATION 260

MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31200939 Order the manual at mid-west-tech.com >

FIGURE 4-9. HYDRAULIC PUMP INSTALLATION 262
FIGURE 4-10. TURBO SHIELD INSTALLATION 264
FIGURE 4-11. FUEL LINES INSTALLATION (SN 1160007024 through 1160007354) 266
FIGURE 4-12. FUEL LINES INSTALLATION (SN 1160007354 through 1160008790) 268
FIGURE 4-13. FUEL TANK INSTALLATION 270
FIGURE 4-14. FUEL TANK 272
FIGURE 4-15. COOLING SYSTEM INSTALLATION - 74KW 274
FIGURE 4-16. COOLING SYSTEM INSTALLATION - 55KW (SN E160000001 through E160000342, Excluding E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 276
FIGURE 4-17. COOLING SYSTEM INSTALLATION - 55KW (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 278
FIGURE 4-18. EXPANSION TANK 280
FIGURE 4-19. RADIATOR ASSEMBLY - 74KW 282
FIGURE 4-20. RADIATOR ASSEMBLY - 55KW 284
FIGURE 4-21. RADIATOR LINES INSTALLATION 286
FIGURE 4-22. RADIATOR LINES INSTALLATION - ARCTIC 288
FIGURE 4-23. TRANSMISSION COOLING INSTALLATION 290
FIGURE 4-24. THERMAL BYPASS INSTALLATION - ARCTIC 292
FIGURE 4-25. HEATER LINES INSTALLATION 294
FIGURE 4-26. HEATER BLOCK INSTALLATION - ARCTIC 296
FIGURE 4-27. ENGINE COOLANT HOSE INSTALLATION 298
FIGURE 4-28. AIR SYSTEM INSTALLATION - 74KW 300
FIGURE 4-29. AIR SYSTEM INSTALLATION - 55KW (SN E160000001 through E160000342, Excluding E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 302
FIGURE 4-30. AIR SYSTEM INSTALLATION - 55KW (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 304
FIGURE 4-31. AIR FILTER ASSEMBLY 306
FIGURE 4-32. AIR INTAKE FILTER 308
FIGURE 4-33. EXHAUST SYSTEM INSTALLATION (ULS) - 74KW 310
FIGURE 4-34. EXHAUST SYSTEM INSTALLATION (ULS) - 55KW (SN E160000001 through E160000342, Excluding E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 312
FIGURE 4-35. EXHAUST SYSTEM INSTALLATION (ULS) - 55KW (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 314
FIGURE 4-36. EXHAUST SYSTEM INSTALLATION (LS) 316
FIGURE 4-37. ENGINE OIL DRAIN INSTALLATION 318
FIGURE 4-38. ENGINE INSTALLATION (SN 1160008519 through 1160008790) 320
FIGURE 4-39. ENGINE, DEUTZ 55 KW 322

SECTION 5 - DRIVETRAIN 325

FIGURE 5-1. AXLE INSTALLATION - 3614RS (74KW) 326
FIGURE 5-2. AXLE INSTALLATION, (NO FOAM FILL) - 4017RS (74KW) 328
FIGURE 5-3. AXLE INSTALLATION (FOAM FILL) - 4017RS (74KW) 330
FIGURE 5-4. AXLE INSTALLATION - 3614RS (55KW) (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 332
FIGURE 5-5. AXLE INSTALLATION - 4017RS (55KW) (SN E160000342 through E160000496, Including E160000328, E160000329, E160000330, E160000331, E160000332 and E160000336) 334
FIGURE 5-6. DRIVE SHAFT INSTALLATION - 3614RS 336
FIGURE 5-7. DRIVE SHAFT INSTALLATION - 4017RS 338
FIGURE 5-8. FRONT AXLE - 3614RS 340
FIGURE 5-9. FRONT AXLE, CENTRAL HOUSING - 3614RS 342
FIGURE 5-10. FRONT AXLE, DIFFERENTIAL - 3614RS 344
FIGURE 5-11. FRONT AXLE, HUB REDUCTION - 3614RS 346
FIGURE 5-12. FRONT AXLE, BRAKES - 3614RS 348
FIGURE 5-13. FRONT AXLE, STEERING - 3614RS 350
FIGURE 5-14. FRONT AXLE, TRUNION - 3614RS 352
FIGURE 5-15. FRONT AXLE, TRUNION KIT - 3614RS 354
FIGURE 5-16. DIFFERENTIAL KIT 356
FIGURE 5-17. FRONT AXLE - 4017RS (SN 1160007024 through 1160007543, Excluding 1160007516 and 1160007537) 358
FIGURE 5-18. FRONT AXLE, CENTRAL HOUSING - 4017RS (SN 1160007024 through 1160007543, Excluding 1160007516 and 1160007537) 360
FIGURE 5-19. FRONT AXLE, DIFFERENTIAL - 4017RS (SN 1160007024 through 1160007543, Excluding 1160007516 and 1160007537) 362
FIGURE 5-20. FRONT AXLE, HUB REDUCTION - 4017RS (SN 1160007024 through 1160007543, Excluding 1160007516 and 1160007537) 364
FIGURE 5-21. FRONT AXLE, BRAKES - 4017RS (SN 1160007024 through 1160007543, Excluding 1160007516 and 1160007537) 366

MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31200939 Order the manual at mid-west-tech.com >

FIGURE 2-23. FOURTH BOOM SECTION - 4017RS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001144244	Ref	Fourth Boom Section - 4017RS	N
1	1001095650	AR	Compound, Locking	
2	1001125117	AR	Washer	
3	1001147731	AR	Shim, 1X45X185	
4	1001148147	AR	Shim, 1X67.5X185	
5	0760808	12	Bolt, M8X20	
6	4811902	12	Washer, M8	
8	0771212	4	Bolt, M12X25, Grade 10.9	
9	0711214	4	Bolt, M12X30, Grade 10.9	
10	0771210	8	Bolt, M12X20, Grade 10.9	
11	1001144245	1	Weldment	
12	1001147657	4	Pad, 15X45X181	
13	1001147902	1	Support, Hose	
14	1001148100	2	Pad, 22X45X181	
15	1001148103	2	Pad, 15X67.5X181	
16	1001154174	AR	Shim, 0.5X45X185	
17	1001154176	AR	Shim, 0.5X67.5X185	
18	4031707	8	Screw, M6X16	
19	1001147914	4	Pad, Hose Support	
20	2160016	1	Fitting, Grease	

MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31200939 Order the manual at mid-west-tech.com >

FIGURE 3-35. BUCKET GUARD ACCESSORY (ITALY)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001105476	Ref	Bucket Guard Accessory (Italy)	B
1	1001003064	2	Retainer	
2	3290601	2	Nut, M6X1	
3	1001008605	2	Nut	
4	8303545	2	Nut, M6X1	
5	10701275	4	Washer	
6	1001008666	4	Washer	
7	0760810	2	Nut, M8X20	
8	1001105474	1	Plate, Bucket Guard Right	
9	1001105475	1	Plate, Bucket Guard Left	

MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31200939 Order the manual at mid-west-tech.com >

FIGURE 8-26. 17M PUMP LINES AUXILIARY INSTALLATION (HIGH VIS CAB)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001199256	Ref	17M Pump Lines Aux Installation (High Vis Cab)	A
1	0701012	3	Bolt, M10X25	
2	0760808	3	Bolt, M8X16	
3	0760810	2	Bolt, M8X20	
4	0761010	2	Bolt, M10X20	
5	2140211	2	Adapter	
6	2140406	1	Fitting	
7	2141907	1	Fitting, Union Tee	
8	2142117	1	Fitting, Swivel Branch Tee	
9	2142207	1	Fitting, Swivel Run Tee	
10	2142706	1	Connector	
11	2142711	1	Connector	
12	2142718	1	Connector	
13	2142733	8	Connector	
14	2142735	1	Connector	
15	2142748	1	Connector	
16	2142808	3	Adapter	
17	4811900	5	Washer, M8	
18	4812000	5	Washer, M10	
19	1001008667	2	Clip	
20	1001095650	AR	Compound, Locking	
21	1001148382	2	Clamp, Tube	
22	1001148552	1	Hose	
23	1001148553	1	Hose	
24	1001148658	1	Hose	
25	1001148659	1	Hose	
26	1001154645	1	Hose	
27	1001154646	1	Hose	
28	1001154647	1	Hose	
29	1001162929	1	Adapter	
30	1001165561	1	Hose	
31	1001173147	1	Main Control Valve (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
32	1001173742	1	Valve, Bypass	
33	1001175757	1	Filter, Hydraulic Oil (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
34	1001188875	1	Plate	
35	1001199166	1	Pipe, Oil Cooling	
36	1001199402	1	Hose	
37	1001202335	1	Tube	

MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31200939 Order the manual at mid-west-tech.com >