Service and Maintenance Manual

Model
60HT
60HTH

3120257
August 01, 1989

ANSI

MidWestTech | JLG 60HT, 60HTH Boom Lift Service Manual | Publication 3120257
Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT - SECTION, PARAGRAPH	PAGE NO.
LIST OF ILLUSTRATIONS AND TABLES	ii
SECTION 1 — SPECIFICATIONS	
1-1. Capacities	1-1
1-2. Component Data	1-1
1-3. Performance Data	1-3
1-4. Torque Requirements	1-3
1-5. Lubrication	1-4
1-6. Pressure Settings	1-5
1-7. Cylinder Specifications	1-6
1-8. Boom Tape	1-6
1-9. Major Component Weights	1-7
SECTION 2 — PROCEDURES	
2-1. General	2-1
2-2. Servicing and Maintenance	2-1
2-3. Lubrication Information	2-2
2-4. Cylinders - Theory of Operation	2-3
2-5. Valves - Theory of Operation	2-4
2-6. Boom Chains	2-4
2-7. Wear Pads	2-6
2-8. Drift Test	2-7
2-9. Cylinder Repair	2-8
2-10. Telescope Cylinder Removal and Installation	2-10
2-11. Tilt Alarm Switch Leveling	2-11
2-12. Slave Cylinder Pin	2-12
2-13. Telescope Cylinder Eccentric Bushing	2-1[illegible]
2-14. Governor Checks and Adjustments, Solenoid, LSG 423	2-14
2-15. Governor Checks and Adjustments, Adeco, LSG 423	2-15
2-16. Throttle Checks and Adjustments, Precision Governor, LSG 423	2-17
2-17. Throttle Adjustments, F3L912W	2-20
2-18. Throttle Checks and Adjustments, V465D	2-24
2-19. Pressure Setting Procedures	2-24
2-20. Racine Proportional Air Gap Adjustment	2-32
2-21. Swing Bearing	2-33
2-22. Torque Hub	2-39
2-23. Controllers	2-40
2-24. Oscillating Axle Bleeding Procedure	2-40
2-25. Oscillating Axle Lockout Test	2-41
2-26. Swing Brake, Mico	2-41
2-27. Drive Brake, Mico	2-43
2-28. Swing Brake, Ausco	2-45
2-29. Drive Brake, Ausco	2-47
2-30. Basket Rotator Brake	2-49
2-31. Dual Fuel System	2-49
2-32. Preventive Maintenance and Inspection Schedule	2-50
SECTION 3 — TROUBLESHOOTING	
3-1. General	3-1
3-2. Troubleshooting Information	3-1
3-3. Hydraulic Circuit Checks	3-1

MidWestTech | JLG 60HT, 60HTH Boom Lift Service Manual | Publication 3120257 Order the manual at mid-west-tech.com >

LIST OF ILLUSTRATIONS AND TABLES

FIGURE NO.	TITLE	PAGE NO.
1-1	Torque Chart	1-8
1-2	Lube Chart	1-10
2-1	Typical Boom Assembly	2-5
2-2	Slave Cylinder Pin	2-12
2-3	Telescope Cylinder Eccentric Bushing	2-13
2-4	Governor Adjustment, Solenoid, LSG 423	2-14
2-5	Governor Adjustment, Adeco, LSG 423	2-15
2-6	Adeco Adjustment, LSG 423	2-16
2-7	Precision Governor Adjustment, LSG 423	2-18
2-8	Adeco Actuator Adjustments, F3L-912	2-21
2-9	Throttle Adjustments, V465D	2-23
2-10	Adeco Actuator Adjustments, V465D	2-23
2-11	Racine Proportional Valve Pressure Setting	2-24
2-12	Vickers Proportional Valve Pressure Setting, Without Accessory Valve	2-26
2-13	Solenoid Valve Pressure Settings, Without Steering Wheel	2-30
2-14	Pressure and Flow Settings With Steering Wheel	2-31
2-15	Racine Proportional Air Gap	2-32
2-16	Swing Bearing Tolerance Boom Placement	2-33
2-17	Swing Bearing Tolerance Measuring Point	2-34
2-18	Swing Bearing Torquing Sequence	2-36
2-19	Drive Hub Carrier Timing	2-37
2-20	Torque Hub	2-38
2-21	Swing Brake Assembly, Mico	2-42
2-22	Drive Brake Assembly, Mico	2-44
2-23	Swing Brake Assembly, Ausco	2-46
2-24	Drive Brake Assembly, Ausco	2-48

TABLE NO.	TITLE	PAGE NO.
1-1	Hydraulic Oil	1-4
1-2	Lubrication Specification	1-5
3-1	Platform Assembly Troubleshooting	3-2
3-2	Boom Assembly Troubleshooting	3-3
3-3	Turntable Assembly Troubleshooting	3-9
3-4	Chassis Assembly Troubleshooting	3-12
3-5	Hydraulic Systems Troubleshooting	3-18
3-6	Electrical Systems Troubleshooting	3-20

MidWestTech | JLG 60HT, 60HTH Boom Lift Service Manual | Publication 3120257 Order the manual at mid-west-tech.com >