Illustrated Parts Manual

Models
60HT
60HTH

3120258
November 1 1987

ANSI

MidWestTech | JLG 60HT, 60HTH Boom Lift Parts Manual | Publication 3120258
Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT	PAGE NO.
SECTION 1 — RECOMMENDED SERVICE PARTS STOCK	1-1
SECTION 2 — ILLUSTRATED PARTS LIST	2-1

FIG. NO.	TITLE	PAGE NO.
2-1	Boom and Limit Switches Installations	2-2
2-2	Boom Assembly	2-6
2-3	Telescope Cylinder Assembly	2-13
2-4	Slave Cylinder Assembly	2-14
2-5	Slave Cylinder Assembly	2-15
2-6	Master Cylinder Assembly	2-16
2-7	Lift Cylinder Assembly	2-17
2-8	Boom Wipers Installation	2-18
2-9	Boom Prop Installation	2-22
2-10	Steering Tube Support Installation	2-23
2-11	Platforms and Control Stands Assemblies and Installations	2-24
2-12	Hydraulic Motor Assembly	2-29
2-13	Platform Control Box Assembly (Vickers Valves and OEM Controllers)	2-30
2-14	Platform Control Box Assembly (Vickers Valves, PQ Controllers and Proportional Telescope)	2-34
2-15	Platform Control Box Assembly (PQ Controllers and Non-Proportional Telescope)	2-38
2-16	Platform Control Box Assembly (Racine Valves)	2-42
2-17	Ground Controls Assembly and Installation	2-46
2-18	Ground Controls Assembly and Installation	2-50
2-19	Control Valves Installations - Racine	2-54
2-20	Proportional Control Valve Assembly (Racine)	2-60
2-21	Working Sections - Proportional Control Valve (Racine)	2-62
2-22	Inlet Section - Proportional Control Valve (Racine)	2-64
2-23	Servo Section - Proportional Control Valve (Racine)	2-68
2-24	Control Valves Installations - Vickers	2-72
2-25	Control Valve Assembly - Vickers	2-78
2-26	Control Valve - Racine Bang-Bang	2-82
2-27	Engine and Components Assembly and Installation - Ford LSG-423 Gas	2-86
2-28	Dual Fuel Installation - Ford	2-94
2-29	Precision Governor Installation - Ford	2-96
2-30	Adeco Throttle Installation - Ford	2-98
2-31	AC Generator Installation - Ford	2-100
2-32	Remote Oil Filter and Drain - Ford	2-103
2-33	Engine and Components Assembly and Installation - Deutz F3L912 Diesel	2-104
2-34	Fuel Shut Off and High Engine Installations - Deutz	2-110
2-35	Adeco Throttle Components Installation - Deutz	2-112
2-36	AC Generator Installation - Deutz	2-116
2-37	Engine and Components Assembly and Installation - Wisconsin V465D Gas	2-118
2-38	Oxy Catalyst Purifier Installation	2-123
2-39	Main Pump Assembly - Gear (Without Ported End)	2-124
2-40	Main Pump Assembly - Gear (With Ported End)	2-126
2-41	Main Pump Assembly - Piston	2-128
2-42	Gear Pump Assembly	2-131
2-43	Tank Installation (Racine)	2-133
2-44	Tank Installation (Vickers)	2-136
2-45	LP Gas Tanks Installation	2-140
2-46	Hood Installation and Accessories (Standard)	2-142
2-47	Hood Installation and Accessories (7' x 7' Vickers and 60HTH)	2-146
2-48	Tilt Indicator Installation	2-151
2-49	Oil Cooler Installation	2-152
2-50	Turntables and Swing Components Assemblies and Installations	2-154
2-51	Swing Drive Motor Assembly	2-157

MidWestTech | JLG 60HT, 60HTH Boom Lift Parts Manual | Publication 3120258 Order the manual at mid-west-tech.com >

FIG. NO.	TITLE	PAGE NO.
2-52	Swing Drive Brake Assembly (Ausco)	2-156
2-53	Swing Drive Brake Assembly (Mico)	2-159
2-54	Swing Drive Hub Assembly	2-162
2-55	Frame, Steering and Drive Components, Assemblies and Installations - Fixed Axle (Standard and 7' x 7')	2-164
2-56	Frame, Steering and Drive Components, Assemblies and Installations - Fixed Axle (Vickers and 60HTH)	2-168
2-57	Frame, Steeering and Drive Components, Assemblies and Installations - Oscillating Axle (60HTH)	2-172
2-58	Frame, Steering and Drive Components, Assemblies and Installations - 4WD	2-176
2-59	Drive Motor (Standard and 7' x 7' Fixed Axle)	2-180
2-60	Drive Motor (Vickers Fixed, 60HTH Fixed and Oscillating and 4WD Rear)	2-182
2-61	Drive Motor (4WD Front)	2-185
2-62	Drive Brake - Ausco (Fixed and Oscillating Axles Except Vickers and 4WD)	2-186
2-63	Drive Brake - Mico (Fixed and Oscillating Axle Except Vickers and 4WD)	2-187
2-64	Drive Brake (Vickers and 4WD)	2-190
2-65	Drive Reducer (Vickers Fixed and 60HTH Fixed and Oscillating)	2-192
2-66	Drive Torque Hub	2-194
2-67	Steer Cylinder Assemblies	2-198
2-68	Lockout Cylinder Assemblies	2-200
2-69	Valves Installation (Frame Mounted)	2-202
2-70	Lockout Valve Assembly	2-204
2-71	Tow Package Installation	2-206
2-72	Nameplates and Decals Installations	2-208
2-73	Axle Lockout Circuit, Hydraulic	2-211
2-74	Drive Circuit, Hydraulic (Standard and 7' x 7')	2-212
2-75	Drive Circuit, Hydraulic (Vickers and 60HTH)	2-214
2-76	Drive Circuit, Hydraulic (4WD)	2-216
2-77	Level Circuit, Hydraulic	2-219
2-78	Lift Circuit, Hydraulic (Standard and 7' x 7')	2-220
2-79	Lift Circuit, Hydraulic (Vickers and 60HTH)	2-221
2-80	Manual Descent Circuit, Hydraulic	2-223
2-81	Pump Circuit, Hydraulic (Standard and 7' x 7' With Gear Pump and Without Steering Wheel)	2-224
2-82	Pump Circuit, Hydraulic (Standard and 7' x 7' With Gear Pump and With Steering Wheel	2-228
2-83	Pump Circuit, Hydraulic (Standard and 7' x 7' With Piston Pump)	2-232
2-84	Pump Circuit, Hydraulic (Vickers and 60HTH Without Steering Wheel	2-236
2-85	Pump Circuit, Hydraulic (Vickers and 60HTH With Steering Wheel)	2-240
2-86	Rotate Circuit, Hydraulic	2-244
2-87	Steer Circuit, Hyd aulic (Without Steering Wheel)	2-245
2-88	Steer Circuit, Hydraulic (With Steering Wheel)	2-246
2-89	Swing Circuit, Hydraulic (Gear Pump)	2-247
2-90	Swing Circuit, Hydraulic (Piston Pump)	2-248
2-91	Telescope Circuit, Hydraulic (Standard/7' x 7' With Gear Pump and Vickers/ 60HTH With Prop Tele)	2-249
2-92	Telescope Circuit, Hydraulic (Standard/7' x 7' Piston Pump)	2-250
2-93	Telescope Circuit, Hydraulic (Vickers/60HTH Without Prop Tele)	2-251
2-94	Towing Circuit, Hydraulic	2-252

MidWestTech | JLG 60HT, 60HTH Boom Lift Parts Manual | Publication 3120258 Order the manual at mid-west-tech.com >