OPERATORS & SAFETY
SERVICE & MAINTENANCE
ILLUSTRATED PARTS

Models
CM2033
CM2046
CM2546
CM2558

3120573
October 01, 1995

AUSTRALIAN OFFICE

JLG INDUSTRIES, INC.
P.O. Box 5119
11 Bolwarra Road
Port Macquarie, Australia
Telephone: 065 811111
Fax: 065 810122

EUROPEAN OFFICE

JLG INDUSTRIES (EUROPE)
Kilmartin Place,
Tannochside Park
Uddingston, Scotland, G71 5PH
Telephone: 01698 811005
Main Fax: 01698 811055
Parts Fax: 01698 811455

CORPORATE OFFICE

JLG INDUSTRIES, INC.
1 JLG Drive
McConnellsburg, PA.
17233-9533
USA
Telephone: (717) 485-5161
Fax: (717) 485-6417

MidWestTech | JLG CM2033, CM2046, CM2546, CM2558 Scissor Lift Operation, Parts, Service Manual | Publication 3120573
Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT - SECTION, PARAGRAPH		PAGE NO.
INTRODUCTION - OPERATION SAFETY PRECAUTIONS		a
INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		b
TABLE OF CONTENTS		i
LIST OF ILLUSTRATIONS		iii
LIST OF TABLES		iv
SECTION 1 — SAFETY PRECAUTIONS		
1-1.	General	1-1
1-2.	Driving/Towing/Carrying	1-1
1-3.	Electrocution Hazard	1-2
1-4.	Pre-Operational	1-3
1-5.	Driving	1-4
1-6.	Operation	1-5
1-7.	Towing and Hauling	1-9
1-8.	Maintenance	1-10
SECTION 2 — PREPARATION AND INSPECTION		
2-1.	General	2-1
2-2.	Preparation For Use	2-1
2-3.	Delivery and Periodic Inspection	2-1
2-4.	Daily Walk-Around Inspection	2-2
2-5.	Daily Functional Check	2-2
2-6.	Torque Requirements	2-3
2-7.	Battery Charging	2-3
SECTION 3 — USER RESPONSIBILITIES AND MACHINE CONTROL		
3-1.	General	3-1
3-2.	Personnel Training	3-1
3-3.	Operating Characteristics and Limitations	3-1
3-4.	Controls and Indicators	3-2
SECTION 4 — MACHINE OPERATION		
4-1.	Description	4-1
4-2.	General	4-1
4-3.	Motor Operation	4-1
4-4.	Raising and Lowering (Lifting)	4-2
4-5.	Platform Extension (If Equipped)	4-2
4-6.	Steering	4-2
4-7.	Traveling (Driving)	4-3
4-8.	Parking and Stowing	4-4
4-9.	Platform Loading	4-4
4-10.	Safety Prop	4-4
4-11.	Tie Down and Lifting	4-4
4-12.	Towing	4-4
SECTION 5 — OPTIONAL EQUIPMENT		
5-1.	PQ Controller	5-1
5-2.	Horn	5-1
5-3.	Travel Alarm	5-1
5-4.	Motion Alarm	5-1
5-5.	Descent Alarm	5-1
5-6.	Tilt Alarm	5-1

MidWestTech | JLG CM2033, CM2046, CM2546, CM2558 Scissor Lift Operation, Parts... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT-SECTION, PARAGRAPH		PAGE NO.
SECTION 5 — OPTIONAL EQUIPMENT (cont.)		
5-7.	110 Volt Generator	5-1
5-8.	110 Volt Receptacle	5-1
5-9.	Platform Work Lights	5-1
5-10.	Foam Filled Tires (CM2046 and CM2558 Only)	5-1
5-11.	Non-Marking Tires	5-1
5-12.	Rotating Beacon	5-1
5-13.	High Output Batteries (CM2046, CM2546 and CM2558 Only)	5-1
5-14.	Battery Condition Indicator	5-1
5-15.	Fold-Down Hand Rails	5-1
5-16.	Control Box Cover (Standard Controls Only)	5-1
5-17.	Lifting Lugs	5-1
5-18.	Powered Deck Extension	5-1
SECTION 6 — EMERGENCY PROCEDURES		
6-1.	General	6-1
6-2.	Emergency Towing Procedures	6-1
6-3.	Emergency Controls and Their Locations	6-1
6-4.	Emergency Operation	6-1
6-5.	Incident Notifications	6-2
SECTION 7 — SPECIFICATIONS		
7-1.	Capacities	7-1
7-2.	Component Data	7-1
7-3.	Performance Data	7-1
7-4.	Torque Requirements	7-2
7-5.	Lubrication	7-2
7-6.	Cylinder Specifications	7-2
7-7.	Pressure Settings	7-5
7-8.	Serial Number Locations	7-5
7-9.	Limit Switches	7-5
7-10.	Major Component Weights	7-5
7-11.	Critical Stability Weights	7-5
SECTION 8 — PROCEDURES		
8-1.	General	8-1
8-2.	Servicing and Maintenance Guidelines	8-1
8-3.	Lubrication Information	8-2
8-4.	Cylinders - Theory of Operation	8-3
8-5.	Valves - Theory of Operation	8-3
8-6.	Component Functional Description	8-4
8-7.	Wear Pads	8-4
8-8.	Cylinder Checking Procedures	8-5
8-9.	Cylinder Removal and Installation	8-5
8-10.	Cylinder Repair (Except Brake Cylinder)	8-6
8-11.	Brake Cylinder Repair	8-9
8-12.	Tilt Alarm Switch (If Equipped)	8-11
8-13.	Limit Switch Adjustment	8-12
8-14.	Pressure Setting Procedures	8-12
8-15.	Preventive Maintenance and Inspection Schedule	8-16
SECTION 9 — TROUBLESHOOTING		
9-1.	General	9-1
9-2.	Troubleshooting Information	9-1
9-3.	Hydraulic Circuit Checks	9-1

MidWestTech | JLG CM2033, CM2046, CM2546, CM2558 Scissor Lift Operation, Parts... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT-SECTION, PARAGRAPH		PAGE NO.
SECTION 10 — RECOMMENDED SPARE PARTS LIST		
	Recommended Spare Parts List	10-1
SECTION 11 — ILLUSTRATED PARTS LIST		
	Table of Contents	11-0-1
11-7-1	Electrical Diagrams and Components Chart	11-7-2

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE NO.
2-1	Daily Walk-Around Inspection	2-4
3-1	Ground Control Station - CM2033/CM2046/CM2546/CM2558	3-4
3-2	Platform Control Station w/o PQ Controller - CM2033/CM2046/CM2546/CM2558 (Machines Built Before August 1992)	3-5
3-3	Platform Control Station w/PQ Controller - CM2033/CM2046/CM2546/CM2558 (Machines Built Before August 1992)	3-5
3-4	Platform Control Station w/o PQ Controller - CM2033/CM2046/CM2546/CM2558 (Machines Built After August 1992)	3-6
3-5	Platform Control Station w/PQ Controller - CM2033/CM2046/CM2546/CM2558 (Machines Built After August 1992)	3-6
4-1	Grade and Sideslope	4-3
7-1	Torque Chart	7-3
7-2	Lubrication Chart	7-4
7-3	Serial Number Locations	7-6
8-1	Poly-Pak Seal Installation	8-7
8-2	Brake Cylinder Assembly	8-10
8-3	Tilt Alarm Switch Leveling - Voltmeter Adjustment	8-12
8-4	Pressure Adjustment Locations - Proportional Valve	8-13
8-5	Pressure Adjustment Locations - Bang-Bang Valve	8-14
11-1-1	Frame, Steering and Drive Installation	11-1-2
11-1-2	Drive Motor Assemblies	11-1-8
11-1-3	Rear Axle and Brake Installations (Prior to March 1992)	11-1-10
11-1-4	Rear Axle and Brake Installations (March 1992 to Present)	11-1-14
11-1-5	Frame Mounted Components Installation	11-1-16
11-2-1	Covers, Controls, Tank and Valves Installation	11-2-2
11-2-2	Control Valve Assembly - Hydro-Air (Machines with Bang-Bang Drive Built Prior to June 1992)	11-2-8
11-2-3	Control Valve Assembly - Hydro-Air (Machines with Bang-Bang Drive Built June 1992 to Present)	11-2-12
11-2-4	Control Valve Assembly - Hydro-Air (Machines with Proportional Drive)	11-2-16
11-2-5	Control Valve Assembly (Hydraulically Extended Deck Option)	11-2-20
11-2-6	Batteries and Chargers Installation	11-2-22
11-2-7	Battery Charger Assembly	11-2-26
11-2-8	UL Listed Components Installation - Ground Components	11-2-28
11-3-1	Sizzor Arms Installation - CM2033 and CM2046	11-3-2
11-3-2	Sizzor Arms Installation - CM2546 and CM2558	11-3-4
11-4-1	Standard Handrails and and Accessories Installation	11-4-2
11-4-2	Optional Fold-Down Handrail Installation	11-4-8
11-4-3	Optional Extendable Deck Installation with Standard Handrails	11-4-12
11-4-4	Optional Extendable Deck Installation with Fold-Down Handrails	11-4-14
11-4-5	Optional Hydraulically Extended Deck Installation with standard Handrails	11-4-16
11-4-5A	Optional Hydraulically Extended Deck Installation with Fold-Down Handrails	11-4-18
11-4-6	Steel Platform Console Box Assembly	11-4-20
11-4-7	Molded Platform Console Box Assembly	11-4-24
11-5-1	Brake Cylinder Assembly (Prior to March 1992)	11-5-2

MidWestTech | JLG CM2033, CM2046, CM2546, CM2558 Scissor Lift Operation, Parts... Order the manual at mid-west-tech.com >