OPERATORS & SAFETY
SERVICE & MAINTENANCE
ILLUSTRATED PARTS

Models

CM1432
CM1432 PLUS
CM1732

3120579
October 2, 1995

AUSTRALIAN OFFICE

JLG INDUSTRIES, INC.
P.O. Box 5119
11 Bolwarra Road
Port Macquarie, Australia
Telephone: 065 811111
Fax: 065 810122

EUROPEAN OFFICE

JLG INDUSTRIES (EUROPE)
Kilmarting Place,
Tannochside Park
Uddingston, Scotland, G71 5PH
Telephone: 01698 811005
Main Fax: 01698 811055
Parts Fax: 01698 811455

WORLD HEADQUARTERS

JLG INDUSTRIES, INC.
1 JLG Drive
McConnellsburg, PA.
17233-9533
USA
Telephone: (717) 485-5161
Fax: (717) 485-6417

MidWestTech | JLG CM1432, CM1432PLUS, CM1732 Scissor Lift Operation, Parts, Service Manual | Publication 3120579

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT - SECTION, PARAGRAPH	PAGE NO.
INTRODUCTION - OPERATION SAFETY PRECAUTIONS	a
INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS	b
TABLE OF CONTENTS	i
LIST OF ILLUSTRATIONS	iii
LIST OF TABLES	iv
SECTION 1 — SAFETY PRECAUTIONS	
1-1. General	1-1
1-2. Driving/Towing/Carrying	1-1
1-3. Electrocution Hazard	1-2
1-4. Pre-Operational	1-3
1-5. Driving	1-4
1-6. Operation	1-5
1-7. Towing and Hauling	1-9
1-8. Maintenace	1-10
SECTION 2 — PREPARATION AND INSPECTION	
2-1. General	2-1
2-2. Preparation For Use	2-1
2-3. Delivery and Periodic Inspection	2-1
2-4. Daily Walk-Around Inspection	2-2
2-5. Daily Functional Check	2-2
2-6. Torque Requirements	2-3
2-7. Battery Charging	2-3
SECTION 3 — USER RESPONSIBILITIES AND MACHINE CONTROL	
3-1. General	3-1
3-2. Personnel Training	3-1
3-3. Operating Characteristics and Limitations	3-1
3-4. Controls and Indicators	3-2
SECTION 4 — MACHINE OPERATION	
4-1. Description	4-1
4-2. General	4-1
4-3. Motor Operation	4-1
4-4. Raising and Lowering (Lifting)	4-2
4-5. Platform Extension	4-2
4-6. Steering	4-3
4-7. Traveling (Driving)	4-3
4-8. Parking and Stowing	4-4
4-9. Platform Loading	4-4
4-10. Safety Prop	4-4
4-11. Tie Down and Lifting	4-5
4-12. Towing	4-5
SECTION 5 — OPTIONAL EQUIPMENT	
5-1. PQ Controller	5-1
5-2. Horn	5-1
5-3. Tilt Alarm	5-1
5-4. Travel Alarm	5-1
5-5. Motion Alarm	5-1

MidWestTech | JLG CM1432, CM1432PLUS, CM1732 Scissor Lift Operation, Parts, Service... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (cont.)

SUBJECT-SECTION, PARAGRAPH **PAGE NO.**

SECTION 5 — OPTIONAL EQUIPMENT (cont.)

5-6. Descent Alarm 5-1
5-7. 110 Volt Platform Receptacle 5-1
5-8. Platform Work Lights 5-1
5-9. Non-Marking Tires 5-1
5-10. Rotating Beacon 5-1
5-11. Battery Condition Indicator 5-1
5-12. Fold-Down Hand Rails 5-1
5-13. Control Box Cover (Standard Toggle Switch Controls Only) 5-1
5-14. Platform Access Door 5-1
5-15. Lifting Lugs 5-1

SECTION 6 — EMERGENCY PROCEDURES

6-1. General 6-1
6-2. Emergency Towing Procedures 6-1
6-3. Emergency Controls and Their Locations 6-1
6-4. Emergency Operation 6-1
6-5. Incident Notification 6-2

SECTION 7 — SPECIFICATIONS

7-1. Capacities 7-1
7-2. Component Data 7-1
7-3. Performance Data 7-1
7-4. Torque Requirements 7-1
7-5. Lubrication 7-2
7-6. Cylinder Specifications 7-2
7-7. Pressure Settings 7-2
7-8. Serial Number Locations 7-5
7-9. Limit Switches 7-5
7-10. Major Component Weights 7-5
7-11. Critical Stability Weights 7-6

SECTION 8 — PROCEDURES

8-1. General 8-1
8-2. Servicing and Maintenance Guidelines 8-1
8-3. Lubrication Information 8-2
8-4. Cylinders - Theory of Operation 8-3
8-5. Valves - Theory of Operation 8-3
8-6. Component Functional Description 8-4
8-7. Wear Pads 8-4
8-8. Cylinder Checking Procedures 8-5
8-9. Cylinder Removal and Installation 8-5
8-10. Cylinder Repair (Except Brake Cylinder) 8-6
8-11. Brake Cylinder Repair 8-8
8-12. Tilt Alarm Switch (If Equipped) 8-11
8-13. Limit Switch Adjustment 8-11
8-14. Pressure Setting Procedures 8-12
8-15. Preventive Maintenance and Inspection Schedule 8-14

SECTION 9 — TROUBLESHOOTING

9-1. General 9-1
9-2. Troubleshooting Information 9-1
9-3. Hydraulic Circuit Checks 9-1

MidWestTech | JLG CM1432, CM1432PLUS, CM1732 Scissor Lift Operation, Parts, Service... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (cont.)

SUBJECT-SECTION, PARAGRAPH	PAGE NO.
SECTION 10 — RECOMMENDED SPARE PARTS LIST	
Recommended Spare Parts List	10-1
SECTION 11 — ILLUSTRATED PARTS LIST	
Table of Contents	11-0-1

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE NO.
2-1	Daily Walk-Around Inspection - All Models	2-4
3-1	Ground Control Station - All Models	3-4
3-2	Platform Control Station w/o PQ Controller - All Models (Machines Built Before August 1992)	3-5
3-3	Platform Control Station w/PQ Controller - All Models (Machines Built Before August 1992)	3-5
3-4	Platform Control Station w/o PQ Controller - All Models (Machines Built After August 1992)	3-6
3-5	Platform Control Station w/PQ Controller - All Models (Machines Built After August 1992)	3-6
4-1	Grade and Sideslope	4-3
7-1	Torque Chart	7-3
7-2	Lubrication Chart - All Models	7-4
7-3	Serial Number Locations - All Models	7-5
8-1	Poly-Pak Seal Installation	8-7
8-2	Brake Cylinder Assembly	8-9
8-3	Tilt Alarm Switch Leveling - Voltmeter Adjustment	8-12
8-4	Pressure Adjustment Locations	8-13
11-1-1	Frame, Steering and Drive Installation	11-1-2
11-1-2	Drive Motor Assemblies	11-1-4
11-1-3	Rear Axle and Brake Installations	11-1-6
11-1-4	Frame Mounted Components Installation	11-1-8
11-1-5	Battery Charger Assembly	11-1-12
11-2-1	Electrical Components Installation	11-2-2
11-2-2	Hydraulic Components and Covers Installation	11-2-6
11-2-3	Control Valve Assembly - Hydro-Air	11-2-10
11-2-4	U/L Listed Components Installation - Ground Components	11-2-14
11-3-1	Sizzor Arms Installation - CM1432 and CM1432 Plus	11-3-2
11-3-2	Sizzor Arms Installation - CM1732	11-3-4
11-4-1	Platform and Handrail Installation	11-4-2
11-4-2	Optional Platform Extension Installation with Standard Handrails	11-4-6
11-4-2A	Optional Platform Extension Installation with Fold-Down Handrails	11-4-7C
11-4-3	Steel Platform Console Box Assembly	11-4-8
11-4-4	Molded Platform Console Box Assembly	11-4-12
11-5-1	Brake Cylinder Assembly	11-5-2
11-5-2	Lift Cylinder Sub-Assembly	11-5-4
11-5-3	Steer Cylinder Assembly	11-5-6
11-6-1	Hydraulic Diagram - Standard	11-6-2
11-7-2	Electrical Diagram - Toggle Switch Drive	11-7-6
11-7-3	Electrical Diagram - PQ Controller Bang-Bang Drive	11-7-9
11-7-4	Electrical Diagram - Circuit Cards	11-7-10
11-7-5	Main Electrical Connector and Tools	11-7-12
11-8-1	Decals Installation - CM1432 and CM1432 Plus	11-8-2
11-8-2	Decals Installation - CM1732	11-8-6

MidWestTech | JLG CM1432, CM1432PLUS, CM1732 Scissor Lift Operation, Parts, Service... Order the manual at mid-west-tech.com >