Operators and Safety Manual
Service & Maintenance Manual
Illustrated Parts Manual

Models

AM-19
AM-24
AM-30
AM-36

AC & DC Models

3120596
January 1, 1998

ANSI

ISO9001 REGISTERED COMPANY

MidWestTech | JLG AM19, AM24, AM30, AM36 Vertical Mast Operation, Parts, Service Manual | Publication 3120596
Order the manual at mid-west-tech.com >

SUBJECT - SECTION, PARAGRAPH		PAGE NO.
INTRODUCTION - OPERATION SAFETY PRECAUTIONS		a
INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		b
A.	General	b
B.	Hydraulic System Safety	b
C.	Maintenance	b
EFFECTIVITY CHANGES		c
TABLE OF CONTENTS		i
LIST OF ILLUSTRATIONS		ii
LIST OF TABLES		ii
SECTION 1 — SAFETY PRECAUTIONS		
1-1.	General	1-1
1-2.	Electrocution Hazard	1-1
1-3.	Transporting	1-1
1-4.	Transporting Safety	1-1
1-5.	Pre-Operational Safety	1-2
1-6.	Operation Safety	1-4
SECTION 2 — PREPARATION AND INSPECTION		
2-1.	General	2-1
2-2.	Preparation For Use	2-1
2-3.	Delivery and Periodic Inspection	2-1
2-4.	Daily Walk-Around Inspection	2-2
2-5.	Daily Functional Check	2-4
2-6.	Torque Requirements	2-4
2-7.	Battery Charging (DC Machines)	2-5
SECTION 3 — USER RESPONSIBILITIES AND MACHINE CONTROLS		
3-1.	General	3-1
3-2.	Personnel Training	3-1
3-3.	Operating Characteristics and Limitations	3-2
3-4.	Controls and Indicators	3-2
SECTION 4 — MACHINE OPERATION		
4-1.	Machine Description	4-1
4-2.	General	4-1
4-3.	Machine Set-Up and Operation	4-2
4-4.	Stowing Machine	4-3
4-5.	Transporting and Lifting	4-4
SECTION 5 — OPTIONAL EQUIPMENT		
5-1.	Optional Equipment	5-1
5-2.	AM-SE - Straddle Extension Kit - Set-Up and Operation	5-1
SECTION 6 — EMERGENCY PROCEDURES		
6-1.	General	6-1
6-2.	Emergency Controls and Their Locations	6-1
6-3.	Emergency Operation	6-1
6-4.	Incident Notification	6-2
SECTION 7 — SPECIFICATIONS		
7-1.	Capacities	7-1
7-2.	Component Data	7-1
7-3.	Performance Data	7-1
7-4.	Torque Requirements	7-2
7-5.	Lubrication	7-2
7-6.	Pressure Adjustment	7-2
7-7.	Cylinder Specifications	7-2
7-8.	Serial Number Locations	7-2

MidWestTech | JLG AM19, AM24, AM30, AM36 Vertical Mast Operation, Parts, Service Man... Order the manual at mid-west-tech.com >

SUBJECT-SECTION, PARAGRAPH		PAGE NO.
SECTION 8 — PROCEDURES		
8-1.	General	8-1
8-2.	Servicing and Maintenance Guidelines	8-1
8-3.	Lubrication Information	8-4
8-4.	Mast Assembly and Disassembly Procedure	8-5
8-5.	Mast to Base Frame Installation	8-13
8-6.	Mast Chains and Sequencing Cables Adjustment	8-14
8-7.	Preventive Maintenance and Inspection Schedule	8-14
SECTION 9 — TROUBLESHOOTING		
9-1.	General	9-1
9-2.	Troubleshooting Information	9-1
9-3.	Hydraulic Circuit Checks	9-1
9-4.	Outrigger Interlock Contacts	9-1
SECTION 10 — ILLUSTRATED PARTS MANUAL		
	Illustrated Parts – Table of Contents	10-0-1

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE NO.
1-1.	Pushing Machine on a Smooth, Firm Surface	1-2
1-2.	Pushing Machine on a Slope	1-3
2-1.	Daily Walk-Around Inspection	2-3
2-2.	Battery Box & Charger Assembly (DC models only)	2-5
3-1.	Ground Control Station	3-2
3-2.	Platform Control Station	3-3
4-1.	Outriggers Installed	4-2
4-2.	Pushing Machine on a Smooth, Firm Surface	4-4
4-3.	Pushing Machine on a Slope	4-5
4-4.	Tilt-Back Assembly Set-Up	4-6
4-5.	Loading Machine onto Pickup Truck for Transport	4-8
5-1.	Straddle Adaptor Wiring Harness Installation	5-2
5-2.	Straddle Adaptor - AC Control Box Wiring Connections	5-3
5-3.	Straddle Adaptor - DC Ground Control Station Wiring Connections	5-3
5-4.	Straddle Extension - Component Assembly	5-4
5-5.	Lowering AccessMaster on Straddle Unit - Side Lifting Rail Quick-Release Pins	5-6
7-1.	Torque Chart	7-3
7-2.	Lubrication Chart	7-4
8-1.	AccessMaster Mast Assembly	8-7
8-2.	Mast Chains/Cables Routing Diagram	8-15
9-1.	Base Frame Outrggr. Socket Contactor Heads and Outrggr. Beam Contactor Plate	9-1
9-2.	Hydraulic Diagram (AC & DC Machines)	9-5

LIST OF TABLES

TABLE NO.	TITLE	PAGE NO.
1-1.	**Minimum Safe Approach Distances *(to energized power lines)***	**1-1**
7-1.	**Recommended Hydraulic Oils**	**7-2**
7-2.	**Lubrication Specifications**	**7-2**
8-1.	**Chain Stretch Tolerance**	**8-3**
8-2.	**Preventive Maintenance and Inspection Schedule**	**8-16**
9-1.	**A.C. Units Troubleshooting**	**9-2**
9-2.	**D.C. Units Troubleshooting**	**9-3**

MidWestTech | JLG AM19, AM24, AM30, AM36 Vertical Mast Operation, Parts, Service Man... Order the manual at mid-west-tech.com >