Service and Maintenance Manual

Model
60H
70H

3120630
January 15, 1995

ANSI

MidWestTech | JLG 60H, 70H Boom Lift Service Manual | Publication 3120630
Order the manual at mid-west-tech.com >

SUBJECT - SECTION, PARAGRAPH — PAGE NO.

INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS . . . . . a
LIST OF ILLUSTRATIONS AND TABLES ii

SECTION 1 — SPECIFICATIONS
1-1. Capacities 1-1
1-2. Component Data 1-1
1-3. Performance Data 1-3
1-4. Torque Requirements 1-4
1-5. Lubrication 1-4
1-6. Pressure Setting 1-8
1-7. Cylinder Specifications 1-9
1-8. Boom Tape 1-9
1-9. Major Component Weights 1-10
1-10. Critical Stability Weights 1-10
1-11. Relay/Circuit Breakers 1-10
1-12. Serial Number Location 1-11

SECTION 2 — PROCEDURES
2-1. General 2-1
2-2. Servicing and Maintenance Guidelines 2-1
2-3. Lubrication Information 2-2
2-4. Cylinders - Theory of Operation 2-3
2-5. Valves - Theory of Operation 2-3
2-6. Boom Chains 2-4
2-7. Wear Pads 2-7
2-8. Cylinder Checking Procedure 2-7
2-9. Cylinder Repair 2-9
2-10. Cylinder Removal and Installation 2-13
2-11. Telescope Cylinder Eccentric Bushing 2-14
2-12. Boom Maintenance 2-15
2-13. Tilt Alarm Switch 2-19
2-14. Horizontal Cutoff Switch Adjustment Procedure 2-20
2-15. Governor Checks and Adeco Adjustment 2-20
2-16. Throttle Checks and Precision Governor Adjustments 2-22
2-17. Throttle Checks and Adjustments Deutz Engine 2-23
2-18. Pressure Setting Procedures 2-27
2-19. Racine Proportional Air Gap Adjustment 2-47
2-20. Swing Bearing 2-48
2-21. Torque Hub (Machines Built Prior to Mid 1991) 2-52
2-22. Torque Hub 2WD/4WD 2-56
2-23. Swing Drive Brake, Mico (Machines Built Prior to May 1992) 2-60
2-24. Drive Brake, Mico (Machines Built Prior to May 1992) 2-62
2-25. Swing Drive Brake, Ausco (Machines Built Prior to May 1992) 2-64
2-26. Drive Brake, Ausco (Machines Built Prior to May 1992) 2-66
2-27. Drive Brake, Mico (Machines Built From May 1992 to Present) 2-68
2-28. Swing Drive Brake, Mico (Machines Built From May 1992 to Present) 2-70
2-29. Controllers 2-72
2-30. Oscillating Axle Bleeding Procedure 2-72
2-31. Oscillating Axle Lockout Test 2-73
2-32. Basket Rotator Brake 2-74
2-33. Free Wheeling Option 2-74
2-34. Spark Arrestor Mufflers 2-74
2-35. Footswitch Adjustment 2-74
2-36. Hydraulic Pump W/Hayes Pump Drive Coupling Lubrication 2-74
2-37. Dual Fuel System 2-75
2-38. Preventive Maintenance and Inspection Schedule 2-76

SECTION 3 — TROUBLESHOOTING
3-1. General 3-1
3-2. Troubleshooting Information 3-1
3-3. Hydraulic Circuit Checks 3-1

Order the manual at mid-west-tech.com >

FIGURE NO.	TITLE	PAGE NO.
1-1.	Torque Chart	1-5
1-2.	Lubrication Chart	1-6
1-3.	Relay Wiring	1-11
1-4.	Serial Number Location	1-11
2-1.	Typical Three Section Boom Assembly	2-5
2-2.	Boom Positioning and Support - Cylinder Repair	2-8
2-3.	Poly Pak Seal Installation	2-11
2-4.	Telescope Cylinder Eccentric Bushing	2-14
2-5.	Governor Adjustment, LSG-423 with Adeco	2-21
2-6.	Adeco Adjustment, LSG-423	2-22
2-7.	Precision Governor Adjustment, LSG-423	2-24
2-8.	Adeco Actuator Adjustment, F3L912	2-26
2-9.	Racine Proportional Valve Pressure Setting Procedures (Machines Built Prior to Mid 1987)	2-28
2-10.	Vickers Pressure Setting Procedures (Machines Built Prior to 1989 with Accessory Valve)	2-30
2-11.	Solenoid Valve Pressure Setting Procedures (Machines Built Prior to May 1992 with Steer Wheel)	2-34
2-12.	Pressure and Flow Setting Procedures (Machines Built Prior to May 1992 with Steer Wheel)	2-35
2-13.	Vickers Proportional Pressure Setting Procedures	2-36
2-14.	Vickers All Hydraulic Pressure Setting Procedures	2-40
2-15.	Solenoid Valve Pressure Setting Procedures	2-44
2-16.	Solenoid Valve Pressure Setting Procedures 4 W/S	2-45
2-17.	Pressure and Speed Setting Procedures - Extend-A-Reach (Model 60H+6)	2-46
2-18.	Racine Proportional Air Gap Adjustment (Machines Built Prior to Mid 1987)	2-47
2-19.	Swing Bearing Tolerance Boom Placement	2-48
2-20.	Swing Bearing Tolerance Measuring Point	2-49
2-21.	Swing Bearing Bolt Torquing Sequence	2-51
2-22.	Torque Hub Assembly (Machines Built Prior to Mid 1991)	2-54
2-23.	Torque Hub Assembly 2WD/4WD	2-57
2-24.	Torque Hub Carrier Timing	2-59
2-25.	Swing Brake Assembly - Mico (Machines Built Prior to May 1992)	2-61
2-26.	Drive Brake Assembly - Mico (Machines Built Prior to May 1992)	2-63
2-27.	Swing Brake Assembly -Ausco (Machines Built Prior to May 1992)	2-65
2-28.	Drive Brake Assembly - Ausco (Machines Built Prior to May 1992)	2-67
2-29.	Drive Brake Assembly - Mico (Machines Built From May 1992 to Present)	2-69
2-30.	Swing Brake Assembly - Mico (Machines Built From May 1992 to Present)	2-71
2-31.	Basket Rotator Brake	2-74
3-1.	Wiring Diagram - Dual Fuel (Ford and Wisconsin)	3-18
3-2.	Wiring Diagram - 110V Generator (Ford)	3-19
3-3.	Wiring Diagram - 110V Generator (Deutz)	3-20
3-4.	Wiring Diagram - Platform Console (w/ All Hydraulic Controls)	3-21
3-5.	Wiring Diagram - Platform Console (Standard Controls)	3-22
3-6.	Wiring Diagram - Precision Governor	3-24
3-7.	Wiring Diagram - Ford Engine	3-26
3-8.	Wiring Diagram - Deutz, Wisconsin Engine	3-28
3-9.	Wiring Diagram - Deutz Engine Hyd. Controls	3-30

TABLE NO.	TITLE	PAGE NO.
1-1.	Hydraulic Oil	1-4
1-2.	Lubrication Specifications	1-8
1-3.	Cylinder Specifications	1-9
1-4.	Major Components Weights	1-10
1-5.	Critical Stability Weights	1-10
2-1.	Chain Stretch Tolerances	2-7
2-2.	Cylinder Piston Nut Torque Specifications	2-12
2-3.	Holding Valve Torque Specifications	2-13
2-4.	Preventive Maintenance and Inspection Schedule	2-77
3-1.	Platform Assembly Troubleshooting	3-2
3-2.	Boom Assembly Troubleshooting	3-3
3-3.	Turntable Assembly Troubleshooting	3-7
3-4.	Chassis Assembly Troubleshooting	3-8
3-5.	Hydraulic System Troubleshooting	3-13
3-6.	Electrical System Troubleshooting	3-15

MidWestTech | JLG 60H, 70H Boom Lift Service Manual | Publication 3120630 Order the manual at mid-west-tech.com >