An Oshkosh Corporation Company

Service and Maintenance Manual

Model

100HX
100HX+10
110HX

P/N - 3120636

March 11, 2010

ANSI

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		
A	General	A-1
B	Hydraulic System Safety	A-1
C	Maintenance	A-1
SECTION 1 - SPECIFICATIONS		
1.1	Capacities	1-1
1.2	Component Data	1-1
	Engine - Ford LSG-423 & LRG-423	1-1
	Engine - Ford LRG-425	1-1
	Engine - Deutz F4L912	1-1
	Engine - Cummins 4B3.9C	1-1
	Drive System	1-2
	Steer System	1-2
	Swing System	1-2
	Hydraulic Pump	1-2
	Auxiliary Power Pump	1-2
	Hydraulic Filter - Tank	1-2
	Hydraulic Filter - Inline	1-2
1.3	Performance Data	1-2
	Travel Speed	1-2
	Gradeability	1-2
	Turning Radius	1-2
	Boom Speed	1-2
	Swing Speed	1-2
	Boom Elevation	1-2
	Machine Weight	1-3
	Machine Stowed Height	1-3
	Machine Stowed Length	1-3
	Machine Width	1-3
	Wheelbase	1-3
	Maximum Tire Loads	1-3
1.4	Torque Requirements	1-3
1.5	Lubrication	1-3
	Ford LSG423 & LRG423 & LRG425 Engines	1-3
	Deutz F4L912 Engine	1-4
	Cummins 4B3.9C Engine	1-4
	Lubrication Specifications	1-5
1.6	Pressure Settings	1-8
	Proportional Valve	1-8
	Accessory Valve	1-8
	Solenoid Valve	1-8
	Extend-A-Reach Valve	1-8
1.7	Cylinder Specifications	1-8
1.8	Boom Tape	1-9
	With 4620038 Turntable	1-9
	With 4620044 or 4620078 Turntable	1-9
1.9	Major Component Weights	1-9
1.10	Serial Number Locations	1-9
1.11	Critical Stability Weights	1-10

MidWestTech | JLG 100HX, 100HX+10, 110HX Boom Lift Service Manual | Publication 312... Order the manual at mid-west-tech.com >

SECTION NO. TITLE PAGE NO.

SECTION 2 - PROCEDURES

2.1 General 2-1
2.2 Servicing and Maintenance Guidelines 2-1
General 2-1
Safety and Workmanship 2-1
Cleanliness 2-1
Components Removal and Installation 2-1
Component Disassembly and Reassembly 2-1
Pressure-Fit Parts 2-1
Bearings 2-2
Gaskets 2-2
Bolt Usage and Torque Application 2-2
Hydraulic Lines and Electrical Wiring 2-2
Hydraulic System 2-2
Lubrication 2-2
Battery 2-2
Lubrication and Servicing 2-2
2.3 Lubrication Information 2-2
Hydraulic System 2-2
Hydraulic Oil 2-3
Changing Hydraulic Oil 2-3
Lubrication Specifications 2-3
2.4 Cylinders - Theory of Operation 2-3
2.5 Valves - Theory of Operation 2-3
Solenoid Control Valves (Bang-Bang) 2-3
Manual Hydraulic Control Valves 2-4
Proportional Control Valves - Vickers 2-4
Relief Valves 2-4
Crossover Relief Valves 2-4
2.6 Boom Chains 2-4
Adjusting Procedures 2-4
Inspection Procedure 2-8
2.7 Wear Pads 2-10
2.8 Drift Test 2-10
Telescope Cylinder 2-10
Lift Cylinder 2-11
2.9 Cylinder Checking Procedures 2-11
Cylinder w/o Counterbalance Valves 2-11
Cylinders w/Single Counterbalance Valves 2-12
Cylinders w/Dual Counterbalance Valve 2-13
2.10 Cylinder Removal and Installation 2-13
Telescope Cylinder Removal 2-13
Telescope Cylinder Installation 2-18
Lift Cylinder Removal 2-19
Lift Cylinder Installation 2-19
Master Level Cylinder Removal 2-19
Master Level Cylinder Installation 2-20
2.11 Cylinder Repair 2-20
Disassembly 2-20
Cleaning and Inspection 2-21
Assembly 2-22

MidWestTech | JLG 100HX, 100HX+10, 110HX Boom Lift Service Manual | Publication 312... Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
2.12	Boom Maintenance	2-23
	Removal	2-23
	Disassembly	2-24
	Inspection	2-28
	Assembly	2-28
	Installation	2-30
2.13	Tilt Alarm Switch Leveling	2-30
	Manual Adjustment	2-30
	Voltmeter Adjustment	2-31
2.14	Limit Switch Adjustments	2-32
	Boom Limit Switch	2-32
	Horizontal Cut-Out Switch	2-32
2.15	Throttle Checks and Adjustments - Deutz F4I-912 Engine	2-32
2.16	Throttle Checks and Precision Governor Adjustments - Ford Engine	2-32
	Checks	2-32
	Automatic Choke Adjustments	2-32
	Carburetor and Governor Adjustments	2-36
2.17	Pressure Setting Procedures	2-36
	Sequence Pressure (Prior to 1990)	2-36
	Sequence Pressure (1990 to Present)	2-40
	Pilot Pressure	2-40
	Proportional Valve	2-40
	Solenoid Valve	2-41
	Extend-A-Reach Valve (If Equipped)	2-41
2.18	Swing Bearing	2-42
	Turntable Bearing Mounting Bolt Condition Check	2-42
	Bearing Wear Tolerance	2-42
	Bearing Replacement	2-44
	Swing Bearing Torque Values	2-46
2.19	Drive Torque Hub	2-47
	Disassembly	2-47
	Cleaning and Inspection	2-47
	Assembly	2-49
2.20	Swing Torque hub	2-57
	Disassembly	2-57
	Cleaning and Inspection	2-58
	Assembly	2-60
2.21	Swing Brake - Ausco - Machines Built To 1992	2-61
	Disassembly	2-61
	Cleaning and Inspection	2-61
	Assembly	2-61
2.22	Swing Brake - Mico - Machines Built To 1992	2-63
	Cleaning and Inspection	2-63
	Assembly	2-63
2.23	Swing Brake - Machines Built 1992 To Present	2-65
	Cleaning and Inspection	2-65
	Assembly	2-67
2.24	Drive Brake - Ausco - Machines Built Prior To March 1992	2-67
	Disassembly	2-67
	Inspection	2-67
	Assembly	2-69
2.25	Drive Brake - Mico - Machines Built March 1992 TO S/N 33476	2-69
	Disassembly	2-69
	Cleaning and Inspection	2-69
	Assembly	2-71

MidWestTech | JLG 100HX, 100HX+10, 110HX Boom Lift Service Manual | Publication 312... Order the manual at mid-west-tech.com >

1.8 BOOM TAPE

With 4620038 Turntable

110HX Single Capacity

Blue - Not used

Yellow - Not used

Red - 119.5 in. (303.5 cm)

White - 154.5 in. (392.4 cm)

110HX Dual Capacity

Blue - Not used

Yellow - 82.5 in. (209.6 cm)

Red - 119.5 in. (303.5 cm)

White - 154.5 in. (392.4 cm)

100HX+10

Blue - 50 in. (127 cm)

Yellow - Not used

Red - 84 in. (213.4 cm)

White - 135.5 in. (344.2 cm)

With 4620044 or 4620078 Turntable

100HX Dual Capacity

Blue - Not used

Yellow - 62 in. (157.5 cm)

Red - 90 in. (228.6 cm)

White- 118 in. (299.7 cm)

110HX Single Capacity

Blue - Not used

Yellow - Not used

Red - 122.5 in. (311.2 cm)

White - 157.5 in. (400.1 cm)

110HX Dual Capacity

Blue - Not used

Yellow - 85.5 in. (217.2 cm)

Red - 122.5 in. (311.2 cm)

White - 160.5 in. (400.1 cm)

100HX+10.

Blue - 53 in. (134.6 cm)

Yellow - Not used

Red - 87 in. (221.0 cm)

White - 138.5 in. (351.8 cm)

1.9 MAJOR COMPONENT WEIGHTS

Table 1-10.Major Component Weights

Component	Lbs.	KG.
Platform (36x48) w\o Control Box	150	68
Platform (36x60) w\o Control Box	165	75
Platform (36x72) w\o Control Box	180	82
Platform (36x96) w\o Control Box	220	100
Boom - 100HX (Incl. Lift Cylinder)	9920	4,500
Boom - 110HX (Incl. Lift Cylinder)	10960	4,971
Boom - 100HX+10 (Incl. Lift Cylinder)	10680	4,844
Turntable (w\Ford Engine, Less Cwt.)	10300	4,672
Turntable (w\Deutz Engine, Less Cwt.)	10620	4,817
Turntable (w\Cummins Engine, Less Cwt.)	10455	4,742
Frame Complete (incl. Wheels and Tires)	13620	6,178
Complete Machine - 100HX	37000	16,783
Complete Machine - 110HX	40500	18,371
Complete Machine - 100HX+10	38500	17,464

1.10 SERIAL NUMBER LOCATIONS

For machine identification, a serial number plate is affixed to the left side of the frame, below the battery compartment. If the serial number plate is damaged or missing, the machine serial number is stamped on the left side of the frame between the front and rear wheels, below the turntable bearing and on the right side of the turntable in the bottom of the valve compartment. In addition, the last five digits of the serial number are stamped on top of the fly end of the base boom section.

MidWestTech | JLG 100HX, 100HX+10, 110HX Boom Lift Service Manual | Publication 312... Order the manual at mid-west-tech.com >

SECTION 3. TROUBLESHOOTING

3.1 GENERAL

This section contains troubleshooting information to be used for locating and correcting most of the operating problems which may develop. If a problem should develop which is not presented in this section or which is not corrected by listed corrective actions, technically qualified guidance should be obtained before proceeding with any maintenance.

Troubleshooting and maintenance information pertaining to the engine that are not contained in this manual are contained in the applicable engine maintenance manual.

3.2 TROUBLESHOOTING

The troubleshooting procedures applicable to the aerial platform are listed and defined in Tables 3-1 through 3-6. As an aid to table use, the aerial platform is divided into four major groups, each covered separately within this section. These groups are as follows: elevation system, chassis assembly, hydraulic system and electrical system.

Each malfunction within an individual group or system is followed by a listing of probable causes which will enable determination of the applicable remedial action. The probable causes and the remedial action should, where possible, be checked in the order listed in the tables.

It should be noted that there is no substitute for a thorough knowledge of the equipment and related systems.

It should be recognized that the majority of the problems arising in the machine will be centered in the hydraulic and electrical systems. For this reason, every effort has been made to ensure that all likely problems in these areas are given the fullest possible treatment. In the remaining machine groups, only those problems which are symptomatic of greater problems which have more that one probable cause and remedy are included. This means that problems for which the probable cause and remedy may be immediately obvious are not listed in this section.

The first rule for troubleshooting any circuit that is hydraulically operated and electrically controlled is to determine if the circuit is lacking hydraulic oil and electrical control power. This can be ascertained by overriding the bypass valve (mechanically or electrically) so that oil is available to the function valve, then overriding the function valve mechanically. If the function performs satisfactorily, the problem exists with the control circuit.

3.3 HYDRAULIC CIRCUIT CHECKS

The reference for improper function of a hydraulic system, where the cause is not immediately apparent, should be the Troubleshooting Chart. The best place to begin the problem analysis is at the power source (pump). Once it is determined that the pump is serviceable, then a systematic check of the circuit components, beginning with the control, would follow. For aid in troubleshooting, refer to the Illustrated Parts Manual for hydraulic diagrams of the various circuits

MidWestTech | JLG 100HX, 100HX+10, 110HX Boom Lift Service Manual | Publication 312... Order the manual at mid-west-tech.com >




Figure 3-18. Wiring Diagram - 100HX+10 w/Ford Engine (Sheet 2 of 4)

MidWestTech | JLG 100HX, 100HX+10, 110HX Boom Lift Service Manual | Publication 312... Order the manual at mid-west-tech.com >