# Service and Maintenance Manual

## Model
## 60HA

**3120655**
June 1, 1994

**ANSI**

MidWestTech | JLG 60HA Boom Lift Service Manual | Publication 3120655

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| SUBJECT - SECTION, PARAGRAPH | | PAGE NO. |
|---|---|---|
| FOREWORD | | a |
| TABLE OF CONTENTS | | i |
| LIST OF ILLUSTRATIONS | | ii |
| LIST OF TABLES | | ii |
| SECTION 1 — SPECIFICATIONS | | |
| 1-1. | Capacities | 1-1 |
| 1-2. | Component Data | 1-1 |
| 1-3. | Performance Data | 1-2 |
| 1-4. | Torque Specifications | 1-3 |
| 1-5. | Lubrication | 1-3 |
| 1-6. | Pressure Setting | 1-4 |
| 1-7. | Cylinder Specifications | 1-5 |
| 1-8. | Major Component Weight | 1-5 |
| 1-9. | Critical Weight | 1-5 |
| 1-10. | Relays | 1-6 |
| 1-11. | Serial Number Locations | 1-6 |
| SECTION 2 — PROCEDURES | | |
| 2-1. | General | 2-1 |
| 2-2. | Servicing and Maintenance Guidelines | 2-1 |
| 2-3. | Lubrication Information | 2-2 |
| 2-4. | Cylinder - Theory of Operation | 2-3 |
| 2-5. | Valves - Theory of Operation | 2-3 |
| 2-6. | Wear Pads | 2-4 |
| 2-7. | Cylinder Checking Procedures | 2-4 |
| 2-8. | Cylinder Repair | 2-7 |
| 2-9. | Cylinder Removal and Installation | 2-10 |
| 2-10. | Tilt Indicator Switch Leveling Procedures | 2-13 |
| 2-11. | Boom Limit Switches | 2-14 |
| 2-12. | Throttle Checks and Precision Governor Adjustments - Ford | 2-15 |
| 2-13. | Throttle Checks and Adjustments - Deutz | 2-18 |
| 2-14. | Pressure Setting Procedures | 2-19 |
| 2-15. | Swing Bearing | 2-26 |
| 2-16. | Drive Torque Hub | 2-30 |
| 2-17. | Drive Torque Hub/Brake - 4WD Front | 2-34 |
| 2-18. | Drive Torque Hub - 4WD Rear | 2-39 |
| 2-19. | Swing Brake - Ausco (Machines Built Prior to August 1991) | 2-43 |
| 2-20. | Swing Brake - Ausco (Machines Built From August 1991 to Present) | 2-43 |
| 2-21. | Drive Brake - Ausco (Machines Built Prior to July 1990) | 2-46 |
| 2-22. | Drive Brake - Mico (Machines Built Prior to August 1991) | 2-48 |
| 2-23. | Drive Brake - Mico (Machines Built From August 1991 to Present) | 2-50 |
| 2-24. | PQ Controllers | 2-52 |
| 2-25. | Oscillating Axle Bleeding Procedure and Lockout Test | 2-54 |
| 2-26. | Basket Rotator Brake | 2-55 |
| 2-27. | Dual Fuel System | 2-55 |
| 2-28. | Free Wheeling Option | 2-56 |
| 2-29. | Spark Arrestor Mufflers | 2-56 |
| 2-30. | Foot Switch Adjustment | 2-56 |
| 2-31. | Hydraulic Pump W/Hayes Pump Drive Coupling Lubrication | 2-56 |
| 2-32. | Preventive Maintenance and Inspection Schedule | 2-58 |
| SECTION 3 — TROUBLESHOOTING | | |
| 3-1. | General | 3-1 |
| 3-2. | Troubleshooting Information | 3-1 |
| 3-3. | Hydraulic Circuit Checks | 3-1 |




MidWestTech | JLG 60HA Boom Lift Service Manual | Publication 3120655 Order the manual at mid-west-tech.com >

## LIST OF ILLUSTRATIONS


| FIGURE NO. | TITLE | PAGE NO. |
|---|---|---|
| 1-1. | Relay Wiring | 1-6 |
| 1-2. | Torque Chart | 1-7 |
| 1-3. | Lubrication Chart | 1-8 |
| 1-4. | Serial Number Locations | 1-10 |
| 2-1. | Boom Prop Configurations | 2-6 |
| 2-2. | Poly-Pak Seal Installation | 2-8 |
| 2-3. | Tower Boom Limit Cam Valve Adjustment | 2-14 |
| 2-4. | Precision Governor Adjustment, LSG-423 | 2-16 |
| 2-5. | Adeco Actuator Adjustments | 2-18 |
| 2-6. | Pressure Setting Procedures, Accessory Valve | 2-19 |
| 2-7. | Pressure Setting Procedure, Proportional Valve | 2-21 |
| 2-8. | Pressure Setting Procedure, Racine 2-Stack Valve | 2-22 |
| 2-9. | Pressure Setting Procedure, Racine 2-Stack - 4WS Valve | 2-24 |
| 2-10. | Pressure Setting Procedure, Racine 4-Stack Valve | 2-25 |
| 2-11. | Swing Bearing Tolerance Boom Placement | 2-27 |
| 2-12. | Swing Bearing Tolerance Boom Measuring Point | 2-28 |
| 2-13. | Swing Bearing Bolt Torquing Sequence | 2-29 |
| 2-14. | Drive Torque Hub Assembly | 2-31 |
| 2-15. | Torque Hub Carrier Timing | 2-34 |
| 2-16. | Torque Hub/Brake - 4WD Front | 2-35 |
| 2-17. | Torque Hub - 4WD Rear | 2-41 |
| 2-18. | Swing Brake - Ausco. (Machines Built Prior To August 1991) | 2-44 |
| 2-19. | Swing Brake - Ausco. (Machines Built From August 1991 To Present) | 2-45 |
| 2-20. | Drive Brake - Ausco (Machines Built Prior To July 1990) | 2-47 |
| 2-21. | Drive Brake - Mico (Machines Built Prior To August 1991) | 2-49 |
| 2-22. | Drive Brake - Mico (Machines Built From August 1991 To Present) | 2-51 |
| 2-23. | Basket Rotator Brake | 2-56 |
| 3-1. | Electrical Diagram - Dual Fuel | 3-21 |
| 3-2. | Electrical Diagram - Generator (Deutz) | 3-22 |
| 3-3. | Electrical Diagram - Generator (Ford) | 3-23 |
| 3-4. | Electrical Diagram - Engine & Valve (Deutz) | 3-24 |
| 3-5. | Electrical Diagram - Engine & Valve (Ford) | 3-25 |
| 3-6. | Electrical Diagram - Ground Control Box (Deutz) | 3-26 |
| 3-7. | Electrical Diagram - Ground Control Box (Ford) | 3-28 |
| 3-8. | Electrical Diagram - Ground Control Box (Kubota) | 3-30 |
| 3-9. | Electrical Diagram - Platform Console (PQ Controllers) | 3-32 |


## LIST OF TABLES


| TABLE NO. | TITLE | PAGE NO. |
|---|---|---|
| 1-1. | Hydraulic Oil | 1-4 |
| 1-2. | Lubrication Specifications | 1-4 |
| 1-3. | Cylinder Specifications | 1-5 |
| 1-4. | Major Component Weight | 1-5 |
| 1-5. | Critical Stability Weight | 1-5 |
| 2-1. | Cylinder Piston Nut Torque Specifications | 2-9 |
| 2-2. | Holding Valve Torque Specifications | 2-9 |
| 2-3. | Preventive Maintenance and Inspection Schedule | 2-59 |
| 3-1. | Platform Assembly Troubleshooting | 3-2 |
| 3-2. | Boom Assembly Troubleshooting | 3-3 |
| 3-3. | Turntable Assembly Troubleshooting | 3-10 |
| 3-4. | Chassis Troubleshooting | 3-12 |
| 3-5. | Hydraulic System Troubleshooting | 3-16 |
| 3-6. | Electrical System Troubleshooting | 3-18 |




MidWestTech | JLG 60HA Boom Lift Service Manual | Publication 3120655 Order the manual at mid-west-tech.com >