SERVICE & MAINTENANCE MANUAL

WORLD HEADQUARTERS

JLG INDUSTRIES, INC.
1 JLG Drive
McConnellsburg, PA 17233-9502
USA
Telephone (717) 485-5161
Fax (717) 485-6417



MODEL 40HA

REVISED APRIL 1995
15 APRIL 1990

PRINTED IN U.S.A.

3120672

MidWestTech | JLG 40HA Boom Lift Service Manual | Publication 3120672

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT - SECTION, PARAGRAPH	PAGE NO.
FOREWORD	a
TABLE OF CONTENTS	i
LIST OF ILLUSTRATIONS	ii
LIST OF TABLES	iii
SECTION 1 — SPECIFICATIONS	
1-1. Capacities	1-1
1-2. Component Data	1-1
1-3. Performance Data	1-3
1-4. Torque Requirements	1-3
1-5. Lubrication	1-3
1-6. Pressure Settings	1-8
1-7. Cylinder Specifications	1-9
1-8. Major Component Weights	1-9
1-9. Critical Stability Weights	1-9
1-10. Serial Number Locations	1-10
SECTION 2 — PROCEDURES	
2-1. General	2-1
2-2. Servicing and Maintenance Guidelines	2-1
2-3. Lubrication Information	2-2
2-4. Cylinder - Theory of Operation	2-3
2-5. Valves - Theory of Operation	2-3
2-6. Wear Pads	2-4
2-7. Cylinder Checking Procedures	2-4
2-8. Cylinder Repair	2-6
2-9. Cylinder Removal and Installation	2-10
2-10. Boom Maintenance	2-13
2-11. Tilt Alarm Switch	2-15
2-12. Main Boom Limit Switch Adjustment Procedures	2-15
2-13. Throttle Checks and Precision Governor Adjustments - Ford VGS411 Engine	2-16
2-14. Throttle Checks and Adjustments - Deutz F2L-1011/Kubota Engines	2-16
2-15. Pressure Setting Procedures	2-19
2-16. Swing Bearing	2-23
2-17. Drive Torque Hub	2-27
2-18. Drive Torque Hub/Brake - 4WD Front	2-32
2-19. Swing Brake - Ausco (Machines Built Prior to August 1991)	2-38
2-20. Swing Brake - Ausco (Machines Built Prior to November 1992)	2-40
2-21. Swing Brake - Sepac (Machines Built From November 1992 to Present)	2-42
2-22. Drive Brake - Ausco (Machines Built Prior to March 1992)	2-44
2-23. Drive Brake - Mico (Machines Built March 1992 To Present)	2-46
2-24. PQ Controllers	2-48
2-25. Oscillating Axle Bleeding Procedure and Lockout Test	2-49
2-26. Basket Rotator Brake	2-50
2-27. Dual Fuel System	2-50
2-28. Free Wheeling Option	2-51
2-29. Spark Arrestor Mufflers	2-51
2-30. Foot Switch Adjustment	2-51
2-31. Hydraulic Pump W/Hayes Pump Drive Coupling Lubrication	2-51
2-32. Boom Synchronizing Procedure	2-51
2-33. Preventive Maintenance and Inspection Schedule	2-52

MidWestTech | JLG 40HA Boom Lift Service Manual | Publication 3120672 Order the manual at mid-west-tech.com >

SECTION 3 — TROUBLESHOOTING

3-1.	General	3-1
3-2.	Troubleshooting Information	3-1
3-3.	Hydraulic Circuit Checks	3-1

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE NO.
1-1.	Torque Chart	1-5
1-2.	Lubrication Chart	1-6
1-3.	Serial Number Locations	1-10
2-1.	Boom Prop Configurations	2-7
2-2.	Poly-Pak Seal Installation	2-8
2-3.	Throttle Checks and Precision Governor Adjustment, Ford LSG-411 Engine	2-17
2-4.	Throttle Checks and Adjustment, Deutz F2L-1011/Kubota Engine	2-18
2-5.	Pressure Settings, Standard Bang-Bang Valves - Gas and Diesel	2-20
2-6.	Pressure Settings, Proportional Valves - Gas and Diesel	2-21
2-7.	Pressure Settings, Manual Hydraulic Valves - Gas and Diesel	2-22
2-8.	Swing Bearing Tolerance Boom Placement	2-24
2-9.	Swing Bearing Tolerance Boom Measuring Point	2-26
2-10.	Swing Bearing Bolt Torquing Sequence	2-28
2-11.	Drive Torque Hub Assembly	2-30
2-12.	Torque Hub Carrier Timing	2-32
2-13.	Drive Torque Hub/Brake - 4WD Front	2-34
2-14.	Hub/Brake Assembly Cover Alignment	2-37
2-15.	Swing Brake - Ausco (Machines Built Prior To August 1991)	2-39
2-16.	Swing Brake - Ausco (Machines Built Prior To November 1992)	2-41
2-17.	Swing Brake - Sepac (Machines Built From November 1992 To Present)	2-43
2-18.	Drive Brake - Ausco (Machines Built Prior To March 1992)	2-45
2-19.	Drive Brake - Mico (Machines Built From March 1992 To Present)	2-47
2-20.	Basket Rotator Brake Torquing	2-51
3-1.	Electrical Diagram - Dual Fuel (Ford Engine)	3-21
3-2.	Electrical Diagram - Deutz Engine	3-22
3-3.	Electrical Diagram - Ford Engine	3-23
3-4.	Electrical Diagram - Kubota Engine	3-24
3-5.	Electrical Diagram - Main Terminal Box - Deutz Engine - Hydraulic Controls	3-25
3-6.	Electrical Diagram - Main Terminal Box - Deutz Engine - Standard Controls	3-26
3-7.	Electrical Diagram - Main Terminal Box - Ford Engine - Hydraulic Controls	3-27
3-8.	Electrical Diagram - Main Terminal Box - Ford Engine - Standard Controls	3-28
3-9.	Electrical Diagram - Main Terminal Box - Kubota Engine - Proportional Controls	3-29
3-10.	Electrical Diagram - Main Terminal Box - Kubota Engine - Standard Controls	3-30
3-11.	Electrical Diagram - Platform - Hydraulic Controls	3-31
3-12.	Electrical Diagram - Platform - Proportional Controls	3-32
3-13.	Electrical Diagram - Platform - Standard Controls	3-33
3-14.	Electrical Diagram - Valves	3-34

MidWestTech | JLG 40HA Boom Lift Service Manual | Publication 3120672 Order the manual at mid-west-tech.com >

LIST OF TABLES

TABLE NO.	TITLE	PAGE NO.
1-1.	Hydraulic Oil	1-4
1-2.	Lubrication Specifications	1-4
1-3.	Cylinder Specifications	1-9
1-4.	Major Component Weights	1-9
1-5.	Critical Stability Weights	1-9
2-1.	Cylinder Piston Nut Torque Specifications	2-9
2-2.	Holding Valve Torque Specifications	2-9
2-3.	Preventive Maintenance and Inspection Schedule	2-53
3-1.	Platform Assembly Troubleshooting	3-2
3-2.	Boom Assembly Troubleshooting	3-4
3-3.	Turntable Assembly Troubleshooting	3-9
3-4.	Chassis Assembly Troubleshooting	3-12
3-5.	Hydraulic System Troubleshooting	3-16
3-6.	Electrical System Troubleshooting	3-18

MidWestTech | JLG 40HA Boom Lift Service Manual | Publication 3120672 Order the manual at mid-west-tech.com >