Service and Maintenance Manual

Model 34HA

3120675
November 1,1990

ANSI

TABLE OF CONTENTS

SUBJECT - SECTION, PARAGRAPH	PAGE NO.
FOREWORD	a
TABLE OF CONTENTS	i
LIST OF ILLUSTRATIONS	ii
LIST OF TABLES	ii
SECTION 1 — SPECIFICATIONS	
1-1. Capacities	1-1
1-2. Component Data	1-1
1-3. Performance Data	1-2
1-4. Torque Requirements	1-3
1-5. Lubrication	1-3
1-6. Pressure Settings	1-4
1-7. Cylinder Specifications	1-5
1-8. Major Component Weights	1-5
1-9. Relays/Circuit Breakers	1-5
1-10. Serial Number Locations	1-5
SECTION 2 — PROCEDURES	
2-1. General	2-1
2-2. Servicing and Maintenance Guidelines	2-1
2-3. Lubrication Information	2-2
2-4. Cylinders - Theory of Operation	2-3
2-5. Valves - Theory of Operation	2-3
2-6. Wear Pads	2-4
2-7. Cylinder Checking Procedures	2-4
2-8. Cylinder Repair	2-7
2-9. Cylinder Removal and Installation	2-9
2-10. Tilt Alarm Switch	2-11
2-11. Horizontal Cutoff Switch Adjustment	2-12
2-12. Throttle Checks and Precision Governor Adjustments, Ford Engine	2-14
2-13. Throttle Checks and Adjustments, Deutz Engine	2-16
2-14. Pressure Setting Procedures	2-18
2-15. Swing Bearing	2-22
2-16. Torque Hub - Drive Axle (2WD)	2-27
2-17. Torque Hub/Brake - Drive/Steer Axle (4WD)	2-31
2-18. Swing Brake	2-36
2-19. Drive Brake	2-38
2-20. Controllers	2-40
2-21. Oscillating Axle Bleeding Procedure	2-40
2-22. Oscillating Axle Lockout Test	2-41
2-23. Basket Rotator Brake	2-41
2-24. Dual Fuel System	2-42
2-25. Free Wheeling Option	2-42
2-26. Spark Arrestor Mufflers	2-42
2-27. Preventive Maintenance and Inspection Schedule	2-43
SECTION 3 — TROUBLESHOOTING	
3-1. General	3-1
3-2. Troubleshooting Information	3-1
3-3. Hydraulic Circuit Checks	3-1

MidWestTech | JLG 34HA Boom Lift Service Manual | Publication 3120675 Order the manual at mid-west-tech.com >

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE NO.
1-1	Relay Wiring	1-5
1-2	Torque Chart	1-6
1-3	Serial Number Locations	1-7
1-4	Lubrication Chart	1-8
2-1	Boom Prop Configuration	2-5
2-2	Poly-Pak Piston Seal Configuration	2-8
2-3	Horizontal Cutoff Switch Adjustment Procedure	2-13
2-4	Throttle Checks and Adjustments, Ford VSG-411	2-15
2-5	Throttle Checks and Adjustments, Deutz	2-17
2-6	Pressure Setting - Racine Bang-Bang Control (4640645, 4640646)	2-19
2-7	Pressure Setting - Pressure Reducing Valve (4640632)	2-20
2-8	Pressure Setting - Racine Bang-Bang (4640601)	2-21
2-9	Swing Bearing Tolerance Boom Placement	2-23
2-10	Swing Bearing Tolerance Measuring Point	2-24
2-11	Swing Bearing Bolt Torquing Procedure	2-26
2-12	Drive Torque Hub Assembly	2-28
2-13	Torque Hub Carrier Timing	2-30
2-14	Torque Hub/Brake Assembly	2-34
2-15	Swing Brake Assembly	2-37
2-16	Drive Brake	2-39
2-17	Basket Rotator Brake	2-41
3-1	Wiring Diagram - Platform (Electric)	3-25
3-2	Wiring Diagram - Platform (Gas and Diesel)	3-26
3-3	Wiring Diagram - Standard (Electric)	3-28
3-4	Wiring Diagram - Standard (Deutz	3-30
3-5	Wiring Diagram - Standard (Ford)	3-32
3-6	Hydraulic Schematic - Gas and Diesel	3-34
3-7	Hydraulic Schematic - 4WD (Gas and Diesel)	3-35
3-8	Hydraulic Schematic - Electric	3-36
3-9	Hydraulic Schematic - Drive Circuit (Gas and Diesel)	3-37
3-10	Hydraulic Schematic - Drive Circuit (Electric)	3-38

LIST OF TABLES

TABLE NO.	TITLE	PAGE NO.
1-1	Hydraulic Oil	1-3
1-2	Lubrication Specifications	1-4
1-3	Cylinder Specifications	1-5
2-1	Preventive Maintenance and Inspection Schedule	2-43
3-1	Platform Assembly Troubleshooting	3-2
3-2	Boom Assembly Troubleshooting	3-4
3-3	Turntable Assembly Troubleshooting	3-11
3-4	Chassis Assembly Troubleshooting	3-15
3-5	Hydraulic System Troubleshooting	3-20
3-6	Electrical System Troubleshooting	3-22

MidWestTech | JLG 34HA Boom Lift Service Manual | Publication 3120675 Order the manual at mid-west-tech.com >