Operators and Safety Manual
Service & Maintenance Manual
Illustrated Parts Manual

Models
CM1432
CM1432 PLUS
CM1732
CM2033
CM2046
CM2546
CM2558

3120809

October 2, 1995

MidWestTech | JLG CM1432, CM1432PLUS, CM1732, CM2033, CM2046, CM2546, CM2558 Scissor Lift Operation, Parts, Service Manual | Publication 3120809

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT - SECTION, PARAGRAPH	PAGE NO.
INTRODUCTION - OPERATION SAFETY PRECAUTIONS	a
INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS	b
EURO CM1432-CM2558 3120809 PARTS MANUAL REVISION LOG	c
TABLE OF CONTENTS	i
LIST OF ILLUSTRATIONS	iii
LIST OF TABLES	v
SECTION 1 — SAFETY PRECAUTIONS	
1-1. General	1-1
1-2. Driving/Towing/Carrying	1-1
1-3. Electrocution Hazard	1-2
1-4. Pre-Operational	1-3
1-5. Driving	1-4
1-6. Operation	1-5
1-7. Towing and Hauling	1-9
1-8. Maintnenace	1-10
SECTION 2 — PREPARATION AND INSPECTION	
2-1. General	2-1
2-2. Preparation For Use	2-1
2-3. Delivery and Periodic Inspection	2-1
2-4. Daily Walk-Around Inspection	2-2
2-5. Daily Functional Check	2-2
2-6. Torque Requirements	2-3
2-7. Battery Charging	2-3
SECTION 3 — USER RESPONSIBILITIES AND MACHINE CONTROL	
3-1. General	3-1
3-2. Personnel Training	3-1
3-3. Operating Characteristics and Limitations	3-1
3-4. Controls and Indicators	3-2
SECTION 4 — MACHINE OPERATION	
4-1. Description	4-1
4-2. General	4-1
4-3. Motor Operation	4-1
4-4. Raising and Lowering (Lifting)	4-2
4-5. Platform Extension (If Equipped)	4-2
4-6. Steering	4-3
4-7. Traveling (Driving)	4-3
4-8. Parking and Stowing	4-4
4-9. Platform Loading	4-4
4-10. Safety Prop	4-5
4-11. Tie Down and Lifting	4-5
4-12. Towing	4-5
SECTION 5 — OPTIONAL EQUIPMENT	
5-1. PQ Controller	5-1
5-2. Platform Extension	5-1
5-3. Horn	5-1
5-4. Travel Alarm	5-1
5-5. Motion Alarm	5-1

MidWestTech | JLG CM1432, CM1432PLUS, CM1732, CM2033, CM2046, CM2546, CM255... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (cont.)

SUBJECT-SECTION, PARAGRAPH **PAGE NO.**

SECTION 5 — OPTIONAL EQUIPMENT (cont.)

5-6. Descent Alarm 5-1
5-7. Platform Work Lights 5-1
5-8. Foam Filled Tires (CM2046 and CM2558 Only) 5-1
5-9. Non-Marking Tires 5-1
5-10. Rotating Beacon 5-1
5-11. High Output Batteries (CM2046, CM2546 and CM2558 Only) 5-1
5-12. Battery Condition Indicator 5-1
5-13. Fold-Down Hand Rails 5-1
5-14. Control Box Cover (Standard Toggle Switch Controls Only) 5-1
5-15. Lifting Lugs 5-1
5-16. Platform Access Door 5-1

SECTION 6 — EMERGENCY PROCEDURES

6-1. General 6-1
6-2. Emergency Towing Procedures 6-1
6-3. Emergency Controls and Their Locations 6-1
6-4. Emergency Operation 6-2
6-5. Incident Notification 6-2

SECTION 7 — SPECIFICATIONS

7-1. Capacities 7-1
7-2. Component Data 7-1
7-3. Performance Data 7-1
7-4. Torque Requirements 7-2
7-5. Lubrication 7-2
7-6. Pressure Settings 7-2
7-7. Cylinder Specifications 7-6
7-8. Serial Number Locations 7-6
7-9. Limit Switches 7-6
7-10. Major Component Weights 7-9
7-11. Critical Stability Weights 7-9

SECTION 8 — PROCEDURES

8-1. General 8-1
8-2. Servicing and Maintenance Guidelines 8-1
8-3. Lubrication Information 8-2
8-4. Cylinders - Theory of Operation 8-3
8-5. Valves - Theory of Operation 8-3
8-6. Component Functional Description 8-4
8-7. Wear Pads 8-4
8-8. Cylinder Checking Procedures 8-5
8-9. Cylinder Removal and Installation 8-5
8-10. Cylinder Repair (Except Brake Cylinder) 8-6
8-11. Brake Cylinder Repair 8-8
8-12. Tilt Alarm Switch 8-10
8-13. Limit Switch Adjustments 8-11
8-14. Pressure Setting Procedures 8-12
8-15. Preventive Maintenance and Inspection Schedule 8-14

SECTION 9 — TROUBLESHOOTING

9-1. General 9-1
9-2. Troubleshooting Information 9-1
9-3. Hydraulic Circuit Checks 9-1

MidWestTech | JLG CM1432, CM1432PLUS, CM1732, CM2033, CM2046, CM2546, CM255... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (cont.)

SUBJECT-SECTION, PARAGRAPH	PAGE NO.
SECTION 10 — RECOMMENDED SPARE PARTS LIST - CM2033/CM2046/CM2546/CM2558	
Recommended Spare Parts List	10-1
SECTION 11 — ILLUSTRATED PARTS LIST - CM2033/CM2046/CM2546/CM2558	
Table of Contents	11-0-1
SECTION 12 — RECOMMENDED SPARE PARTS LIST - CM1432/CM1432 PLUS/CM1732	
Recommended Spare Parts List	12-1
SECTION 13 — ILLUSTRATED PARTS LIST - CM1432/CM1432 PLUS/CM1732	
Table of Contents	13-0-1

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE NO.
2-1	Daily Walk-Around Inspection - CM1432/CM1432 Plus/CM1732	2-4
2-2	Daily Walk-Around Inspection - CM2033/CM2046/CM2546/CM2558	2-6
3-1	Ground Control Station - CM1432/CM1432 Plus/CM1732	3-4
3-2	Ground Control Station - CM2033/CM2046/CM2546/CM2558	3-4
3-3	Platform Control Station w/o PQ Controller - All Models (Machines Built Before August 1992)	3-5
3-4	Platform Control Station w/PQ Controller - All Models (Machines Built Before August 1992)	3-5
3-5	Platform Control Station w/o PQ Controller - All Models (Machines Built After August 1992)	3-6
3-6	Platform Control Station w/PQ Controller - All Models (Machines Built After August 1992)	3-6
4-1	Grade and Sideslope	4-3
7-1	Torque Chart	7-3
7-2	Lubrication Chart - CM1432/CM1432 Plus/CM1732	7-4
7-3	Lubrication Chart - CM2033/CM2046/CM2546/CM2558	7-5
7-4	Serial Number Locations - CM1432/CM1432 Plus/CM1732	7-7
7-5	Serial Number Locations - CM2033/CM2046/CM2546/CM2558	7-8
8-1	Poly-Pak Seal Installation	8-7
8-2	Brake Cylinder Assembly	8-10
8-3	Tilt Alarm Switch Leveling - Voltmeter Adjustment	8-11
8-4	Pressure Adjustment Locations - Proportional Valve	8-12
8-5	Pressure Adjustment Locations - Bang-Bang Valve	8-13
11-1-1	Frame, Steering and Drive Installation	11-1-2
11-1-2	Drive Motor Assemblies	11-1-8
11-1-3	Rear Axle and Brake Installations (Prior to March 1992)	11-1-10
11-1-4	Rear Axle and Brake Installations (March 1992 to Present)	11-1-14
11-1-5	Frame Mounted Components Installation	11-1-16
11-2-1	Covers, Controls, Tank and Valves Installation	11-2-2
11-2-2	Control Valve Assembly - Hydro-Air (Machines with Bang-Bang Drive Built Prior to June 1992)	11-2-8
11-2-3	Control Valve Assembly - Hydro-Air (Machines with Bang-Bang Drive Built June 1992 to Present)	11-2-12
11-2-4	Control Valve Assembly - Hydro-Air (Machines with Proportional Drive)	11-2-16
11-2-5	Batteries and Chargers Installation	11-2-20
11-2-6	Battery Charger Assembly - Single Voltage	11-2-24
11-2-7	Battery Charger Assembly - Dual Voltage	11-2-26
11-3-1	Sizzor Arms Installation - CM2033 and CM2046	11-3-2
11-3-2	Sizzor Arms Installation - CM2546 and CM2558	11-3-4
11-3-3	Sizzor Arms Guard Installation (Prior to August 1992)	11-3-10

MidWestTech | JLG CM1432, CM1432PLUS, CM1732, CM2033, CM2046, CM2546, CM255... Order the manual at mid-west-tech.com >