Illustrated Parts Manual

Model

45HA

P/N
3120824

March 15, 2012

CE

An Oshkosh Corporation Company

MidWestTech | JLG 45HA Boom Lift Parts Manual | Publication 3120824

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 7

FIGURE 1-1. FRAME AND STEERING INSTALLATION - 5FT-9IN/1.75M 2WD FRAME (WITH SINGLE ROD CYLINDER) 8
FIGURE 1-2. FRAME AND STEERING INSTALLATION - 6FT-6IN/2M 2WD FRAME (WITH DOUBLE ROD CYLINDER) 12
FIGURE 1-3. FRAME AND STEERING INSTALLATION 6FT-6IN/2M 4WD FRAME 14
FIGURE 1-4. TIRE AND WHEEL DRIVE INSTALLATIONS 18
FIGURE 1-5. DRIVE HUB ASSEMBLIES 22
FIGURE 1-6. DRIVE HUB/BRAKE ASSEMBLIES 28
FIGURE 1-7. DRIVE BRAKE ASSEMBLY - AUSCO 32
FIGURE 1-8. DRIVE BRAKE ASSEMBLY - MICO 34
FIGURE 1-9. DRIVE MOTOR ASSEMBLY - 2WD 38
FIGURE 1-10. DRIVE MOTOR ASSEMBLY - 4WD 42
FIGURE 1-11. VALVES INSTALLATION (FRAME MOUNTED) 46
FIGURE 1-12. TOW PACKAGE INSTALLATION 48

SECTION 2 - TURNTABLE 51

FIGURE 2-1. CONTROL VALVES INSTALLATIONS - VICKERS (FORD GAS AND DEUTZ DIESEL) 52
FIGURE 2-2. CONTROL VALVES INSTALLATIONS - VICKERS (ELECTRIC MACHINES) 56
FIGURE 2-3. ACCESSORY VALVE ASSEMBLY 60
FIGURE 2-4. VALVE ASSEMBLY - FPS (STEER) 62
FIGURE 2-5. CONTROL VALVE ASSEMBLY (VICKERS) (PRIOR TO OCTOBER 1994) 64
FIGURE 2-6. CONTROL VALVE ASSEMBLY - (VICKERS) (OCTOBER 1994 TO PRESENT) 68
FIGURE 2-7. VALVE ASSEMBLY - SINGLE STACK BANG-BANG 72
FIGURE 2-8. VALVE ASSEMBLY - FPS 74
FIGURE 2-9. TURNTABLE, BEARING AND SWING DRIVE INSTALLATION 76
FIGURE 2-10. SWING BRAKE ASSEMBLY 80
FIGURE 2-11. SWING MOTOR ASSEMBLY 82
FIGURE 2-12. FORD ENGINE INSTALLATION - WITH DISTRIBUTORLESS IGNITION SYSTEM 84
FIGURE 2-13. DUAL FUEL INSTALLATION (FORD DISTRIBUTORLESS IGNITION) 92
FIGURE 2-14. GENERATOR INSTALLATION - 110V (FORD) (OPTIONAL) 94
FIGURE 2-15. DEUTZ ENGINE INSTALLATION 98
FIGURE 2-16. GENERATOR INSTALLATION 110 VOLT (DEUTZ) (OPTIONAL) 104
FIGURE 2-17. PUMP ASSEMBLY - BARNES (FORD AND DEUTZ POWERED MACHINES) 108
FIGURE 2-18. ELECTRIC POWERED MACHINES COMPONENTS INSTALLATION 110
FIGURE 2-19. PUMP ASSEMBLY - BARNES (ELECTRIC POWERED MACHINES) 114
FIGURE 2-20. BATTERY CHARGER ASSEMBLY (ELECTRIC POWERED MACHINE) 116
FIGURE 2-21. TANKS INSTALLATION 118
FIGURE 2-22. ROTARY OIL COUPLING INSTALLATION 124
FIGURE 2-23. OPTIONAL MANUAL DESCENT INSTALLATION 126
FIGURE 2-24. GROUND CONTROL BOX INSTALLATION (GAS/DIESEL MACHINES) 128
FIGURE 2-25. GROUND CONTROL BOX INSTALLATION (ELECTRIC MACHINES) 132
FIGURE 2-26. TILT INDICATOR, LIGHTS AND ALARMS INSTALLATIONS (TURNTABLE MOUNTED) 136
FIGURE 2-27. HOODS INSTALLATION (GAS/DIESEL MACHINES BUILT THROUGH 1992) 138
FIGURE 2-28. HOODS INSTALLATION (GAS/DIESEL MACHINES BUILT 1993 TO PRESENT) 140
FIGURE 2-29. HOODS INSTALLATION (ELECTRIC MACHINES) 144

SECTION 3 - BOOM 147

FIGURE 3-1. BOOMS AND LIMIT SWITCHES INSTALLATIONS 148
FIGURE 3-2. MAIN BOOM ASSEMBLY 152
FIGURE 3-3. TOWER BOOM ASSEMBLIES 156
FIGURE 3-4. BOOM WIPERS INSTALLATION 160

SECTION 4 - PLATFORM 163

FIGURE 4-1. STANDARD PLATFORM AND FOOTSWITCH INSTALLATION 164
FIGURE 4-2. LOW MOUNT PLATFORM AND FOOTSWITCH INSTALLATIONS 168
FIGURE 4-3. ROTATOR MOTOR ASSEMBLY 172
FIGURE 4-4. CONSOLE BOX ASSEMBLY (ELECTRIC MACHINES) 174
FIGURE 4-5. CONSOLE BOX ASSEMBLY (GAS, DIESEL AND DUAL FUEL MACHINES PRIOR TO JANUARY 1993) 178
FIGURE 4-6. CONSOLE BOX ASSEMBLY (GAS, DIESEL AND DUAL FUEL MACHINES JANUARY 1993 TO PRESENT) 182
FIGURE 4-7. OPTIONAL COMMON PLATFORM MOUNTED COMPONENTS 186

SECTION 5 - CYLINDER 189

MidWestTech | JLG 45HA Boom Lift Parts Manual | Publication 3120824 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 5-1. AXLE LOCKOUT CYLINDER ASSEMBLY 190
FIGURE 5-2. LEVEL CYLINDER ASSEMBLY (TOWER BOOM) 192
FIGURE 5-3. LIFT CYLINDER ASSEMBLY (MAIN BOOM) 194
FIGURE 5-4. LIFT CYLINDER ASSEMBLY (TOWER BOOM) 196
FIGURE 5-5. PLATFORM LEVEL CYLINDER ASSEMBLY (MAIN BOOM) (PRIOR TO OCTOBER 1992) 198
FIGURE 5-6. PLATFORM LEVEL CYLINDER ASSEMBLY (MAIN BOOM) (OCTOBER 1992 TO PRESENT) 200
FIGURE 5-7. STEER CYLINDER ASSEMBLY (2WD - DOUBLE ACTING ROD) 202
FIGURE 5-8. STEER CYLINDER ASSEMBLY (2WD SINGLE ACTING ROD) 204
FIGURE 5-9. STEER CYLINDER ASSEMBLY (4WD) 206
FIGURE 5-10. TELESCOPE CYLINDER ASSEMBLY - MAIN BOOM 208
FIGURE 5-11. TELESCOPE CYLINDER ASSEMBLY (TOWER BOOM) 210
FIGURE 5-12. CYLINDER BELLOWS INSTALLATION (OPTIONAL) 212

SECTION 6 - HYDRAULIC 215

FIGURE 6-1. HYDRAULIC DIAGRAM - AXLE LOCKOUT 216
FIGURE 6-2. DRIVE HYDRAULIC DIAGRAM (2WD WITH SWIVEL) 218
FIGURE 6-3. DRIVE HYDRAULIC DIAGRAM (4WD WITH SWIVEL) 222
FIGURE 6-4. LIFT AND LEVEL (TOWER BOOM) HYDRAULIC DIAGRAM 224
FIGURE 6-5. LIFT AND SLAVE (MAIN BOOM) HYDRAULIC DIAGRAM 226
FIGURE 6-6. PUMP HYDRAULIC DIAGRAM (GAS AND DIESEL MACHINES) 228
FIGURE 6-7. PUMP HYDRAULIC DIAGRAM (ELECTRIC MACHINES) 232
FIGURE 6-8. ROTATION HYDRAULIC DIAGRAM 236
FIGURE 6-9. STEER WITH SWIVEL HYDRAULIC DIAGRAM 238
FIGURE 6-10. SWING HYDRAULIC DIAGRAM 240
FIGURE 6-11. TELESCOPE (MAIN BOOM) HYDRAULIC DIAGRAM 242
FIGURE 6-12. TELESCOPE (TOWER BOOM) HYDRAULIC DIAGRAM (GAS AND DIESEL MACHINES) 244
FIGURE 6-13. TELESCOPE (TOWER BOOM) HYDRAULIC DIAGRAM (ELECTRIC MACHINES) 246
FIGURE 6-14. HYDRAULIC DIAGRAM LIST 248

SECTION 7 - ELECTRICAL 251

FIGURE 7-1. ELECTRICAL DIAGRAM LIST 252
FIGURE 7-2. ELECTRICAL SCHEMATIC 256

SECTION 8 - DECALS 259

FIGURE 8-1. DECALS INSTALLATIONS 260

SECTION 9 - RECOMMENDED SERVICE PARTS STOCK 265

FIGURE 9-1. MODELS 45HA GAS AND DIESEL MACHINES WITH VICKERS VALVES STANDARD PARTS 266
FIGURE 9-2. MODELS 45HA GAS AND DIESEL MACHINES WITH VICKERS VALVES VARIABLE PARTS 268

SECTION 10 - SPECIAL OPTIONS 269

FIGURE 10-1. SPECIAL OPTIONS 270

PART NUMBER INDEX 273

MidWestTech | JLG 45HA Boom Lift Parts Manual | Publication 3120824 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
308	70001349	2	Aluminum Cover (Service Replacement) (was p/n 7017094)	
		Ref	**INPUT SHAFT ASSEMBLY**	
	7000250	Ref	**2WD**	
	7007650	Ref	**4WD**	
401		Ref	Shaft Options:	
401	7000260	1	2WD	
401	7007651	1	4WD	
402	7000263	2	Spacer	
403	7000262	1	Spring	
404	7000261	1	Ring, Retaining	
		Ref	**KIT OPTIONS:**	
	7010429	1	Bearing Kit (Includes Items 103 & 104)	
	2900034	1	Seal Kit (Includes Items 5, 102, 110 & 111)	
	See Note	1	Disconnect and Seal Kit (Includes Items 5, 102, 110, 111 & 302-306) (was p/n 2900137) (Note: Use Cover Kit as Replacement)	
		Ref	Cover Kit Options: (Note: Kit Replaces Items 5, 11 (Spacer), 12, 13 (Dowel Pins) & 301-308)	
	70001111	1	Cast Cover (Original Equipment) (was p/n 7001989 & p/n 7017099)	
	70001349	1	Aluminum Cover (Service Replacement) (was p/n 7017090)	
	2901157	Ref	**DISCONNECT HUB ASSEMBLY (CAST COVER (ORIGINAL EQUIPMENT) ONLY) (OPTIONAL)**	-
501	7002025	1	Cover	
502	7000215	1	O-Ring	
503	7007669	1	Pin, Spring	
504	7010446	1	Seal	
505	7010444	1	Rod, Disconnect	
506	7010447	1	Cap, Dust	

MidWestTech | JLG 45HA Boom Lift Parts Manual | Publication 3120824 Order the manual at mid-west-tech.com >

SECTION 2 - TURNTABLE

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
150		Ref	**Working Section Options:**	
150	7012332	Ref	Drive	
150	7012334	Ref	Lift	
150	7012334	Ref	Lift	
150	7012335	Ref	Swing	
151		Ref	Spool Options:	
151	7012331	1	Spool for Drive and Lift Sections	
151	7012340	1	Spool for Swing Section	
152		Ref	Poppet Options:	
152	7009399	2	Poppet for Drive and Swing Sections	
152	7009397	2	Poppet for Lift Sections	
153		Ref	Piston Options:	
153	Not Required	0	Piston for Drive and Lift Sections	
153	7012300	2	Piston for Swing Section	
		Ref	**Outlet Section**	
201	7006782	6	Nut	
202	7009361	3	Rod, Tie	
203	7012337	1	Cover End	
204	Kit	2	O-Ring	
205	7006778	2	Plug	
206	7012338	1	Setscrew Orifice Sub-Assembly	
207	Kit	1	O-Ring	
208	7012336	1	Plug	

MidWestTech | JLG 45HA Boom Lift Parts Manual | Publication 3120824 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	0235238	Ref	**ROTATOR ASSEMBLY:**	E
		Ref	**Note: For Machines Built Prior to September 1991 refer to Service Information Bulletin #91-5 for required upgrade.**	
101	3160083	1	Rotator Motor Assy (See ROTATOR MOTOR ASSEMBLY for Breakdown)	
102	0080099	1	Adapter, Motor	
103	2760064	1	Housing, Gear	
104	0440134	2	Bearing, Sleeve	
105	4740199	4	Washer, Thrust	
106	0440120	2	Bearing, Thrust	
107	2440043	1	Gear, Worm	
108	3440816	4	Rollpin 1/4in x 1in	
109	0080098	1	Adapter, Motor to Worm Gear	
110	2440044	1	Gear, Worm	
111	4740256	2	Washer, Thrust	
112	0440135	1	Bearing, Sleeve	
113	1760068	1	Disc, Brake	
115	3931010	5	Bolt, Socket Head #10-24NC x 5/8in	
116	3441228	2	Rollpin 3/8in x 1 3/4in	
117	3931620	2	Bolt, Socket Head 3/8in-16NC x 1 1/4in	
118	4761600	6	Lockwasher 3/8in	
119	3931612	4	Bolt, Socket Head 3/8in-16NC x 3/4in	
120	4070585	AR	Shim .010	
121	4070586	AR	Shim .005	
122	4070587	AR	Shim .002	
123	0100019	AR	Loctite #271	
124	0100021	AR	Primer	
125	2160001	1	Fitting, Grease - 90	
126	3020025	AR	Grease	
		Ref	**PLATFORM WELDMENTS**	
		Ref	**Note: Replacement Decals Must Be Ordered Separately - See DECALS SECTION.**	
201		Ref	Low Mount Platform Options:	
201	3510376	1	76cm x 122cm Platform	
201	3510377	1	76cm x 152.4cm Platform	
201	3510378	1	76cm x 183cm Platform	
		Ref	Standard Platform Components	
202	2600143	2	Pin, Hinge	
203	3311805	2	Locknut 1/2in-13NC	
204	2160006	2	Fitting, Grease	
205	1780254	1	Door Weldment	
206	2940006	1	Latch, Door	
207	2560010	1	Handle	
208	0961450	1	Bushing, Bronze (Top)	
209	0961259	1	Bushing, Bronze (Bottom)	
	0237963	Ref	**FOOTSWITCH INSTALLATION**	F
301	0641408	3	Bolt 1/4in-20NC x 1in	
301	3311405	3	Locknut 1/4in-20NC	
301	4740362	3	Washer, Fender 1/4in	
301	4360031	1	Footswitch	
301	7000625	2	Block, Contact	
301	4460071	1	Connector, Strain Relief	

MidWestTech | JLG 45HA Boom Lift Parts Manual | Publication 3120824 Order the manual at mid-west-tech.com >