Illustrated Parts Manual

Models

1532E/1932E
2033E/2046E
2646E/2658E

P/N
3120847

January 27, 2012

An Oshkosh Truck Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE NO.	TITLE	PAGE NO.
SECTION 1 - FRAME		**1-1**
1-1	DRIVE AND STEERING INSTALLATION	1-2
1-2	DRIVE MOTOR ASSEMBLIES - WHITE	1-8
1-3	DRIVE MOTOR ASSEMBLIES - EATON	1-12
1-4	AXLE/BRAKE INSTALLATIONS (POWER DOWN MACHINES)	1-14
1-5	AXLE/BRAKE INSTALLATIONS (GRAVITY DOWN MACHINES)	1-18
1-6	JLG POTHOLE PROTECTION SYSTEM INSTALLATION (POWER DOWN MACHINES)	1-20
1-7	JLG POTHOLE PROTECTION SYSTEM INSTALLATION (GRAVITY DOWN MACHINES)	1-24
1-8	FRAME MOUNTED COMPONENTS INSTALLATION (POWER DOWN MACHINES)	1-28
1-9	FRAME MOUNTED COMPONENTS INSTALLATION (GRAVITY DOWN MACHINES)	1-32
1-10	BATTERY CHARGER ASSEMBLIES - SINGLE VOLTAGE	1-38
1-11	BATTERY CHARGER ASSEMBLIES - DUAL VOLTAGE	1-40
1-12	BATTERY CHARGER ASSEMBLIES - REPLACEMENT KIT	1-42
SECTION 2 - GROUND COMPONENTS		**2-1**
2-1	HYDRAULIC COMPONENTS AND COVER INSTALLATION - 1532E/1932E (POWER DOWN MACHINES)	2-2
2-2	HYDRAULIC COMPONENTS AND COVERS INSTALLATION -1532E/1932E (GRAVITY DOWN MACHINES)	2-4
2-3	HYDRAULIC COMPONENTS AND COVERS INSTALLATION -2033E/2046E/ 2646E/2658E (POWER DOWN MACHINES)	2-6
2-4	HYDRAULIC COMPONENTS AND COVERS INSTALLATION -2033E/2046E/ 2646E/2658E (GRAVITY DOWN MACHINES)	2-10
2-5	VALVE ASSEMBLY	2-14
2-6	ELECTRICAL COMPONENTS INSTALLATIONS (AT GROUND CONTROLS)	2-18
2-7	BATTERY INSTALLATIONS	2-22
SECTION 3 - SCISSOR ARMS		**3-1**
3-1	SCISSOR ARMS INSTALLATION - 1532E (POWER DOWN MACHINES)	3-2
3-2	SCISSOR ARMS INSTALLATION - 1532E (GRAVITY DOWN MACHINES)	3-6
3-3	SCISSOR ARMS INSTALLATION - 1932E (POWER DOWN MACHINES)	3-10
3-4	SCISSOR ARMS INSTALLATION - 1932E (GRAVITY DOWN MACHINES)	3-14
3-5	SCISSOR ARMS INSTALLATION - 2033E/2046E (POWER DOWN MACHINES)	3-18
3-6	SCISSOR ARMS INSTALLATION - 2033E/2046E (GRAVITY DOWN MACHINES)	3-22
3-7	SCISSOR ARMS INSTALLATION - 2646E/2658E (POWER DOWN MACHINES)	3-26
3-8	SCISSOR ARMS INSTALLATION - 2646E/2658E (GRAVITY DOWN MACHINES)	3-30
3-9	ARM GUARDS INSTALLATION - 1532E/1932E PRIOR TO S/N 30542	3-34
3-10	ARM GUARDS INSTALLATION - 2033E/2046E/2646E BUILT PRIOR TO S/N 30542 AND ALL 2658E BUILT PRIOR TO S/N 51216	3-36
3-11	ARM GUARDS INSTALLATION - ALL 2658E BUILT S/N 51216 TO PRESENT	3-38
3-12	PLATFORM DESCENT DELAY SYSTEM INSTALLATION - 1532E/1932E/2033E/ 2046E/2646E BUILT S/N 30542 TO PRESENT	3-42
SECTION 4 - PLATFORM		**4-1**
4-1	PLATFORM INSTALLATION - MANUALLY OPERATED EXTENSION	4-2
4-2	HANDRAILS AND EXTENSION INSTALLATION - STANDARD RAILS (MANUALLY OPERATED) (1532E/1932E)	4-8
4-3	HANDRAILS AND EXTENSION INSTALLATION -STANDARD RAILS (MANUALLY OPERATED) (2033E/2046E/2646E/2658E)	4-12

MidWestTech | JLG 1532E, 1932E, 2033E, 2046E, 2646E, 2658E Scissor Lift Parts Manual... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE NO.	TITLE	PAGE NO.
4-4	HANDRAILS AND EXTENSION INSTALLATION - FOLDDOWN RAILS (MANUALLY OPERATED) (1532E/1932E)	4-18
4-5	HANDRAILS AND EXTENSION INSTALLATION - FOLDDOWN RAILS (MANUALLY OPERATED) (2033E/2046E/2646E/2658E)	4-24
4-6	PLATFORM CONSOLE BOX ASSEMBLY	4-30
4-7	CONTROLLER ASSEMBLY - OEM	4-34
4-8	CONTROLLER ASSEMBLY - PQ	4-36
SECTION 5 - CYLINDER		**5-1**
5-1	BRAKE CYLINDER ASSEMBLY	5-2
5-2	LIFT CYLINDER COMPONENTS ASSEMBLY (1532/1932 POWER DOWN MACHINES BUILT PRIOR TO S/N 27181)	5-4
5-3	LIFT CYLINDER COMPONENTS ASSEMBLY (1532/1932 POWERDOWN MACHINES BUILT S/N 27181 TO PRESENT)	5-8
5-4	LIFT CYLINDER COMPONENTS ASSEMBLY (1532E/1932E GRAVITY DOWN MACHINES)	5-10
5-5	LIFT CYLINDER COMPONENTS ASSEMBLY (2033E/2046E POWER DOWN MACHINES BUILT PRIOR TO S/N 27085 & 2646E/2658E POWER DOWN MACHINES BUILT PRIOR TO S/N 26916)	5-14
5-6	LIFT CYLINDER COMPONENTS ASSEMBLY (2033E/2046E POWER DOWN MACHINES BUILT S/N 27085 TO PRESENT & 2646E/2658E POWER DOWN MACHINES BUILT S/N 26916 TO PRESENT)	5-18
5-7	LIFT CYLINDER COMPONENTS ASSEMBLY (2033E/2046E/2646E/2658E GRAVITY DOWN MACHINES)	5-22
5-8	STEER CYLINDER ASSEMBLY	5-26
SECTION 6 - HYDRAULIC		**6-1**
6-1	HYDRAULIC DIAGRAM (POWER DOWN MACHINES)	6-2
6-2	HYDRAULIC DIAGRAM (GRAVITY DOWN MACHINES)	6-6
6-3	HYDRAULIC DIAGRAM LIST	6-10
SECTION 7 - ELECTRICAL		**7-1**
7-1	ELECTRICAL DIAGRAM LIST	7-2
7-2	STANDARD ELECTRICAL DIAGRAM (POWER DOWN MACHINES)	7-4
7-3	STANDARD ELECTRICAL DIAGRAM (GRAVITY DOWN MACHINES)	7-6
7-4	HARNESS AND CABLE ASSEMBLIES	7-8
SECTION 8 - DECALS		**8-1**
8-1	DECALS INSTALLATION - 1532E/1932E POWER DOWN MACHINES	8-2
8-2	DECALS INSTALLATION - 1532E/1932E GRAVITY DOWN MACHINES	8-6
8-3	DECALS INSTALLATION - 2033E/2046E/2646E/2658E POWER DOWN MACHINES	8-12
8-4	DECALS INSTALLATION - 2033E/2046E/2646E/2658E GRAVITY DOWN MACHINES	8-18
SECTION 9 - RECOMMENDED SERVICE PARTS STOCK		**9-1**
SECTION 10 - SPECIAL OPTIONS		**10-1**
SECTION 11 - PART NUMBER INDEX		**11-1**

MidWestTech | JLG 1532E, 1932E, 2033E, 2046E, 2646E, 2658E Scissor Lift Parts Manual... Order the manual at mid-west-tech.com >

SECTION 1 FRAME

TABLE OF CONTENTS

FIGURE	DESCRIPTION	PAGE
1-1	DRIVE AND STEERING INSTALLATIONS	1-2
1-2	DRIVE MOTOR ASSEMBLIES- WHITE	1-8
1-3	DRIVE MOTOR ASSEMBLIES- EATON	1-12
1-4	AXLE/BRAKE INSTALLATIONS (POWER DOWN MACHINES)	1-14
1-5	AXLE/BRAKE INSTALLATIONS (GRAVITY DOWN MACHINES)	1-18
1-6	JLG POTHOLE PROTECTION SYSTEM INSTALLATIONS (POWER DOWN MACHINES)	1-20
1-7	JLG POTHOLE PROTECTION SYSTEM INSTALLATIONS (GRAVITY DOWN MACHINES)	1-24
1-8	FRAME MOUNTED COMPONENTS INSTALLATIONS (POWER DOWN MACHINES)	1-28
1-9	FRAME MOUNTED COMPONENTS INSTALLATIONS (GRAVITY DOWN MACHINES)	1-32
1-10	BATTERY CHARGER ASSEMBLIES - SINGLE VOLTAGE	1-38
1-11	BATTERY CHARGER ASSEMBLIES - DUAL VOLTAGE	1-40
1-12	BATTERY CHARGER ASSEMBLIES - REPLACEMENT KIT	1-42

MidWestTech | JLG 1532E, 1932E, 2033E, 2046E, 2646E, 2658E Scissor Lift Parts Manual... Order the manual at mid-west-tech.com >

FIGURE 4-7. CONTROLLER ASSEMBLY - OEM

FIG & ITEM #	PART NUMBER	DESCRIPTION	QTY.	REV.
		CONTROLLER ASSEMBLY - OEM	Ref.	
	1600235	**Prior to S/N 29608**	Ref.	—
	1600257	**S/N 29608 to S/N 35956 - OEM**	Ref.	C
	1600257	**S/N 35965 to S/N 36011 - OEM**	Ref.	C
1	7003946	Spring, Handle Return	1	
2		Shaft Assembly Options:	1	
	7019100	Prior to S/N 29608		
	7019102	S/N 29608 to Present		
3		Harness, Electrical (Lower)	1	
	7003999	Prior to S/N 29608		
	7019101	S/N 29608 to Present		
3A	4460265	Connector, Receptacle - 9 Pin	1	
4	Not Serviced	Label	1	
5	7003961	Microswitch	2	
6	7003998	Screw	2	
7	7003966	Boot	1	
8	7003973	Handle Halves	2	
9	7003972	Cap, Rubber	1	
10	7003980	Screw	4	
11	7003979	Nut	4	
12	7003995	Harness, Electrical (Upper) (Not Shown)	1	
13	Not Serviced	Tie-strap	10	
14	Not Serviced	Housing	1	
15	7003995	Plate, Pot Mounting	1	
16*	7003983	Setscrew	2	
17	7003994	Screw	2	
18	7003993	Nut	2	
19	7003992	Washer	2	
20	7003991	Strip, Terminal	1	
21	0100011	Loctite (Not Shown)	A/R	
22	7003933	Gasket	1	
23	7003990	Screw	2	
24	7003969	Washer	2	
25	7003989	Gasket, Handle	2	
26	Not Serviced	Grease	A/R	
27	0100015	Loctite (Not Shown)	A/R	
28	7003988	Setscrew	1	
29	7003981	Rocker	1	
30	7003984	Coupling	1	
31	7003997	Potentiometer	1	
32	Not Serviced	Insulator	1	
		- - - - - - - - - -		
	7003978	Handle Assembly (Includes Items 7-11, 25, 29 & 30)	1	

MidWestTech | JLG 1532E, 1932E, 2033E, 2046E, 2646E, 2658E Scissor Lift Parts Manual... Order the manual at mid-west-tech.com >

FIGURE 5-8. STEER CYLINDER ASSEMBLY

FIG & ITEM #	PART NUMBER	DESCRIPTION	QTY.	REV.
		STEER CYLINDER ASSEMBLY (STANDARD PARTS)	Ref.	
1	Kit	Wiper	2	
2	Not Used			
3	Kit	U-Cup	2	
4	Kit	Ring, Back-up	2	
5	Kit	O-Ring	2	
6	Not Serviced	Barrel	1	
7 to 8	Not Used			
9	7016708	Piston	1	
10	Kit	O-Ring	1	
11	Not Used			
12	Kit	Seal, Piston	1	
13	Kit	O-Ring	1	
		- - - - - - - - - -		
	7016707	Seal Kit- Cylinder (Includes Items 1-5, 10, 12 and 13)	1	
		STEER CYLINDER ASSEMBLY (VARIABLE PARTS)	Ref.	
	1683351	**1532E/1932E/2033E PRIOR TO S/N 24267**	Ref.	A
	1683428	**1532E/1932E/2033E S/N 24267 TO PRESENT**	Ref.	B
	1683351	**2046E/2646E/2658E PRIOR TO S/N 24267**	Ref.	A
	1683429	**2046E/2646E/2658E S/N 24267 TO PRESENT**	Ref.	B
51		Guide Options:	2	
	Not Serviced	Prior to S/N 24267		
	7017207	S/N 24267 to Present		
52		Rod with Clevis Options:	1	
	7001632	Prior to S/N 24267		
	7017208	S/N 24267 to Present		
53		Rod Options:	1	
	7016709	Prior to S/N 24267		
	7017209	S/N 24267 to Present		

MidWestTech | JLG 1532E, 1932E, 2033E, 2046E, 2646E, 2658E Scissor Lift Parts Manual... Order the manual at mid-west-tech.com >

FIGURE 8-3. DECALS INSTALLATION - 2033E/2046E/2646E/2658E POWER DOWN MACHINES (CONTINUED)

FIG & ITEM #	PART NUMBER	DESCRIPTION	QTY.	REV.
	0256460	**German/Austrian Spec 2646E**	Ref.	4
	0256468	**German/Austrian Spec 2658E**	Ref.	4
	0256435	**Italian Spec 2033E**	Ref.	4
	0256454	**Italian Spec 2046E**	Ref.	4
	0256451	**Italian Spec 2646E**	Ref.	4
	0256469	**Italian Spec 2658E**	Ref.	4
	0256431	**Spanish Spec 2033E**	Ref.	4
	0256450	**Spanish Spec 2046E**	Ref.	4
	0256457	**Spanish Spec 2646E**	Ref.	4
	0256465	**Spanish Spec 2658E**	Ref.	4
	0256432	**UK English Spec 2033E**	Ref.	4
	0256451	**UK English Spec 2046E**	Ref.	4
	0256458	**UK English Spec 2646E**	Ref.	4
	0256466	**UK English Spec 2658E**	Ref.	4
50		Decal - Caution	1	
	1701623	Australian Spec		
	1701648	Dutch Spec		
	1701629	French Spec		
	1701630	German/Austrian Spec		
	1701632	Italian Spec		
	1701861	Spanish Spec		
	1701631	UK English Spec		
51		Decal - Safety Prop	1	
	1701839	Australian Spec		
	1701615	Dutch Spec		
	1701512	French Spec		
	1701519	German/Austrian Spec		
	1701524	Italian Spec		
	1701856	Spanish Spec		
	1701839	UK English Spec		
52		Decal - Ground Control	1	
	1702248	Australian Spec		
	1701616	Dutch Spec		
	1701515	French Spec		
	1701525	German/Austrian Spec		
	1701535	Italian Spec		
	1701858	Spanish Spec		
	1702248	UK English Spec		
53		Decal - Electrocution	3	
	1703156	Australian Spec		
	Not Required	Dutch/French/German/Austrian/Italian/Spanish/UK English Spec		
54		Decal - Crushing	2	
	1703158	Australian Spec		
	Not Required	Dutch/French/German/Austrian/Italian/Spanish/UK English Spec		

MidWestTech | JLG 1532E, 1932E, 2033E, 2046E, 2646E, 2658E Scissor Lift Parts Manual... Order the manual at mid-west-tech.com >