Illustrated Parts Manual

MODEL / MODELE

DSP M
DSPi M

ISO9001 REGISTERED COMPANY
UKAS QUALITY MANAGEMENT 015

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - COVERS INSTALL / INSTALLATION CAPOTS 7

FIGURE 1-1. HOODS INSTALL / INSTALLATION CAPOTS 8
FIGURE 1-2. MAST GUARDS INSTALL / INSTALLATION PROTECTIONS MAT 10
FIGURE 1-3. FRAME COVERS INSTALL / INSTALLATION CAPOTS CHASSIS 12
FIGURE 1-4. FRAME COVERS INSTALL, SENSITIVE / INSTALLATION CAPOTS CHASSIS SENSIBLES 14

SECTION 2 - FRAME INSTALL / INSTALLATION CHASSIS 17

FIGURE 2-1. FRAME AND OSCILLATING INSTALL / INSTALLATION OSCILLATION ET CHASSIS 18
FIGURE 2-2. STEERING AND DRIVE INSTALL / INSTALLATION DIRECTION ET TRANSLATION 20
FIGURE 2-3. MOTOR,WHEEL DRIVE PARTS / MOTOREDUCTEUR TRANSLATION, PIECES 22
FIGURE 2-4. WHEELS AND CTW INSTALL / INSTALLATIONS ROUES ET CONTREPOIDS 24

SECTION 3 - MAST INSTALL / INSTALLATION MAT 27

FIGURE 3-1. MAST INSTALL / INSTALLATION MAT 28
FIGURE 3-2. MAST SECTION ASSY / ASSEMBLAGE SECTION MAT 32
FIGURE 3-3. CYL, 4 STAGES, 4 STROKES / VERIN 4 ETAGES 4 COURSES 34

SECTION 4 - PLATFORM AND TRAY INSTALL / INSTALLATION PLATE-FORME ET TABLETTE 37

FIGURE 4-1. PLATFORM AND NAME PLATES INSTALL / INSTALLATION PLATE-FORME ET PLAQUES CONSTRUCTEUR 38
FIGURE 4-2. POWERED TRAY INSTALL / INSTALLATION TABLETTE MOTORISEE 40
FIGURE 4-3. MANUAL TRAY INSTALL / INSTALLATION TABLETTE MANUELLE 44

SECTION 5 - HYDRAULIC INSTALL / INSTALLATION HYDRAULIQUE 47

FIGURE 5-1. HYDRAULIC POWERPACK INSTALL / INSTALLATION CENTRALE HYDRAULIQUE 48
FIGURE 5-2. POWERPACK ASSEMBLY / CENTRALE HYDRAULIQUE 50

SECTION 6 - ELECTRICAL INSTALL / INSTALLATION ELECTRIQUE 53

FIGURE 6-1. CABLES DIAGRAM / DIAGRAMME FAISCEAUX 54
FIGURE 6-2. POWER CABLES KIT / KIT CABLES PUISSANCE 56
FIGURE 6-3. SENSORS AND BEACONS INSTALL / INSTALLATION CAPTEURS ET FEUX 58
FIGURE 6-4. CONTROLS INSTALL / INSTALLATION COMMANDES 60
FIGURE 6-5. GROUND CONTROL PANEL ASSY / ASSEMBLAGE PANNEAU COMMANDES BASSES 62
FIGURE 6-6. PLATFORM CONTROL BOX ASSY / ASSEMBLAGE BOITIER COMMANDES HAUTES 64
FIGURE 6-7. BATTERIES AND CHARGEUR INSTALL / INSTALLATION BATTERIES ET CHARGEUR 66

SECTION 7 - DECALS INSTALL / INSTALLATION AUTOCOLLANTS 69

FIGURE 7-1. DECALS INSTALL / INSTALLATION AUTOCOLLANTS 70

SECTION 8 - OPTIONS / OPTIONS 73

FIGURE 8-1. GATE LATCH INSTALL / INSTALLATION VERROU PORTES 74
FIGURE 8-2. LATCH,SUB ASSY / ASSEMBLAGE VERROUILLAGE PORTES 76
FIGURE 8-3. TIE STRAP INSTALL / INSTALLATION ENROULEUR TABLETTE 78
FIGURE 8-4. PANEL CARRIER INSTALL / INSTALLATION TRANSPORT PORTES 80
FIGURE 8-5. CASTER WHEEL GUARD INSTALL / INSTALLATION PROTECTION ROUE 82

SECTION 9 - RECOMMENDED PARTS LIST / LISTE DE PIECES RECOMMANDEES 85

FIGURE 9-1. RECOMMENDED PARTS LIST 86

PART NUMBER INDEX 89

MidWestTech | JLG DSP M, DSP S, DSPi-M, DSPi-S Vertical Mast Parts Manual | Publicati... Order the manual at mid-west-tech.com >

FIGURE 6-4. CONTROLS INSTALL / INSTALLATION COMMANDES

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001243074	REF	**GROUND CONTROLS INSTALL / INSTALLATION COMMANDES BASSES**	D
1	000005	2	M06x20 8.8 SOCKET HEAD MACH SCREW / VIS CHC M06x20 8.8 BI FT	
2	000008	1	M06x25 8.8 SOCKET HEAD MACH SCREW / VIS CHC M06x25 8.8 BI FT	
3	000015	9	M06x16 8.8 SOCKET HEAD MACH SCREW / VIS CHC M06x16 8.8 BI FT	
4	120004	1	dD 06x25x1.2 WASHER / RONDELLE dD 06x25x1.2 BI	
5	120009	9	LOCK WASHER D06x14 / RONDELLE CONTACT dD 06x14 BI	
7	130062	3	M04x16 8.8 ROUND HEAD MACH SCREW / VIS BOMBEE ULF M04x16 8.8 BI FT	
8	250031	6	BOOT,BATTERY TERMINAL / CAPUCHON DE PROTECTION	
9	260077	1	TERMINAL,FUSE HOLDER,DIN43560 / PORTE FUSIBLE DE PUISSANCE	
10	260095	1	FUSE 160A / FUSIBLE 160A	
11	400018	1	CLAMP,TWIN 12-12 PP,BLK / COLLIER DOUBLE D12	
12	3740150	1	RELAY,24VDC/100A / RELAIS 24VDC/100A	
13	1001231972	1	HARNESS,MOTION ALARM / FAISCEAU ALARME MOUVEMENT	
14	1001254421	1	CONTROL,DSP POWER / VARIATEUR DE PUISSANCE	
15	1001254422	1	CONTROL,DSP GROUND / VARIATEUR BOITIER BAS	
16	1001243874	1	GROUND CONTROL PANEL / PANNEAU COMMANDES BASSES	
17	1001246399	6	SCREW RD HD MACH,M6X16 / VIS BOMBEE ULF M06x16 8.8 BI FT	
18	1321293	1	CLAMP,CABLE / COLLIER ISOLE	
	1001243073	REF	**PLATFORM CONTROLS INSTALL / INSTALLATION COMMANDES HAUTES**	
101	000050	2	M04x10 8.8 SOCKET HEAD MACH SCREW / VIS CHC M04x10 8.8 BI FT	
102	120024	2	LOCK WASHER D04x10 / RONDELLE CONTACT M4 BI	
103	1001244165	1	PLATFORM CONTROL BOX / BOITIER COMMANDES HAUTES	
104	1001249832	2	SCREW RD HD MACH,THD FORMING,PLASTIC TORX 5 / VIS AUTOFORMEUSE TORX 5 POUR PLASTIC	

MidWestTech | JLG DSP M, DSP S, DSPi-M, DSPi-S Vertical Mast Parts Manual | Publicati... Order the manual at mid-west-tech.com >

FIGURE 6-7. BATTERIES AND CHARGEUR INSTALL / INSTALLATION BATTERIES ET CHARGEUR

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001243080	REF	**BATTERIES INSTALL / INSTALLATION BATTERIES**	B
1	000015	4	M06x16 8.8 SOCKET HEAD MACH SCREW / VIS CHC M06x16 8.8 BI FT	
2	100049	1	M06x70 8.8 HEX HEAD MACHINE SCREW / VIS H M06x70 8.8 BI FT	
3	110003	3	M06 GR. 8.8 LOCK NUT / ECROU FREIN M6 CL08 BI	
4	120009	4	LOCK WASHER D06x14 / RONDELLE CONTACT dD 06x14 BI	
5	130003	2	M06x16 10.9 COUNTERSUNK HEAD M. S. / VIS FHC M06x16 10.9 BI FT	
6	250031	8	BOOT,BATTERY TERMINAL / CAPUCHON DE PROTECTION	
7	1001177558	4	BATTERY,6 VOLT 200Ah AGM / BATTERIE AGM 6V-200Ah	
8	1001243683	2	STOP,BATTERY,REAR / MAINTIEN ARRIERE BATTERIES	
9	1001243690	4	STOP,BATTERY,FRONT / MAINTIEN AVANT BATTERIES	
	1001243081	REF	**CHARGER INSTALL / INSTALLATION CHARGEUR**	B
101	000015	3	M06x16 8.8 SOCKET HEAD MACH SCREW / VIS CHC M06x16 8.8 BI FT	
102	120009	2	LOCK WASHER D06x14 / RONDELLE CONTACT dD 06x14 BI	
103	1001246900	1	CHARGER / CHARGEUR	
104	1321293	1	CLAMP,INSULATED BAND / COLLIER ISOLE	
	1001248249	REF	**CHARGER PLUG W/ REEL CEE7 INSTALL / INSTALLATION ENROULEUR AVEC PRISE CEE7**	
	1001248250	REF	**CHARGER PLUG W/ REEL BS1362 INSTALL / INSTALLATION ENROULEUR AVEC PRISE BS1362**	
	1001248251	REF	**CHARGER PLUG W/ REEL W/O PLUG INSTALL / INSTALLATION ENROULEUR SANS PRISE**	
201	100027	2	M06x12 8.8 HEX HEAD MACHINE SCREW / VIS H M06x12 8.8 BI FT	
202	120009	2	LOCK WASHER D06x14 / RONDELLE CONTACT dD 06x14 BI	
203A	260214	1	FRENCH AND GERMAN 230V CONNECTOR / PRISE 230V FRANCAISE ET ALLEMANDE	
203B	250117	1	UK 230 MALE CONNECTOR / PRISE MALE ROYAUME UNI	
204	1060689	1	CABLE AC CORD, W/O PLUG / CABLE CA CHARGEUR, SANS PRISE	
205	260287	1	CABLE REAL / ENROULEUR	
301	250211	1	CABLE IEC22 / PLUG CEE7 2m 10A / CORDON IEC22 / FICHE CEE7 2m 10A	
302	250213	1	CABLE IEC22 / PLUG BS1362 2m 10A / CORDON IEC22 / FICHE BS1362 2m 10A	
303	1060689	1	CABLE AC CORD, W/O PLUG / CABLE CA CHARGEUR, SANS PRISE	

MidWestTech | JLG DSP M, DSP S, DSPi-M, DSPi-S Vertical Mast Parts Manual | Publicati... Order the manual at mid-west-tech.com >

SECTION 9 - RECOMMENDED PARTS LIST / LISTE DE PIECES RECOMMANDEES

FIGURE 9-1. RECOMMENDED PARTS LIST

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	Note	Ref	**The following list will service one Machine with emergency repair parts wich can be installed in the field. Parts from the list should be replaced when inventory is depleted to keep service parts stock supplied. For further information, contact your JLG Industries Parts Department. / La liste suivante indique (pour une Machine) les pièces de réparation d'urgence qui peuvent être installées sur le terrain. La quantité de pièces de cette liste doit être tenue en stock minimum. Pour de plus amples informations, contactez votre SAV JLG Industries.**	
		Ref	**STANDARD PARTS / PIECES STANDARD**	
	3740150	1	RELAY, 24VDC/100A / RELAIS, 24VDC/100A	
	1001243876	1	MEMBRANE SWITCHES / INTERUPTEURS A MEMBRANE	
	260095	1	FUSE 160A / FUSIBLE 160A	
	1001255561	1	HIGH PRESSURE FILTER / FILTRE HAUTE PRESSION	
	1001245091	1	COMPLETE KNOB / ARRET D'URGENCE COMPLET	
	1001245090	1	SELECTOR CONTROLS / SELECTEUR POSTE DE TRAVAIL	
	4360467	1	SWITCH KEY SWITCH OFF/ON / SELECTEUR A CLE OFF/ON	
	260324	2	NO/NC SWITCH PG11 / CAPTEUR NO/NF PE11	
	8229242	1	FUSE,5 AMP MINI ATO / FUSIBLE,5 AMP MINI	
	8229244	1	FUSE,15 AMP MINI ATO / FUSIBLE,15 AMP MINI	
		Ref	**VARIABLE PARTS / AUTRE PIECES**	
	1001252080	1	ELEC ASSY,STEERING THUMB JOYSTICK / FAISCEAU JOYSTICK DIRECTION	
	1001255541	1	ELEC ASSY,DRIVE THUMB JOYSTICK / FAISCEAU JOYSTICK TRANSLATION	
	1001255620	1	ELEC ASSY,PUSH BUTTON / FAISCEAU BOUTON POUSSOIR	
	1001255621	1	ELEC ASSY,TRIANGULATION SENSOR / FAISCEAU CAPTEUR TRIANGULATION	
	1001151895	1	TILT SENSOR / DETECTEUR DE DEVERS	
	1001246397	1	HARNESS,IR EMITTER / FAISCEAU EMETTEUR IR	
	1001246398	1	HARNESS,IR RECEIVER / FAISCEAU RECEPTEUR IR	
	1001258161	1	SENSOR WITH SOFT,DISTANCE DTO 12M / CAPTEUR AVEC SOFT DISTANCE DTO 12m	
	1001247306	1	HARNESS,WHEEL POSITION SENSOR / FAISCEAU CAPTEUR POSITION	
	PC0468	1	HARNESS, LOAD SENSING SWITCH / FAISCEAU CAPTEUR DE SURCHARGE	
	1001255623	1	GAUGE,DISPLAY / AFFICHEUR MULTIFONCTION	
	1001254421	1	CONTROL,DSP POWER / VARIATEUR DE PUISSANCE	
	1001254422	1	CONTROL,DSP GROUND / VARIATEUR BOITIER BAS	
	1001255630	1	PC BRD,PLATFORM MODULE / CARTE MODULE PLATE-FORME	
	1001255556	1	PUMP VALVE PROP. 4/3 / VALVE PROPORTIONELLE 4/3 POUR POMPE	
	1001255557	1	COIL (INCLUDED IN 1001255557) / BOBINE (INCLUSE DANS 1001255557)	
	1001255558	1	PUMP VALVE 3/2 WITH COIL / VALVE 3/2 AVEC BOBINE POUR POMPE	
	1001264037	1	CYLINDER VALVE 2/2 PROPORTIONAL / VALVE 2/2 PROPORTIONELLE VERIN	

MidWestTech | JLG DSP M, DSP S, DSPi-M, DSPi-S Vertical Mast Parts Manual | Publicati... Order the manual at mid-west-tech.com >