Illustrated Parts Manual
Illustrated Parts Manual

Agrovector

35.7

SN 1160007966 to Present

31211270

August 13, 2018 - Rev C

An Oshkosh Corporation Company

MidWestTech | JLG DEUTZ FAHR Agrovector 35.7 Telehandler Parts Manual | Publication 31211270

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 17

FIGURE 1-1. FRAME INSTALLATION 18
FIGURE 1-2. ENGINE ENCLOSURE INSTALLATION (NO RHOC) 20
FIGURE 1-3. ENGINE ENCLOSURE INSTALLATION (RHOC) 22
FIGURE 1-4. ENGINE ENCLOSURE COVER INSTALLATION (NO RHOC) 24
FIGURE 1-5. ENGINE ENCLOSURE COVER INSTALLATION (RHOC) 26
FIGURE 1-6. AIR INTAKE SEAL INSTALLATION 28
FIGURE 1-7. HOOD INSTALLATION (DEUTZ-FAHR) 30
FIGURE 1-8. COVER PLATES INSTALLATION (NO OUTRIGGERS - ULS) 32
FIGURE 1-9. COVER PLATES INSTALLATION (NO OUTRIGGERS - LS) 34
FIGURE 1-10. COVER PLATE INSTALLATION (NO TRAILER BRAKES) 36
FIGURE 1-11. COVER PLATE INSTALLATION (TRAILER BRAKES) 38
FIGURE 1-12. COVER PLATE INSTALLATION (NO REAR AUX) 40
FIGURE 1-13. COVER PLATE INSTALLATION (REAR AUX) 42
FIGURE 1-14. COVER PLATE INSTALLATION (HYDRAULIC HITCH AND REAR AUX) 44
FIGURE 1-15. REAR COVER PLATE INSTALLATION (NO HYDRAULIC HITCH) 46
FIGURE 1-16. REAR COVER PLATE INSTALLATION (HYDRAULIC HITCH) 48
FIGURE 1-17. TANKS INSTALLATION 50
FIGURE 1-18. FUEL TANK INSTALLATION 52
FIGURE 1-19. HYDRAULIC TANK INSTALLATION 54
FIGURE 1-20. FUEL TANK ASSEMBLY 56
FIGURE 1-21. HYDRAULIC TANK ASSEMBLY 58
FIGURE 1-22. FUEL AND HYDRAULIC CAP INSTALLATION 60
FIGURE 1-23. HITCH RETRIEVAL INSTALLATION 62
FIGURE 1-24. HITCH INSTALLATION (EEC AUTO) 64
FIGURE 1-25. HITCH INSTALLATION (PITON) 66
FIGURE 1-26. HITCH ASSEMBLY (EEC AUTO) 68
FIGURE 1-27. SLIDING HITCH ASSEMBLY (PITON) 70
FIGURE 1-28. HITCH INSTALLATION (EEC MANUAL) 72
FIGURE 1-29. HITCH ASSEMBLY (EEC MANUAL) 74
FIGURE 1-30. HITCH INSTALLATION (CUNA CATEGORY C) 76
FIGURE 1-31. HITCH ASSEMBLY (CUNA CATEGORY C) 78
FIGURE 1-32. HITCH INSTALLATION (CUNA CATEGORY D2) 80
FIGURE 1-33. HITCH ASSEMBLY (CUNA CATEGORY D2) 82
FIGURE 1-34. HITCH INSTALLATION (FIXED) 84
FIGURE 1-35. HITCH ASSEMBLY (FIXED) 86
FIGURE 1-36. HITCH INSTALLATION (HYDRAULIC) (Prior to SN 1160008518) 88
FIGURE 1-37. HITCH INSTALLATION (HYDRAULIC) (SN 1160008518 to Present) 90

SECTION 2 - BOOM 93

FIGURE 2-1. BOOM INSTALLATION 94
FIGURE 2-2. BOOM ASSEMBLY 96
FIGURE 2-3. FIRST BOOM SECTION ASSEMBLY 98
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 100
FIGURE 2-5. LINK ASSEMBLY 102
FIGURE 2-6. LEVER ASSEMBLY 104
FIGURE 2-7. MANUAL QUICK COUPLER INSTALLATION 106
FIGURE 2-8. HYDRAULIC QUICK COUPLER INSTALLATION 108
FIGURE 2-9. BOOM ANGLE INDICATOR INSTALLATION 110
FIGURE 2-10. BOOM PROP INSTALLATION 112
FIGURE 2-11. BOOM BRUSHES INSTALLATION 114

SECTION 3 - ATTACHMENTS 117

FIGURE 3-1. CARRIAGE ASSEMBLY (1524MM) (CE & AUS) 118
FIGURE 3-2. CARRIAGE ASSEMBLY (1829MM) (CE & AUS) 120
FIGURE 3-3. CARRIAGE ASSEMBLY (1225MM) (CE & AUS) 122
FIGURE 3-4. CARRIAGE ASSEMBLY (JOHN DEERE FIT) (CE) 124
FIGURE 3-5. CARRIAGE ASSEMBLY (MANITOU FIT) (CE) 126
FIGURE 3-6. CARRIAGE ASSEMBLY (JCB FIT) (CE) 128
FIGURE 3-7. DUAL TINE BAILING FORK CARRIAGE (CE & AUS) 130
FIGURE 3-8. FEM CARRIAGE AND FORKS (CE & AUS) 132
FIGURE 3-9. SIDE TILTING CARRIAGE (4.5 TON - 1225 MM) (CE & AUS) 134
FIGURE 3-10. SIDE SHIFT CARRIAGE (4.0 TON - 1225 MM) (CE & AUS) 136

MidWestTech | JLG DEUTZ FAHR Agrovector 35.7 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-11. FORK POSITIONING CARRIAGE WITH FORKS (4.0 TON) (CE & AUS) 138
FIGURE 3-12. DUAL FORK CARRIAGE ASSEMBLY 140
FIGURE 3-13. DUAL FORK CARRIAGE VALVE ASSEMBLY 142
FIGURE 3-14. FORK ROTATING CARRIAGE (4.5 TON - 1270 MM) 144
FIGURE 3-15. PALLET FORK (50X100X1070) (CE & AUS) 148
FIGURE 3-16. PALLET FORK (50X100X1220) (CE & AUS) 150
FIGURE 3-17. PALLET FORK (50X120X1200) (CE) 152
FIGURE 3-18. PALLET FORK (50X120X1200) (CE & AUS - IF EQUIPPED WITH 1170002) 154
FIGURE 3-19. BUCKET (1 M³) (CE & AUS) 156
FIGURE 3-20. BUCKET (1.5 M³) (CE & AUS) 158
FIGURE 3-21. BUCKET (2 M³) (CE & AUS) 160
FIGURE 3-22. BUCKET (2.5 M³) (CE & AUS) 162
FIGURE 3-23. BUCKET (3 M³) (CE & AUS) 164
FIGURE 3-24. DIRT BUCKET (1.0 M³) (CE & AUS) 166
FIGURE 3-25. 4 IN 1 BUCKET (0.6 M³) (CE & AUS) 168
FIGURE 3-26. 4 IN 1 BUCKET (1.0 M³) (CE & AUS) 170
FIGURE 3-27. MULTI-PURPOSE GRAPPLE BUCKET (WIDE GRIP - 2450 MM) (CE & AUS) 172
FIGURE 3-28. MANURE GRAPPLE BUCKET (CE & AUS) 174
FIGURE 3-29. BOLT-ON EDGE (2450 MM) 176
FIGURE 3-30. BUCKET GUARD 178
FIGURE 3-31. BUCKET TEETH KIT 180
FIGURE 3-32. BALE HANDLER KIT (SPIKES) (CE & AUS) 182
FIGURE 3-33. BALE HANDLER KIT (SPIKES TO TUBE) (CE & AUS) 184
FIGURE 3-34. TRUSS BOOM (4 TON - 2.1M) (CE & AUS) 186
FIGURE 3-35. TRUSS BOOM (1 TON - 3.4M) (CE & AUS) 188
FIGURE 3-36. TRUSS BOOM (1.8 TON - 3 FT WITH WINCH) (CE) 190
FIGURE 3-37. TRUSS BOOM (0.9 TON - 12 FT WITH WINCH) (CE) 192
FIGURE 3-38. CRANE HOOK (CE & AUS) 194
FIGURE 3-39. FORK MOUNTED HOOK (4 TON) (CE) 196
FIGURE 3-40. BALE HANDLER (TUBE CLAMP) (CE & AUS) 198
FIGURE 3-41. BALE HANDLER (SPIKE CLAMP) (CE & AUS) 200
FIGURE 3-42. MUCK FORK AND GRAB (CE & AUS) 202
FIGURE 3-43. CONCRETE BUCKET (CE) 204
FIGURE 3-44. AUGER (COUPLER MOUNTED) (CE & AUS) 208
FIGURE 3-45. FORK EXTENSION (50X100X1910) (CE) 210
FIGURE 3-46. FORK EXTENSIONS (60X100X1920) (AUS) 212
FIGURE 3-47. FORK TRANSPORT LATCHES INSTALLATION 214
FIGURE 3-48. AUGER BIT (6INX4IN) 216
FIGURE 3-49. AUGER BIT (9INX4IN) 218
FIGURE 3-50. AUGER BIT (12INX4IN) 220
FIGURE 3-51. AUGER BIT (15INX4IN) 222
FIGURE 3-52. AUGER BIT (18INX4IN) 224
FIGURE 3-53. AUGER BIT (24INX4IN) 226
FIGURE 3-54. AUGER BIT (36INX4IN) 228

SECTION 4 - ENGINE AND ATTACHING PARTS 231

FIGURE 4-1. ENGINE INSTALLATION (74.4KW - ULS - PISTON PUMP) 232
FIGURE 4-2. ENGINE INSTALLATION (90KW - ULS - PISTON PUMP) 234
FIGURE 4-3. ENGINE INSTALLATION (74.4KW - LS - PISTON PUMP) 236
FIGURE 4-4. ENGINE INSTALLATION (90KW - LS - PISTON PUMP) 238
FIGURE 4-5. ENGINE MOUNTING INSTALLATION (74.4KW) 240
FIGURE 4-6. ENGINE MOUNTING INSTALLATION (90KW/100KW) 242
FIGURE 4-7. 3.6L ENGINE (74.4KW - ULS - PISTON PUMP) 244
FIGURE 4-8. 3.6L ENGINE (90KW - ULS - PISTON PUMP) 246
FIGURE 4-9. 3.6L ENGINE (74.4KW - LS - PISTON PUMP) 248
FIGURE 4-10. 3.6L ENGINE (90KW - LS - PISTON PUMP) 250
FIGURE 4-11. ENGINE ECU INSTALLATION (ULS) 252
FIGURE 4-12. ENGINE ECU INSTALLATION (LS) 254
FIGURE 4-13. BRACKET GUARD INSTALLATION 256
FIGURE 4-14. FUEL LINES INSTALLATION (ULS) 258
FIGURE 4-15. FUEL LINES INSTALLATION (ULS - RHOC) 260
FIGURE 4-16. FUEL LINES INSTALLATION (LS) 262
FIGURE 4-17. FUEL LINES INSTALLATION (LS - RHOC) 264
FIGURE 4-18. EXHAUST INSTALLATION (ULS) 266
FIGURE 4-19. EXHAUST INSTALLATION (LS) 268
FIGURE 4-20. COOLING PACKAGE INSTALLATION (74.4KW - ULS) 270

MidWestTech | JLG DEUTZ FAHR Agrovector 35.7 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >

FIGURE 4-21. COOLING PACKAGE INSTALLATION (74.4KW - LS) 272
FIGURE 4-22. COOLING PACKAGE INSTALLATION (90KW - ULS) 274
FIGURE 4-23. COOLING PACKAGE INSTALLATION (90KW - LS) 276
FIGURE 4-24. COOLING FAN INSTALLATION 278
FIGURE 4-25. FAN LINES INSTALLATION (74.4KW) 280
FIGURE 4-26. FAN LINES INSTALLATION (90KW) 282
FIGURE 4-27. FAN DRIVE MOTOR (NO RHOC) 284
FIGURE 4-28. FAN DRIVE MOTOR (RHOC) 286
FIGURE 4-29. PRIMARY FUEL FILTER INSTALLATION (74.4KW - ULS) 288
FIGURE 4-30. FUEL FILTER INSTALLATION (90/100KW - ULS) 290
FIGURE 4-31. PRIMARY FUEL FILTER INSTALLATION (90KW - LS) 292
FIGURE 4-32. PRIMARY FUEL FILTER INSTALLATION (74.4KW - LS) 294
FIGURE 4-33. AIR CLEANER INSTALLATION (74.4KW - ULS) 296
FIGURE 4-34. AIR CLEANER INSTALLATION (90/100KW) 298
FIGURE 4-35. AIR CLEANER INSTALLATION (74.4KW - LS) 300
FIGURE 4-36. AIR CLEANER ASSEMBLY (74.4KW) 302
FIGURE 4-37. AIR CLEANER ASSEMBLY (90/100KW) 304
FIGURE 4-38. AIR INTAKE LINES INSTALLATION (74.4KW - ULS) 306
FIGURE 4-39. AIR INTAKE LINES INSTALLATION (90/100KW - ULS) 308
FIGURE 4-40. AIR INTAKE LINES INSTALLATION (74.4KW - LS) 310
FIGURE 4-41. AIR INTAKE LINES INSTALLATION (90KW - LS) 312
FIGURE 4-42. COOLER INSTALLATION (74.4KW) 314
FIGURE 4-43. COOLER INSTALLATION (90KW) 316
FIGURE 4-44. RADIATOR COOLING PACKAGE (74.4KW) 318
FIGURE 4-45. RADIATOR COOLING PACKAGE (90KW) 320
FIGURE 4-46. REMOTE HOC INSTALLATION 322
FIGURE 4-47. COOLANT LINES INSTALLATION (ULS) 324
FIGURE 4-48. COOLANT LINES INSTALLATION (LS) 326
FIGURE 4-49. COOLER LINES INSTALLATION (74.4KW) (Prior to SN 1160008518) 328
FIGURE 4-50. COOLER LINES INSTALLATION (SN 1160008518 to Present) 330
FIGURE 4-51. COOLER LINES INSTALLATION (90KW) 332
FIGURE 4-52. CAC LINES INSTALLATION (ULS) 334
FIGURE 4-53. CAC LINES INSTALLATION (LS) 336
FIGURE 4-54. SURGE TANK INSTALLATION 338
FIGURE 4-55. TANK EXPANSION 340
FIGURE 4-56. BULKHEAD INSTALLATION 342
FIGURE 4-57. DEF CONTROL MODULE INSTALLATION (ULS) 344
FIGURE 4-58. DEF TANK INSTALLATION (ULS) (Prior to SN 1160008518) 346
FIGURE 4-59. DEF TANK INSTALLATION (ULS) (SN 1160008518 to Present) 348
FIGURE 4-60. DEF LINES INSTALLATION (ULS) 350
FIGURE 4-61. DEF TANK ASSEMBLY (ULS) (Prior to SN 1160008518) 352
FIGURE 4-62. DEF TANK ASSEMBLY (ULS) (SN 1160008518 to Present) 354
FIGURE 4-63. REMOTE FUEL PUMP INSTALLATION (74.4KW) 356
FIGURE 4-64. HYDRAULIC PUMP INSTALLATION (74.4KW) 358
FIGURE 4-65. HYDRAULIC PUMP INSTALLATION (90KW) 360
FIGURE 4-66. HEATER LINES INSTALLATION (ULS) 362
FIGURE 4-67. HEATER LINES INSTALLATION (LS) 364
FIGURE 4-68. BLOCK HEATER INSTALLATION (230V - LS) 366
FIGURE 4-69. BLOCK HEATER INSTALLATION (120V - LS) 368
FIGURE 4-70. BLOCK HEATER (ULS) 370
FIGURE 4-71. BLOCK HEATER (LS) 372
FIGURE 4-72. A/C PUMP INSTALLATION 374
FIGURE 4-73. A/C LINES INSTALLATION 376

SECTION 5 - DRIVE TRAIN 379

FIGURE 5-1. AXLES INSTALLATION (NO HYDRAULIC PARK BRAKE) 380
FIGURE 5-2. AXLES INSTALLATION (HYDRAULIC PARK BRAKE) 382
FIGURE 5-3. FRONT AXLE INSTALLATION (NO HYDRAULIC PARK BRAKE) 384
FIGURE 5-4. FRONT AXLE, CENTRAL HOUSING (NO HYDRAULIC PARK BRAKE) 386
FIGURE 5-5. FRONT AXLE, DIFFERENTIAL (NO HYDRAULIC PARK BRAKE) 388
FIGURE 5-6. FRONT AXLE, HUB REDUCTION (NO HYDRAULIC PARK BRAKE) 390
FIGURE 5-7. FRONT AXLE, BRAKES (NO HYDRAULIC PARK BRAKE) 392
FIGURE 5-8. FRONT AXLE, STEERING (NO HYDRAULIC PARK BRAKE) 394
FIGURE 5-9. FRONT AXLE INSTALLATION (HYDRAULIC PARK BRAKE) 396
FIGURE 5-10. FRONT AXLE, CENTRAL HOUSING (HYDRAULIC PARK BRAKE) 398
FIGURE 5-11. FRONT AXLE, DIFFERENTIAL (HYDRAULIC PARK BRAKE) 400

MidWestTech | JLG DEUTZ FAHR Agrovector 35.7 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >