Illustrated Parts Manual

Illustrated Parts Manual

Agrovector

40.8

SN 1160007890 to Present

31211271

August 13, 2018 - Rev C

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 17

FIGURE 1-1. FRAME INSTALLATION 18
FIGURE 1-2. ENGINE ENCLOSURE INSTALLATION (NO RHOC) 20
FIGURE 1-3. ENGINE ENCLOSURE INSTALLATION (RHOC) 22
FIGURE 1-4. ENGINE ENCLOSURE COVER INSTALLATION (NO RHOC) 24
FIGURE 1-5. ENGINE ENCLOSURE COVER INSTALLATION (RHOC) 26
FIGURE 1-6. AIR INTAKE SEAL INSTALLATION 28
FIGURE 1-7. HOOD INSTALLATION 30
FIGURE 1-8. COVER PLATES INSTALLATION (NO OUTRIGGERS - ULS) 32
FIGURE 1-9. COVER PLATES INSTALLATION (NO OUTRIGGERS - LS) 34
FIGURE 1-10. COVER PLATE INSTALLATION (NO TRAILER BRAKES) 36
FIGURE 1-11. COVER PLATE INSTALLATION (TRAILER BRAKES) 38
FIGURE 1-12. COVER PLATE INSTALLATION (NO REAR AUX) 40
FIGURE 1-13. COVER PLATE INSTALLATION (REAR AUX) 42
FIGURE 1-14. COVER PLATE INSTALLATION (HYDRAULIC HITCH AND REAR AUX) 44
FIGURE 1-15. REAR COVER PLATE INSTALLATION (NO HYDRAULIC HITCH) 46
FIGURE 1-16. REAR COVER PLATE INSTALLATION (HYDRAULIC HITCH) 48
FIGURE 1-17. COUNTERWEIGHT INSTALLATION 50
FIGURE 1-18. TANKS INSTALLATION 52
FIGURE 1-19. FUEL TANK INSTALLATION 54
FIGURE 1-20. HYDRAULIC TANK INSTALLATION 56
FIGURE 1-21. FUEL TANK ASSEMBLY 58
FIGURE 1-22. HYDRAULIC TANK ASSEMBLY 60
FIGURE 1-23. FUEL AND HYDRAULIC CAP INSTALLATION 62
FIGURE 1-24. HITCH RETRIEVAL INSTALLATION 64
FIGURE 1-25. HITCH INSTALLATION (EEC AUTO) 66
FIGURE 1-26. HITCH INSTALLATION (PITON) 68
FIGURE 1-27. HITCH ASSEMBLY (EEC AUTO) 70
FIGURE 1-28. SLIDING HITCH ASSEMBLY (PITON) 72
FIGURE 1-29. HITCH INSTALLATION (EEC MANUAL) 74
FIGURE 1-30. HITCH ASSEMBLY (EEC MANUAL) 76
FIGURE 1-31. HITCH INSTALLATION (CUNA CATEGORY C) 78
FIGURE 1-32. HITCH ASSEMBLY (CUNA CATEGORY C) 80
FIGURE 1-33. HITCH INSTALLATION (CUNA CATEGORY D2) 82
FIGURE 1-34. HITCH ASSEMBLY (CUNA CATEGORY D2) 84
FIGURE 1-35. HITCH INSTALLATION (FIXED) 86
FIGURE 1-36. HITCH ASSEMBLY (FIXED) 88
FIGURE 1-37. HITCH INSTALLATION (HYDRAULIC) (Prior to SN 1160008505) 90
FIGURE 1-38. HITCH INSTALLATION (HYDRAULIC) (SN 1160008505 to Present) 92

SECTION 2 - BOOM 95

FIGURE 2-1. BOOM INSTALLATION 96
FIGURE 2-2. BOOM ASSEMBLY 98
FIGURE 2-3. FIRST BOOM SECTION 100
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 102
FIGURE 2-5. LINK ASSEMBLY 104
FIGURE 2-6. LEVER ASSEMBLY 106
FIGURE 2-7. MANUAL QUICK COUPLER INSTALLATION 108
FIGURE 2-8. HYDRAULIC QUICK COUPLER INSTALLATION 110
FIGURE 2-9. BOOM ANGLE INDICATOR INSTALLATION 112
FIGURE 2-10. BOOM PROP INSTALLATION 114
FIGURE 2-11. BOOM BRUSHES INSTALLATION 116

SECTION 3 - ATTACHMENTS 119

FIGURE 3-1. CARRIAGE ASSEMBLY (1524MM) (CE & AUS) 120
FIGURE 3-2. CARRIAGE ASSEMBLY (1829MM) (CE & AUS) 122
FIGURE 3-3. CARRIAGE ASSEMBLY (1225MM) (CE & AUS) 124
FIGURE 3-4. SIDE TILTING CARRIAGE (4.5 TON - 1225 MM) (CE & AUS) 126
FIGURE 3-5. SIDE SHIFT CARRIAGE (4.0 TON - 1225 MM) (CE & AUS) 128
FIGURE 3-6. FORK POSITIONING CARRIAGE WITH FORKS (4.0 TON) (CE & AUS) 130
FIGURE 3-7. DUAL FORK CARRIAGE ASSEMBLY 132
FIGURE 3-8. DUAL FORK CARRIAGE VALVE ASSEMBLY 134
FIGURE 3-9. FORK ROTATING CARRIAGE (4.5 TON - 1270 MM) (AUS) 136

MidWestTech | JLG DEUTZ FAHR Agrovector 40.8 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-10. CARRIAGE ASSEMBLY (JOHN DEERE FIT) (CE) 140
FIGURE 3-11. CARRIAGE ASSEMBLY (MANITOU FIT) (CE) 142
FIGURE 3-12. FORK ASSEMBLY (JCB FIT) (CE) 144
FIGURE 3-13. DUAL TINE BAILING FORK CARRIAGE (CE & AUS) 146
FIGURE 3-14. FEM CARRIAGE AND FORKS (CE & AUS) 148
FIGURE 3-15. PALLET FORK (50X100X1220) (CE) 150
FIGURE 3-16. PALLET FORK (50X120X1200) (CE) 152
FIGURE 3-17. PALLET FORK (50X120X1200) (CE & AUS - IF EQUIPPED WITH 1170002) 154
FIGURE 3-18. BUCKET (1 M³) (CE & AUS) 156
FIGURE 3-19. BUCKET (1.5 M³) (CE & AUS) 158
FIGURE 3-20. BUCKET (2 M³) (CE & AUS) 160
FIGURE 3-21. BUCKET (2.5 M³) (CE & AUS) 162
FIGURE 3-22. BUCKET (3 M³) (CE & AUS) 164
FIGURE 3-23. BOLT-ON EDGE (2450 MM) (IF EQUIPPED WITH GENERAL BUCKET) 166
FIGURE 3-24. DIRT BUCKET (1.0 M³) (CE & AUS) 168
FIGURE 3-25. 4 IN 1 BUCKET (0.6 M³) (CE & AUS) 170
FIGURE 3-26. 4 IN 1 BUCKET (1.0 M³) (CE & AUS) 172
FIGURE 3-27. MULTI-PURPOSE GRAPPLE BUCKET (WIDE GRIP - 2450 MM) (CE & AUS) 174
FIGURE 3-28. MANURE GRAPPLE BUCKET (CE & AUS) 176
FIGURE 3-29. BUCKET GUARD 178
FIGURE 3-30. BUCKET TEETH KIT 180
FIGURE 3-31. BALE HANDLER (SPIKE CLAMP) (CE & AUS) 182
FIGURE 3-32. BALE HANDLER KIT (SPIKES) (CE AND AUS) 184
FIGURE 3-33. BALE HANDLER KIT (SPIKES TO TUBE) (CE & AUS) 186
FIGURE 3-34. BALE HANDLER (TUBE CLAMP) (CE & AUS) 188
FIGURE 3-35. TRUSS BOOM (4 TON - 2.1M) (CE AND AUS) 190
FIGURE 3-36. TRUSS BOOM (1 TON - 3.4M) (CE AND AUS) 192
FIGURE 3-37. TRUSS BOOM (1.8 TON - 3 FT WITH WINCH) (CE) 194
FIGURE 3-38. TRUSS BOOM (0.9 TON - 12 FT WITH WINCH) (CE) 196
FIGURE 3-39. CRANE HOOK (CE AND AUS) 198
FIGURE 3-40. FORK MOUNTED HOOK (4 TON) (CE) 200
FIGURE 3-41. MUCK FORK AND GRAB (CE & AUS) 202
FIGURE 3-42. FORK MOUNTED PLATFORM 204
FIGURE 3-43. CONCRETE BUCKET (CE) 206
FIGURE 3-44. AUGER (CE & AUS) 210
FIGURE 3-45. AUGER BIT, (6INX4IN) (CE & AUS) 212
FIGURE 3-46. AUGER BIT, (9INX4IN) (CE & AUS) 214
FIGURE 3-47. AUGER BIT, (12INX4IN) (CE & AUS) 216
FIGURE 3-48. AUGER BIT, (15INX4IN) (CE & AUS) 218
FIGURE 3-49. AUGER BIT, (18INX4IN) (CE & AUS) 220
FIGURE 3-50. AUGER BIT, (24INX4IN) (CE & AUS) 222
FIGURE 3-51. AUGER BIT, (36INX4IN) (CE & AUS) 224
FIGURE 3-52. FORK EXTENSION (50X100X1910) (CE) 226
FIGURE 3-53. FORK EXTENSIONS (60X100X1920) (AUS) 228
FIGURE 3-54. FORK TRANSPORT LATCHES INSTALLATION 230

SECTION 4 - ENGINE AND ATTACHING PARTS 233

FIGURE 4-1. ENGINE INSTALLATION (74.4KW - ULS - PISTON PUMP) 234
FIGURE 4-2. ENGINE INSTALLATION (90KW - ULS - PISTON PUMP) 236
FIGURE 4-3. ENGINE INSTALLATION (100KW - ULS - PISTON PUMP) 238
FIGURE 4-4. ENGINE INSTALLATION (74.4KW - LS - PISTON PUMP) 240
FIGURE 4-5. ENGINE INSTALLATION (90KW - LS - PISTON PUMP) 242
FIGURE 4-6. ENGINE MOUNTING INSTALLATION (74.4KW) 244
FIGURE 4-7. ENGINE MOUNTING INSTALLATION (90KW/100KW) 246
FIGURE 4-8. 3.6L ENGINE (74.4KW - ULS - PISTON PUMP) 248
FIGURE 4-9. 3.6L ENGINE (90KW - ULS - PISTON PUMP) 250
FIGURE 4-10. 3.6L ENGINE (100KW - ULS - PISTON PUMP) 252
FIGURE 4-11. 3.6L ENGINE (74.4KW - LS - PISTON PUMP) 254
FIGURE 4-12. 3.6L ENGINE (90KW - LS - PISTON PUMP) 256
FIGURE 4-13. ENGINE ECU INSTALLATION (ULS) 258
FIGURE 4-14. ENGINE ECU INSTALLATION (LS) 260
FIGURE 4-15. BRACKET GUARD INSTALLATION 262
FIGURE 4-16. FUEL LINES INSTALLATION (ULS) 264
FIGURE 4-17. FUEL LINES INSTALLATION (ULS - RHOC) 266
FIGURE 4-18. FUEL LINES INSTALLATION (LS) 268
FIGURE 4-19. FUEL LINES INSTALLATION (LS - RHOC) 270

MidWestTech | JLG DEUTZ FAHR Agrovector 40.8 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >

FIGURE 4-20. EXHAUST INSTALLATION (ULS) 272
FIGURE 4-21. EXHAUST INSTALLATION (LS) 274
FIGURE 4-22. COOLING PACKAGE INSTALLATION (74.4KW - ULS) 276
FIGURE 4-23. COOLING PACKAGE INSTALLATION (74.4KW - LS) 278
FIGURE 4-24. COOLING PACKAGE INSTALLATION (90KW - ULS) 280
FIGURE 4-25. COOLING PACKAGE INSTALLATION (90KW - LS) 282
FIGURE 4-26. COOLING FAN INSTALLATION 284
FIGURE 4-27. FAN LINES INSTALLATION (74.4KW) 286
FIGURE 4-28. FAN LINES INSTALLATION (90KW) 288
FIGURE 4-29. FAN DRIVE MOTOR (NO RHOC) 290
FIGURE 4-30. FAN DRIVE MOTOR (RHOC) 292
FIGURE 4-31. PRIMARY FUEL FILTER INSTALLATION (74.4KW - ULS) 294
FIGURE 4-32. FUEL FILTER INSTALLATION (90/100KW - ULS) 296
FIGURE 4-33. PRIMARY FUEL FILTER INSTALLATION (90KW - LS) 298
FIGURE 4-34. AIR CLEANER INSTALLATION (74.4KW - ULS) 300
FIGURE 4-35. AIR CLEANER INSTALLATION (90/100KW) 302
FIGURE 4-36. AIR CLEANER INSTALLATION (74.4KW - LS) 304
FIGURE 4-37. AIR CLEANER ASSEMBLY (74.4KW) 306
FIGURE 4-38. AIR CLEANER ASSEMBLY (90/100KW) 308
FIGURE 4-39. AIR INTAKE LINES INSTALLATION (74.4KW - ULS) 310
FIGURE 4-40. AIR INTAKE LINES INSTALLATION (90/100KW - ULS) 312
FIGURE 4-41. AIR INTAKE LINES INSTALLATION (74.4KW - LS) 314
FIGURE 4-42. AIR INTAKE LINES INSTALLATION (90KW - LS) 316
FIGURE 4-43. COOLER INSTALLATION (74.4KW) 318
FIGURE 4-44. COOLER INSTALLATION (90KW) 320
FIGURE 4-45. RADIATOR COOLING PACKAGE (74.4KW) 322
FIGURE 4-46. RADIATOR COOLING PACKAGE (90KW) 324
FIGURE 4-47. REMOTE HOC INSTALLATION 326
FIGURE 4-48. COOLANT LINES INSTALLATION (ULS) 328
FIGURE 4-49. COOLANT LINES INSTALLATION (LS) 330
FIGURE 4-50. COOLER LINES INSTALLATION (74.4KW) (Prior to SN 1160008505) 332
FIGURE 4-51. COOLER LINES INSTALLATION (74.4KW) (SN 1160008505 to Present) 334
FIGURE 4-52. COOLER LINES INSTALLATION (90KW) 336
FIGURE 4-53. CAC LINES INSTALLATION (ULS) 338
FIGURE 4-54. CAC LINES INSTALLATION (LS) 340
FIGURE 4-55. SURGE TANK INSTALLATION 342
FIGURE 4-56. TANK EXPANSION 344
FIGURE 4-57. BULKHEAD INSTALLATION 346
FIGURE 4-58. DEF CONTROL MODULE INSTALLATION (ULS) 348
FIGURE 4-59. DEF TANK INSTALLATION (ULS) (Prior to SN 1160008505) 350
FIGURE 4-60. DEF TANK INSTALLATION (ULS) (SN 1160008505 to Present) 352
FIGURE 4-61. DEF LINES INSTALLATION (ULS) 354
FIGURE 4-62. DEF TANK ASSEMBLY (ULS) (Prior to SN 1160008505) 356
FIGURE 4-63. DEF TANK ASSEMBLY (ULS) (SN 1160008505 to Present) 358
FIGURE 4-64. REMOTE FUEL PUMP INSTALLATION (74.4KW) 360
FIGURE 4-65. HYDRAULIC PUMP INSTALLATION (74.4KW) 362
FIGURE 4-66. HYDRAULIC PUMP INSTALLATION (90KW) 364
FIGURE 4-67. HEATER LINES INSTALLATION (ULS) 366
FIGURE 4-68. HEATER LINES INSTALLATION (LS) 368
FIGURE 4-69. BLOCK HEATER INSTALLATION (230V - LS) 370
FIGURE 4-70. BLOCK HEATER INSTALLATION (120V - LS) 372
FIGURE 4-71. BLOCK HEATER (ULS) 374
FIGURE 4-72. BLOCK HEATER (LS) 376
FIGURE 4-73. A/C PUMP INSTALLATION 378
FIGURE 4-74. A/C LINES INSTALLATION 380

SECTION 5 - DRIVETRAIN 383

FIGURE 5-1. AXLES INSTALLATION (NO HYDRAULIC PARK BRAKE) 384
FIGURE 5-2. AXLES INSTALLATION (HYDRAULIC PARK BRAKE) 386
FIGURE 5-3. FRONT AXLE INSTALLATION (NO HYDRAULIC PARK BRAKE) 388
FIGURE 5-4. FRONT AXLE, CENTRAL HOUSING (NO HYDRAULIC PARK BRAKE) 390
FIGURE 5-5. FRONT AXLE, DIFFERENTIAL (NO HYDRAULIC PARK BRAKE) 392
FIGURE 5-6. FRONT AXLE, HUB REDUCTION (NO HYDRAULIC PARK BRAKE) 394
FIGURE 5-7. FRONT AXLE, BRAKES (NO HYDRAULIC PARK BRAKE) 396
FIGURE 5-8. FRONT AXLE, STEERING (NO HYDRAULIC PARK BRAKE) 398
FIGURE 5-9. FRONT AXLE INSTALLATION (HYDRAULIC PARK BRAKE) 400

MidWestTech | JLG DEUTZ FAHR Agrovector 40.8 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >

FIGURE 10-3. CAB ELECTRICAL INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001184069	Ref	Cab Electrical Installation	O
1	3290501	7	Nut, M5X0.8 Grade 8	
2	3290601	2	Nut, M6X1 Grade 8	
3	120034	7	Washer, Plastic	
4	4811700	4	Washer, M6	
5	1001146588	23	Strap, Cable Tie	
6	1001184070	1	Harness, Cab (See Separate Breakdown in this Section)	
7	1001161769	1	Assembly, Standard Electrical Board (See Separate Breakdown in this Section)	
8	1001161770	1	Assembly, Option 1 Electrical Board (See Separate Breakdown in this Section)	
9	1001209578	1	Module, Cab Control	
10	0700618	2	Bolt, M6X50	
11	1001178933	1	Bracket	
12	4460496	5	Washer, Terminal Lock	
13	4460497	5	Nut, Terminal	
14	1001161771	1	Assembly, Option 2 Electrical Board (See Separate Breakdown in this Section)	
15	1001181681	1	Harness, Cab Option LBP (See Separate Breakdown in this Section)	
16	1001213988	1	Cable, Communication Analyzer	
17	1001211693	2	Seal	
18	1001214281	1	Connector, Wiper Module	

MidWestTech | JLG DEUTZ FAHR Agrovector 40.8 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >

FIGURE 10-67. ENGINE HARNESS (LS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001184503	Ref	Engine Harness (LS)	D
1	4460891	1	Connector	
2	80604018	1	Lock, Connector	
3	4460465	2	Terminal	
4	4460891	1	Connector	
5	80604018	1	Lock, Connector	
6	4460465	2	Terminal	
10	1001126360	1	Connector	
11	1001126351	13	Terminal	
12	1001126384	17	Terminal	
13	1001126357	11	Plug	
14	1001126356	19	Plug	
15	1001126362	1	Connector	
16	1001166556	24	Terminal	
17	1001166701	24	Seal	
18	1001166774	10	Terminal	
19	1001126393	10	Seal	
20	1001166543	2	Terminal	
21	4461054	2	Seal	
22	1001126391	22	Plug	
23	1001116696	4	Plug	
24	1001116950	1	Connector	
25	4460465	2	Terminal	
26	1001133714	1	Connector	
27	1001133715	3	Terminal	
28	1001135650	3	Seal	
29	1001135651	1	Plug	
30	1001117018	1	Connector (includes 25 amp auto fuse)	
31	1001116734	1	Terminal	
32	1001116735	1	Terminal	
33	1001126349	1	Connector	
34	1001126352	6	Terminal	
35	1001126353	6	Seal	
36	1001126384	19	Terminal	
37	1001126351	2	Terminal	
38	1001126356	65	Terminal	
39	1001126357	2	Plug	
42	1001116812	1	Connector	
43	91554019	1	Lock, Connector	
44	4460944	2	Terminal	
45	4460466	1	Plug	
46	4460539	1	Connector	
47	4460944	2	Terminal	
48	4460466	1	Plug	
49	1001116812	1	Connector	
50	91554019	1	Lock, Connector	
51	4460944	2	Terminal	
52	4460466	1	Plug	
53	1001116812	1	Connector	
54	91554019	1	Lock, Connector	

MidWestTech | JLG DEUTZ FAHR Agrovector 40.8 Telehandler Parts Manual | Publication... Order the manual at mid-west-tech.com >