Illustrated Parts Manual

Models

7013H

SN 0160000001 to SN 0160097406

P/N
31211279

May 28, 2020 - Rev B

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. FRAME WELDMENT 16
FIGURE 1-2. FRAME WELDMENT (TUV) 18
FIGURE 1-3. GROMMETS INSTALLATION 20
FIGURE 1-4. TANK INSTALLATION 22
FIGURE 1-5. FUEL TANK INSTALLATION 24
FIGURE 1-6. HYDRAULIC TANK INSTALLATION 26
FIGURE 1-7. TANK SUPPORT INSTALLATION 28
FIGURE 1-8. FUEL TANK ASSEMBLY 30
FIGURE 1-9. LOCKING FUEL CAP 32
FIGURE 1-10. HYDRAULIC TANK ASSEMBLY 34
FIGURE 1-11. COUNTERWEIGHT INSTALLATION 36
FIGURE 1-12. ENGINE ENCLOSURE INSTALLATION 38
FIGURE 1-13. ENGINE ENCLOSURE ASSEMBLY 40
FIGURE 1-14. ENGINE HOOD ASSEMBLY 42
FIGURE 1-15. ENGINE HOOD INSULATION INSTALLATION 44
FIGURE 1-16. COVER INSTALLATION (ULS) 46
FIGURE 1-17. COVER INSTALLATION (LS) 48
FIGURE 1-18. FRAME COVER INSTALLATION 50
FIGURE 1-19. FRONT LOWER COVER INSTALLATION 52
FIGURE 1-20. PAD LOCK 54
FIGURE 1-21. REFLECTORS INSTALLATION 56
FIGURE 1-22. MIRROR INSTALLATION 58
FIGURE 1-23. MIRROR INSTALLATION 60
FIGURE 1-24. WHEEL CHOCK INSTALLATION 62
FIGURE 1-25. TANK INSTALLATION 64
FIGURE 1-26. TANK INSTALLATION (TUV) 66
FIGURE 1-27. FUEL TANK INSTALLATION 68
FIGURE 1-28. FUEL TANK INSTALLATION (TUV) 70
FIGURE 1-29. TANK SUPPORT INSTALLATION 72

SECTION 2 - BOOM 75

FIGURE 2-1. BOOM INSTALLATION 76
FIGURE 2-2. BOOM INSTALLATION 78
FIGURE 2-3. BOOM ASSEMBLY 80
FIGURE 2-4. BOOM ASSEMBLY 82
FIGURE 2-5. FIRST BOOM SECTION ASSEMBLY 84
FIGURE 2-6. FIRST BOOM SECTION ASSEMBLY 86
FIGURE 2-7. SECOND BOOM SECTION ASSEMBLY 88
FIGURE 2-8. SECOND BOOM SECTION ASSEMBLY 90
FIGURE 2-9. THIRD BOOM SECTION ASSEMBLY 92
FIGURE 2-10. COUPLER INSTALLATION (MANUAL) 94
FIGURE 2-11. COUPLER INSTALLATION (HYDRAULIC) 96
FIGURE 2-12. COUPLER LOCKING CYLINDER ASSEMBLY 98
FIGURE 2-13. BOOM ANGLE INDICATOR INSTALLATION (LS - AUS) 100
FIGURE 2-14. BOOM PROP INSTALLATION 102
FIGURE 2-15. MANUAL COUPLER PIN HOLDER INSTALLATION 104
FIGURE 2-16. BOOM BRUSHES INSTALLATION 106
FIGURE 2-17. BOOM PROP BRACKET ASSEMBLY 108

SECTION 3 - ATTACHMENTS 111

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION 112
FIGURE 3-2. COMPONENTS ATTACHMENT RECOGNITION INSTALLATION 114
FIGURE 3-3. CARRIAGE ASSEMBLY, (60IN/1524MM) 116
FIGURE 3-4. CARRIAGE ASSEMBLY, (72IN/1829MM) 118
FIGURE 3-5. CARRIAGE ASSEMBLY, (87IN/2290MM) 120
FIGURE 3-6. DUAL FORK POSITIONING SIDE SHIFT CARRIAGE, (75IN/1899MM) 122
FIGURE 3-7. DUAL FORK POSITIONING CARRIAGE, (72IN/1829MM) 124
FIGURE 3-8. BUCKET (2.6 YD^3/2.0M^3) 126
FIGURE 3-9. BUCKET (5.23 YD3) 128
FIGURE 3-10. 4 IN 1 BUCKET (2.6 YD^3/2.0M^3) 130
FIGURE 3-11. 4 IN 1 BUCKET (1.3 YD^3/1.0M^3) 132
FIGURE 3-12. GRAPPLE BUCKET (1.7 YD^3/1.3M^3) 134

MidWestTech | JLG 7013H Boom Lift Parts Manual | Publication 31211279 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-13. GRAPPLE BUCKET (2.6 YD³/2.0M³) 136
FIGURE 3-14. TRUSS BOOM (7.6 TON) 138
FIGURE 3-15. CRANE HOOK (7.6 TON) 140
FIGURE 3-16. COUPLER MOUNTED WINCH 142
FIGURE 3-17. BALE HANDLER (ROUND) 144
FIGURE 3-18. BALE HANDLER (SQUARE) 148
FIGURE 3-19. PIPE HANDLER CARRIAGE 150
FIGURE 3-20. TIRE HANDLER CARRIAGE 154
FIGURE 3-21. LOG HANDLER CARRIAGE 156
FIGURE 3-22. STEEL COIL HANDLER CARRIAGE 160
FIGURE 3-23. PALLET FORK (2.25X6X48) 162
FIGURE 3-24. PALLET FORK (2.25X6X60) 164
FIGURE 3-25. PALLET FORK (2.25X6X72) 166
FIGURE 3-26. PALLET FORK (2.25X6X96) 168
FIGURE 3-27. FORK RETENTION INSTALLATION 170

SECTION 4 - ENGINE AND ATTACHING PARTS 173

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS) 174
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (LS) 176
FIGURE 4-3. ENGINE INSTALLATION (LS) 178
FIGURE 4-4. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS) 180
FIGURE 4-5. ENGINE POD COMPONENT INSTALLATION (MINING) (LS) 182
FIGURE 4-6. ENGINE POD COMPONENT INSTALLATION (LS) 184
FIGURE 4-7. ENGINE INSTALLATION (ULS) 186
FIGURE 4-8. ENGINE (100KW - ULS) 188
FIGURE 4-9. ENGINE (100KW - LS) 192
FIGURE 4-10. ENGINE MOUNT INSTALLATION 194
FIGURE 4-11. AIR INTAKE INSTALLATION (ULS) 196
FIGURE 4-12. AIR INTAKE INSTALLATION (LS) 198
FIGURE 4-13. AIR CLEANER INSTALLATION 200
FIGURE 4-14. AIR CLEANER ASSEMBLY (90/100KW) 202
FIGURE 4-15. AIR INTAKE DUCT INSTALLATION 204
FIGURE 4-16. PRIMARY FUEL FILTER INSTALLATION (ULS) 206
FIGURE 4-17. PRIMARY FUEL FILTER INSTALLATION (LS) 208
FIGURE 4-18. REMOTE FUEL PUMP INSTALLATION 210
FIGURE 4-19. FUEL LINES INSTALLATION 212
FIGURE 4-20. FUEL LINES INSTALLATION 214
FIGURE 4-21. FUEL LINES INSTALLATION 216
FIGURE 4-22. HYDROSTATIC ADAPTOR INSTALLATION 218
FIGURE 4-23. DUAL DRIVE SUPPORT ASSEMBLY 220
FIGURE 4-24. HYDROSTATIC DRIVE PUMP INSTALLATION 222
FIGURE 4-25. HYDROSTATIC DRIVE PUMP ASSEMBLY 224
FIGURE 4-26. IMPLEMENT PUMP INSTALLATION 226
FIGURE 4-27. IMPLEMENT PUMP ASSEMBLY 228
FIGURE 4-28. DEF COOLANT LINES INSTALLATION (ULS) 230
FIGURE 4-29. COOLING PACKAGE INSTALLATION 232
FIGURE 4-30. COOLING PACKAGE INSTALLATION (LS) 234
FIGURE 4-31. COOLING PACKAGE INSTALLATION (TUV) 236
FIGURE 4-32. COOLING PACKAGE INSTALLATION 238
FIGURE 4-33. RADIATOR COOLING PACKAGE 242
FIGURE 4-34. COOLANT LINES INSTALLATION 244
FIGURE 4-35. RADIATOR LINES INSTALLATION 246
FIGURE 4-36. CAC LINES INSTALLATION 248
FIGURE 4-37. SURGE TANK INSTALLATION 250
FIGURE 4-38. TRANSMISION OIL COOLER LINES INSTALLATION 252
FIGURE 4-39. TRANSMISION OIL COOLER LINES INSTALLATION (TUV) 254
FIGURE 4-40. FAN GUARD INSTALLATION 256
FIGURE 4-41. FAN GUARD (REVERSING) INSTALLATION 258
FIGURE 4-42. COOLING FAN INSTALLATION 260
FIGURE 4-43. REVERSE COOLING FAN INSTALLATION 262
FIGURE 4-44. COOLING FAN INSTALLATION 264
FIGURE 4-45. COMPRESSOR COVER INSTALLATION 266
FIGURE 4-46. EXHAUST INSTALLATION (ULS) 268
FIGURE 4-47. EXHAUST INSTALLATION (LS) 270
FIGURE 4-48. DEF CONTROL MODULE INSTALLATION 272
FIGURE 4-49. DEF LINES INSTALLATION 274

MidWestTech | JLG 7013H Boom Lift Parts Manual | Publication 31211279 Order the manual at mid-west-tech.com >

FIGURE 4-50. DEF TANK INSTALLATION 276
FIGURE 4-51. DEF TANK ASSEMBLY 278
FIGURE 4-52. MUFFLER INSTALLATION (LS) 280
FIGURE 4-53. MUFFLER INSTALLATION (LS) 282
FIGURE 4-54. HEATER LINES INSTALLATION (ULS) 284
FIGURE 4-55. HEATER LINES INSTALLATION (LS) 286
FIGURE 4-56. A/C PUMP INSTALLATION 288
FIGURE 4-57. A/C LINES INSTALLATION 290
FIGURE 4-58. BLOCK HEATER INSTALLATION (230V) (ULS) 292
FIGURE 4-59. BLOCK HEATER INSTALLATION (115V) (ULS) 294
FIGURE 4-60. BLOCK HEATER INSTALLATION (230V) (LS) 296
FIGURE 4-61. BLOCK HEATER INSTALLATION (115V) (LS) 298
FIGURE 4-62. AIR SHUT OFF VALVE 300
FIGURE 4-63. AIR SHUT OFF VALVE 302
FIGURE 4-64. HEATED BREATHER TUBE INSTALLATION 304

SECTION 5 - DRIVETRAIN 307

FIGURE 5-1. DRIVETRAIN INSTALLATION 308
FIGURE 5-2. FRONT AXLE INSTALLATION 310
FIGURE 5-3. FRONT AXLE MOUNTING INSTALLATION 312
FIGURE 5-4. FRONT AXLE LINES INSTALLATION 314
FIGURE 5-5. REAR AXLE INSTALLATION 316
FIGURE 5-6. REAR AXLE MOUNTING INSTALLATION 318
FIGURE 5-7. REAR AXLE LINES INSTALLATION 320
FIGURE 5-8. FRONT AXLE 322
FIGURE 5-9. FRONT AXLE, CENTRAL HOUSING 324
FIGURE 5-10. FRONT AXLE, DIFFERENTIAL 326
FIGURE 5-11. FRONT AXLE, HUB REDUCTION 328
FIGURE 5-12. FRONT AXLE, BRAKES 330
FIGURE 5-13. FRONT AXLE, STEERING 332
FIGURE 5-14. FRONT AXLE, TRUNION 334
FIGURE 5-15. REAR AXLE 336
FIGURE 5-16. REAR AXLE, CENTRAL HOUSING 338
FIGURE 5-17. REAR AXLE, DIFFERENTIAL 340
FIGURE 5-18. REAR AXLE, HUB REDUCTION 342
FIGURE 5-19. REAR AXLE, BRAKES 344
FIGURE 5-20. REAR AXLE, STEERING 346
FIGURE 5-21. REAR AXLE, TRUNION 348
FIGURE 5-22. DIFFERENTIAL KIT 350
FIGURE 5-23. DIFFERENTIAL KIT 352
FIGURE 5-24. STEERING CASE KIT (RF, LR) 354
FIGURE 5-25. STEERING CASE KIT (LF, RR) 356
FIGURE 5-26. TRUNION KIT 358
FIGURE 5-27. RING GEAR SUPPORT KIT 360
FIGURE 5-28. REDUCTION BUSHING KIT 362
FIGURE 5-29. PLANET GEAR CARRIER KIT 364
FIGURE 5-30. GEARBOX INSTALLATION 366
FIGURE 5-31. GEAR BOX 368
FIGURE 5-32. HYDROSTATIC MOTOR INSTALLATION 372
FIGURE 5-33. HYDROSTATIC MOTOR ASSEMBLY 374
FIGURE 5-34. DRIVE SHAFT INSTALLATION 376
FIGURE 5-35. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 378
FIGURE 5-36. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 380
FIGURE 5-37. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 382
FIGURE 5-38. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 384
FIGURE 5-39. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 386
FIGURE 5-40. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 388
FIGURE 5-41. TIRE/WHEEL SET (AIR 17.5-25 - 22 PLY) 390
FIGURE 5-42. TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - PLY) 392
FIGURE 5-43. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 394
FIGURE 5-44. FENDER INSTALLATION 396
FIGURE 5-45. RH FENDER ASSEMBLY 398
FIGURE 5-46. LH FENDER ASSEMBLY 400

SECTION 6 - CAB 403

MidWestTech | JLG 7013H Boom Lift Parts Manual | Publication 31211279 Order the manual at mid-west-tech.com >

FIGURE 4-3. ENGINE INSTALLATION (LS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001222454	Ref	Engine Installation (LS)	A
1	1001193393	Ref	Installation, Main Hydraulic Pump (See Separate Breakdown in Hydraulic Circuits Section)	
2	1001193703	Ref	Installation, Transmission Hydrostatic Adapter (See Separate Breakdown in this Section)	
3	1001193704	Ref	Installation, Transmission Hydrostatic Drive Pump (See Separate Breakdown in this Section)	
4	1001200862	Ref	Installation, Engine Mounting (See Separate Breakdown in this Section)	
5	1001200864	Ref	Installation, Air Cleaner (See Separate Breakdown in this Section)	
6	1001200869	Ref	Installation, Engine ECU (See Separate Breakdown in Electrical Section)	
7	1001209585	Ref	Engine (LS) (See Separate Breakdown in this Section)	
8	1001210600	Ref	Installation, Air Intake Lines (LS) (See Separate Breakdown in this Section)	
9	1001210602	Ref	Installation, Primary Fuel Filter (LS) (See Separate Breakdown in this Section)	
10	1001217752	Ref	Installation, Engine Wiring (LS) (See Separate Breakdown in Electrical Section)	
11	1001221041	Ref	Installation, Remote Fuel Pump (See Separate Breakdown in this Section)	
12	1001222163	Ref	Installation, Fuel Lines (See Separate Breakdown in this Section)	

MidWestTech | JLG 7013H Boom Lift Parts Manual | Publication 31211279 Order the manual at mid-west-tech.com >

FIGURE 4-46. EXHAUST INSTALLATION (ULS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001200447	Ref	Exhaust Installation (ULS)	I
1	0700610	1	Bolt, M6X20	
2	0700614	2	Bolt, M6X30	
3	0700814	2	Bolt, M8X30	
4	0701014	6	Bolt, M10X30	
5	0760607	4	Bolt, M6X14	
6	0760812	8	Bolt, M8X25	
7	0761010	2	Bolt, M10X20	
9	0761214	4	Bolt, M12X30	
11	4811700	1	Washer, M6	
12	4811900	8	Washer, M8	
13	4812000	12	Washer, M10	
14	4812100	4	Washer, M12	
15	8275212	2	Clamp	
16	24921332	2	Clamp	
17	77213042	1	Tube, Flexible	
18	91163268	2	Clamp	
19	1001146588	3	Strap, Tie	
20	1001212923	Ref	Installation, DEF Tank, (See Separate Breakdown in this Section)	
21	1001171913	1	Cap	
23	1001199902	1	Pipe	
24	1001200249	1	Pipe	
25	1001200867	Ref	Installation, DEF Lines (See Separate Breakdown in this Section)	
26	1001201856	1	Bracket	
27	1001201857	1	Bracket	
28	1001201858	1	Support	
29	1001202018	Ref	Installation, DEF Control Module (See Separate Breakdown in this Section)	
30	1001202021	1	Plate	
31	1001202899	1	Bracket	
32	1001204411	1	Pipe	
33	1001226797	1	Pipe, Tail	
34	1001204413	1	Bracket	
35	1001204414	1	Bracket	
36	4811902	2	Washer, M8	
37	0760612	4	Bolt, M6X25	
38	3290605	4	Nut, M6X1	

MidWestTech | JLG 7013H Boom Lift Parts Manual | Publication 31211279 Order the manual at mid-west-tech.com >

FIGURE 10-66. ENGINE HARNESS, (LS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001217751	Ref	Engine Harness, (LS)	A
1	1001126360	1	Connector	
2	1001126357	11	Plug	
3	1001126351	13	Terminal	
4	1001126356	19	Plug	
5	1001126384	17	Terminal	
6	1001126362	1	Connector	
7	1001166556	24	Terminal	
8	1001166701	24	Terminal Seal	
9	1001126391	22	Plug	
10	1001166774	10	Terminal	
11	1001126393	10	Terminal Seal	
12	4461008	4	Plug	
13	1001166543	2	Terminal	
14	4461054	2	Terminal Seal	
15	1001138110	1	Connector	
16	1001138111	2	Terminal	
17	1001138113	2	Terminal Seal	
18	1001148842	1	Connector	
19	1001148841	3	Terminal	
20	1001135650	3	Terminal Seal	
21	1001135651	1	Plug	
22	1001116812	1	Connector	
23	4460944	2	Terminal	
24	4460466	1	Plug	
25	4460539	1	Connector	
26	4460944	2	Terminal	
27	4460466	1	Plug	
28	1001126349	1	Connector	
29	1001126352	6	Terminal	
30	1001126353	6	Terminal Seal	
31	1001126357	2	Plug	
32	1001126356	65	Plug	
33	1001126384	21	Terminal	
34	1001133714	1	Connector	
35	1001133715	3	Terminal	
36	1001135650	3	Terminal Seal	
37	1001135651	1	Plug	
38	1001187070	1	Ring Terminal	
39	1001187078	1	Ring Terminal	
40	1001116812	1	Connector	
41	4460944	2	Terminal	
42	4460466	1	Plug	
43	1001117068	1	Connector	
44	8220124	2	Terminal	
45	4460608	2	Terminal Seal	
46	4460539	1	Connector	
47	4460944	2	Terminal	
48	4460466	1	Plug	
49	4460539	1	Connector	

MidWestTech | JLG 7013H Boom Lift Parts Manual | Publication 31211279 Order the manual at mid-west-tech.com >