Illustrated Parts Manual

Models

1732

SN 0160000001 to SN 0160100939

P/N
31211280

Revised
May 22, 2020 - Rev E

An Oshkosh Corporation Company

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211280

Order the manual at mid-west-tech.com >

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. FRAME WELDMENT 16
FIGURE 1-2. GROMMETS INSTALLATION 18
FIGURE 1-3. TANK INSTALLATION 20
FIGURE 1-4. FUEL TANK INSTALLATION 22
FIGURE 1-5. HYDRAULIC TANK INSTALLATION 24
FIGURE 1-6. TANK SUPPORT INSTALLATION 26
FIGURE 1-7. FUEL TANK ASSEMBLY 28
FIGURE 1-8. LOCKING FUEL CAP 30
FIGURE 1-9. HYDRAULIC TANK ASSEMBLY 32
FIGURE 1-10. COUNTERWEIGHT INSTALLATION 34
FIGURE 1-11. ENGINE ENCLOSURE INSTALLATION 36
FIGURE 1-12. ENGINE ENCLOSURE ASSEMBLY 38
FIGURE 1-13. HOOD ASSEMBLY 40
FIGURE 1-14. HOOD ASSEMBLY 42
FIGURE 1-15. COVER INSTALLATION (ULS) 44
FIGURE 1-16. FRAME COVER INSTALLATION 46
FIGURE 1-17. MIRROR INSTALLATION 48

SECTION 2 - BOOM 51

FIGURE 2-1. BOOM INSTALLATION 52
FIGURE 2-2. BOOM ASSEMBLY 54
FIGURE 2-3. FIRST BOOM SECTION ASSEMBLY 56
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 58
FIGURE 2-5. COUPLER INSTALLATION (MANUAL) 60
FIGURE 2-6. COUPLER INSTALLATION (HYDRAULIC) 62
FIGURE 2-7. COUPLER LOCKING CYLINDER ASSEMBLY 64
FIGURE 2-8. MANUAL COUPLER PIN HOLDER INSTALLATION 66
FIGURE 2-9. BOOM BRUSHES INSTALLATION 68
FIGURE 2-10. BOOM PROP INSTALLATION 70
FIGURE 2-11. BOOM PROP BRACKET ASSEMBLY 72

SECTION 3 - ATTACHMENTS 75

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION 76
FIGURE 3-2. COMPONENTS ATTACHMENT RECOGNITION INSTALLATION 78
FIGURE 3-3. CARRIAGE ASSEMBLY, (60IN/1524MM) 80
FIGURE 3-4. CARRIAGE ASSEMBLY, (72IN/1829MM) 82
FIGURE 3-5. CARRIAGE ASSEMBLY, (87IN/2290MM) 84
FIGURE 3-6. DUAL FORK POSITIONING SIDE SHIFT CARRIAGE, (75IN/1899MM) 86
FIGURE 3-7. DUAL FORK POSITIONING CARRIAGE, (72IN/1829MM) 88
FIGURE 3-8. BUCKET (2.6 YD^3/2.0M^3) 90
FIGURE 3-9. BUCKET (5.23 YD3) 92
FIGURE 3-10. 4 IN 1 BUCKET (2.6 YD^3/2.0M^3) 94
FIGURE 3-11. 4 IN 1 BUCKET (1.3 YD^3/1.0M^3) 96
FIGURE 3-12. GRAPPLE BUCKET (1.7 YD^3/1.3M^3) 98
FIGURE 3-13. GRAPPLE BUCKET (2.6 YD^3/2.0M^3) 100
FIGURE 3-14. TRUSS BOOM (7.6 TON) 102
FIGURE 3-15. CRANE HOOK (7.6 TON) 104
FIGURE 3-16. BALE HANDLER (ROUND) 106
FIGURE 3-17. BALE HANDLER (SQUARE) 110
FIGURE 3-18. PIPE HANDLER CARRIAGE 112
FIGURE 3-19. TIRE HANDLER CARRIAGE 116
FIGURE 3-20. LOG HANDLER CARRIAGE 118
FIGURE 3-21. STEEL COIL HANDLER CARRIAGE 122
FIGURE 3-22. PALLET FORK (2.25X6X48) 124
FIGURE 3-23. PALLET FORK (2.25X6X60) 126
FIGURE 3-24. PALLET FORK (2.25X6X72) 128
FIGURE 3-25. PALLET FORK (2.25X6X96) 130
FIGURE 3-26. FORK RETENTION INSTALLATION 132
FIGURE 3-27. HOOK ATTACH, FORK MOUNTED 134

SECTION 4 - ENGINE AND ATTACHING PARTS 137

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211280 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS) 138
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS) 140
FIGURE 4-3. ENGINE INSTALLATION (ULS) 142
FIGURE 4-4. ENGINE (100KW - ULS) 144
FIGURE 4-5. ENGINE MOUNT INSTALLATION 148
FIGURE 4-6. AIR INTAKE INSTALLATION (ULS) 150
FIGURE 4-7. AIR CLEANER INSTALLATION 152
FIGURE 4-8. PRIMARY FUEL FILTER INSTALLATION (ULS) 154
FIGURE 4-9. REMOTE FUEL PUMP INSTALLATION 156
FIGURE 4-10. FUEL LINES INSTALLATION 158
FIGURE 4-11. HYDROSTATIC ADAPTOR INSTALLATION 160
FIGURE 4-12. DUAL DRIVE SUPPORT ASSEMBLY 162
FIGURE 4-13. HYDROSTATIC DRIVE PUMP INSTALLATION 164
FIGURE 4-14. HYDROSTATIC DRIVE PUMP ASSEMBLY 166
FIGURE 4-15. IMPLEMENT PUMP INSTALLATION 168
FIGURE 4-16. IMPLEMENT PUMP ASSEMBLY 170
FIGURE 4-17. DEF COOLANT LINES INSTALLATION (ULS) 172
FIGURE 4-18. COOLING PACKAGE INSTALLATION 174
FIGURE 4-19. COOLING PACKAGE INSTALLATION 176
FIGURE 4-20. RADIATOR 180
FIGURE 4-21. COOLANT LINES INSTALLATION 182
FIGURE 4-22. RADIATOR LINES INSTALLATION 184
FIGURE 4-23. SURGE TANK INSTALLATION 186
FIGURE 4-24. TRANSMISION OIL COOLER LINES INSTALLATION 188
FIGURE 4-25. FAN GUARD INSTALLATION 190
FIGURE 4-26. FAN GUARD (REVERSING) INSTALLATION 192
FIGURE 4-27. COOLING FAN INSTALLATION 194
FIGURE 4-28. REVERSE COOLING FAN INSTALLATION 196
FIGURE 4-29. COMPRESSOR COVER INSTALLATION 198
FIGURE 4-30. EXHAUST INSTALLATION (ULS) 200
FIGURE 4-31. DEF CONTROL MODULE INSTALLATION 202
FIGURE 4-32. DEF LINES INSTALLATION 204
FIGURE 4-33. DEF TANK INSTALLATION 206
FIGURE 4-34. DEF TANK ASSEMBLY 208
FIGURE 4-35. HEATER LINES INSTALLATION (ULS) 210
FIGURE 4-36. A/C PUMP INSTALLATION 212
FIGURE 4-37. A/C LINES INSTALLATION 214
FIGURE 4-38. BLOCK HEATER INSTALLATION (115V) (ULS) 216
FIGURE 4-39. HEATED BREATHER TUBE INSTALLATION 218
FIGURE 4-40. RADIATOR LINES INSTALLATION 220

SECTION 5 - DRIVETRAIN 223

FIGURE 5-1. DRIVETRAIN INSTALLATION 224
FIGURE 5-2. FRONT AXLE INSTALLATION 226
FIGURE 5-3. FRONT AXLE MOUNTING INSTALLATION 228
FIGURE 5-4. FRONT AXLE LINES INSTALLATION 230
FIGURE 5-5. REAR AXLE INSTALLATION 232
FIGURE 5-6. REAR AXLE MOUNTING INSTALLATION 234
FIGURE 5-7. REAR AXLE LINES INSTALLATION 236
FIGURE 5-8. FRONT AXLE 238
FIGURE 5-9. FRONT AXLE, CENTRAL HOUSING 240
FIGURE 5-10. FRONT AXLE, DIFFERENTIAL 242
FIGURE 5-11. FRONT AXLE, HUB REDUCTION 244
FIGURE 5-12. FRONT AXLE, BRAKES 246
FIGURE 5-13. FRONT AXLE, STEERING 248
FIGURE 5-14. FRONT AXLE, TRUNION 250
FIGURE 5-15. REAR AXLE 252
FIGURE 5-16. REAR AXLE, CENTRAL HOUSING 254
FIGURE 5-17. REAR AXLE, DIFFERENTIAL 256
FIGURE 5-18. REAR AXLE, HUB REDUCTION 258
FIGURE 5-19. REAR AXLE, BRAKES 260
FIGURE 5-20. REAR AXLE, STEERING 262
FIGURE 5-21. REAR AXLE, TRUNION 264
FIGURE 5-22. DIFFERENTIAL KIT 266
FIGURE 5-23. DIFFERENTIAL KIT 268
FIGURE 5-24. STEERING CASE KIT (RF, LR) 270

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211280 Order the manual at mid-west-tech.com >

FIGURE 5-25. STEERING CASE KIT (LF, RR) 272
FIGURE 5-26. TRUNION KIT 274
FIGURE 5-27. RING GEAR SUPPORT KIT 276
FIGURE 5-28. REDUCTION BUSHING KIT 278
FIGURE 5-29. PLANET GEAR CARRIER KIT 280
FIGURE 5-30. RALP INSTALLATION 282
FIGURE 5-31. RALP MECHANICAL INSTALLATION 284
FIGURE 5-32. GEARBOX INSTALLATION 286
FIGURE 5-33. GEAR BOX 288
FIGURE 5-34. HYDROSTATIC MOTOR INSTALLATION 292
FIGURE 5-35. HYDROSTATIC MOTOR ASSEMBLY 294
FIGURE 5-36. DRIVE SHAFT INSTALLATION 296
FIGURE 5-37. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 298
FIGURE 5-38. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 300
FIGURE 5-39. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 302
FIGURE 5-40. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 304
FIGURE 5-41. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 306
FIGURE 5-42. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 308
FIGURE 5-43. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 310
FIGURE 5-44. FENDER INSTALLATION 312
FIGURE 5-45. RH FENDER ASSEMBLY 314
FIGURE 5-46. LH FENDER ASSEMBLY 316

SECTION 6 - CAB 319

FIGURE 6-1. CAB MOUNTING INSTALLATION 320
FIGURE 6-2. FRONT CAB MOUNT BRACKET INSTALLATION 322
FIGURE 6-3. CAB MOUNTS INSTALLATION 324
FIGURE 6-4. CAB COMPONENTS INSTALLATION 326
FIGURE 6-5. CAB INSTALLATION 328
FIGURE 6-6. CAB ASSEMBLY 330
FIGURE 6-7. DOOR INSTALLATION 332
FIGURE 6-8. DOOR ASSEMBLY 334
FIGURE 6-9. DOOR UPPER GLASS ASSEMBLY 336
FIGURE 6-10. CAB LATCH ASSEMBLY 338
FIGURE 6-11. CAB DOOR TRIGGER ASSEMBLY 340
FIGURE 6-12. DOOR STRAP INSTALLATION 342
FIGURE 6-13. REAR WINDOW INSTALLATION 344
FIGURE 6-14. REAR WINDOW GROUP 346
FIGURE 6-15. CAB PLUG GROUP 348
FIGURE 6-16. BASIC MIRROR INSTALLATION 350
FIGURE 6-17. INTERIOR MIRROR INSTALLATION 352
FIGURE 6-18. INTERIOR MIRROR 354
FIGURE 6-19. FRONT WIPER INSTALLATION 356
FIGURE 6-20. WASHER TANK INSTALLATION 358
FIGURE 6-21. WASHER BOTTLE 360
FIGURE 6-22. FRONT COVER INSTALLATION 362
FIGURE 6-23. FRONT DUCT COVER 364
FIGURE 6-24. FILTER TRAY PANEL 366
FIGURE 6-25. LEVEL INDICATOR INSTALLATION 368
FIGURE 6-26. REAR WIPER INSTALLATION 370
FIGURE 6-27. MULTIFUNCTION DISPLAY INSTALLATION 372
FIGURE 6-28. SEAT INSTALLATION (CLOTH) 374
FIGURE 6-29. SEAT ASSEMBLY 376
FIGURE 6-30. SEAT INSTALLATION (AIR SUSPENSION - STANDARD) 378
FIGURE 6-31. SEAT ASSEMBLY (AIR SUSPENSION - STANDARD) 380
FIGURE 6-32. SEAT INSTALLATION (AIR SUSPENSION - PREMIUM) 382
FIGURE 6-33. SEAT ASSEMBLY (AIR SUSPENSION - PREMIUM) 384
FIGURE 6-34. HEATER INSTALLATION 386
FIGURE 6-35. HEATER AND A/C INSTALLATION (CAB PARTS) 388
FIGURE 6-36. CAB CONDENSER ASSEMBLY 392
FIGURE 6-37. CONDENSER 394
FIGURE 6-38. A/C RECEIVER DRIER 396
FIGURE 6-39. HEATER ASSEMBLY 398
FIGURE 6-40. HEATER AND A/C ASSEMBLY 400
FIGURE 6-41. HVAC CAB ACTUATOR 402
FIGURE 6-42. HEATER 404

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211280 Order the manual at mid-west-tech.com >

FIGURE 6-48. CAB TRIM INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001195816	Ref	Cab Trim Installation	I
1	3290605	2	Nut, Lock M6X1	
2	4031608001	3	Screw, M5X20	
3	4811600	1	Washer, M5	
4	4811700001	23	Washer, M6	
5	4811702001	7	Washer, M6	
7	8305919	2	Nut, M6	
8	8405201	2	Clamp	
9	1001147449	2	Vent	
10	1001149278	2	Connector, Vent	
11	1001161252	1	Cover, LH C-Post	
12	1001161253	1	Cover, RH C-Post	
13	1001219864	1	Plate, Switch	
14	1001219865	1	Plate, Switch	
15	1001169603	1	Tray	
16	1001169604	1	Assembly, Dash Cover (See Separate Breakdown in this Section)	
17	1001161855	1	Cover, Side Dash	
18	1001170504	1	Cover, Recirculation Grille	
19	1001170518	1	Holder, Cup	
20	1001170519	1	Assembly, Rear Panel Cover (See Separate Breakdown in this Section)	
21	1001173965	1	Bezel, Net	
22	1001175903	1	Cover, Lower Dash	
23	1001219863	1	Plate, Switch	
24	1001181726	1	Installation, Armrest (See Separate Breakdown in this Section)	
25	1001184975	1	Decal, HVAC	
26	1001185870	1	Cover, Lower A-Post	
27	1001189182	1	Cover, RH Side	
28	1001223265	2	Grommet	
29	1001195817	1	Cover, RH Extension	
30	1001195818	1	Panel, LH Side	
31	4010608002	26	Screw, M6X16	
32	4010610002	1	Screw, M6X20	
33	4010612002	3	Screw, M6X25	
34	1001211907	2	Screw	
35	1001208308	4	Thumb Screw, M6X15	
36	1001226481	1	Decal, Blank	
37	1001098150	1	Washer, M6	
38	1001132564	1	Screw, M6X20	
39	1001227133	2	Grommet	

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211280 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
153	1001176004	2	Terminal	
154	1001176002	2	Terminal Seal	
155	1001167624	2	Plug	
156	1001116812	1	Connector	
157	4460944	2	Terminal	
158	4460466	1	Plug	
159	4460539	1	Connector	
160	4460944	2	Terminal	
161	4460466	1	Plug	
162	4460891	1	Connector	
163	4460897	1	Mating Connector	
164	4460466	1	Plug	
165	4460465	2	Terminal	
166	4460539	1	Connector	
167	4460944	2	Terminal	
168	4460466	1	Plug	
169	1001116812	1	Connector	
170	4460944	2	Terminal	
171	4460466	1	Plug	
172	1001116812	1	Connector	
173	4460944	2	Terminal	
174	4460466	1	Plug	
175	4460539	1	Connector	
176	4460944	2	Terminal	
177	4460466	1	Plug	

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211280 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
54	1001231404	4	Seal	
55	1001231406	1	Plug	
56	1001231398	1	Connector	
57	1001231401	2	Terminal	
58	1001231402	2	Seal	
59	1001231400	2	Terminal	
60	1001231404	2	Seal	
61	1001231406	1	Plug	
62	1001231397	1	Connector	
63	8229234	1	Fuse, 20amp	
64	1001231400	2	Terminal	
65	1001230403	1	Seal	
66	1001230404	1	Seal	

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211280 Order the manual at mid-west-tech.com >