Illustrated Parts Manual

Models

1644

SN 0160000001 to SN 0160100942

P/N
31211281

Revised
May 22, 2020 - Rev E

An Oshkosh Corporation Company

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211281

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. FRAME WELDMENT 16
FIGURE 1-2. GROMMETS INSTALLATION 18
FIGURE 1-3. TANK INSTALLATION 20
FIGURE 1-4. FUEL TANK INSTALLATION 22
FIGURE 1-5. HYDRAULIC TANK INSTALLATION 24
FIGURE 1-6. TANK SUPPORT INSTALLATION 26
FIGURE 1-7. FUEL TANK ASSEMBLY 28
FIGURE 1-8. LOCKING FUEL CAP 30
FIGURE 1-9. HYDRAULIC TANK ASSEMBLY 32
FIGURE 1-10. COUNTERWEIGHT INSTALLATION 34
FIGURE 1-11. ENGINE ENCLOSURE INSTALLATION 36
FIGURE 1-12. ENGINE ENCLOSURE ASSEMBLY 38
FIGURE 1-13. HOOD ASSEMBLY 40
FIGURE 1-14. HOOD ASSEMBLY 42
FIGURE 1-15. COVER INSTALLATION (ULS) 44
FIGURE 1-16. FRAME COVER INSTALLATION 46
FIGURE 1-17. MIRROR INSTALLATION 48

SECTION 2 - BOOM 51

FIGURE 2-1. BOOM INSTALLATION 52
FIGURE 2-2. BOOM ASSEMBLY 54
FIGURE 2-3. FIRST BOOM SECTION ASSEMBLY 56
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 58
FIGURE 2-5. THIRD BOOM SECTION ASSEMBLY 60
FIGURE 2-6. COUPLER INSTALLATION (MANUAL) 62
FIGURE 2-7. COUPLER INSTALLATION (HYDRAULIC) 64
FIGURE 2-8. COUPLER LOCKING CYLINDER ASSEMBLY 66
FIGURE 2-9. MANUAL COUPLER PIN HOLDER INSTALLATION 68
FIGURE 2-10. BOOM BRUSHES INSTALLATION 70
FIGURE 2-11. BOOM PROP BRACKET ASSEMBLY 72

SECTION 3 - ATTACHMENTS 75

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION 76
FIGURE 3-2. COMPONENTS ATTACHMENT RECOGNITION INSTALLATION 78
FIGURE 3-3. CARRIAGE ASSEMBLY, (60IN/1524MM) 80
FIGURE 3-4. CARRIAGE ASSEMBLY, (72IN/1829MM) 82
FIGURE 3-5. CARRIAGE ASSEMBLY, (87IN/2290MM) 84
FIGURE 3-6. DUAL FORK POSITIONING SIDE SHIFT CARRIAGE, (75IN/1899MM) 86
FIGURE 3-7. DUAL FORK POSITIONING CARRIAGE, (72IN/1829MM) 88
FIGURE 3-8. BUCKET (2.6 YD^3/2.0M^3) 90
FIGURE 3-9. BUCKET (5.23 YD3) 92
FIGURE 3-10. 4 IN 1 BUCKET (1.3 YD^3/1.0M^3) 94
FIGURE 3-11. GRAPPLE BUCKET (1.7 YD^3/1.3M^3) 96
FIGURE 3-12. TRUSS BOOM (7.6 TON) 98
FIGURE 3-13. CRANE HOOK (7.6 TON) 100
FIGURE 3-14. BALE HANDLER (ROUND) 102
FIGURE 3-15. BALE HANDLER (SQUARE) 106
FIGURE 3-16. PIPE HANDLER CARRIAGE 108
FIGURE 3-17. LOG HANDLER CARRIAGE 112
FIGURE 3-18. STEEL COIL HANDLER CARRIAGE 116
FIGURE 3-19. PALLET FORK (2.25X6X48) 118
FIGURE 3-20. PALLET FORK (2.25X6X60) 120
FIGURE 3-21. PALLET FORK (2.25X6X72) 122
FIGURE 3-22. PALLET FORK (2.25X6X96) 124
FIGURE 3-23. FORK RETENTION INSTALLATION 126
FIGURE 3-24. HOOK ATTACH, FORK MOUNTED 128

SECTION 4 - ENGINE AND ATTACHING PARTS 131

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS) 132
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS) 134
FIGURE 4-3. ENGINE INSTALLATION (ULS) 136

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211281 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 4-4. ENGINE (100KW - ULS) 138
FIGURE 4-5. ENGINE MOUNT INSTALLATION 142
FIGURE 4-6. AIR INTAKE INSTALLATION (ULS) 144
FIGURE 4-7. AIR CLEANER INSTALLATION 146
FIGURE 4-8. PRIMARY FUEL FILTER INSTALLATION (ULS) 148
FIGURE 4-9. REMOTE FUEL PUMP INSTALLATION 150
FIGURE 4-10. FUEL LINES INSTALLATION 152
FIGURE 4-11. HYDROSTATIC ADAPTOR INSTALLATION 154
FIGURE 4-12. DUAL DRIVE SUPPORT ASSEMBLY 156
FIGURE 4-13. HYDROSTATIC DRIVE PUMP INSTALLATION 158
FIGURE 4-14. HYDROSTATIC DRIVE PUMP ASSEMBLY 160
FIGURE 4-15. IMPLEMENT PUMP INSTALLATION 162
FIGURE 4-16. IMPLEMENT PUMP ASSEMBLY 164
FIGURE 4-17. DEF COOLANT LINES INSTALLATION (ULS) 166
FIGURE 4-18. COOLING PACKAGE INSTALLATION 168
FIGURE 4-19. COOLING PACKAGE INSTALLATION 170
FIGURE 4-20. RADIATOR 174
FIGURE 4-21. COOLANT LINES INSTALLATION 176
FIGURE 4-22. RADIATOR LINES INSTALLATION 178
FIGURE 4-23. SURGE TANK INSTALLATION 180
FIGURE 4-24. TRANSMISION OIL COOLER LINES INSTALLATION 182
FIGURE 4-25. FAN GUARD INSTALLATION 184
FIGURE 4-26. FAN GUARD (REVERSING) INSTALLATION 186
FIGURE 4-27. COOLING FAN INSTALLATION 188
FIGURE 4-28. REVERSE COOLING FAN INSTALLATION 190
FIGURE 4-29. COMPRESSOR COVER INSTALLATION 192
FIGURE 4-30. EXHAUST INSTALLATION (ULS) 194
FIGURE 4-31. DEF CONTROL MODULE INSTALLATION 196
FIGURE 4-32. DEF LINES INSTALLATION 198
FIGURE 4-33. DEF TANK INSTALLATION 200
FIGURE 4-34. DEF TANK ASSEMBLY 202
FIGURE 4-35. HEATER LINES INSTALLATION (ULS) 204
FIGURE 4-36. A/C PUMP INSTALLATION 206
FIGURE 4-37. A/C LINES INSTALLATION 208
FIGURE 4-38. BLOCK HEATER INSTALLATION (115V) (ULS) 210
FIGURE 4-39. HEATED BREATHER TUBE INSTALLATION 212

SECTION 5 - DRIVETRAIN 215

FIGURE 5-1. DRIVETRAIN INSTALLATION 216
FIGURE 5-2. FRONT AXLE INSTALLATION 218
FIGURE 5-3. FRONT AXLE MOUNTING INSTALLATION 220
FIGURE 5-4. FRONT AXLE LINES INSTALLATION 222
FIGURE 5-5. REAR AXLE INSTALLATION 224
FIGURE 5-6. REAR AXLE MOUNTING INSTALLATION 226
FIGURE 5-7. REAR AXLE LINES INSTALLATION 228
FIGURE 5-8. FRONT AXLE 230
FIGURE 5-9. FRONT AXLE, CENTRAL HOUSING 232
FIGURE 5-10. FRONT AXLE, DIFFERENTIAL 234
FIGURE 5-11. FRONT AXLE, HUB REDUCTION 236
FIGURE 5-12. FRONT AXLE, BRAKES 238
FIGURE 5-13. FRONT AXLE, STEERING 240
FIGURE 5-14. FRONT AXLE, TRUNION 242
FIGURE 5-15. REAR AXLE 244
FIGURE 5-16. REAR AXLE, CENTRAL HOUSING 246
FIGURE 5-17. REAR AXLE, DIFFERENTIAL 248
FIGURE 5-18. REAR AXLE, HUB REDUCTION 250
FIGURE 5-19. REAR AXLE, BRAKES 252
FIGURE 5-20. REAR AXLE, STEERING 254
FIGURE 5-21. REAR AXLE, TRUNION 256
FIGURE 5-22. DIFFERENTIAL KIT 258
FIGURE 5-23. DIFFERENTIAL KIT 260
FIGURE 5-24. STEERING CASE KIT (RF, LR) 262
FIGURE 5-25. STEERING CASE KIT (LF, RR) 264
FIGURE 5-26. TRUNION KIT 266
FIGURE 5-27. RING GEAR SUPPORT KIT 268
FIGURE 5-28. REDUCTION BUSHING KIT 270

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211281 Order the manual at mid-west-tech.com >

FIGURE 5-29. PLANET GEAR CARRIER KIT 272
FIGURE 5-30. RALP INSTALLATION 274
FIGURE 5-31. RALP MECHANICAL INSTALLATION 276
FIGURE 5-32. GEARBOX INSTALLATION 278
FIGURE 5-33. GEAR BOX 280
FIGURE 5-34. HYDROSTATIC MOTOR INSTALLATION 284
FIGURE 5-35. HYDROSTATIC MOTOR ASSEMBLY 286
FIGURE 5-36. DRIVE SHAFT INSTALLATION 288
FIGURE 5-37. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 290
FIGURE 5-38. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 292
FIGURE 5-39. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 294
FIGURE 5-40. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 296
FIGURE 5-41. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 298
FIGURE 5-42. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 300
FIGURE 5-43. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 302
FIGURE 5-44. FENDER INSTALLATION 304
FIGURE 5-45. RH FENDER ASSEMBLY 306
FIGURE 5-46. LH FENDER ASSEMBLY 308

SECTION 6 - CAB 311

FIGURE 6-1. CAB MOUNTING INSTALLATION 312
FIGURE 6-2. FRONT CAB MOUNT BRACKET INSTALLATION 314
FIGURE 6-3. CAB MOUNTS INSTALLATION 316
FIGURE 6-4. CAB COMPONENTS INSTALLATION 318
FIGURE 6-5. CAB INSTALLATION 320
FIGURE 6-6. CAB ASSEMBLY 322
FIGURE 6-7. CAB DOOR INSTALLATION 324
FIGURE 6-8. CAB DOOR ASSEMBLY 326
FIGURE 6-9. CAB DOOR WINDOW INSTALLATION 328
FIGURE 6-10. CAB LATCH ASSEMBLY 330
FIGURE 6-11. CAB DOOR TRIGGER ASSEMBLY 332
FIGURE 6-12. DOOR STRAP INSTALLATION 334
FIGURE 6-13. REAR WINDOW INSTALLATION 336
FIGURE 6-14. REAR WINDOW GROUP 338
FIGURE 6-15. CAB PLUG GROUP 340
FIGURE 6-16. BASIC MIRROR INSTALLATION 342
FIGURE 6-17. INTERIOR MIRROR INSTALLATION 344
FIGURE 6-18. INTERIOR MIRROR 346
FIGURE 6-19. FRONT WIPER INSTALLATION 348
FIGURE 6-20. WASHER TANK INSTALLATION 350
FIGURE 6-21. WASHER BOTTLE 352
FIGURE 6-22. FRONT COVER INSTALLATION 354
FIGURE 6-23. FRONT DUCT COVER 356
FIGURE 6-24. FILTER TRAY PANEL 358
FIGURE 6-25. LEVEL INDICATOR INSTALLATION 360
FIGURE 6-26. REAR WIPER INSTALLATION 362
FIGURE 6-27. MULTIFUNCTION DISPLAY INSTALLATION 364
FIGURE 6-28. SEAT INSTALLATION (MECHANICAL) 366
FIGURE 6-29. SEAT ASSEMBLY (MECHANICAL) 368
FIGURE 6-30. SEAT INSTALLATION (AIR SUSPENSION - STANDARD) 370
FIGURE 6-31. SEAT ASSEMBLY (AIR SUSPENSION - STANDARD) 372
FIGURE 6-32. SEAT INSTALLATION (AIR SUSPENSION - PREMIUM) 374
FIGURE 6-33. SEAT ASSEMBLY (AIR SUSPENSION - PREMIUM) 376
FIGURE 6-34. HEATER INSTALLATION (CAB PARTS) 378
FIGURE 6-35. HEATER AND A/C INSTALLATION (CAB PARTS) 380
FIGURE 6-36. CAB CONDENSER ASSEMBLY 384
FIGURE 6-37. CONDENSER 386
FIGURE 6-38. A/C RECEIVER DRIER 388
FIGURE 6-39. HEATER ASSEMBLY 390
FIGURE 6-40. HEATER AND A/C ASSEMBLY 392
FIGURE 6-41. HVAC CAB ACTUATOR 394
FIGURE 6-42. HEATER 396
FIGURE 6-43. HEATER 398
FIGURE 6-44. HEATER AND A/C 400
FIGURE 6-45. ROOF WIPER INSTALLATION 402
FIGURE 6-46. HEADLINER INSTALLATION 404

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211281 Order the manual at mid-west-tech.com >

FIGURE 6-4. CAB COMPONENTS INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001194698	Ref	Cab Components Installation	F
1	1001155447	Ref	Installation, Front Wiper (See Separate Breakdown in this Section)	
2	1001160508	Ref	Installation, Basic Mirror (See Separate Breakdown in this Section)	
3	1001161499	Ref	Installation, Accelerator Pedal (See Separate Breakdown in CONTROLS Section)	
4	1001162789	Ref	Installation, Washer Tank (See Separate Breakdown in this Section)	
6	1001170366	Ref	Installation, Front Cover (See Separate Breakdown in this Section)	
7	1001172401	Ref	Installation, Level Indicator (See Separate Breakdown in this Section)	
8	1001194699	Ref	Installation, Cab (See Separate Breakdown in this Section)	
9	1001220329	Ref	Installation, Rear Wiper (See Separate Breakdown in this Section)	

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211281 Order the manual at mid-west-tech.com >

FIGURE 8-25. CAB HYDRAULICS INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001193709	Ref	Cab Hydraulics Installation	I
3	4240018	3	Strap, Cable	
5	8405006	1	Clamp	
8	1001215256	1	Fitting, Cross Barb	
15	88662434	2	Fitting, Tee ORFS	
22	1001210800	1	Hose	
23	1001221989	1	Hose	
24	1001210327	1	Hose	
26	1001196989	1	Hose	
27	1001206709	1	Hose	
28	1001210282	1	Hose	
29	1001196992	1	Hose	
30	1001196993	1	Hose	
32	1001196995	1	Hose	
33	1001196996	1	Hose	
34	1001196997	1	Hose	
36	4240099	3	Tie, Wire	
40	0760807	2	Bolt, M8X14	
41	4811900	2	Washer, M8	
42	8410013	7	Clamp	
44	85941018	1	Clamp	
45	8430032	1	Plug	
46	8430081	1	Fitting, Straight ORFS	
47	1001212787	1	Hose	
48	1001212788	Ref	Installation, Check Valve (See Separate Breakdown in this Section)	
49	1001212880	1	Hose	
50	8406201	1	Clip	
52	90206198	186 mm	Compound, Locking	
53	1001221987	Ref	Installation, Solenoid Valve (See Separate Breakdown in this Section)	
54	1001221988	1	Hose	
57	2720160	2290 mm	Hose	
58	1001008654	750 mm	Hose	

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211281 Order the manual at mid-west-tech.com >

FIGURE 10-92. AIR SHUT OFF VALVE HARNESS (ENGINE)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001231483	Ref	Air Shut Off Valve Harness (Engine)	D
1	1001187079	1	Terminal, Ring	
2	1001231397	1	Connector	
3	8229235	1	Fuse, 20amp	
4	1001231401	2	Terminal	
5	1001230402	2	Seal	
10	1001187078	1	Terminal, Ring	
11	1001231397	1	Connector	
12	8229261	1	Fuse, 20amp	
13	1001231400	2	Terminal	
14	1001230403	2	Seal	
15	1001116812	1	Connector	
16	4460465	2	Terminal	
17	4460466	1	Plug	
18	4460884	1	Connector	
19	4460465	4	Terminal	
20	1001187079	1	Terminal, Ring	
21	1001144147	1	Connector	
22	4460464	2	Terminal	
23	4460466	1	Plug	
24	1001116812	1	Connector	
25	4460465	2	Terminal	
26	4460466	1	Plug	
27	1001116812	1	Connector	
28	4460465	2	Terminal	
29	4460466	1	Plug	
30	4460539	1	Connector	
31	4460465	2	Terminal	
32	4460466	1	Plug	
33	1001116815	1	Connector, 3 Pin	
34	4460945	1	Terminal, 3 Way "T" Receptacle	
35	4460891	1	Connector	
36	1001157890	2	Terminal	
37	4460742	1	Connector	
38	4460475	2	Terminal	
39	4460458	2	Plug	
40	1001116774	1	Connector	
41	4460518	8	Plug	
42	1001126008	4	Terminal	
43	1001116808	1	Connector	
44	1001126008	9	Terminal	
45	4460518	3	Plug	
46	4460761	1	Connector	
47	4460321	1	Terminal	
48	1001118378	4	Terminal	
49	4460809	4	Plug	
50	1001143551	1	Seal	
51	1001218358	1	Lanyard Rope	
52	1001231398	1	Connector	
53	1001231400	4	Terminal	

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211281 Order the manual at mid-west-tech.com >