Illustrated Parts Manual

Models

1043

SN 0160084859 to SN 0160101059

31211315

May 22, 2020- Rev E

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. FRAME (OUTRIGGERS) 16
FIGURE 1-2. ENGINE ENCLOSURE INSTALLATION 18
FIGURE 1-3. ENGINE ENCLOSURE COVER INSTALLATION 20
FIGURE 1-4. HOOD ASSEMBLY 22
FIGURE 1-5. HOOD ASSEMBLY 24
FIGURE 1-6. COVER INSTALLATION (OUTRIGGERS) (ULS) 26
FIGURE 1-7. COVER INSTALLATION (OUTRIGGERS) (LS) 28
FIGURE 1-8. COUNTERWEIGHT INSTALLATION 30
FIGURE 1-9. TANK INSTALLATION 32
FIGURE 1-10. FUEL TANK INSTALLATION 34
FIGURE 1-11. HYDRAULIC TANK INSTALLATION 36
FIGURE 1-12. FUEL CAP ASSEMBLY 38
FIGURE 1-13. OUTRIGGERS INSTALLATION 40
FIGURE 1-14. MIRROR INSTALLATION 42
FIGURE 1-15. BOOM PROP INSTALLATION (ANSI) 44
FIGURE 1-16. BOOM PROP BRACKET 46

SECTION 2 - BOOM 49

FIGURE 2-1. BOOM ASSEMBLY 50
FIGURE 2-2. FIRST BOOM SECTION ASSEMBLY 52
FIGURE 2-3. SECOND BOOM SECTION ASSEMBLY 54
FIGURE 2-4. THIRD BOOM SECTION ASSEMBLY 56
FIGURE 2-5. RETRACT CHAIN SHEAVE 58
FIGURE 2-6. RETRACT CHAIN INSTALLATION 60
FIGURE 2-7. EXTEND CHAIN INSTALLATION 62
FIGURE 2-8. PINS INSTALLATION 64
FIGURE 2-9. EXTEND CHAIN ROLLER 66
FIGURE 2-10. HOSE BRACKET INSTALLATION 68
FIGURE 2-11. BOOM PINNING INSTALLATION 70
FIGURE 2-12. LIFT CYLINDER PINS INSTALLATION 72
FIGURE 2-13. COMPENSATION CYLINDER PINS INSTALLATION 74
FIGURE 2-14. BOOM PIVOT PIN INSTALLATION 76
FIGURE 2-15. MANUAL QUICK COUPLER INSTALLATION 78
FIGURE 2-16. HYDRAULIC QUICK COUPLER INSTALLATION 80
FIGURE 2-17. BOOM PIN INSTALLATION 82
FIGURE 2-18. TILT CYLINDER PIN INSTALLATION 84
FIGURE 2-19. BOOM ANGLE INDICATOR INSTALLATION 86
FIGURE 2-20. BOOM BRUSHES INSTALLATION 88
FIGURE 2-21. QUICK COUPLER ASSEMBLY 90

SECTION 3 - ATTACHMENTS 93

FIGURE 3-1. CARRIAGE ASSEMBLY (1270MM) 94
FIGURE 3-2. CARRIAGE ASSEMBLY (1524 MM) 96
FIGURE 3-3. CARRIAGE ASSEMBLY (1829 MM) 98
FIGURE 3-4. SIDE TILT CARRIAGE ASSEMBLY 100
FIGURE 3-5. 90 SWING CARRIAGE ASSEMBLY (72 INCH) 102
FIGURE 3-6. SIDE SHIFT CARRIAGE (5.5 TON - 1270 MM) 104
FIGURE 3-7. FORK POSITIONING CARRIAGE WITH FORKS (4.5 TON) 106
FIGURE 3-8. PALLET FORK (2.36X4X48) 108
FIGURE 3-9. PALLET FORK (2.36X5X48) 110
FIGURE 3-10. PALLET FORK (2.36X4X48) 112
FIGURE 3-11. FORK - PALLET (2.4X4X60) 114
FIGURE 3-12. LUMBER FORK (50X180X1540) 116
FIGURE 3-13. LUMBER FORK (60X150X1524) 118
FIGURE 3-14. PALLET FORK (2.00X6X72) 120
FIGURE 3-15. BLOCKING FORK (50X50X1220) 122
FIGURE 3-16. FORK CLAMPS INSTALL 124
FIGURE 3-17. FORK EXTENSIONS (62X163X2286) 126
FIGURE 3-18. FORK MOUNTED BUCKET (1.0 M^3) 128
FIGURE 3-19. BUCKET 1.0 YD^3 (ANSI - JLG) 130
FIGURE 3-20. BUCKET (1.15 M^3) 132
FIGURE 3-21. BUCKET (102 INCH) 134

MidWestTech | JLG 1043 Telehandler Parts Manual | Publication 31211315 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-22. MULTI-PURPOSE GRAPPLE BUCKET (2450 MM) 136
FIGURE 3-23. TRUSS BOOM (0.9 TON - 3.7M) 138
FIGURE 3-24. TRUSS BOOM (15 FOOT) 140
FIGURE 3-25. ADJUSTABLE TRUSS BOOM 142
FIGURE 3-26. ADJUSTABLE TRUSS BOOM INSTALLATION (FORK MOUNTED) 144
FIGURE 3-27. TRUSS BOOM (1.8 TON - 1M FT WITH WINCH) 146
FIGURE 3-28. TRUSS BOOM (0.9 TON - 3.7M WITH WINCH) 148
FIGURE 3-29. FORK MOUNTED HOOK (4 TON) 150
FIGURE 3-30. CRANE HOOK 152
FIGURE 3-31. MAST (8 FOOT) 154
FIGURE 3-32. SIDE TILT ELECTRIC MAST (8 FOOT) 158
FIGURE 3-33. FORK MOUNTED BASKET 164
FIGURE 3-34. FORK MOUNTED BASKET 166
FIGURE 3-35. FORK MOUNTED BASKET 168
FIGURE 3-36. FORK MOUNTED PLATFORM 170
FIGURE 3-37. SWEEPER - HOPPER ASSEMBLY 172
FIGURE 3-38. FORK MOUNTED TRASH HOPPER 174
FIGURE 3-39. MAIN LIFT CYLINDER 176
FIGURE 3-40. KIT DECAL 178
FIGURE 3-41. DUAL FORK CARRIAGE VALVE ASSEMBLY 180
FIGURE 3-42. DRYWALL SWING CARRIAGE INSTALLATION 182
FIGURE 3-43. ROTATING DRYWALL CARRIAGE 184
FIGURE 3-44. DRYWALL BOARD HANDLER 186
FIGURE 3-45. PIVOT FRAME GROUP 188
FIGURE 3-46. DRYWALL CYLINDER 190
FIGURE 3-47. DRYWALL HYDRAULIC GROUP 192
FIGURE 3-48. DRYWALL VALVE ASSEMBLY 194
FIGURE 3-49. DRYWALL CYLINDER 196
FIGURE 3-50. DRYWALL FORK GROUP 198

SECTION 4 - ENGINE AND ATTACHING PARTS 201

FIGURE 4-1. ENGINE INSTALLATION (ULS) 202
FIGURE 4-2. ENGINE INSTALLATION (LS) 204
FIGURE 4-3. 3.8L ENGINE (ULS) 206
FIGURE 4-4. 3.8L ENGINE (LS) 208
FIGURE 4-5. ENGINE MOUNTING INSTALLATION 210
FIGURE 4-6. FAN INSTALLATION 212
FIGURE 4-7. ENGINE WIRING INSTALLATION (ULS) 214
FIGURE 4-8. ENGINE WIRING INSTALLATION (LS) 218
FIGURE 4-9. PRIMARY FUEL FILTER INSTALLATION (LS) 222
FIGURE 4-10. PRIMARY FUEL FILTER INSTALLATION (ULS) 224
FIGURE 4-11. AIR CLEANER LINES INSTALLATION (LS) 226
FIGURE 4-12. AIR CLEANER LINES INSTALLATION (ULS) 228
FIGURE 4-13. AIR CLEANER INSTALLATION (ULS) 230
FIGURE 4-14. AIR CLEANER INSTALLATION (LS) 232
FIGURE 4-15. AIR CLEANER ASSEMBLY (74.4KW) 234
FIGURE 4-16. AIR CLEANER ASSEMBLY (90/100KW) 236
FIGURE 4-17. AIR INTAKE DUCT INSTALLATION 238
FIGURE 4-18. AIR INTAKE SHUT OFF VALVE INSTALLATION 240
FIGURE 4-19. ENGINE ECU INSTALLATION (ULS) 242
FIGURE 4-20. ENGINE ECU INSTALLATION (LS) 244
FIGURE 4-21. FUEL LINES INSTALLATION (LS) 246
FIGURE 4-22. FUEL LINES INSTALLATION (ULS) 250
FIGURE 4-23. DEF LINES INSTALLATION 254
FIGURE 4-24. COOLING PACKAGE INSTALLATION (ULS) 256
FIGURE 4-25. COOLING PACKAGE INSTALLATION (LS) 258
FIGURE 4-26. RADIATOR COOLING PACKAGE 260
FIGURE 4-27. HOC LINES INSTALLATION 262
FIGURE 4-28. COOLANT LINES INSTALLATION (ULS) 264
FIGURE 4-29. COOLANT LINES INSTALLATION (LS) 266
FIGURE 4-30. CAC LINES INSTALLATION (ULS) 268
FIGURE 4-31. CAC LINES INSTALLATION (LS) 270
FIGURE 4-32. TOC LINES INSTALLATION 272
FIGURE 4-33. SURGE TANK INSTALLATION 274
FIGURE 4-34. FAN GUARD INSTALLATION 276
FIGURE 4-35. EXHAUST INSTALLATION (ULS) 278

MidWestTech | JLG 1043 Telehandler Parts Manual | Publication 31211315 Order the manual at mid-west-tech.com >

FIGURE 4-36. EXHAUST INSTALLATION (LS) 280
FIGURE 4-37. ENGINE PARTS INSTALLATION (NO HEATER) 282
FIGURE 4-38. ENGINE PARTS INSTALLATION (HEATER) 284
FIGURE 4-39. A/C PUMP INSTALLATION (ULS) 286
FIGURE 4-40. A/C PUMP INSTALLATION (LS) 288
FIGURE 4-41. FUEL TANK ASSEMBLY 290
FIGURE 4-42. DEF TANK INSTALLATION 292
FIGURE 4-43. DEF TANK ASSEMBLY (SN 0160084859 through 0160091872) 294
FIGURE 4-44. DEF TANK ASSEMBLY (SN 0160091873 through 0160101059) 296
FIGURE 4-45. DEF PUMP AND CONTROL INSTALLATION 298
FIGURE 4-46. DEF PUMP LINES INSTALLATION 300
FIGURE 4-47. MUFFLER INSTALLATION (LS) 302
FIGURE 4-48. A/C LINES INSTALLATION 304
FIGURE 4-49. HEATER BREATHER 306
FIGURE 4-50. DEF BREATHER VALVE 308

SECTION 5 - DRIVETRAIN 311

FIGURE 5-1. DRIVETRAIN INSTALLATION 312
FIGURE 5-2. FRONT AXLE INSTALLATION 314
FIGURE 5-3. REAR AXLE INSTALLATION 316
FIGURE 5-4. DRIVE SHAFTS INSTALLATION 318
FIGURE 5-5. FRONT AXLE MOUNTING INSTALLATION 320
FIGURE 5-6. FRONT AXLE LINES INSTALLATION 322
FIGURE 5-7. REAR AXLE MOUNTING INSTALLATION 324
FIGURE 5-8. REAR AXLE LINES INSTALLATION 326
FIGURE 5-9. FRONT DRIVE SHAFT INSTALLATION 328
FIGURE 5-10. REAR DRIVE SHAFT INSTALLATION 330
FIGURE 5-11. FRONT AXLE 332
FIGURE 5-12. FRONT AXLE, CENTRAL HOUSING 334
FIGURE 5-13. FRONT AXLE, DIFFERENTIAL 336
FIGURE 5-14. FRONT AXLE, HUB REDUCTION 338
FIGURE 5-15. FRONT AXLE, BRAKES 340
FIGURE 5-16. FRONT AXLE, STEERING 342
FIGURE 5-17. FRONT AXLE, TRUNION 344
FIGURE 5-18. FRONT AXLE, DIFFERENTIAL KIT 346
FIGURE 5-19. FRONT AXLE, PLANET GEAR CARRIER 348
FIGURE 5-20. FRONT AXLE, RING GEAR SUPPORT 350
FIGURE 5-21. FRONT AXLE, PLANET GEAR CARRIER 352
FIGURE 5-22. FRONT AXLE, SUPPORT 354
FIGURE 5-23. FRONT AXLE, SUPPORT 356
FIGURE 5-24. REAR AXLE 358
FIGURE 5-25. REAR AXLE, BRAKES 360
FIGURE 5-26. REAR AXLE, CENTRAL HOUSING 362
FIGURE 5-27. REAR AXLE, DIFFERENTIAL 364
FIGURE 5-28. REAR AXLE, HUB REDUCTION 366
FIGURE 5-29. REAR AXLE, STEERING 368
FIGURE 5-30. REAR AXLE, TRUNION 370
FIGURE 5-31. REAR AXLE, DIFFERENTIAL KIT 372
FIGURE 5-32. REAR AXLE, PLANET GEAR CARRIER 374
FIGURE 5-33. REAR AXLE, PLANET GEAR CARRIER 376
FIGURE 5-34. REAR AXLE, SUPPORT 378
FIGURE 5-35. REAR AXLE, RING GEAR SUPPORT 380
FIGURE 5-36. TRANSMISSION INSTALLATION 382
FIGURE 5-37. POWERSHIFT TRANSMISSION 384
FIGURE 5-38. TRANSMISION, ENGINE CONNECTION 388
FIGURE 5-39. TRANSMISSION, CONVERTER 390
FIGURE 5-40. TRANSMISSION, INPUT 392
FIGURE 5-41. TRANSMISSION, HOUSING GROUP 1 394
FIGURE 5-42. TRANSMISSION, HOUSING GROUP 2 396
FIGURE 5-43. TRANSMISSION, CLUTCH GROUP 1 398
FIGURE 5-44. TRANSMISSION, CLUTCH GROUP 2 400
FIGURE 5-45. TRANSMISSION, COUPLING GROUP 1 402
FIGURE 5-46. TRANSMISSION, COUPLING GROUP 2 404
FIGURE 5-47. TRANSMISSION, COUPLING GROUP 3 406
FIGURE 5-48. TRANSMISSION, COUPLING GROUP 4 408
FIGURE 5-49. TRANSMISSION, OUTPUT 410

MidWestTech | JLG 1043 Telehandler Parts Manual | Publication 31211315 Order the manual at mid-west-tech.com >

FIGURE 5-24. REAR AXLE

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001165832	Ref	Rear Axle	G
		Ref	Rear Axle, Brakes (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Central Housing (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Differential (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Hub Reduction (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Steering (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Trunion (See Separate Breakdown in this Section)	

MidWestTech | JLG 1043 Telehandler Parts Manual | Publication 31211315 Order the manual at mid-west-tech.com >

FIGURE 10-5. POWER DISTRIBUTION ELECTRICAL BOX

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001164402	Ref	Power Distribution Electrical Box	G
1	1001095336	1	Fuse, 150AMP	
2	70026296	1	Fuse, 200AMP	
3	70026297	1	Fuse, 80AMP	
4	70026297	1	Fuse, 80AMP	
5	70026297	1	Fuse, 80AMP	
6	8229247	1	Fuse, 25AMP	
7	8229244	1	Fuse, 15AMP	
8	8229245	1	Fuse, 30AMP	
9	8229247	1	Fuse, 25AMP	
10	8229245	1	Fuse, 30AMP	
11	8229245	1	Fuse, 30AMP	
12	8229245	1	Fuse, 30AMP	
13	70026294	1	Fuse, 70AMP	
14	70026294	1	Fuse, 70AMP	
15	70026294	1	Fuse, 70AMP	
16	70026294	1	Fuse, 70AMP	
17	70026295	1	Fuse, 35AMP	
18	70026295	1	Fuse, 35AMP	
19	70026295	1	Fuse, 35AMP	

MidWestTech | JLG 1043 Telehandler Parts Manual | Publication 31211315 Order the manual at mid-west-tech.com >

FIGURE 10-60. CAB HARNESS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001196451	Ref	Cab Harness	E
1	4460932	1	Connector	
2	80604020	1	Lock, Connector	
3	4460941	4	Terminal	
4	1001201081	1	Connector	
5	4460941	6	Terminal	
6	4460466	8	Plug	
13	1001112612	1	Connector	
14	4460497	1	Nut	
15	4460496	1	Washer, Lock	
16	4460464	3	Terminal	
17	4460943	2	Terminal	
18	4460466	4	Plug	
19	1001116991	1	Connector	
20	1001118384	2	Terminal	
23	1001117081	1	Connector	
24	1001118384	4	Terminal	
25	1001116723	2	Terminal	
26	4460884	1	Connector	
27	80604021	1	Lock, Connector	
28	4460465	4	Terminal	
29	4460884	1	Connector	
30	80604021	1	Lock, Connector	
31	4460465	4	Terminal	
32	4460894	1	Connector	
33	80604023	1	Lock, Connector	
34	4460465	3	Terminal	
35	4460944	2	Terminal	
36	4460466	1	Plug	
43	1001230931	1	Connector	
44	1001116748	6	Terminal	
46	1001117081	1	Connector	
47	1001116723	6	Terminal	
48	1001118384	1	Terminal	
49	1001118684	1	Connector	
50	1001116754	2	Terminal	
51	1001117081	1	Connector	
52	1001118384	5	Terminal	
53	1001116723	6	Terminal	
54	1001117081	1	Connector	
55	1001118384	2	Terminal	
56	1001116723	4	Terminal	
57	8220051	1	Terminal, Female Blade	
58	8220051	1	Terminal, Female Blade	
59	1001162886	1	Connector	
60	1001162887	7	Terminal	
61	1001163340	13	Plug	
62	4460933	1	Connector	
63	80604016	1	Lock, Connector	
64	4460465	9	Terminal	

MidWestTech | JLG 1043 Telehandler Parts Manual | Publication 31211315 Order the manual at mid-west-tech.com >