Illustrated Parts Manual

Models

G5-18A

SN 0160091004 to 0160100938
Including 0160088263 & 0160088264
and Excluding 0160091013 through 0160091021

P/N
31211319

May 21, 2020 - Rev C

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 13

FIGURE 1-1. FRAME WELDMENT 14
FIGURE 1-2. HOODS INSTALLATION 16
FIGURE 1-3. HOOD ASSEMBLY 18
FIGURE 1-4. PAD LOCK 20
FIGURE 1-5. COUNTERWEIGHT INSTALLATION 22
FIGURE 1-6. TANK INSTALLATION 24
FIGURE 1-7. OIL TANK 26
FIGURE 1-8. FUEL TANK ASSEMBLY 28
FIGURE 1-9. FUEL CAP INSTALLATION 30
FIGURE 1-10. MIRROR INSTALLATION 32
FIGURE 1-11. REAR CONVEX MIRROR INSTALLATION 34
FIGURE 1-12. MIRROR ASSEMBLY (CONVEX) 36
FIGURE 1-13. WHEEL CHOCKS 38
FIGURE 1-14. BATTERY COVER INSTALLATION 40
FIGURE 1-15. REAR COVER PLATE INSTALLATION, (NO HITCH) 42
FIGURE 1-16. HITCH INSTALLATION, MECHANICAL 44
FIGURE 1-17. HITCH INSTALLATION, MECHANICAL, AUITOMATIC 46
FIGURE 1-18. HITCH INSTALLATION 48
FIGURE 1-19. HITCH INSTALLATION - EEC 50
FIGURE 1-20. HITCH ASSEMBLY (FIXED) 52
FIGURE 1-21. HITCH INSTALLATION - CUNA-C 54
FIGURE 1-22. HITCH ASSEMBLY (CUNA-C) 56
FIGURE 1-23. LICENSE HOLDER INSTALLATION, SMALL 58
FIGURE 1-24. LICENSE HOLDER INSTALLATION, LARGE 60
FIGURE 1-25. LIFT CYLINDER PROP SUPPORT 62

SECTION 2 - BOOM 65

FIGURE 2-1. BOOM ASSEMBLY INSTALLATION, STD W/AUX 66
FIGURE 2-2. BOOM ASSEMBLY INSTALLATION, W/AUX FOR QS 68
FIGURE 2-3. BOOM INSTALLATION, W/O AUX 70
FIGURE 2-4. BOOM W/O AUXILIARY HYDRAULIC INSTALLATION 72
FIGURE 2-5. COUPLER INSTALLATION (MANUAL) 76
FIGURE 2-6. COUPLER INSTALLATION (HYDRAULIC) 78
FIGURE 2-7. FORK LOCKING CYLINDER KIT 80
FIGURE 2-8. COUPLER INSTALLATION, UNIVERSAL (MANUAL) 82
FIGURE 2-9. UNIVERSAL QUICK COUPLER ASSEMBLY 84
FIGURE 2-10. BOOM SIDE COVER INSTALLATION 86
FIGURE 2-11. BOOM BRUSHES INSTALLATION 88

SECTION 3 - ATTACHMENTS 91

FIGURE 3-1. CARRIAGE ASSEMBLY, (50INCH/1270MM) 92
FIGURE 3-2. CARRIAGE ASSEMBLY, UNIVERSAL QUICK ATTACH, (48IN/1219.2MM) 94
FIGURE 3-3. CARRIAGE, SIDE TILT, (48IN) 96
FIGURE 3-4. CARRIAGE, SIDE TILT, UNIVERSAL QUICK ATTACH, (48IN) 98
FIGURE 3-5. CARRIAGE, SIDE SHIFT, UNIVERSAL QUICK ATTACH, (48IN) 100
FIGURE 3-6. LIGHT MATERIAL BUCKET, (72INCH) (1.0 YD^3/0.76 M^3) 102
FIGURE 3-7. LIGHT MATERIAL BUCKET, (72INCH) (1.7 YD^3/1.29 M^3) 104
FIGURE 3-8. MULTI-PURPOSE GRAPPLE BUCKET (1850MM) (ANSI - JLG) 106
FIGURE 3-9. UNIVERSAL HITCH ATTACHMENT 108
FIGURE 3-10. BLOCKING FORK (50X50X1220) 110
FIGURE 3-11. PALLET FORK (2X4X48) 112
FIGURE 3-12. LUMBER FORK (40X150X1540) 114
FIGURE 3-13. FORK MOUNTED HOOK (4 TON) 116
FIGURE 3-14. BOLT-ON EDGE ASSEMBLY, 72" 118
FIGURE 3-15. HYDRAULIC QUICK SWITCH INSTALLATION 120
FIGURE 3-16. QUICK SWITCH ASSEMBLY 122
FIGURE 3-17. BLOCK VALVE ASSEMBLY 124

SECTION 4 - ENGINE AND ATTACHING PARTS 127

FIGURE 4-1. ENGINE INSTALLATION 128
FIGURE 4-2. ENGINE MOUNT INSTALLATION 130

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211319 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 4-3. ENGINE MOUNT INSTALLATION, (HEATER) 132
FIGURE 4-4. ENGINE MOUNT INSTALLATION, (HEATER & A/C) 134
FIGURE 4-5. ENGINE (55.4KW - ULS) 136
FIGURE 4-6. ENGINE (55.4KW - LS) 138
FIGURE 4-7. FAN INSTALLATION 140
FIGURE 4-8. FAN INSTALLATION, REVERSING 142
FIGURE 4-9. RADIATOR INSTALLATION 144
FIGURE 4-10. RADIATOR LOWER HOSE ASSEMBLY 146
FIGURE 4-11. AIR CLEANER INSTALLATION 148
FIGURE 4-12. AIR FILTER 150
FIGURE 4-13. RAIN CAP 152
FIGURE 4-14. PRECLEANER 154
FIGURE 4-15. EXHAUST INSTALLATION (ULS) 156
FIGURE 4-16. EXHAUST INSTALLATION (LS) 158
FIGURE 4-17. HYDROSTATIC DRIVE PUMP ASSEMBLY 160
FIGURE 4-18. HEATER LINES INSTALLATION 162
FIGURE 4-19. LUBRICITY DOSER INSTALLATION (MIRROR) 164
FIGURE 4-20. LUBRICITY DOSER INSTALLATION (LIGHT & MIRROR) 166
FIGURE 4-21. AIR SHUT OFF VALVE INSTALLATION 168

SECTION 5 - DRIVE TRAIN 171

FIGURE 5-1. DRIVETRAIN INSTALLATION 172
FIGURE 5-2. FRONT AXLE ASSEMBLY 174
FIGURE 5-3. FRONT AXLE 176
FIGURE 5-4. FRONT AXLE, CENTRAL HOUSING 178
FIGURE 5-5. FRONT AXLE, DIFFERENTIAL 180
FIGURE 5-6. FRONT AXLE, HUB REDUCTION 182
FIGURE 5-7. FRONT AXLE, BRAKES 186
FIGURE 5-8. FRONT AXLE, STEERING 188
FIGURE 5-9. REAR AXLE ASSEMBLY 190
FIGURE 5-10. REAR AXLE 192
FIGURE 5-11. REAR AXLE, CENTRAL HOUSING 194
FIGURE 5-12. REAR AXLE, DIFFERENTIAL 196
FIGURE 5-13. REAR AXLE, HUB REDUCTION 198
FIGURE 5-14. REAR AXLE, STEERING 200
FIGURE 5-15. REAR AXLE, TRUNION 202
FIGURE 5-16. DIFFERENTIAL KIT 204
FIGURE 5-17. STEERING CASE KIT (LF/RR) 206
FIGURE 5-18. STEERING CASE KIT (RF/LR) 208
FIGURE 5-19. RING GEAR SUPPORT KIT 210
FIGURE 5-20. PLANET GEAR CARRIER KIT 212
FIGURE 5-21. TIRE/WHEEL SET, CAMSO (AIR 12-16.5 - 12 PLY) 214
FIGURE 5-22. RIGHT TIRE/WHEEL ASSEMBLY, CAMSO (AIR 12-16.5 - 12 PLY) 216
FIGURE 5-23. LEFT TIRE/WHEEL ASSEMBLY, CAMSO (AIR 12-16.5 - 12 PLY) 218
FIGURE 5-24. TIRE/WHEEL SET, FIRESTONE (AIR 12-16.5 - 12 PLY) 220
FIGURE 5-25. RIGHT TIRE/WHEEL ASSEMBLY, FIRESTONE (AIR 12-16.5 - 12 PLY) 222
FIGURE 5-26. LEFT TIRE/WHEEL ASSEMBLY, FIRESTONE (AIR 12-16.5 - 12 PLY) 224
FIGURE 5-27. TIRE/WHEEL SET (AIR 14-17.5 - 12 PLY) 226
FIGURE 5-28. RIGHT TIRE/WHEEL ASSEMBLY (AIR 12-16.5 - 12 PLY) 228
FIGURE 5-29. LEFT TIRE/WHEEL ASSEMBLY (AIR 12-16.5 - 12 PLY) 230
FIGURE 5-30. TIRE/WHEEL SET, CAMSO (FOAM 12-16.5 - 12 PLY) 232
FIGURE 5-31. TIRE/WHEEL SET, FIRESTONE (FOAM 12-16.5 - 12 PLY) 234
FIGURE 5-32. TIRE/WHEEL SET (FOAM 12-16.5 - 14 PLY) 236
FIGURE 5-33. TIRE/WHEEL SET (SOLID 33X12-20 - NM) 238
FIGURE 5-34. TIRE/WHEEL SET, AG (AIR 10.5-18 - 16 PR) 240
FIGURE 5-35. RIGHT TIRE/WHEEL ASSEMBLY, AG (AIR 10.5-18 - 16 PR) 242
FIGURE 5-36. LEFT TIRE/WHEEL ASSEMBLY, AG (AIR 10.5-18 - 16 PR) 244
FIGURE 5-37. FENDER INSTALLATION 246
FIGURE 5-38. FENDER ASSEMBLY 248

SECTION 6 - CAB 251

FIGURE 6-1. CAB INSTALLATION 252
FIGURE 6-2. OPEN CAB INSTALLATION (ANSI - FIXED STEERING) 254
FIGURE 6-3. OPEN CAB INSTALLATION (ANSI - TILT STEERING) 256
FIGURE 6-4. ENCLOSED CAB INSTALLATION (ANSI - TILT STEERING) (HEAT) 258

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211319 Order the manual at mid-west-tech.com >

FIGURE 6-5. ENCLOSED CAB INSTALLATION (ANSI - TILT STEERING) (HEAT & A/C) 260
FIGURE 6-6. ENCLOSED CAB INSTALLATION (LSI - TILT STEERING) (HEAT) 262
FIGURE 6-7. ENCLOSED CAB INSTALLATION (LSI - TILT STEERING) (HEAT & A/C) 264
FIGURE 6-8. CAB COMMON INSTALLATION 266
FIGURE 6-9. CAB COMMON COMPONENTS, ENCLOSED 270
FIGURE 6-10. CAB GLASS INSTALLATION, OPEN 272
FIGURE 6-11. CAB GLASS INSTALLATION, ENCLOSED 274
FIGURE 6-12. REAR WINDOW ASSEMBLY 276
FIGURE 6-13. DOOR ASSEMBLY INSTALLATION 278
FIGURE 6-14. JLG COMMON INSTALLATION 280
FIGURE 6-15. SEAT RISER COVER INSTALLATION 282
FIGURE 6-16. SEAT RISER COVER INSTALLATION, HVAC 284
FIGURE 6-17. OPEN CAB COMMON COMPONENTS INSTALLATION 286
FIGURE 6-18. DASH INSTALLATION, OPEN CAB 288
FIGURE 6-19. DASH INSTALLATION, ENCLOSED CAB 290
FIGURE 6-20. RIGHT SIDE CONSOLE 292
FIGURE 6-21. NA COMMON INSTALLATION 294
FIGURE 6-22. NA COMMON COMPONENTS INSTALLATION (LSI) 296
FIGURE 6-23. FRONT WIPER ASSSEMBLY 298
FIGURE 6-24. WASHER TANK W/PUMP INSTALLATION 300
FIGURE 6-25. ROOF/REAR WIPER INSTALLATION 302
FIGURE 6-26. AUX WIPER ASSEMBLY 304
FIGURE 6-27. SEAT 306
FIGURE 6-28. SEAT, LSI 308
FIGURE 6-29. SEAT BELT INSTALLATION (3 INCH) 310
FIGURE 6-30. SEAT BELT INSTALLATION, LSI (3 INCH) 312
FIGURE 6-31. CONTROL COVER INSTALLATION 314
FIGURE 6-32. HEATER INSTALLATION (CAB PARTS) 316
FIGURE 6-33. HEATER AND A/C INSTALLATION (CAB PARTS) 318
FIGURE 6-34. HEATER ASSEMBLY, 3 SPEED 320
FIGURE 6-35. HEATER AND A/C ASSEMBLY, 3 SPEED 322
FIGURE 6-36. HEATER 324
FIGURE 6-37. HEATER AND A/C 326
FIGURE 6-38. A/C KIT 328
FIGURE 6-39. A/C CONDENSER INSTALLATION 330
FIGURE 6-40. CONDENSER 332
FIGURE 6-41. OVERHEAD CONSOLE INSTALLATION 334
FIGURE 6-42. OVERHEAD CONSOLE INSTALLATION (OPEN) 336
FIGURE 6-43. FRONT FOPS INSTALLATION 338
FIGURE 6-44. OVERHEAD CONSOLE INSTALLATION (LSI) 340
FIGURE 6-45. RADIO READY PACKAGE INSTALLATION 342
FIGURE 6-46. FLOOR MAT INSTALLATION 344
FIGURE 6-47. CAB FENDER INSTALLATION 346
FIGURE 6-48. CAB GUARD INSTALLATION (TOP) 348
FIGURE 6-49. CAB GUARD INSTALLATION (FRONT) 350
FIGURE 6-50. REAR WINDOW ENTRY KIT INSTALLATION (ANSI) 352
FIGURE 6-51. REAR WINDOW ENTRY KIT INSTALLATION (ENGLISH/FRENCH) 354
FIGURE 6-52. REAR WINDOW ENTRY KIT INSTALLATION (ISO) 356
FIGURE 6-53. FIRE EXTINQUISHER INSTALLATION 358
FIGURE 6-54. WASHER FLUID TANK ASSEMBLY 360
FIGURE 6-55. EMERGENCY ENTRY/EXIT WINDOW 362

SECTION 7 - CONTROLS 365

FIGURE 7-1. ACCELERATOR PEDAL ASSEMBLY 366
FIGURE 7-2. ACCELERATOR PEDAL 368
FIGURE 7-3. BRAKE PEDAL INSTALLATION 370
FIGURE 7-4. MASTER CYLINDER VALVE ASSEMBLY 372
FIGURE 7-5. PARK BRAKE VALVE INSTALLATION 374
FIGURE 7-6. PARK BRAKE VALVE INSTALLATION (EURO) 376
FIGURE 7-7. PARK BRAKE VALVE ASSEMBLY 378
FIGURE 7-8. PARK BRAKE VALVE ASSEMBLY (EURO) 380
FIGURE 7-9. FIXED STEERING COLUMN INSTALLATION 382
FIGURE 7-10. FIXED STEERING COLUMN 384
FIGURE 7-11. TILT STEERING COLUMN INSTALLATION 386
FIGURE 7-12. TILT STEERING COLUMN 388
FIGURE 7-13. HYDRAULIC CONTROLLER ASSEMBLY 390

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211319 Order the manual at mid-west-tech.com >

FIGURE 10-33. FRAME OPTION HARNESS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001140635	Ref	Frame Option Harness	D
1	4460761	1	Connector	
2	4460227	4	Terminal	
3	1001116996	1	Connector	
4	1001118392	5	Terminal	
5	4461008	2	Plug	
6	4460891	1	Connector	
7	4460465	2	Terminal	
8	4460891	1	Connector	
9	4460465	2	Terminal	
10	4460891	1	Connector	
11	4460465	2	Terminal	
12	4460897	1	Connector	
13	4460464	1	Terminal	
14	4460466	1	Plug	
15	1001116812	1	Connector	
16	4460945	1	Terminal, 3 Way "T" Receptacle	
17	4460465	3	Terminal	
18	4460539	1	Connector	
19	4460465	2	Terminal	
20	4460466	1	Plug	
21	1001116812	1	Connector	
22	4460465	2	Terminal	
23	4460466	1	Plug	
24	1001116808	1	Connector	
25	1001126008	12	Terminal	
26	1001116774	1	Connector	
27	1001126008	8	Terminal	
28	4460518	4	Plug	
29	1001116808	1	Connector	
30	1001126008	7	Terminal	
31	4460518	5	Plug	
32	1001116774	1	Connector	
33	1001126008	5	Terminal	
34	4460518	7	Plug	
35	1001116996	1	Connector	
36	1001118392	5	Terminal	
37	4461008	2	Plug	
38	1001117133	1	Connector	
39	1001118385	2	Terminal	
40	4460897	1	Connector	
41	4460464	2	Terminal	
42	4460894	1	Connector	
43	4460465	6	Terminal	
44	4460911	1	Connector	
45	1001126008	3	Terminal	
46	4460539	1	Connector	
47	4460465	4	Terminal	
48	4460851	1	Connector	
49	4460852	1	Connector, 8 Pin	

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211319 Order the manual at mid-west-tech.com >

FIGURE 11-4. DECAL INSTALLATION (ENGLISH/FRENCH)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001163326	Ref	Decal Installation (ENGLISH/FRENCH)	C
1	1701500	4	Decal, Lift	
2	1702300	4	Decal, Tie Down	
3	1001163174	1	Decal, Battery Warning	
4	1001163206	1	Decal, Carry Personnel	
5	1001163210	1	Decal, Electrocution Hazard	
6	1001163212	1	Decal, Warning No Either	
7	1001163222	2	Decal, Moving Parts	
8	1001163223	3	Decal, Pinch Point	
11	1001163285	1	Decal, Warning Tip Over	
13	1001163300	1	Decal, No Riders	
14	1001163304	1	Decal, Warning Crushing Hazard	
16	4100181	1	Decal, Hydraulic Oil Fill	
17	8005870	1	Decal, Emergency Exit	
18	91563220	1	Decal, Oil Level	
19	1001156576	1	Decal, Fuse Cover	
20	1001100107	1	Decal, Lube Chart	
21	1001101071	1	Decal, Instructional Joystick	
22	1001163323	1	Decal, Warning Hot Fluid	
23	1001146038	1	Decal, Maintenance Chart	
24	1001223453	1	Decal, ICES	
25	1001233558	1	Decal, Warning/Danger	

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211319 Order the manual at mid-west-tech.com >