# Illustrated Parts Manual

## *Models*
## *3614RS*
## *4017RS*

**PVC**
**1911**
**2005**

**P/N**
**31211338**

**July 7, 2020 - Rev B**

An Oshkosh Corporation Company



Order the manual at mid-west-tech.com >

SECTION 1 - FRAME AND ATTACHING PARTS ..... 15

FIGURE 1-1. FRAME INSTALLATION - 3614RS ..... 16
FIGURE 1-2. FRAME INSTALLATION - 4017RS ..... 18
FIGURE 1-3. FRAME INSTALLATION (HIGH CAB) - 4017RS ..... 20
FIGURE 1-4. ENCLOSURE GROUP INSTALLATION ..... 22
FIGURE 1-5. MIRROR INSTALLATION - 3614RS ..... 24
FIGURE 1-6. MIRROR INSTALLATION - 4017RS ..... 26
FIGURE 1-7. MIRROR INSTALLATION ..... 28
FIGURE 1-8. REAR MIRROR INSTALLATION ..... 30
FIGURE 1-9. MIRROR ASSEMBLY (CONVEX) ..... 32
FIGURE 1-10. BOOM PROP INSTALLATION ..... 34
FIGURE 1-11. WHEEL CHOCK INSTALLATION ..... 36
FIGURE 1-12. HOOD ASSEMBLY ..... 38
FIGURE 1-13. SOUND SUPPRESSION INSTALLATION (LCAD, AFRICA AND MID EAST, PAC RIM) ..... 40
FIGURE 1-14. SOUND SUPPRESSION INSTALLATION ..... 42
FIGURE 1-15. CHASSIS COVER PLATE INSTALLATION - 3614RS ..... 44
FIGURE 1-16. CHASSIS COVER PLATE INSTALLATION - 4017RS ..... 46
FIGURE 1-17. LICENSE PLATE INSTALLATION ..... 48
FIGURE 1-18. RETRIEVAL HITCH INSTALLATION ..... 50
FIGURE 1-19. HYDRAULIC TANK INSTALLATION ..... 52
FIGURE 1-20. PAD LOCK ..... 54
FIGURE 1-21. HITCH PIN ASSEMBLY ..... 56

SECTION 2 - BOOM ..... 59

FIGURE 2-1. BOOM INSTALLATION - 3614RS (NO AUXILIARY HYDRAULICS) ..... 60
FIGURE 2-2. BOOM INSTALLATION - 3614RS (AUXILIARY HYDRAULICS) ..... 62
FIGURE 2-3. BOOM INSTALLATION - 4017RS (NO AUXILIARY HYDRAULICS) ..... 64
FIGURE 2-4. BOOM INSTALLATION - 4017RS (AUXILIARY HYDRAULICS) ..... 66
FIGURE 2-5. BOOM ASSEMBLY - 3614RS (NO AUXILIARY HYDRAULICS) ..... 68
FIGURE 2-6. BOOM ASSEMBLY - 3614RS (AUXILIARY HYDRAULICS) ..... 70
FIGURE 2-7. BOOM ASSEMBLY - 4017RS (NO AUXILIARY HYDRAULICS) ..... 72
FIGURE 2-8. BOOM ASSEMBLY - 4017RS (AUXILIARY HYDRAULICS) ..... 74
FIGURE 2-9. EXTEND CHAIN ASSEMBLY - 3614RS ..... 78
FIGURE 2-10. EXTEND CHAIN ASSEMBLY (1) - 4017RS ..... 80
FIGURE 2-11. EXTEND CHAIN ASSEMBLY (2) - 4017RS ..... 82
FIGURE 2-12. RETRACT CHAIN ASSEMBLY - 3614RS ..... 84
FIGURE 2-13. RETRACT CHAIN ASSEMBLY (1) - 4017RS ..... 86
FIGURE 2-14. RETRACT CHAIN ASSEMBLY (2) - 4017RS ..... 88
FIGURE 2-15. COVER PLATE INSTALLATION - 3614RS ..... 90
FIGURE 2-16. COVER PLATE INSTALLATION - 4017RS ..... 92
FIGURE 2-17. FIRST BOOM SECTION - 3614RS ..... 94
FIGURE 2-18. FIRST BOOM SECTION - 4017RS ..... 96
FIGURE 2-19. SECOND BOOM SECTION - 3614RS ..... 98
FIGURE 2-20. SECOND BOOM SECTION - 4017RS ..... 100
FIGURE 2-21. THIRD BOOM SECTION - 3614RS ..... 102
FIGURE 2-22. THIRD BOOM SECTION - 4017RS ..... 104
FIGURE 2-23. FOURTH BOOM SECTION - 4017RS ..... 106
FIGURE 2-24. HOSE SUPPORT ASSEMBLY - 4017RS ..... 108
FIGURE 2-25. MANUAL QUICK ATTACH ..... 110
FIGURE 2-26. HYDRAULICS INSTALLATION - 3614RS (NO AUXILIARY HYDRAULICS) ..... 112
FIGURE 2-27. HYDRAULICS INSTALLATION - 3614RS (AUXILIARY HYDRAULICS) ..... 114
FIGURE 2-28. HYDRAULICS INSTALLATION - 4017RS ..... 116
FIGURE 2-29. HYDRAULICS ASSEMBLY - 4017RS ..... 118
FIGURE 2-30. HYDRAULICS INSTALLATION - 4017RS (AUXILIARY HYDRAULICS) ..... 120
FIGURE 2-31. AUXILIARY LINES INSTALLATION ..... 122
FIGURE 2-32. BOOM BRUSH INSTALLATION - 3614RS ..... 124
FIGURE 2-33. BOOM BRUSH INSTALLATION - 4017RS ..... 126
FIGURE 2-34. BOOM BRUSH BRACKET ASSEMBLY (1) ..... 128
FIGURE 2-35. BOOM BRUSH BRACKET ASSEMBLY (2) ..... 130
FIGURE 2-36. BOOM BRUSH BRACKET ASSEMBLY (3) ..... 132
FIGURE 2-37. BOOM BRUSH BRACKET ASSEMBLY (4) - 3614RS ..... 134
FIGURE 2-38. BOOM BRUSH BRACKET ASSEMBLY (5) - 3614RS ..... 136
FIGURE 2-39. BOOM BRUSH BRACKET ASSEMBLY (6) ..... 138
FIGURE 2-40. BOOM BRUSH BRACKET ASSEMBLY (7) - 4017RS ..... 140



MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31211338 Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


FIGURE 2-41. BOOM BRUSH BRACKET ASSEMBLY (8) - 4017RS ..... 142
FIGURE 2-42. BOOM BRUSH BRACKET ASSEMBLY (9) - 4017RS ..... 144
FIGURE 2-43. BOOM BRUSH BRACKET ASSEMBLY (10) - 4017RS ..... 146
FIGURE 2-44. BOOM BRUSH BRACKET ASSEMBLY (11) - 4017RS ..... 148

SECTION 3 - ATTACHMENTS ..... 151

FIGURE 3-1. BUCKET 0.9M³ ..... 152
FIGURE 3-2. BUCKET 4 IN 1 (1.0 M³) ..... 154
FIGURE 3-3. BUCKET 1.8M³ ..... 156
FIGURE 3-4. BUCKET EDGE (BOLT-ON) (2450 MM) ..... 158
FIGURE 3-5. CARRIAGE ASSEMBLY (500MM) ..... 160
FIGURE 3-6. CARRIAGE INSTALLATION WITH LIFT LUG (3614RS) ..... 162
FIGURE 3-7. CARRIAGE INSTALLATION WITH LIFT LUG (4017RS) ..... 164
FIGURE 3-8. CARRIAGE INSTALLATION - FORK POSTIONING (3614RS) ..... 166
FIGURE 3-9. CARRIAGE INSTALLATION - FORK POSTIONING (4017RS) ..... 168
FIGURE 3-10. CARRIAGE INSTALLATION - FORK POSTIONING WITH FORKS (4.0 TON) ..... 170
FIGURE 3-11. CARRIAGE INSTALLATION - JCB (3614RS) ..... 172
FIGURE 3-12. CARRIAGE INSTALLATION - JCB (4017RS) ..... 174
FIGURE 3-13. CARRIAGE INSTALLATION - MANITOU (3614RS) ..... 176
FIGURE 3-14. CARRIAGE INSTALLATION - MANITOU (4017RS) ..... 178
FIGURE 3-15. CARRIAGE ASSEMBLY - MANITOU FIT ..... 180
FIGURE 3-16. CARRIAGE - SIDE SHIFT (4.0 TON - 1255 MM) ..... 182
FIGURE 3-17. CARRIAGE INSTALLATION - SIDE SHIFT (3614RS) ..... 184
FIGURE 3-18. CARRIAGE - SIDE SHIFT INSTALLATION (4017RS) ..... 186
FIGURE 3-19. COUPLER INSTALLATION - JCB ..... 188
FIGURE 3-20. COUPLER INSTALLATION - MANITOU ..... 190
FIGURE 3-21. FORK - PALLET (50X100X1200) ..... 192
FIGURE 3-22. FORK - PALLET (50X120X1200) ..... 194
FIGURE 3-23. FORK TRANSPORT LATCH INSTALLATION ..... 196
FIGURE 3-24. FORK AND HOOK INSTALLATION (3614RS) ..... 198
FIGURE 3-25. FORK AND HOOK INSTALLATION (4017RS) ..... 200
FIGURE 3-26. FORK MOUNTED HOOK (4 TON) ..... 202
FIGURE 3-27. FORK AND HOOK CARRIAGE - 4FT ..... 204
FIGURE 3-28. TRUSS BOOM (1 TON - 3.4M) ..... 206
FIGURE 3-29. TRUSS BOOM (4000 KG) ..... 208
FIGURE 3-30. TRUSS BOOM (4000 KG) (3614RS) ..... 210
FIGURE 3-31. TRUSS BOOM (4000 KG) (4017RS) ..... 212

SECTION 4 - ENGINE AND ATTACHING PARTS ..... 215

FIGURE 4-1. ENGINE INSTALLATION - 55KW (ULS) ..... 216
FIGURE 4-2. ENGINE INSTALLATION - 74KW (LS) ..... 218
FIGURE 4-3. ENGINE AND TRANSMISSION INSTALLATION - 55KW (ULS) ..... 220
FIGURE 4-4. ENGINE AND TRANSMISSION INSTALLATION - 74KW (LS) ..... 222
FIGURE 4-5. ENGINE, DEUTZ - 55 KW (ULS) ..... 224
FIGURE 4-6. ENGINE, DEUTZ - 74.4KW (LS) ..... 226
FIGURE 4-7. FUEL LINES INSTALLATION ..... 228
FIGURE 4-8. AIR SYSTEM INSTALLATION - 55KW (ULS) ..... 230
FIGURE 4-9. AIR SYSTEM INSTALLATION - 74KW ..... 232
FIGURE 4-10. AIR FILTER ASSEMBLY ..... 234
FIGURE 4-11. AIR INTAKE FILTER ..... 236
FIGURE 4-12. EXHAUST SYSTEM INSTALLATION - 55KW (ULS) ..... 238
FIGURE 4-13. EXHAUST SYSTEM INSTALLATION - 74KW (LS) ..... 240
FIGURE 4-14. COOLING SYSTEM INSTALLATION - 55KW (ULS) ..... 242
FIGURE 4-15. COOLING SYSTEM INSTALLATION - 74KW (LS) ..... 244
FIGURE 4-16. EXPANSION TANK ..... 246
FIGURE 4-17. RADIATOR ASSEMBLY - 55KW (ULS) ..... 248
FIGURE 4-18. RADIATOR ASSEMBLY - 74KW (LS) ..... 250
FIGURE 4-19. ENGINE MOUNTING INSTALLATION ..... 252
FIGURE 4-20. HYDRAULIC PUMP INSTALLATION ..... 254
FIGURE 4-21. TURBO SHIELD INSTALLATION ..... 256
FIGURE 4-22. FUEL TANK INSTALLATION ..... 258
FIGURE 4-23. FUEL TANK ..... 260
FIGURE 4-24. RADIATOR LINES INSTALLATION ..... 262
FIGURE 4-25. RADIATOR LINES INSTALLATION - ARCTIC ..... 264
FIGURE 4-26. TRANSMISSION COOLING INSTALLATION ..... 266





MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31211338 Order the manual at mid-west-tech.com >

FIGURE 4-27. THERMAL BYPASS INSTALLATION - ARCTIC ..... 268
FIGURE 4-28. HEATER LINES INSTALLATION ..... 270
FIGURE 4-29. HEATER BLOCK INSTALLATION - ARCTIC ..... 272
FIGURE 4-30. ENGINE COOLANT HOSE INSTALLATION ..... 274
FIGURE 4-31. ENGINE OIL DRAIN INSTALLATION ..... 276

SECTION 5 - DRIVE TRAIN ..... 279

FIGURE 5-1. AXLE INSTALLATION - 3614RS (74KW) ..... 280
FIGURE 5-2. AXLE INSTALLATION, (NO FOAM FILL) - 4017RS (74KW) ..... 282
FIGURE 5-3. AXLE INSTALLATION (FOAM FILL) - 4017RS (74KW) ..... 284
FIGURE 5-4. AXLE INSTALLATION - 3614RS (55KW) ..... 286
FIGURE 5-5. AXLE INSTALLATION - 4017RS (55KW) ..... 288
FIGURE 5-6. DRIVE SHAFT INSTALLATION - 3614RS ..... 290
FIGURE 5-7. DRIVE SHAFT INSTALLATION - 4017RS ..... 292
FIGURE 5-8. FRONT AXLE - 3614RS ..... 294
FIGURE 5-9. FRONT AXLE, CENTRAL HOUSING - 3614RS ..... 296
FIGURE 5-10. FRONT AXLE, DIFFERENTIAL - 3614RS ..... 298
FIGURE 5-11. FRONT AXLE, HUB REDUCTION - 3614RS ..... 300
FIGURE 5-12. FRONT AXLE, BRAKES - 3614RS ..... 302
FIGURE 5-13. FRONT AXLE, STEERING - 3614RS ..... 304
FIGURE 5-14. FRONT AXLE, TRUNION - 3614RS ..... 306
FIGURE 5-15. FRONT AXLE, TRUNION KIT - 3614RS ..... 308
FIGURE 5-16. DIFFERENTIAL KIT ..... 310
FIGURE 5-17. FRONT AXLE - 4017RS ..... 312
FIGURE 5-18. FRONT AXLE, CENTRAL HOUSING - 4017RS ..... 314
FIGURE 5-19. FRONT AXLE, DIFFERENTIAL - 4017RS ..... 316
FIGURE 5-20. FRONT AXLE, HUB REDUCTION - 4017RS ..... 318
FIGURE 5-21. FRONT AXLE, BRAKES - 4017RS ..... 320
FIGURE 5-22. FRONT AXLE, STEERING - 4017RS ..... 322
FIGURE 5-23. FRONT AXLE, TRUNION - 4017RS ..... 324
FIGURE 5-24. DIFFERENTIAL KIT ..... 326
FIGURE 5-25. REDUCTION BUSHING ..... 328
FIGURE 5-26. STEERING CASE KIT LH ..... 330
FIGURE 5-27. STEERING CASE KIT RH ..... 332
FIGURE 5-28. STEERING ADJUST BOLT KIT ..... 334
FIGURE 5-29. RING GEAR SUPPORT KIT ..... 336
FIGURE 5-30. PLANET GEAR CARRIER KIT ..... 338
FIGURE 5-31. TRUNION KIT ..... 340
FIGURE 5-32. REAR AXLE - 3614RS, 4017RS (NO FOAM FILL) ..... 342
FIGURE 5-33. REAR AXLE, CENTRAL HOUSING - 3614RS, 4017RS (NO FOAM FILL) ..... 344
FIGURE 5-34. REAR AXLE, DIFFERENTIAL - 3614RS, 4017RS (NO FOAM FILL) ..... 346
FIGURE 5-35. REAR AXLE, HUB REDUCTION - 3614RS, 4017RS (NO FOAM FILL) ..... 348
FIGURE 5-36. REAR AXLE, BRAKES - 3614RS, 4017RS (NO FOAM FILL) ..... 350
FIGURE 5-37. REAR AXLE, STEERING - 3614RS, 4017RS (NO FOAM FILL) ..... 352
FIGURE 5-38. REAR AXLE, TRUNION - 3614RS, 4017RS (NO FOAM FILL) ..... 354
FIGURE 5-39. REAR AXLE, TRUNION KIT - 3614RS, 4017RS (NO FOAM FILL) ..... 356
FIGURE 5-40. PISTON KIT ..... 358
FIGURE 5-41. REAR AXLE - 4017RS (FOAM FILL) ..... 360
FIGURE 5-42. REAR AXLE, CENTRAL HOUSING - 4017RS ..... 362
FIGURE 5-43. REAR AXLE, DIFFERENTIAL - 4017RS ..... 364
FIGURE 5-44. REAR AXLE, HUB REDUCTION - 4017RS ..... 366
FIGURE 5-45. REAR AXLE, BRAKES - 4017RS ..... 368
FIGURE 5-46. REAR AXLE, STEERING - 4017RS ..... 370
FIGURE 5-47. REAR AXLE, TRUNION - 4017RS ..... 372
FIGURE 5-48. DIFFERENTIAL KIT ..... 374
FIGURE 5-49. REDUCTION BUSHING ..... 376
FIGURE 5-50. STEERING CASE KIT LH ..... 378
FIGURE 5-51. STEERING CASE KIT RH ..... 380
FIGURE 5-52. STEERING ADJUST BOLT KIT ..... 382
FIGURE 5-53. RING GEAR SUPPORT KIT ..... 384
FIGURE 5-54. PLANET GEAR CARRIER KIT ..... 386
FIGURE 5-55. PISTON ..... 388
FIGURE 5-56. TRUNION KIT ..... 390
FIGURE 5-57. FRONT AXLE - 3614RS ..... 392
FIGURE 5-58. FRONT AXLE, CENTRAL HOUSING - 3614RS ..... 394
FIGURE 5-59. FRONT AXLE, DIFFERENTIAL - 3614RS ..... 396



MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31211338 Order the manual at mid-west-tech.com >

## FIGURE 6-2. CAB INSTALLATION (FNR LEVER)

| ITEM | PART NUMBER | QTY | DESCRIPTION | REV |
|---|---|---|---|---|
| | 1001241971 | Ref | Cab Installation (FNR Lever) | B |
| 1 | 1001139746 | 1 | Mat, Floor | |
| 2 | 1001142194 | Ref | Assembly, Front Cover (See Separate Breakdown in this Section) | |
| 3 | 1001142968 | Ref | Installation, Front Panel (See Separate Breakdown in this Section) | |
| 4 | 1001148112 | Ref | Installation, Cover Panel (See Separate Breakdown in this Section) | |
| 5 | 8466306 | 1 | Indicator, Level | |
| 6 | 1001168812 | Ref | Installation, Front Wiper (See Separate Breakdown in this Section) | |
| 7 | 1001206068 | Ref | Installation, Brake Pedal (See Separate Breakdown in CONTROLS Section) | |
| 8 | 1001237156 | Ref | Installation, Headliner (See Separate Breakdown in this Section) | |
| 9 | 1001241968 | Ref | Cab (See Separate Breakdown in this Section) | |
| 10 | 1001248291 | Ref | Installation, Steering Column Switch (See Separate Breakdown in CONTROLS Section) | |



MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31211338 Order the manual at mid-west-tech.com >

## FIGURE 8-6. IMPLEMENT LINES INSTALLATION - 3614RS (NO AUX HYDRAULICS)

| ITEM | PART NUMBER | QTY | DESCRIPTION | REV |
|---|---|---|---|---|
| | 1001149648 | Ref | Implement Lines Installation - 3614RS (no auxiliary hydraulics) | I |
| 1 | 2142915 | 2 | Adapter | |
| 2 | 2160016 | 2 | Fitting, Grease | |
| 3 | 1001168803 | 1 | Pin, Lift Cylinder | |
| 4 | 1001168811 | 1 | Pin, Compensation Cylinder | |
| 5 | 1001184284 | 1 | Cylinder, Lift (See Separate Breakdown in HYDRAULIC COMPONENTS Section) | |
| 6 | 1001144203 | 1 | Cylinder, Compensation (See Separate Breakdown in HYDRAULIC COMPONENTS Section) | |
| 8 | 1001174300 | 1 | Hose | |
| 9 | 1001174308 | 1 | Hose | |
| 10 | 1001174305 | 2 | Hose | |
| 12 | 1001174302 | 2 | Hose | |
| 14 | 1001147871 | 1 | Grommet | |
| 15 | 1001178081 | 1 | Channel, Trim | |
| 16 | 0701230 | 1 | Bolt, M12X130 | |
| 17 | 0701632 | 1 | Bolt, M16X150 | |
| 18 | 3291205 | 1 | Nut, Lock, M12X1.75 | |
| 19 | 3291605 | 1 | Nut, Lock, M16X2 | |
| 20 | 4812100 | 2 | Washer, M12 | |
| 21 | 4812300 | 2 | Washer, M16 | |
| 22 | 1001095650 | AR | Compound, Locking | |
| 25 | 1062255 | 2 | Tie, Strap | |



MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31211338 Order the manual at mid-west-tech.com >

## FIGURE 10-3. BATTERY INSTALLATION

| ITEM | PART NUMBER | QTY | DESCRIPTION | REV |
|---|---|---|---|---|
| | 1001239516 | Ref | Battery Installation | D |
| 1 | 0761012 | 1 | Bolt, M10X25 | |
| 2 | 0761212 | 1 | Bolt, M12X25 | |
| 3 | 3290805 | 2 | Nut, Lock M8X1.25 | |
| 5 | 0760810 | 1 | Bolt, M8X20 | |
| 6 | 4812000 | 1 | Washer, M10 | |
| 8 | 4812102 | 1 | Washer, M12 | |
| 9 | 4832100 | 1 | Washer, Lock 12 | |
| 10 | 4831900 | 1 | Washer, Lock 8 | |
| 11 | 4811900 | 3 | Washer, M8 | |
| 12 | 5220800 | 2 | Nut, Ripp 8 | |
| 13 | 1001004723 | 3 | Saddle | |
| 14 | 1001008540 | 1 | Plate | |
| 15 | 1001008559 | 11 | Strap, Cable | |
| 16 | 1001009339 | 1 | Battery | |
| 17 | 1001099701 | 2 | Rod, M8X1.25 | |
| 18 | 1001121265 | 1 | Cable, Battery, Negative to Isolator | |
| 19 | 1001146588 | 4 | Strap, Cable | |
| 20 | 1001147793 | 1 | Cable, Battery, Positive to Starter | |
| 21 | 1001248379 | 1 | Cable, Alternator to Starter | |
| 22 | 1001248380 | 1 | Cable, Glow Plug Power | |
| 23 | 1001147796 | 1 | Cable, Isolator to Frame | |
| 24 | 1001147797 | 1 | Cable, Frame to Engine | |
| 25 | 1001166851 | 1 | Bracket, Battery Clamp | |
| 26 | 1001192142 | 1 | Switch, Disconnect | |
| 27 | 1001239533 | 1 | Harness, Cab Power | |
| 28 | 4832000 | 1 | Washer, Lock 10 | |
| 29 | 5240800 | 2 | Washer, M8 | |



MidWestTech | JLG 3614RS, 4017RS Telehandler Parts Manual | Publication 31211338 Order the manual at mid-west-tech.com >