Illustrated Parts Manual

Model
G5-18A

PVC
1911
2005

P/N
31211364

June 15, 2020 - Rev B

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 13

FIGURE 1-1. HOODS INSTALLATION 14
FIGURE 1-2. HOOD ASSEMBLY 16
FIGURE 1-3. PAD LOCK 18
FIGURE 1-4. TANK INSTALLATION 20
FIGURE 1-5. OIL TANK 22
FIGURE 1-6. FUEL TANK ASSEMBLY 24
FIGURE 1-7. FUEL CAP INSTALLATION 26
FIGURE 1-8. MIRROR INSTALLATION 28
FIGURE 1-9. REAR CONVEX MIRROR INSTALLATION 30
FIGURE 1-10. MIRROR ASSEMBLY (CONVEX) 32
FIGURE 1-11. WHEEL CHOCKS 34
FIGURE 1-12. BATTERY COVER INSTALLATION 36
FIGURE 1-13. REAR COVER PLATE INSTALLATION, (NO HITCH) 38
FIGURE 1-14. HITCH INSTALLATION, MECHANICAL 40
FIGURE 1-15. HITCH INSTALLATION, MECHANICAL, AUITOMATIC 42
FIGURE 1-16. HITCH INSTALLATION 44
FIGURE 1-17. HITCH INSTALLATION - EEC 46
FIGURE 1-18. HITCH ASSEMBLY (FIXED) 48
FIGURE 1-19. HITCH INSTALLATION - CUNA-C 50
FIGURE 1-20. HITCH ASSEMBLY (CUNA-C) 52
FIGURE 1-21. LICENSE HOLDER INSTALLATION, LARGE 54
FIGURE 1-22. LIFT CYLINDER PROP SUPPORT 56

SECTION 2 - BOOM 59

FIGURE 2-1. BOOM ASSEMBLY INSTALLATION, STD W/AUX 60
FIGURE 2-2. BOOM ASSEMBLY INSTALLATION, W/AUX FOR QS 62
FIGURE 2-3. BOOM INSTALLATION, W/O AUXILIARY HYDRAULICS (PVC 1911) 64
FIGURE 2-4. BOOM INSTALLATION, W/O AUXILIARY HYDRAULICS (PVC 2005) 66
FIGURE 2-5. BOOM W/O AUXILIARY HYDRAULIC INSTALLATION (PVC 1911) 68
FIGURE 2-6. BOOM W/O AUXILIARY HYDRAULIC INSTALLATION (PVC 2005) 72
FIGURE 2-7. BOOM W/O AUXILIARY HYDRAULIC INSTALLATION (PVC 2005) 74
FIGURE 2-8. COUPLER INSTALLATION (MANUAL) 78
FIGURE 2-9. COUPLER INSTALLATION (HYDRAULIC) 80
FIGURE 2-10. FORK LOCKING CYLINDER KIT 82
FIGURE 2-11. COUPLER INSTALLATION, UNIVERSAL (MANUAL) 84
FIGURE 2-12. UNIVERSAL QUICK COUPLER ASSEMBLY 86
FIGURE 2-13. BOOM SIDE COVER INSTALLATION 88
FIGURE 2-14. BOOM BRUSHES INSTALLATION 90

SECTION 3 - ATTACHMENTS 93

FIGURE 3-1. CARRIAGE ASSEMBLY, (50INCH/1270MM) 94
FIGURE 3-2. CARRIAGE ASSEMBLY, UNIVERSAL QUICK ATTACH, (48IN/1219.2MM) 96
FIGURE 3-3. CARRIAGE, SIDE TILT, (48IN) 98
FIGURE 3-4. CARRIAGE, SIDE TILT, UNIVERSAL QUICK ATTACH, (48IN) 100
FIGURE 3-5. CARRIAGE, SIDE SHIFT, UNIVERSAL QUICK ATTACH, (48IN) 102
FIGURE 3-6. LIGHT MATERIAL BUCKET, (72INCH) (1.0 YD^3/0.76 M^3) 104
FIGURE 3-7. LIGHT MATERIAL BUCKET, (72INCH) (1.7 YD^3/1.29 M^3) 106
FIGURE 3-8. MULTI-PURPOSE GRAPPLE BUCKET (1850MM) (ANSI - JLG) 108
FIGURE 3-9. UNIVERSAL HITCH ATTACHMENT 110
FIGURE 3-10. BLOCKING FORK (50X50X1220) 112
FIGURE 3-11. PALLET FORK (2X4X48) 114
FIGURE 3-12. LUMBER FORK (40X150X1540) 116
FIGURE 3-13. FORK MOUNTED HOOK (4 TON) 118
FIGURE 3-14. BOLT-ON EDGE ASSEMBLY, 72" 120
FIGURE 3-15. HYDRAULIC QUICK SWITCH INSTALLATION 122
FIGURE 3-16. QUICK SWITCH ASSEMBLY 124
FIGURE 3-17. BLOCK VALVE ASSEMBLY 126
FIGURE 3-18. FORK MOUNTED BUCKET (1.0 M^3) 128
FIGURE 3-19. BASKET, PERSONNEL (1.2MX2.4M) (DOMESTIC) 130
FIGURE 3-20. BASKET, PERSONNEL (1.2MX2.4M) (ISO) 132
FIGURE 3-21. BASKET, PERSONNEL (1.2MX2.4M) (FRENCH) 134
FIGURE 3-22. FORK MOUNTED PLATFORM 136

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211364 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 3-23. TRASH HOPPER INSTALLATION 138

SECTION 4 - ENGINE AND ATTACHING PARTS 141

FIGURE 4-1. ENGINE INSTALLATION 142
FIGURE 4-2. ENGINE MOUNT INSTALLATION 144
FIGURE 4-3. ENGINE MOUNT INSTALLATION, (HEATER) 146
FIGURE 4-4. ENGINE MOUNT INSTALLATION, (HEATER & A/C) 148
FIGURE 4-5. ENGINE (55.4KW - ULS) 150
FIGURE 4-6. ENGINE (55.4KW - LS) 152
FIGURE 4-7. FAN INSTALLATION 154
FIGURE 4-8. FAN INSTALLATION, REVERSING 156
FIGURE 4-9. RADIATOR INSTALLATION 158
FIGURE 4-10. RADIATOR LOWER HOSE ASSEMBLY 160
FIGURE 4-11. AIR CLEANER INSTALLATION 162
FIGURE 4-12. AIR FILTER 164
FIGURE 4-13. RAIN CAP 166
FIGURE 4-14. PRECLEANER 168
FIGURE 4-15. EXHAUST INSTALLATION (ULS) 170
FIGURE 4-16. EXHAUST INSTALLATION (LS) 172
FIGURE 4-17. HYDROSTATIC DRIVE PUMP ASSEMBLY 174
FIGURE 4-18. HEATER LINES INSTALLATION 176
FIGURE 4-19. LUBRICITY DOSER INSTALLATION (MIRROR) 178
FIGURE 4-20. LUBRICITY DOSER INSTALLATION (LIGHT & MIRROR) 180
FIGURE 4-21. AIR SHUT OFF VALVE INSTALLATION 182

SECTION 5 - DRIVE TRAIN 185

FIGURE 5-1. DRIVETRAIN INSTALLATION 186
FIGURE 5-2. FRONT AXLE ASSEMBLY 188
FIGURE 5-3. FRONT AXLE 190
FIGURE 5-4. FRONT AXLE, CENTRAL HOUSING 192
FIGURE 5-5. FRONT AXLE, DIFFERENTIAL 194
FIGURE 5-6. FRONT AXLE, HUB REDUCTION 196
FIGURE 5-7. FRONT AXLE, BRAKES 200
FIGURE 5-8. FRONT AXLE, STEERING 202
FIGURE 5-9. REAR AXLE ASSEMBLY 204
FIGURE 5-10. REAR AXLE 206
FIGURE 5-11. REAR AXLE, CENTRAL HOUSING 208
FIGURE 5-12. REAR AXLE, DIFFERENTIAL 210
FIGURE 5-13. REAR AXLE, HUB REDUCTION 212
FIGURE 5-14. REAR AXLE, STEERING 214
FIGURE 5-15. REAR AXLE, TRUNION 216
FIGURE 5-16. DIFFERENTIAL KIT 218
FIGURE 5-17. STEERING CASE KIT (LF/RR) 220
FIGURE 5-18. STEERING CASE KIT (RF/LR) 222
FIGURE 5-19. RING GEAR SUPPORT KIT 224
FIGURE 5-20. PLANET GEAR CARRIER KIT 226
FIGURE 5-21. TIRE/WHEEL SET, CAMSO (AIR 12-16.5 - 12 PLY) 228
FIGURE 5-22. RIGHT TIRE/WHEEL ASSEMBLY, CAMSO (AIR 12-16.5 - 12 PLY) 230
FIGURE 5-23. LEFT TIRE/WHEEL ASSEMBLY, CAMSO (AIR 12-16.5 - 12 PLY) 232
FIGURE 5-24. TIRE/WHEEL SET, FIRESTONE (AIR 12-16.5 - 12 PLY) 234
FIGURE 5-25. RIGHT TIRE/WHEEL ASSEMBLY, FIRESTONE (AIR 12-16.5 - 12 PLY) 236
FIGURE 5-26. LEFT TIRE/WHEEL ASSEMBLY, FIRESTONE (AIR 12-16.5 - 12 PLY) 238
FIGURE 5-27. TIRE/WHEEL SET (AIR 14-17.5 - 12 PLY) 240
FIGURE 5-28. RIGHT TIRE/WHEEL ASSEMBLY (AIR 12-16.5 - 12 PLY) 242
FIGURE 5-29. LEFT TIRE/WHEEL ASSEMBLY (AIR 12-16.5 - 12 PLY) 244
FIGURE 5-30. TIRE/WHEEL SET, CAMSO (FOAM 12-16.5 - 12 PLY) 246
FIGURE 5-31. TIRE/WHEEL SET, FIRESTONE (FOAM 12-16.5 - 12 PLY) 248
FIGURE 5-32. TIRE/WHEEL SET (FOAM 12-16.5 - 14 PLY) 250
FIGURE 5-33. TIRE/WHEEL SET (SOLID 33X12-20 - NM) 252
FIGURE 5-34. TIRE/WHEEL SET, AG (AIR 10.5-18 - 16 PR) 254
FIGURE 5-35. RIGHT TIRE/WHEEL ASSEMBLY, AG (AIR 10.5-18 - 16 PR) 256
FIGURE 5-36. LEFT TIRE/WHEEL ASSEMBLY, AG (AIR 10.5-18 - 16 PR) 258
FIGURE 5-37. FENDER INSTALLATION 260
FIGURE 5-38. FENDER ASSEMBLY 262
FIGURE 5-39. TIRE/WHEEL SET 33X16LL19.5 TURF/SAND 264

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211364 Order the manual at mid-west-tech.com >

FIGURE 5-40. ASSEMBLY, TIRE/WHEEL 33X16LL19.5 TURF/SAND 266

SECTION 6 - CAB 269

FIGURE 6-1. CAB INSTALLATION 270
FIGURE 6-2. OPEN CAB INSTALLATION (ANSI - FIXED STEERING) 272
FIGURE 6-3. OPEN CAB INSTALLATION (ANSI - TILT STEERING) 274
FIGURE 6-4. ENCLOSED CAB INSTALLATION (ANSI - TILT STEERING) (HEAT) 276
FIGURE 6-5. ENCLOSED CAB INSTALLATION (ANSI - TILT STEERING) (HEAT & A/C) 278
FIGURE 6-6. ENCLOSED CAB INSTALLATION (LSI - TILT STEERING) (HEAT) 280
FIGURE 6-7. ENCLOSED CAB INSTALLATION (LSI - TILT STEERING) (HEAT & A/C) 282
FIGURE 6-8. CAB COMMON INSTALLATION 284
FIGURE 6-9. CAB COMMON COMPONENTS, ENCLOSED 288
FIGURE 6-10. CAB GLASS INSTALLATION, OPEN 290
FIGURE 6-11. CAB GLASS INSTALLATION, ENCLOSED 292
FIGURE 6-12. REAR WINDOW ASSEMBLY 294
FIGURE 6-13. DOOR ASSEMBLY INSTALLATION 296
FIGURE 6-14. JLG COMMON INSTALLATION 298
FIGURE 6-15. SEAT RISER COVER INSTALLATION 300
FIGURE 6-16. SEAT RISER COVER INSTALLATION, HVAC 302
FIGURE 6-17. OPEN CAB COMMON COMPONENTS INSTALLATION 304
FIGURE 6-18. DASH INSTALLATION, OPEN CAB 306
FIGURE 6-19. DASH INSTALLATION, ENCLOSED CAB 308
FIGURE 6-20. RIGHT SIDE CONSOLE 310
FIGURE 6-21. NA COMMON INSTALLATION 312
FIGURE 6-22. NA COMMON COMPONENTS INSTALLATION (LSI) 314
FIGURE 6-23. FRONT WIPER ASSSEMBLY 316
FIGURE 6-24. WASHER TANK W/PUMP INSTALLATION 318
FIGURE 6-25. ROOF/REAR WIPER INSTALLATION 320
FIGURE 6-26. AUX WIPER ASSEMBLY 322
FIGURE 6-27. SEAT 324
FIGURE 6-28. SEAT, LSI 326
FIGURE 6-29. SEAT BELT INSTALLATION (3 INCH) 328
FIGURE 6-30. SEAT BELT INSTALLATION, LSI (3 INCH) 330
FIGURE 6-31. CONTROL COVER INSTALLATION 332
FIGURE 6-32. HEATER INSTALLATION (CAB PARTS) 334
FIGURE 6-33. HEATER AND A/C INSTALLATION (CAB PARTS) 336
FIGURE 6-34. HEATER ASSEMBLY, 3 SPEED 338
FIGURE 6-35. HEATER AND A/C ASSEMBLY, 3 SPEED 340
FIGURE 6-36. HEATER 342
FIGURE 6-37. HEATER AND A/C 344
FIGURE 6-38. A/C KIT 346
FIGURE 6-39. A/C CONDENSER INSTALLATION 348
FIGURE 6-40. CONDENSER 350
FIGURE 6-41. OVERHEAD CONSOLE INSTALLATION 352
FIGURE 6-42. OVERHEAD CONSOLE INSTALLATION (OPEN) 354
FIGURE 6-43. FRONT FOPS INSTALLATION 356
FIGURE 6-44. OVERHEAD CONSOLE INSTALLATION (LSI) 358
FIGURE 6-45. RADIO READY PACKAGE INSTALLATION 360
FIGURE 6-46. FLOOR MAT INSTALLATION 362
FIGURE 6-47. CAB FENDER INSTALLATION 364
FIGURE 6-48. CAB GUARD INSTALLATION (TOP) 366
FIGURE 6-49. CAB GUARD INSTALLATION (FRONT) 368
FIGURE 6-50. REAR WINDOW ENTRY KIT INSTALLATION (ANSI) 370
FIGURE 6-51. REAR WINDOW ENTRY KIT INSTALLATION (ENGLISH/FRENCH) 372
FIGURE 6-52. REAR WINDOW ENTRY KIT INSTALLATION (ISO) 374
FIGURE 6-53. FIRE EXTINQUISHER INSTALLATION 376
FIGURE 6-54. WASHER FLUID TANK ASSEMBLY 378
FIGURE 6-55. EMERGENCY ENTRY/EXIT WINDOW 380

SECTION 7 - CONTROLS 383

FIGURE 7-1. ACCELERATOR PEDAL ASSEMBLY (PVC 1911) 384
FIGURE 7-2. ACCELERATOR PEDAL ASSEMBLY (PVC 2005) 386
FIGURE 7-3. ACCELERATOR PEDAL (PVC 1911) 388
FIGURE 7-4. ACCELERATOR PEDAL (PVC 2005) 390
FIGURE 7-5. BRAKE PEDAL INSTALLATION 392

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211364 Order the manual at mid-west-tech.com >

FIGURE 4-6. ENGINE (55.4KW - LS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
1	1001139668	Ref	Engine (55.4KW - LS)	G
	70029015	1	Fan	
	3580158	1	PULLEY	
	70025150	1	V-GROOVED PULLEY	
	1001225430	1	FILTER,FUEL PRIMARY	
	1001225432	1	FILTER,FUEL ELEMENT	
	70025162	1	OIL PAN, (includes items 2 AND 3)	
	70028929	1	V-Grooved Pulley	
	70028540	1	Sender, Temperature	
	7016331	1	Filter, Oil	
	7020465	2	Cap, Filler	
	70025181	1	Injector, Fuel	
	70024913	1	NARROW V-BELT	
	70006652	1	Alternator	
	70024915	1	Starter (Not Shown - Located on Left Side)	
	70024904	1	DIPSTICK, (includes item 2)	
	70024911	1	TURBOCHARGER	
	70005941	1	Plug, Oil	

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211364 Order the manual at mid-west-tech.com >

FIGURE 6-8. CAB COMMON INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001202007	Ref	Cab Common Installation	H
1	80325	1	Pin	
2	0641406	2	Bolt, 1/4-20X3/4	
3	0641408	7	Bolt, 1/4-20X1	
4	0641508	2	Bolt, 5/16-18X1	
5	0761012	4	Bolt, M10X25	
7	3931412	12	Screw	
9	4711500	2	Washer, 5/16	
10	4761400	9	Washer, Lock 1/4	
11	8035487	1	Screw	
12	8303034	15	Screw	
13	8307109	8	Washer	
14	8310053	4	Washer	
15	8466306	1	Gage, Tilt Angle	
16	88521205	4	Nut, Lock	
17	1001080371	1	Switch	
18	1001080380	1	Switch	
19	1001080462	1	Wheel, Steering	
20	1001080493	1	Console	
21	1001080500	1	Assembly, Hydraulic Controller (See Separate Breakdown in Controls Section)	
22	1001080559	1	Assembly, Master Cylinder Valve (See Separate Breakdown in Controls Section)	
23	1001239184	1	Chart, Load	
24	1001080900	1	Clamp	
25	1001080983	1	Bracket	
26	1001080986	4	Screw	
27	1001080987	4	Nut	
28	1001080988	4	Washer	
29	1001081049	1	Grommet	
32	1001081151	1	Bracket	
33	1001081152	1	Reservoir, Brake	
34	1001081153	1	Hose	
35	1001098235	1	Harness, Mode Select (See Separate Breakdown in Electrical Section)	
36	1001108079	2	Screw	
37	1001108194	8	Screw	
39	1001114867	1	Screw	
40	1001117158	1	Plate	
41	1001137657	1	Guage	
42	1001138639	1	Assembly, Accelerator Pedal (PVC 1911) (See Separate Breakdown in Controls Section)	
42	1001258791	1	Assembly, Accelerator Pedal (PVC 2005) (See Separate Breakdown in Controls Section)	
43	1001156087	2	Clamp	
44	1001189734	1	Installation, Brake Pedal (See Separate Breakdown in Controls Section)	
46	1001202006	1	Assembly, Steering Valve (See Separate Breakdown in Hydraulic Components Section)	
47	1001080418	1	Harness	
48	1001156577	1	Decal, Fuse	

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211364 Order the manual at mid-west-tech.com >

FIGURE 8-20. CAB HYDRAULICS INSTALLATION, (ANSI)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001235716	Ref	Cab Hydraulics Installation, (ANSI)	A
1	2170506	1	Adapter, Run Tee	
2	1001080250	1	Hose Assembly	
3	1001080251	1	Hose Assembly	
4	1001080265	1	Hose Assembly	
5	1001080266	1	Hose Assembly	
6	1001209063	1	Hose Assembly	
7	1001080585	1	Hose Assembly	
8	1001080586	1	Hose Assembly	
9	1001106622	1	Hose Assembly	
10	1001236417	1	Hose Assembly	
11	1001129895	2	Hose Assembly	
12	1001144756	1	Hose Assembly	
13	1001080356	1	Hose Assembly	
14	1001145224	1	Hose Assembly	
15	1001145225	1	Hose Assembly	
16	1001202297	1	Hose Assembly	

MidWestTech | JLG G5-18A Telehandler Parts Manual | Publication 31211364 Order the manual at mid-west-tech.com >