Illustrated Parts Manual

Model
1644

PVC
1911
2005

P/N
31211379

June 15, 2020 - Rev B

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. GROMMETS INSTALLATION 16
FIGURE 1-2. TANKS INSTALLATION 18
FIGURE 1-3. HYDRAULIC TANK INSTALLATION 20
FIGURE 1-4. HYDRAULIC TANK ASSEMBLY 22
FIGURE 1-5. FUEL TANK INSTALLATION 24
FIGURE 1-6. FUEL TANK ASSEMBLY 26
FIGURE 1-7. TANK SUPPORT INSTALLATION 28
FIGURE 1-8. LOCKING FUEL CAP 30
FIGURE 1-9. PAD LOCK 32
FIGURE 1-10. ENGINE ENCLOSURE & HOOD INSTALLATION 34
FIGURE 1-11. ENGINE HOOD ASSEMBLY 36
FIGURE 1-12. ENGINE ENCLOSURE ASSEMBLY 38
FIGURE 1-13. COVER INSTALLATION (ULS) 40
FIGURE 1-14. FRAME COVER INSTALLATION 42
FIGURE 1-15. FRONT LOWER COVER INSTALLATION 44
FIGURE 1-16. MIRRORS INSTALLATION 46
FIGURE 1-17. WHEEL CHOCKS INSTALLATION 48

SECTION 2 - BOOM 51

FIGURE 2-1. BOOM INSTALLATION 52
FIGURE 2-2. BOOM ASSEMBLY 54
FIGURE 2-3. FIRST BOOM SECTION ASSEMBLY 56
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 58
FIGURE 2-5. THIRD BOOM SECTION ASSEMBLY 60
FIGURE 2-6. COUPLER INSTALLATION (MANUAL) 62
FIGURE 2-7. COUPLER INSTALLATION (HYDRAULIC) 64
FIGURE 2-8. COUPLER LOCKING CYLINDER ASSEMBLY 66
FIGURE 2-9. MANUAL COUPLER PIN HOLDER INSTALLATION 68
FIGURE 2-10. BOOM PROP INSTALLATION 70
FIGURE 2-11. BOOM PROP BRACKET ASSEMBLY 72
FIGURE 2-12. BOOM BRUSHES INSTALLATION 74

SECTION 3 - ATTACHMENTS 77

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION - COMPLETE 78
FIGURE 3-2. ATTACHMENT RECOGNITION INSTALLATION 80
FIGURE 3-3. ATTACHMENT RECOGNITION RECEIVER 82
FIGURE 3-4. ATTACHMENT RECOGNITION ANTENNA 84
FIGURE 3-5. BALE HANDLER (ROUND BALES) 86
FIGURE 3-6. BALE HANDLER (SQUARE BALES) 90
FIGURE 3-7. BASKET, PERSONNEL (1.2MX2.4M) (DOMESTIC) 92
FIGURE 3-8. BASKET, PERSONNEL (1.2MX2.4M) (FRENCH LANGUAGE) 94
FIGURE 3-9. BASKET ASSEMBLY - FORK MOUNTED 96
FIGURE 3-10. BASKET DOCKING STATION 98
FIGURE 3-11. BOOM - TRUSS (3.6TON FORK MOUNTED) 100
FIGURE 3-12. BOOM - TRUSS (7.6 TON) 102
FIGURE 3-13. BUCKET (2.6 YD^3/2.0M^3) 104
FIGURE 3-14. BUCKET (5.23 YD^3) 106
FIGURE 3-15. BUCKET - 4 IN 1 (1.3 YD^3/1.0M^3) 108
FIGURE 3-16. BUCKET - GRAPPLE (1.7 YD^3/1.3M^3) 110
FIGURE 3-17. BUCKET - FORK MOUNTED (1.0M^3) 112
FIGURE 3-18. CARRIAGE ASSEMBLY (60IN/1524MM) 114
FIGURE 3-19. CARRIAGE ASSEMBLY (72IN/1829MM) 116
FIGURE 3-20. CARRIAGE ASSEMBLY (87IN/2290MM) 118
FIGURE 3-21. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING CARRIAGE (72IN/1829MM) 120
FIGURE 3-22. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING SIDE SHIFT CARRIAGE (75IN/1899MM) 122
FIGURE 3-23. CARRIAGE ASSEMBLY - LOG HANDLER CARRIAGE 124
FIGURE 3-24. CARRIAGE ASSEMBLY - PIPE HANDLER CARRIAGE 128
FIGURE 3-25. CARRIAGE ASSEMBLY - STEEL COIL HANDLER CARRIAGE 132
FIGURE 3-26. FORK - PALLET (2.25X6X48) 134
FIGURE 3-27. FORK - PALLET (2.25X6X60) 136
FIGURE 3-28. FORK - PALLET (2.25X6X72) 138
FIGURE 3-29. FORK - PALLET (2.25X6X96) 140

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211379 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-30. FORK RETENTION INSTALLATION....142
FIGURE 3-31. HOOK - CRANK (7.6 TON)....144
FIGURE 3-32. HOOK - FORK MOUNTED....146
FIGURE 3-33. HOPPER - TRASH....148
FIGURE 3-34. WINCH - COUPLER MOUNTED....150

SECTION 4 - ENGINE AND ATTACHING PARTS....153

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS)....154
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS)....156
FIGURE 4-3. ENGINE INSTALLATION (ULS)....158
FIGURE 4-4. ENGINE ASSEMBLY (ULS)....160
FIGURE 4-5. ENGINE MOUNT INSTALLATION....164
FIGURE 4-6. AIR INTAKE INSTALLATION (ULS)....166
FIGURE 4-7. AIR CLEANER INSTALLATION....168
FIGURE 4-8. AIR CLEANER ASSEMBLY....170
FIGURE 4-9. AIR INTAKE DUCT INSTALLATION....172
FIGURE 4-10. PRIMARY FUEL FILTER INSTALLATION (ULS)....174
FIGURE 4-11. REMOTE FUEL PUMP INSTALLATION....176
FIGURE 4-12. FUEL LINES INSTALLATION (ULS)....178
FIGURE 4-13. HYDROSTATIC ADAPTOR INSTALLATION....180
FIGURE 4-14. DUAL DRIVE SUPPORT ASSEMBLY....182
FIGURE 4-15. HYDROSTATIC DRIVE PUMP INSTALLATION....184
FIGURE 4-16. HYDROSTATIC DRIVE PUMP ASSEMBLY....186
FIGURE 4-17. IMPLEMENT PUMP INSTALLATION....188
FIGURE 4-18. IMPLEMENT PUMP ASSEMBLY....190
FIGURE 4-19. DEF COOLANT LINES INSTALLATION (ULS)....192
FIGURE 4-20. COOLING PACKAGE INSTALLATION (ULS & NO HIGH AMBIENT)....194
FIGURE 4-21. COOLING PACKAGE INSTALLATION (ULS ASOV)....196
FIGURE 4-22. RADIATOR - COOLING PACKAGE....200
FIGURE 4-23. RADIATOR LINES INSTALLATION (ALL EXCEPT ULS & LS ASOV)....202
FIGURE 4-24. RADIATOR LINES INSTALLATION (ULS ASOV)....204
FIGURE 4-25. COOLANT LINES INSTALLATION....206
FIGURE 4-26. SURGE TANK INSTALLATION....208
FIGURE 4-27. TRANSMISION OIL COOLER LINES INSTALLATION....210
FIGURE 4-28. FAN GUARD INSTALLATION....212
FIGURE 4-29. FAN GUARD (REVERSING) INSTALLATION....214
FIGURE 4-30. COOLING FAN INSTALLATION....216
FIGURE 4-31. COOLING FAN (REVERSING) INSTALLATION....218
FIGURE 4-32. COOLING FAN COVER (REVERSING) INSTALLATION....220
FIGURE 4-33. EXHAUST INSTALLATION (ULS)....222
FIGURE 4-34. DEF TANK INSTALLATION....224
FIGURE 4-35. DEF TANK ASSEMBLY....226
FIGURE 4-36. DEF LINES INSTALLATION....228
FIGURE 4-37. DEF CONTROL MODULE INSTALLATION....230
FIGURE 4-38. HEATER LINES INSTALLATION (ULS)....232
FIGURE 4-39. A/C PUMP INSTALLATION....234
FIGURE 4-40. A/C LINES INSTALLATION....236
FIGURE 4-41. BLOCK HEATER INSTALLATION (115V) (ULS)....238
FIGURE 4-42. HEATED BREATHER TUBE INSTALLATION....240

SECTION 5 - DRIVE TRAIN....243

FIGURE 5-1. DRIVETRAIN INSTALLATION....244
FIGURE 5-2. HYDROSTATIC MOTOR INSTALLATION....246
FIGURE 5-3. HYDROSTATIC MOTOR ASSEMBLY....248
FIGURE 5-4. GEARBOX INSTALLATION....250
FIGURE 5-5. GEAR BOX....252
FIGURE 5-6. DRIVE SHAFT INSTALLATION....256
FIGURE 5-7. FRONT AXLE INSTALLATION....258
FIGURE 5-8. FRONT AXLE MOUNTING INSTALLATION....260
FIGURE 5-9. FRONT AXLE....262
FIGURE 5-10. FRONT AXLE, CENTRAL HOUSING....264
FIGURE 5-11. FRONT AXLE, DIFFERENTIAL....266
FIGURE 5-12. DIFFERENTIAL KIT....268
FIGURE 5-13. FRONT AXLE, HUB REDUCTION....270
FIGURE 5-14. FRONT AXLE, BRAKES....272

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211379 Order the manual at mid-west-tech.com >

FIGURE 5-15. FRONT AXLE, STEERING 274
FIGURE 5-16. FRONT AXLE, TRUNION 276
FIGURE 5-17. FRONT AXLE LINES INSTALLATION 278
FIGURE 5-18. REAR AXLE INSTALLATION 280
FIGURE 5-19. REAR AXLE MOUNTING INSTALLATION 282
FIGURE 5-20. REAR AXLE, BRAKES 284
FIGURE 5-21. REAR AXLE, STEERING 286
FIGURE 5-22. REAR AXLE 288
FIGURE 5-23. REAR AXLE, CENTRAL HOUSING 290
FIGURE 5-24. REAR AXLE, DIFFERENTIAL 292
FIGURE 5-25. DIFFERENTIAL KIT 294
FIGURE 5-26. REAR AXLE, HUB REDUCTION 296
FIGURE 5-27. STEERING CASE KIT (RF, LR) 298
FIGURE 5-28. STEERING CASE KIT (LF, RR) 300
FIGURE 5-29. REAR AXLE, TRUNION 302
FIGURE 5-30. TRUNION KIT 304
FIGURE 5-31. RING GEAR SUPPORT KIT 306
FIGURE 5-32. REDUCTION BUSHING KIT 308
FIGURE 5-33. PLANET GEAR CARRIER KIT 310
FIGURE 5-34. REAR AXLE LINES INSTALLATION 312
FIGURE 5-35. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 314
FIGURE 5-36. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 316
FIGURE 5-37. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 318
FIGURE 5-38. FENDER INSTALLATION 320
FIGURE 5-39. RH FENDER ASSEMBLY 322
FIGURE 5-40. LH FENDER ASSEMBLY 324

SECTION 6 - CAB 327

FIGURE 6-1. CAB MOUNTING INSTALLATION 328
FIGURE 6-2. FRONT CAB MOUNT BRACKET INSTALLATION 330
FIGURE 6-3. CAB MOUNTS INSTALLATION 332
FIGURE 6-4. CAB COMPONENTS INSTALLATION 334
FIGURE 6-5. CAB INSTALLATION 336
FIGURE 6-6. CAB ASSEMBLY (PVC 1911) 338
FIGURE 6-7. CAB ASSEMBLY (PVC 2005) 340
FIGURE 6-8. DOOR INSTALLATION 342
FIGURE 6-9. DOOR ASSEMBLY 344
FIGURE 6-10. CAB DOOR 346
FIGURE 6-11. DOOR UPPER GLASS ASSEMBLY 348
FIGURE 6-12. CAB LATCH ASSEMBLY 350
FIGURE 6-13. CAB DOOR TRIGGER ASSEMBLY 352
FIGURE 6-14. DOOR STRAP INSTALLATION 354
FIGURE 6-15. CAB PLUG GROUP 356
FIGURE 6-16. REAR WINDOW INSTALLATION 358
FIGURE 6-17. REAR WINDOW GROUP 360
FIGURE 6-18. REAR WIPER INSTALLATION 362
FIGURE 6-19. REAR WINDOW RELEASE INSTALLATION (ANSI - ENGLISH) 364
FIGURE 6-20. REAR WINDOW RELEASE INSTALLATION (ENGLISH/FREMCH) 366
FIGURE 6-21. FRONT WIPER INSTALLATION 368
FIGURE 6-22. WASHER TANK INSTALLATION 370
FIGURE 6-23. WASHER BOTTLE 372
FIGURE 6-24. FRONT COVER INSTALLATION 374
FIGURE 6-25. FRONT DUCT COVER 376
FIGURE 6-26. FILTER TRAY PANEL 378
FIGURE 6-27. LEVEL INDICATOR INSTALLATION 380
FIGURE 6-28. BASIC MIRROR INSTALLATION 382
FIGURE 6-29. MULTIFUNCTION DISPLAY INSTALLATION 384
FIGURE 6-30. SEAT INSTALLATION (CLOTH) 386
FIGURE 6-31. SEAT ASSEMBLY 388
FIGURE 6-32. SEAT INSTALLATION (AIR SUSPENSION - STANDARD) 390
FIGURE 6-33. SEAT ASSEMBLY (AIR SUSPENSION - STANDARD) 392
FIGURE 6-34. UPPER SEAT ASSEMBLY 394
FIGURE 6-35. SUSPENSION KIT 396
FIGURE 6-36. SEAT INSTALLATION (AIR SUSPENSION - PREMIUM) 398
FIGURE 6-37. SEAT ASSEMBLY (AIR SUSPENSION - PREMIUM) 400
FIGURE 6-38. SEAT BELT INSTALLATION (3IN) 402

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211379 Order the manual at mid-west-tech.com >

FIGURE 10-64. FRAME - REAR FRAME HARNESS, MINING

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001228741	Ref	Front Frame Harness, Mining	A
1	1001161957	1	Connector	
2	1001161097	6	Terminal	
3	1001161100	18	Plug	
4	1001161101	8	Plug	
5	1001161963	1	Connector	
6	1001161097	26	Terminal	
7	1001161100	14	Plug	
8	1001161099	6	Terminal	
9	1001161101	2	Plug	
10	1001160500	1	Connector	
11	1001161100	18	Plug	
12	1001161097	6	Terminal	
13	1001161099	8	Terminal	
14	4461118	1	Connector	
15	1001107854	2	Terminal	
16	1001116763	2	Terminal Seal	
17	1001116996	1	Connector	
18	1001118392	6	Terminal	
19	1001116696	1	Plug	
20	4461054	6	Terminal Seal	
21	4461262	1	Connector	
22	1001107854	3	Terminal	
23	1001104498	3	Terminal Seal	
24	4460891	1	Connector	
25	4460465	2	Terminal	
26	4460891	1	Connector	
27	4460465	2	Terminal	
28	4460884	1	Connector	
29	4460465	4	Terminal	
30	4460891	1	Connector	
31	4460465	2	Terminal	
32	1001160509	1	Connector	
33	1001160510	1	Terminal	
34	1001175267	1	Terminal Seal	
35	4460884	1	Connector	
36	4460932	1	Mating Connector	
37	4460465	4	Terminal	
38	4460466	1	Plug	
39	4460884	1	Connector	
40	4460932	1	Mating Connector	
41	4460466	2	Plug	
42	4460465	2	Terminal	
43	4460894	1	Connector	
44	4460899	1	Mating Connector	
45	4460466	3	Plug	
46	4460465	3	Terminal	
47	4461018	1	Connector	
48	4461017	1	Mating Connector	
49	4460509	2	Terminal	

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211379 Order the manual at mid-west-tech.com >

FIGURE 10-92. REMOTE CONTROL (BOOM)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001259256	Ref	Remote Control (Boom)	A
1	0760615	2	Bolt M6 x 35	
2	0760808	3	Bolt M8 x 16	
3	3311005	2	Nut #10	
4	3911010	2	Screw #10X5/8	
5	4360657	1	Switch, Ignition	
6	4711000	4	Washer #10	
7	4811700	2	Washer M6	
8	4811900	3	Washer M8	
9	1001008559	4	Strap, As-Cable (Not Shown)	
10	1001181516	1	Decal - Platform Ignition Switch	
11	1001200910	1	Light, Beacon (Blue)	
12	1001206112	1	Control, Remote Controller	
13	1001209194	1	Control, Remote	
14	1001241610	1	Harness, Key (See Separate Breakdown in this Section)	
15	1001258749	1	Bracket, Roof Beacon	
16	1001259205	1	Harness, Remote Control Power (See Separate Breakdown in this Section)	
17	1001259231	1	Installation, Harness (Emergency Lowering - Frame)	
17	1001008559	1	Strap, As-Cable (Not Shown)	
17	1001258719	1	Harness, Emergency Lowering - Frame (See Separate Breakdown in this Section)	
18	1001259246	1	Installation, Emergency Stop Switch (See Separate Breakdown in this Section)	
19	1001259258	1	Installation, Manual Pump (Lift/Tele) (Not Shown) (See Separate Breakdown in HYDRAULIC Section)	

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211379 Order the manual at mid-west-tech.com >

FIGURE 11-2. DECAL INSTALLATION (ENGLISH)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001192745	Ref	Decal Installation (English)	K
1	1670836	1	Cover, Boom	
2	1701500	2	Decal, Lift	
3	See Note	NSS	Decal, Bar Code (Note: Not Available for Purchase)	
5	1706300	1	Decal, Ether Warning	
6	1706296	1	Decal, Battery Warning	
7	1001195849	1	Decal, Carry Personnel	
8	1706299	1	Decal, Contacting Power Lines Warning	
9	1706301	1	Decal, Keep Clear Of Rotating Parts Warning	
10	1706306	1	Decal, Tip Over Warning	
11	1706302	2	Decal, Pinch Point Boom Holes	
12	3251813	1	Decal, USA	
13	4109801	4	Decal, Tie Down Point	
18	1001094708	1	Decal, Hydraulic Oil	
21	1706850	1	Decal, Crush Hazard Warning	
22	1706768	1	Decal, Vehicle Roll Away	
23	1707078	1	Decal, Warning/Danger	
24	1001109053	1	Decal, Coolant Fill	
26	1001130323	1	Decal, Oil Level	
27	1001131271	1	Decal, Patent	
28	1001218704	1	Decal, Ultra Low Sulfur Diesel	
29	1001139578	1	Decal, Hot Fluid Warning	
32	1001171277	1	Decal, Boom Extend	
33	1001172035	1	Decal, No Weld or Drill	
35	1001184632	1	Decal, Battery Positive	
36	1001188372	1	Decal, Sway	
38	1001191229	1	Decal, Fuse Panel	
41	1001195855	1	Decal, Battery Disconnect	
42	1001196806	1	Decal, Diesel Exhaust Fluid	
43	1001227287	1	Decal, Manual	
45	1001214206	1	Decal, Park Brake	
46	AU2105	1	Decal, No Karcher	
47	1001207217	1	Decal, Danger Swinging Loads	
48	1001218659	1	Decal, Brake Fluid	
49	1001219212	1	Decal, DEF Fluid	
50	1001222650	2	Decal, Axle Lift	
51	1001223453	1	DECAL,ICES (CAN)	
53	1001231801	1	Decal, Warning Prop 65	
54	1001247646	1	Decal, DEF Min. Refill Volume	

MidWestTech | JLG 1644 Telehandler Parts Manual | Publication 31211379 Order the manual at mid-west-tech.com >