Illustrated Parts Manual

Model
7013H

PVC
1911
2005

P/N
31211380

June 15, 2020 - Rev B

An Oshkosh Corporation Company

MidWestTech | JLG 7013H Telehandler Parts Manual | Publication 31211380

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. GROMMETS INSTALLATION 16
FIGURE 1-2. TANKS INSTALLATION 18
FIGURE 1-3. HYDRAULIC TANK INSTALLATION 20
FIGURE 1-4. HYDRAULIC TANK ASSEMBLY 22
FIGURE 1-5. FUEL TANK INSTALLATION 24
FIGURE 1-6. FUEL TANK ASSEMBLY 26
FIGURE 1-7. TANK SUPPORT INSTALLATION 28
FIGURE 1-8. LOCKING FUEL CAP 30
FIGURE 1-9. PAD LOCK 32
FIGURE 1-10. ENGINE ENCLOSURE & HOOD INSTALLATION 34
FIGURE 1-11. ENGINE HOOD ASSEMBLY 36
FIGURE 1-12. ENGINE HOOD INSULATION INSTALLATION 38
FIGURE 1-13. ENGINE ENCLOSURE ASSEMBLY 40
FIGURE 1-14. COVER INSTALLATION (ULS) 42
FIGURE 1-15. COVER INSTALLATION (LS) 44
FIGURE 1-16. FRAME COVER INSTALLATION 46
FIGURE 1-17. FRONT LOWER COVER INSTALLATION 48
FIGURE 1-18. MIRRORS INSTALLATION 50
FIGURE 1-19. WHEEL CHOCKS INSTALLATION 52
FIGURE 1-20. REFLECTORS INSTALLATION 54

SECTION 2 - BOOM 57

FIGURE 2-1. BOOM INSTALLATION 58
FIGURE 2-2. BOOM ASSEMBLY 60
FIGURE 2-3. FIRST BOOM SECTION ASSEMBLY 62
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 64
FIGURE 2-5. THIRD BOOM SECTION ASSEMBLY 66
FIGURE 2-6. COUPLER INSTALLATION (MANUAL) 68
FIGURE 2-7. COUPLER INSTALLATION (HYDRAULIC) 70
FIGURE 2-8. COUPLER LOCKING CYLINDER ASSEMBLY 72
FIGURE 2-9. MANUAL COUPLER PIN HOLDER INSTALLATION 74
FIGURE 2-10. BOOM ANGLE INDICATOR INSTALLATION 76
FIGURE 2-11. BOOM PROP INSTALLATION 78
FIGURE 2-12. BOOM PROP BRACKET ASSEMBLY 80
FIGURE 2-13. BOOM BRUSHES INSTALLATION 82

SECTION 3 - ATTACHMENTS 85

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION - COMPLETE 86
FIGURE 3-2. ATTACHMENT RECOGNITION INSTALLATION 88
FIGURE 3-3. ATTACHMENT RECOGNITION RECEIVER (ALL SPECS EXCEPT AUS & CE SPECS 90
FIGURE 3-4. ATTACHMENT RECOGNITION RECEIVER (AUS & CE SPECS 92
FIGURE 3-5. ATTACHMENT RECOGNITION ANTENNA (ALL SPECS EXCEPT AUS & CE SPECS 94
FIGURE 3-6. ATTACHMENT RECOGNITION ANTENNA (AUS & CE SPECS 96
FIGURE 3-7. BALE HANDLER (ROUND BALES) 98
FIGURE 3-8. BALE HANDLER (SQUARE BALES) 102
FIGURE 3-9. BASKET, PERSONNEL (1.2MX2.4M) (ISO) 104
FIGURE 3-10. BASKET ASSEMBLY - FORK MOUNTED 106
FIGURE 3-11. BOOM - TRUSS (3.6TON FORK MOUNTED) 108
FIGURE 3-12. BOOM - TRUSS (7.6 TON) 110
FIGURE 3-13. BUCKET (2.6 YD^3/2.0M^3) 112
FIGURE 3-14. BUCKET (5.23 YD^3) 114
FIGURE 3-15. BUCKET - 4 IN 1 (1.3 YD^3/1.0M^3) 116
FIGURE 3-16. BUCKET - GRAPPLE (1.7 YD^3/1.3M^3) 118
FIGURE 3-17. BUCKET - FORK MOUNTED (1.0M^3) 120
FIGURE 3-18. CARRIAGE ASSEMBLY (60IN/1524MM) 122
FIGURE 3-19. CARRIAGE ASSEMBLY (72IN/1829MM) 124
FIGURE 3-20. CARRIAGE ASSEMBLY (87IN/2290MM) 126
FIGURE 3-21. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING CARRIAGE (72IN/1829MM) 128
FIGURE 3-22. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING SIDE SHIFT CARRIAGE (75IN/1899MM) 130
FIGURE 3-23. CARRIAGE ASSEMBLY - LOG HANDLER CARRIAGE 132
FIGURE 3-24. CARRIAGE ASSEMBLY - PIPE HANDLER CARRIAGE 136
FIGURE 3-25. CARRIAGE ASSEMBLY - STEEL COIL HANDLER CARRIAGE 140

MidWestTech | JLG 7013H Telehandler Parts Manual | Publication 31211380 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 3-26. FORK - PALLET (2.25X6X48) 142
FIGURE 3-27. FORK - PALLET (2.25X6X60) 144
FIGURE 3-28. FORK - PALLET (2.25X6X72) 146
FIGURE 3-29. FORK - PALLET (2.25X6X96) 148
FIGURE 3-30. FORK RETENTION INSTALLATION 150
FIGURE 3-31. HOOK - CRANK (7.6 TON) 152
FIGURE 3-32. HOPPER - TRASH 154
FIGURE 3-33. WINCH - COUPLER MOUNTED 156

SECTION 4 - ENGINE AND ATTACHING PARTS 159

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS) 160
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS) 162
FIGURE 4-3. ENGINE POD COMPONENT INSTALLATION (LS) 164
FIGURE 4-4. ENGINE POD COMPONENT INSTALLATION (LS HIGH AMBIENT) 166
FIGURE 4-5. ENGINE POD COMPONENT INSTALLATION (MINING) (LS) 168
FIGURE 4-6. ENGINE POD COMPONENT INSTALLATION (MINING) (LS HIGH AMBIENT) 170
FIGURE 4-7. ENGINE INSTALLATION (ULS) 172
FIGURE 4-8. ENGINE ASSEMBLY (ULS) 174
FIGURE 4-9. ENGINE ASSEMBLY (LS) 178
FIGURE 4-10. ENGINE MOUNT INSTALLATION 180
FIGURE 4-11. AIR INTAKE INSTALLATION (ULS) 182
FIGURE 4-12. AIR INTAKE INSTALLATION (LS) 184
FIGURE 4-13. AIR CLEANER INSTALLATION 186
FIGURE 4-14. AIR CLEANER FILTER ASSEMBLY 188
FIGURE 4-15. AIR INTAKE DUCT INSTALLATION 190
FIGURE 4-16. PRIMARY FUEL FILTER INSTALLATION (ULS) 192
FIGURE 4-17. PRIMARY FUEL FILTER INSTALLATION (LS 194
FIGURE 4-18. REMOTE FUEL PUMP INSTALLATION 196
FIGURE 4-19. FUEL LINES INSTALLATION (ULS) 198
FIGURE 4-20. FUEL LINES INSTALLATION (LS) 200
FIGURE 4-21. FUEL LINES INSTALLATION (LS HIGH AMBIENT) 202
FIGURE 4-22. HYDROSTATIC ADAPTOR INSTALLATION 204
FIGURE 4-23. DUAL DRIVE SUPPORT ASSEMBLY 206
FIGURE 4-24. HYDROSTATIC DRIVE PUMP INSTALLATION 208
FIGURE 4-25. HYDROSTATIC DRIVE PUMP ASSEMBLY 210
FIGURE 4-26. IMPLEMENT PUMP INSTALLATION 212
FIGURE 4-27. IMPLEMENT PUMP ASSEMBLY 214
FIGURE 4-28. DEF COOLANT LINES INSTALLATION (ULS) 216
FIGURE 4-29. COOLING PACKAGE INSTALLATION (ULS & LS NO HIGH AMBIENT) 218
FIGURE 4-30. COOLING PACKAGE INSTALLATION (ULS & LS ASOV) 220
FIGURE 4-31. COOLING PACKAGE INSTALLATION (LS HIGH AMBIENT) 224
FIGURE 4-32. RADIATOR - COOLING PACKAGE 226
FIGURE 4-33. RADIATOR LINES INSTALLATION (ALL EXCEPT ULS & LS ASOV) 228
FIGURE 4-34. RADIATOR LINES INSTALLATION (ULS & LS ASOV) 230
FIGURE 4-35. COOLANT LINES INSTALLATION 232
FIGURE 4-36. SURGE TANK INSTALLATION 234
FIGURE 4-37. TRANSMISION OIL COOLER LINES INSTALLATION (ALL EXCEPT ULS TUV) 236
FIGURE 4-38. FAN GUARD INSTALLATION 238
FIGURE 4-39. FAN GUARD (REVERSING) INSTALLATION 240
FIGURE 4-40. COOLING FAN INSTALLATION (NO HIGH AMBIENT) 242
FIGURE 4-41. COOLING FAN INSTALLATION (HIGH AMBIENT) 244
FIGURE 4-42. COOLING FAN (REVERSING) INSTALLATION 246
FIGURE 4-43. COOLING FAN COVER (REVERSING) INSTALLATION 248
FIGURE 4-44. EXHAUST INSTALLATION (ULS) 250
FIGURE 4-45. DEF TANK INSTALLATION 252
FIGURE 4-46. DEF TANK ASSEMBLY 254
FIGURE 4-47. DEF LINES INSTALLATION 256
FIGURE 4-48. DEF CONTROL MODULE INSTALLATION 258
FIGURE 4-49. EXHAUST INSTALLATION (LS) 260
FIGURE 4-50. MUFFLER INSTALLATION (LS) 262
FIGURE 4-51. HEATER LINES INSTALLATION (ULS) 264
FIGURE 4-52. HEATER LINES INSTALLATION (LS) 266
FIGURE 4-53. A/C PUMP INSTALLATION 268
FIGURE 4-54. A/C LINES INSTALLATION 270
FIGURE 4-55. BLOCK HEATER INSTALLATION (115V) (ULS) 272
FIGURE 4-56. BLOCK HEATER INSTALLATION (115V) (LS) 274

MidWestTech | JLG 7013H Telehandler Parts Manual | Publication 31211380 Order the manual at mid-west-tech.com >

FIGURE 4-57. BLOCK HEATER INSTALLATION (230V) (LS) 276
FIGURE 4-58. HEATED BREATHER TUBE INSTALLATION 278

SECTION 5 - DRIVE TRAIN 281

FIGURE 5-1. DRIVETRAIN INSTALLATION 282
FIGURE 5-2. HYDROSTATIC MOTOR INSTALLATION 284
FIGURE 5-3. HYDROSTATIC MOTOR ASSEMBLY 286
FIGURE 5-4. GEARBOX INSTALLATION 288
FIGURE 5-5. GEAR BOX 290
FIGURE 5-6. DRIVE SHAFT INSTALLATION 294
FIGURE 5-7. FRONT AXLE INSTALLATION 296
FIGURE 5-8. FRONT AXLE MOUNTING INSTALLATION 298
FIGURE 5-9. FRONT AXLE 300
FIGURE 5-10. FRONT AXLE, CENTRAL HOUSING 302
FIGURE 5-11. FRONT AXLE, DIFFERENTIAL 304
FIGURE 5-12. DIFFERENTIAL KIT 306
FIGURE 5-13. FRONT AXLE, HUB REDUCTION 308
FIGURE 5-14. FRONT AXLE, BRAKES 310
FIGURE 5-15. FRONT AXLE, STEERING 312
FIGURE 5-16. FRONT AXLE, TRUNION 314
FIGURE 5-17. FRONT AXLE LINES INSTALLATION 316
FIGURE 5-18. REAR AXLE INSTALLATION 318
FIGURE 5-19. REAR AXLE MOUNTING INSTALLATION 320
FIGURE 5-20. REAR AXLE, BRAKES 322
FIGURE 5-21. REAR AXLE, STEERING 324
FIGURE 5-22. REAR AXLE 326
FIGURE 5-23. REAR AXLE, CENTRAL HOUSING 328
FIGURE 5-24. REAR AXLE, DIFFERENTIAL 330
FIGURE 5-25. DIFFERENTIAL KIT 332
FIGURE 5-26. REAR AXLE, HUB REDUCTION 334
FIGURE 5-27. STEERING CASE KIT (RF, LR) 336
FIGURE 5-28. STEERING CASE KIT (LF, RR) 338
FIGURE 5-29. REAR AXLE, TRUNION 340
FIGURE 5-30. TRUNION KIT 342
FIGURE 5-31. RING GEAR SUPPORT KIT 344
FIGURE 5-32. REDUCTION BUSHING KIT 346
FIGURE 5-33. PLANET GEAR CARRIER KIT 348
FIGURE 5-34. REAR AXLE LINES INSTALLATION 350
FIGURE 5-35. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 352
FIGURE 5-36. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 354
FIGURE 5-37. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 356
FIGURE 5-38. TIRE/WHEEL SET (AIR 17.5-25 - 22 PLY) 358
FIGURE 5-39. FENDER INSTALLATION 360
FIGURE 5-40. RH FENDER ASSEMBLY 362
FIGURE 5-41. LH FENDER ASSEMBLY 364

SECTION 6 - CAB 367

FIGURE 6-1. CAB MOUNTING INSTALLATION 368
FIGURE 6-2. FRONT CAB MOUNT BRACKET INSTALLATION 370
FIGURE 6-3. CAB MOUNTS INSTALLATION 372
FIGURE 6-4. CAB COMPONENTS INSTALLATION 374
FIGURE 6-5. CAB INSTALLATION 376
FIGURE 6-6. CAB ASSEMBLY (PVC 1911) 378
FIGURE 6-7. CAB ASSEMBLY (PVC 2005) 380
FIGURE 6-8. DOOR INSTALLATION 382
FIGURE 6-9. DOOR ASSEMBLY 384
FIGURE 6-10. CAB DOOR 386
FIGURE 6-11. GLASS ASSEMBLY - DOOR UPPER 388
FIGURE 6-12. CAB LATCH ASSEMBLY 390
FIGURE 6-13. CAB DOOR TRIGGER ASSEMBLY 392
FIGURE 6-14. DOOR STRAP INSTALLATION 394
FIGURE 6-15. CAB PLUG GROUP 396
FIGURE 6-16. REAR WINDOW INSTALLATION 398
FIGURE 6-17. REAR WINDOW GROUP 400
FIGURE 6-18. REAR WIPER INSTALLATION 402

MidWestTech | JLG 7013H Telehandler Parts Manual | Publication 31211380 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
152	4460466	1	Plug	
153	4460539	1	Connector	
154	4460944	2	Terminal	
155	4460466	1	Plug	
156	1001116812	1	Connector	
157	4460944	2	Terminal	
158	4460466	1	Plug	
159	1001133714	1	Connector	
160	1001133715	3	Terminal	
161	1001135650	3	Terminal Seal	
162	1001135651	1	Plug	
163	4460891	1	Connector	
164	4460942	2	Terminal	
165	4460891	1	Connector	
166	4460942	2	Terminal	
167	1001167528	1	Connector	
168	1001166704	4	Terminal	
169	1001137578	4	Terminal Seal	
170	1001165194	1	Connector	
171	1001126391	2	Plug	
172	1001166556	8	Terminal	
173	1001166774	2	Terminal	
174	1001126393	10	Terminal Seal	
175	4460891	1	Connector	
176	4460942	2	Terminal	
177	1001167620	1	Connector	
178	1001176004	2	Terminal	
179	1001176002	2	Terminal Seal	
180	1001167624	2	Plug	
181	1001116815	3	Connector	
182	4460945	4	Connector, 3 Way	

MidWestTech | JLG 7013H Telehandler Parts Manual | Publication 31211380 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
51	4460930	1	Connector	
52	4460931	1	Mating Connector	
53	4460466	2	Plug	
54	4460465	6	Terminal	
55	4460933	1	Connector	
56	1001125677	1	Bussbar Connector	
57	4460465	10	Terminal	
58	4460466	2	Plug	
59	1001116996	1	Connector	
60	1001118392	6	Terminal	
61	1001116696	1	Plug	
62	4461054	6	Terminal Seal	
63	1001187080	1	Ring Terminal	
64	1001187079	1	Ring Terminal	
65	1001116812	1	Connector	
66	4460944	2	Terminal	
67	4460466	1	Plug	
68	4460539	1	Connector	
69	4460944	2	Terminal	
70	4460466	1	Plug	
71	1001116812	1	Connector	
72	4460944	2	Terminal	
73	4460466	1	Plug	
74	4460891	1	Connector	
75	4460465	2	Terminal	
76	4460891	1	Connector	
77	4460465	2	Terminal	
78	4460891	1	Connector	
79	4460465	2	Terminal	
80	4460891	1	Connector	
81	4460465	2	Terminal	
82	4460891	1	Connector	
83	4460465	2	Terminal	
84	4460930	1	Connector	
85	4460931	1	Mating Connector	
86	4460466	2	Plug	
87	4460465	6	Terminal	
88	1001121726	1	Connector	
89	1001121727	1	Mating Connector	
90	1001116728	4	Terminal	
91	1001116727	1	Plug	
92	4460748	1	Plug	
93	1001175265	3	Terminal Seal	
94	4460458	1	Terminal Seal	
95	4460970	1	Connector	
96	4460464	6	Terminal	
97	4460941	1	Terminal	
98	4460466	5	Plug	
99	1001165311	1	Connector	
100	91013191	2	Terminal	
101	4460539	1	Connector	

MidWestTech | JLG 7013H Telehandler Parts Manual | Publication 31211380 Order the manual at mid-west-tech.com >