Illustrated Parts Manual

Model
8010H

PVC
1911
2005

P/N
31211382

June 15, 2020 - Rev B

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. GROMMETS INSTALLATION 16
FIGURE 1-2. TANKS INSTALLATION 18
FIGURE 1-3. HYDRAULIC TANK INSTALLATION 20
FIGURE 1-4. HYDRAULIC TANK ASSEMBLY 22
FIGURE 1-5. FUEL TANK INSTALLATION 24
FIGURE 1-6. FUEL TANK ASSEMBLY 26
FIGURE 1-7. TANK SUPPORT INSTALLATION 28
FIGURE 1-8. LOCKING FUEL CAP 30
FIGURE 1-9. PAD LOCK 32
FIGURE 1-10. ENGINE ENCLOSURE & HOOD INSTALLATION 34
FIGURE 1-11. ENGINE HOOD ASSEMBLY 36
FIGURE 1-12. ENGINE HOOD INSULATION INSTALLATION 38
FIGURE 1-13. ENGINE ENCLOSURE ASSEMBLY 40
FIGURE 1-14. COVER INSTALLATION (ULS) 42
FIGURE 1-15. COVER INSTALLATION (LS) 44
FIGURE 1-16. FRAME COVER INSTALLATION 46
FIGURE 1-17. FRONT LOWER COVER INSTALLATION 48
FIGURE 1-18. MIRRORS INSTALLATION 50
FIGURE 1-19. WHEEL CHOCKS INSTALLATION 52
FIGURE 1-20. REFLECTORS INSTALLATION 54

SECTION 2 - BOOM 57

FIGURE 2-1. BOOM INSTALLATION 58
FIGURE 2-2. BOOM ASSEMBLY 60
FIGURE 2-3. FIRST BOOM SECTION ASSEMBLY 62
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 64
FIGURE 2-5. COUPLER INSTALLATION (MANUAL) 66
FIGURE 2-6. COUPLER INSTALLATION (HYDRAULIC) 68
FIGURE 2-7. COUPLER LOCKING CYLINDER ASSEMBLY 70
FIGURE 2-8. MANUAL COUPLER PIN HOLDER INSTALLATION 72
FIGURE 2-9. BOOM BRUSHES INSTALLATION 74
FIGURE 2-10. BOOM PROP INSTALLATION 76
FIGURE 2-11. BOOM PROP BRACKET ASSEMBLY 78

SECTION 3 - ATTACHMENTS 81

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION - COMPLETE 82
FIGURE 3-2. ATTACHMENT RECOGNITION INSTALLATION 84
FIGURE 3-3. ATTACHMENT RECOGNITION RECEIVER (ALL SPECS EXCEPT AUS & CE SPECS 86
FIGURE 3-4. ATTACHMENT RECOGNITION RECEIVER (AUS & CE SPECS 88
FIGURE 3-5. ATTACHMENT RECOGNITION ANTENNA (ALL SPECS EXCEPT AUS & CE SPECS 90
FIGURE 3-6. ATTACHMENT RECOGNITION ANTENNA (AUS & CE SPECS 92
FIGURE 3-7. BALE HANDLER (ROUND BALES) 94
FIGURE 3-8. BALE HANDLER (SQUARE BALES) 98
FIGURE 3-9. BASKET, PERSONNEL (1.2MX2.4M) (ISO) 100
FIGURE 3-10. BASKET ASSEMBLY - FORK MOUNTED 102
FIGURE 3-11. BOOM - TRUSS (3.6TON FORK MOUNTED) 104
FIGURE 3-12. BOOM - TRUSS (7.6 TON) 106
FIGURE 3-13. BUCKET (2.6 YD^3/2.0M^3) 108
FIGURE 3-14. BUCKET (5.23 YD^3) 110
FIGURE 3-15. BUCKET - 4 IN 1 (2.6 YD^3/2.0M^3) 112
FIGURE 3-16. BUCKET - 4 IN 1 (1.3 YD^3/1.0M^3) 114
FIGURE 3-17. BUCKET - GRAPPLE (1.7 YD^3/1.3M^3) 116
FIGURE 3-18. BUCKET - GRAPPLE (2.6 YD^3/2.0M^3) 118
FIGURE 3-19. BUCKET - FORK MOUNTED (1.0M^3) 120
FIGURE 3-20. CARRIAGE ASSEMBLY (60IN/1524MM) 122
FIGURE 3-21. CARRIAGE ASSEMBLY (72IN/1829MM) 124
FIGURE 3-22. CARRIAGE ASSEMBLY (87IN/2290MM) 126
FIGURE 3-23. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING CARRIAGE (72IN/1829MM) 128
FIGURE 3-24. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING SIDE SHIFT CARRIAGE (75IN/1899MM) 130
FIGURE 3-25. CARRIAGE ASSEMBLY - LOG HANDLER CARRIAGE 132
FIGURE 3-26. CARRIAGE ASSEMBLY - PIPE HANDLER CARRIAGE 136
FIGURE 3-27. CARRIAGE ASSEMBLY - STEEL COIL HANDLER CARRIAGE 140

MidWestTech | JLG 8010H Telehandler Parts Manual | Publication 31211382 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-28. CARRIAGE ASSEMBLY - TIRE HANDLER CARRIAGE (PVC1911) 142
FIGURE 3-29. CARRIAGE ASSEMBLY - TIRE HANDLER (PVC 2005) 144
FIGURE 3-30. FORK - PALLET (2.25X6X48) 148
FIGURE 3-31. FORK - PALLET (2.25X6X60) 150
FIGURE 3-32. FORK - PALLET (2.25X6X72) 152
FIGURE 3-33. FORK - PALLET (2.25X6X96) 154
FIGURE 3-34. FORK RETENTION INSTALLATION 156
FIGURE 3-35. HOOK - CRANK (7.6 TON) 158
FIGURE 3-36. HOPPER - TRASH 160
FIGURE 3-37. WINCH - COUPLER MOUNTED 162

SECTION 4 - ENGINE AND ATTACHING PARTS 165

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS) 166
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS) 168
FIGURE 4-3. ENGINE POD COMPONENT INSTALLATION (LS) 170
FIGURE 4-4. ENGINE POD COMPONENT INSTALLATION (LS HIGH AMBIENT) 172
FIGURE 4-5. ENGINE POD COMPONENT INSTALLATION (MINING) (LS) 174
FIGURE 4-6. ENGINE POD COMPONENT INSTALLATION (MINING) (LS HIGH AMBIENT) 176
FIGURE 4-7. ENGINE INSTALLATION (ULS) 178
FIGURE 4-8. ENGINE ASSEMBLY (ULS) 180
FIGURE 4-9. ENGINE ASSEMBLY (LS) 184
FIGURE 4-10. ENGINE MOUNT INSTALLATION 186
FIGURE 4-11. AIR INTAKE INSTALLATION (ULS) 188
FIGURE 4-12. AIR INTAKE INSTALLATION (LS) 190
FIGURE 4-13. AIR CLEANER INSTALLATION 192
FIGURE 4-14. AIR CLEANER FILTER ASSEMBLY 194
FIGURE 4-15. AIR INTAKE DUCT INSTALLATION 196
FIGURE 4-16. PRIMARY FUEL FILTER INSTALLATION (ULS) 198
FIGURE 4-17. PRIMARY FUEL FILTER INSTALLATION (LS 200
FIGURE 4-18. REMOTE FUEL PUMP INSTALLATION 202
FIGURE 4-19. FUEL LINES INSTALLATION (ULS) 204
FIGURE 4-20. FUEL LINES INSTALLATION (LS) 206
FIGURE 4-21. FUEL LINES INSTALLATION (LS HIGH AMBIENT) 208
FIGURE 4-22. HYDROSTATIC ADAPTOR INSTALLATION 210
FIGURE 4-23. DUAL DRIVE SUPPORT ASSEMBLY 212
FIGURE 4-24. HYDROSTATIC DRIVE PUMP INSTALLATION 214
FIGURE 4-25. HYDROSTATIC DRIVE PUMP ASSEMBLY 216
FIGURE 4-26. IMPLEMENT PUMP INSTALLATION 218
FIGURE 4-27. IMPLEMENT PUMP ASSEMBLY 220
FIGURE 4-28. DEF COOLANT LINES INSTALLATION (ULS) 222
FIGURE 4-29. COOLING PACKAGE INSTALLATION (ULS & LS NO HIGH AMBIENT) 224
FIGURE 4-30. COOLING PACKAGE INSTALLATION (ULS & LS ASOV) 226
FIGURE 4-31. COOLING PACKAGE INSTALLATION (LS HIGH AMBIENT) 230
FIGURE 4-32. RADIATOR - COOLING PACKAGE 232
FIGURE 4-33. RADIATOR LINES INSTALLATION (ALL EXCEPT ULS & LS ASOV) 234
FIGURE 4-34. RADIATOR LINES INSTALLATION (ULS & LS ASOV) 236
FIGURE 4-35. COOLANT LINES INSTALLATION 238
FIGURE 4-36. SURGE TANK INSTALLATION 240
FIGURE 4-37. TRANSMISION OIL COOLER LINES INSTALLATION (ALL EXCEPT ULS TUV) 242
FIGURE 4-38. FAN GUARD INSTALLATION 244
FIGURE 4-39. FAN GUARD (REVERSING) INSTALLATION 246
FIGURE 4-40. COOLING FAN INSTALLATION (NO HIGH AMBIENT) 248
FIGURE 4-41. COOLING FAN INSTALLATION (HIGH AMBIENT) 250
FIGURE 4-42. COOLING FAN (REVERSING) INSTALLATION 252
FIGURE 4-43. COOLING FAN COVER (REVERSING) INSTALLATION 254
FIGURE 4-44. EXHAUST INSTALLATION (ULS) 256
FIGURE 4-45. DEF TANK INSTALLATION 258
FIGURE 4-46. DEF TANK ASSEMBLY 260
FIGURE 4-47. DEF LINES INSTALLATION 262
FIGURE 4-48. DEF CONTROL MODULE INSTALLATION 264
FIGURE 4-49. EXHAUST INSTALLATION (LS) 266
FIGURE 4-50. MUFFLER INSTALLATION (LS) 268
FIGURE 4-51. HEATER LINES INSTALLATION (ULS) 270
FIGURE 4-52. HEATER LINES INSTALLATION (LS) 272
FIGURE 4-53. A/C PUMP INSTALLATION 274
FIGURE 4-54. A/C LINES INSTALLATION 276

MidWestTech | JLG 8010H Telehandler Parts Manual | Publication 31211382 Order the manual at mid-west-tech.com >

FIGURE 4-55. BLOCK HEATER INSTALLATION (115V) (ULS) 278
FIGURE 4-56. BLOCK HEATER INSTALLATION (115V) (LS) 280
FIGURE 4-57. BLOCK HEATER INSTALLATION (230V) (LS) 282
FIGURE 4-58. HEATED BREATHER TUBE INSTALLATION 284

SECTION 5 - DRIVE TRAIN 287

FIGURE 5-1. DRIVETRAIN INSTALLATION 288
FIGURE 5-2. HYDROSTATIC MOTOR INSTALLATION 290
FIGURE 5-3. HYDROSTATIC MOTOR ASSEMBLY 292
FIGURE 5-4. GEAR BOX 294
FIGURE 5-5. GEARBOX INSTALLATION 298
FIGURE 5-6. DRIVE SHAFT INSTALLATION 300
FIGURE 5-7. FRONT AXLE INSTALLATION 302
FIGURE 5-8. FRONT AXLE MOUNTING INSTALLATION 304
FIGURE 5-9. FRONT AXLE 306
FIGURE 5-10. FRONT AXLE, CENTRAL HOUSING 308
FIGURE 5-11. FRONT AXLE, DIFFERENTIAL 310
FIGURE 5-12. DIFFERENTIAL KIT 312
FIGURE 5-13. FRONT AXLE, HUB REDUCTION 314
FIGURE 5-14. FRONT AXLE, BRAKES 316
FIGURE 5-15. FRONT AXLE, STEERING 318
FIGURE 5-16. FRONT AXLE, TRUNION 320
FIGURE 5-17. FRONT AXLE LINES INSTALLATION 322
FIGURE 5-18. REAR AXLE INSTALLATION 324
FIGURE 5-19. REAR AXLE MOUNTING INSTALLATION 326
FIGURE 5-20. REAR AXLE, BRAKES 328
FIGURE 5-21. REAR AXLE, STEERING 330
FIGURE 5-22. REAR AXLE 332
FIGURE 5-23. REAR AXLE, CENTRAL HOUSING 334
FIGURE 5-24. REAR AXLE, DIFFERENTIAL 336
FIGURE 5-25. DIFFERENTIAL KIT 338
FIGURE 5-26. REAR AXLE, HUB REDUCTION 340
FIGURE 5-27. STEERING CASE KIT (RF, LR) 342
FIGURE 5-28. STEERING CASE KIT (LF, RR) 344
FIGURE 5-29. REAR AXLE, TRUNION 346
FIGURE 5-30. TRUNION KIT 348
FIGURE 5-31. RING GEAR SUPPORT KIT 350
FIGURE 5-32. REDUCTION BUSHING KIT 352
FIGURE 5-33. PLANET GEAR CARRIER KIT 354
FIGURE 5-34. REAR AXLE LINES INSTALLATION 356
FIGURE 5-35. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 358
FIGURE 5-36. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 360
FIGURE 5-37. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 362
FIGURE 5-38. TIRE/WHEEL SET (AIR 17.5-25 - 22 PLY) 364
FIGURE 5-39. FENDER INSTALLATION 366
FIGURE 5-40. RH FENDER ASSEMBLY 368
FIGURE 5-41. LH FENDER ASSEMBLY 370

SECTION 6 - CAB 373

FIGURE 6-1. CAB MOUNTING INSTALLATION 374
FIGURE 6-2. FRONT CAB MOUNT BRACKET INSTALLATION 376
FIGURE 6-3. CAB MOUNTS INSTALLATION 378
FIGURE 6-4. CAB COMPONENTS INSTALLATION 380
FIGURE 6-5. CAB INSTALLATION 382
FIGURE 6-6. CAB ASSEMBLY (PVC 1911) 384
FIGURE 6-7. CAB ASSEMBLY (PVC 2005) 386
FIGURE 6-8. DOOR INSTALLATION 388
FIGURE 6-9. DOOR ASSEMBLY 390
FIGURE 6-10. CAB DOOR 392
FIGURE 6-11. GLASS ASSEMBLY - DOOR UPPER 394
FIGURE 6-12. CAB LATCH ASSEMBLY 396
FIGURE 6-13. CAB DOOR TRIGGER ASSEMBLY 398
FIGURE 6-14. DOOR STRAP INSTALLATION 400
FIGURE 6-15. CAB PLUG GROUP 402
FIGURE 6-16. REAR WINDOW INSTALLATION 404

MidWestTech | JLG 8010H Telehandler Parts Manual | Publication 31211382 Order the manual at mid-west-tech.com >

FIGURE 4-4. ENGINE POD COMPONENT INSTALLATION (LS HIGH AMBIENT)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001222454	Ref	Engine Installation (LS)	A
1	1001193393	Ref	Installation, Main Hydraulic Pump (See Separate Breakdown in Hydraulic Circuits Section)	
2	1001193703	Ref	Installation, Transmission Hydrostatic Adapter (See Separate Breakdown in this Section)	
3	1001193704	Ref	Installation, Transmission Hydrostatic Drive Pump (See Separate Breakdown in this Section)	
4	1001200862	Ref	Installation, Engine Mounting (See Separate Breakdown in this Section)	
5	1001200864	Ref	Installation, Air Cleaner (See Separate Breakdown in this Section)	
6	1001200869	Ref	Installation, Engine ECU (See Separate Breakdown in Electrical Section)	
7	1001209585	Ref	Engine (LS) (See Separate Breakdown in this Section)	
8	1001210600	Ref	Installation, Air Intake Lines (LS) (See Separate Breakdown in this Section)	
9	1001210602	Ref	Installation, Primary Fuel Filter (LS) (See Separate Breakdown in this Section)	
10	1001217752	Ref	Installation, Engine Wiring (LS) (See Separate Breakdown in Electrical Section)	
11	1001221041	Ref	Installation, Remote Fuel Pump (See Separate Breakdown in this Section)	
12	1001222163	Ref	Installation, Fuel Lines (See Separate Breakdown in this Section)	

MidWestTech | JLG 8010H Telehandler Parts Manual | Publication 31211382 Order the manual at mid-west-tech.com >

FIGURE 5-22. REAR AXLE

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
1	1001184985	Ref	Rear Axle	F
		Ref	Rear Axle, Central Housing (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Differential (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Hub Reduction (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Brakes (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Steering (See Separate Breakdown in this Section)	
		Ref	Rear Axle, Trunnion (See Separate Breakdown in this Section)	

MidWestTech | JLG 8010H Telehandler Parts Manual | Publication 31211382 Order the manual at mid-west-tech.com >

FIGURE 6-4. CAB COMPONENTS INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001194698	Ref	Cab Components Installation	F
1	1001155447	Ref	Installation, Front Wiper (See Separate Breakdown in this Section)	
2	1001160508	Ref	Installation, Basic Mirror (See Separate Breakdown in this Section)	
3	1001161499	Ref	Installation, Accelerator Pedal (See Separate Breakdown in CONTROLS Section)	
4	1001162789	Ref	Installation, Washer Tank (See Separate Breakdown in this Section)	
6	1001170366	Ref	Installation, Front Cover (See Separate Breakdown in this Section)	
7	1001172401	Ref	Installation, Level Indicator (See Separate Breakdown in this Section)	
8	1001194699	Ref	Installation, Cab (See Separate Breakdown in this Section)	
9	1001220329	Ref	Installation, Rear Wiper (See Separate Breakdown in this Section)	

MidWestTech | JLG 8010H Telehandler Parts Manual | Publication 31211382 Order the manual at mid-west-tech.com >