Illustrated Parts Manual

Model
925

PVC
1911
2005

P/N
31211474

July 10, 2020 - Rev B

ANSI

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. FRAME INSTALLATION 16
FIGURE 1-2. ENGINE ENCLOSURE INSTALLATION (NO RHOC) 18
FIGURE 1-3. ENGINE ENCLOSURE INSTALLATION (RHOC) 20
FIGURE 1-4. ENGINE ENCLOSURE COVER INSTALLATION 22
FIGURE 1-5. HOOD INSTALLATION (NO RHOC) 24
FIGURE 1-6. HOOD INSTALLATION (RHOC) 26
FIGURE 1-7. COVER PLATES INSTALLATION (NO OUTRIGGERS - ULS) 28
FIGURE 1-8. COVER PLATES INSTALLATION (NO OUTRIGGERS - LS) 30
FIGURE 1-9. COVER PLATE INSTALLATION (NO TRAILER BRAKES) 32
FIGURE 1-10. COVER PLATE INSTALLATION (TRAILER BRAKES) 34
FIGURE 1-11. COVER PLATE INSTALLATION (NO REAR AUX) 36
FIGURE 1-12. COVER PLATE INSTALLATION (REAR AUX) 38
FIGURE 1-13. COVER PLATE INSTALLATION (HYDRAULIC HITCH AND REAR AUX) 40
FIGURE 1-14. REAR COVER PLATE INSTALLATION (NO HYDRAULIC HITCH) 42
FIGURE 1-15. TANKS INSTALLATION 44
FIGURE 1-16. FUEL TANK INSTALLATION 46
FIGURE 1-17. FUEL TANK ASSEMBLY 48
FIGURE 1-18. HYDRAULIC TANK INSTALLATION 50
FIGURE 1-19. HYDRAULIC TANK ASSEMBLY 52
FIGURE 1-20. FUEL AND HYDRAULIC CAP INSTALLATION 54
FIGURE 1-21. HITCH RETRIEVAL INSTALLATION 56
FIGURE 1-22. TOOLBOX INSTALLATION 58

SECTION 2 - BOOM 61

FIGURE 2-1. BOOM PINNING INSTALLATION 62
FIGURE 2-2. LIFT CYLINDER PINNING INSTALLATION 64
FIGURE 2-3. COMPENSATION CYLINDER PINNING INSTALLATION 66
FIGURE 2-4. BOOM PIVOT INSTALLATION 68
FIGURE 2-5. BOOM ASSEMBLY 70
FIGURE 2-6. FIRST BOOM SECTION 72
FIGURE 2-7. SECOND BOOM SECTION ASSEMBLY 74
FIGURE 2-8. LINK ASSEMBLY 76
FIGURE 2-9. LEVER ASSEMBLY 78
FIGURE 2-10. MANUAL QUICK COUPLER INSTALLATION 80
FIGURE 2-11. HYDRAULIC QUICK COUPLER INSTALLATION 82
FIGURE 2-12. BOOM ANGLE INDICATOR INSTALLATION 84
FIGURE 2-13. BOOM PROP INSTALLATION 86
FIGURE 2-14. BOOM BRUSHES INSTALLATION 88

SECTION 3 - ATTACHMENTS 91

FIGURE 3-1. AUGER COUPLING 92
FIGURE 3-2. AUGER BIT (6INX4IN) 94
FIGURE 3-3. AUGER BIT (9INX4IN) 96
FIGURE 3-4. AUGER BIT (12INX4IN) 98
FIGURE 3-5. AUGER BIT (15INX4IN) 100
FIGURE 3-6. AUGER BIT (18INX4IN) 102
FIGURE 3-7. AUGER BIT (24INX4IN) 104
FIGURE 3-8. AUGER BIT (36INX4IN) 106
FIGURE 3-9. BALE HANDLER (TUBE CLAMP) 108
FIGURE 3-10. BALE HANDLER KIT (TUBE CLAMP) 110
FIGURE 3-11. BALE HANDLER (SPIKE CLAMP) 112
FIGURE 3-12. BALE HANDLER KIT (SPIKE CLAMP) 114
FIGURE 3-13. BASKET PERSONNEL (1.2MX2.4M) (DOMESTIC) 116
FIGURE 3-14. BASKET PERSONNEL (1.2MX2.4M) (ISO) 118
FIGURE 3-15. BASKET PERSONNEL (1.2MX2.4M) (FRENCH LANGUAGE) 120
FIGURE 3-16. BASKET ASSEMBLY 122
FIGURE 3-17. BUCKET (CONCRETE) 124
FIGURE 3-18. BUCKET (DIRT) 128
FIGURE 3-19. BUCKET (GRAPPLE MULTI-PURPOSE) 130
FIGURE 3-20. BUCKET (MANURE GRAPPLE) 132
FIGURE 3-21. BUCKET(0.6 M^3) (MULTI-PURPOSE 4I N 1) 134
FIGURE 3-22. BUCKET(1 M^3) (GENERAL PURPOSE) 136

MidWestTech | JLG 925 Telehandler Parts Manual | Publication 31211474 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-23. BUCKET(1 M³) (MULTI-PURPOSE 4I N 1) 138
FIGURE 3-24. BUCKET (1 M³) (FORK MOUNTED) 140
FIGURE 3-25. BUCKET (1.5 M³) (GENERAL PURPOSE) 142
FIGURE 3-26. BUCKET (2 M³) (GENERAL PURPOSE) 144
FIGURE 3-27. BUCKET (2.5 M³) (GENERAL PURPOSE) 146
FIGURE 3-28. BUCKET (3 M³) (GENERAL PURPOSE) 148
FIGURE 3-29. BUCKET BOLT-ON EDGE 150
FIGURE 3-30. BUCKET FRONT GUARD 152
FIGURE 3-31. BUCKET TEETH KIT 154
FIGURE 3-32. CARRIAGE ASSEMBLY (1225MM) 156
FIGURE 3-33. CARRIAGE ASSEMBLY (1524MM) 158
FIGURE 3-34. CARRIAGE ASSEMBLY (1829MM) 160
FIGURE 3-35. CARRIAGE ASSEMBLY - SIDE TILTING (4.5 TON - 1225 MM) 162
FIGURE 3-36. CARRIAGE ASSEMBLY - SIDE TILTING (4.0 TON - 1575 MM) 164
FIGURE 3-37. CARRIAGE ASSEMBLY - SID TILTING (4.0 TON - 1829 MM) 166
FIGURE 3-38. CARRIAGE ASSEMBLY - SIDE SHIFT (4.0 TON - 1225 MM) 168
FIGURE 3-39. CARRIAGE ASSEMBLY - FORK POSITIONING (4.0 TON 170
FIGURE 3-40. CARRIAGE ASSEMBLY (JOHN DEERE FIT) 172
FIGURE 3-41. CARRIAGE ASSEMBLY (MANITOU FIT) 174
FIGURE 3-42. CARRIAGE ASSEMBLY (JCB FIT) 176
FIGURE 3-43. CARRIAGE ASSEMBLY - FEM CARRIAGE AND FORKS 178
FIGURE 3-44. FORK - LUMBER (45X150X1540) 180
FIGURE 3-45. FORK - LUMBER (50X150X1830) 182
FIGURE 3-46. FORK - PALLET (50X50X1220) 184
FIGURE 3-47. FORK - PALLET (50X100X1070) 186
FIGURE 3-48. FORK - PALLET (50X100X1200) 188
FIGURE 3-49. FORK - PALLET (50X100X1200) (CE & AUS WITH SIDE SHIFT CARRIAAGE) (4.0 TON - 1225MM) 190
FIGURE 3-50. FORK - PALLET (50X120X1200) 192
FIGURE 3-51. FORK - PALLET (60X125X1220) 194
FIGURE 3-52. FORK - MUCK WITH GRAB 196
FIGURE 3-53. FORK - DUAL TINE BAILING WITH CARRIAGE 198
FIGURE 3-54. FORK _ EXTENSIONS (62X163X2286) (ANSI) 200
FIGURE 3-55. HOOK_CRANE (COUPLER MOUNTED) 202
FIGURE 3-56. HOOK_CRANE (FORK MOUNTED) 204
FIGURE 3-57. HOPPER_TRASH 206
FIGURE 3-58. SWEEPER 208
FIGURE 3-59. TRUSS BOOM (0.9 TON - 12 FT WITH WINCH) 210
FIGURE 3-60. TRUSS BOOM (1 TON - 3.4M) 212
FIGURE 3-61. TRUSS BOOM (1.8 TON - 3 FT WITH WINCH) 214
FIGURE 3-62. TRUSS BOOM (4 TON - 2.1M) 216

SECTION 4 - ENGINE AND ATTACHING PARTS 219

FIGURE 4-1. ENGINE INSTALLATION (90KW - ULS - PISTON PUMP) 220
FIGURE 4-2. ENGINE INSTALLATION (100KW - ULS - PISTON PUMP) 222
FIGURE 4-3. ENGINE INSTALLATION (90KW - LS - PISTON PUMP) 224
FIGURE 4-4. ENGINE MOUNTING INSTALLATION (90KW/100KW) 226
FIGURE 4-5. 3.6L ENGINE (90KW - ULS - PISTON PUMP) 228
FIGURE 4-6. 3.6L ENGINE (100KW - ULS - PISTON PUMP) 230
FIGURE 4-7. 3.6L ENGINE (90KW - LS - PISTON PUMP) 232
FIGURE 4-8. ENGINE ECU INSTALLATION (ULS) 234
FIGURE 4-9. ENGINE ECU INSTALLATION (LS) 236
FIGURE 4-10. BRACKET GUARD INSTALLATION 238
FIGURE 4-11. FUEL LINES INSTALLATION (ULS - RHOC) 240
FIGURE 4-12. FUEL LINES INSTALLATION (LS - RHOC) 242
FIGURE 4-13. EXHAUST INSTALLATION (ULS) 244
FIGURE 4-14. EXHAUST INSTALLATION (LS) 246
FIGURE 4-15. COOLING PACKAGE INSTALLATION (90KW - ULS) 248
FIGURE 4-16. COOLING PACKAGE INSTALLATION (90KW - LS) 250
FIGURE 4-17. COOLING FAN INSTALLATION 252
FIGURE 4-18. FAN LINES INSTALLATION (90KW) 254
FIGURE 4-19. FAN DRIVE MOTOR (NO RHOC) 256
FIGURE 4-20. FUEL FILTER INSTALLATION (90/100KW - ULS) 258
FIGURE 4-21. PRIMARY FUEL FILTER INSTALLATION (90KW - LS) 260
FIGURE 4-22. AIR CLEANER INSTALLATION (90/100KW) 262
FIGURE 4-23. AIR CLEANER ASSEMBLY (90/100KW) 264
FIGURE 4-24. PRE-AIR CLEANER ACCESSORY 266

MidWestTech | JLG 925 Telehandler Parts Manual | Publication 31211474 Order the manual at mid-west-tech.com >

FIGURE 4-25. AIR INTAKE RAIN CAP ACCESSORY 268
FIGURE 4-26. AIR INTAKE LINES INSTALLATION (90/100KW - ULS) 270
FIGURE 4-27. AIR INTAKE LINES INSTALLATION (90KW - LS) 272
FIGURE 4-28. COOLER INSTALLATION (90KW) 274
FIGURE 4-29. RADIATOR COOLING PACKAGE (90KW) 276
FIGURE 4-30. REMOTE HOC INSTALLATION 278
FIGURE 4-31. FAN DRIVE MOTOR (RHOC) 280
FIGURE 4-32. COOLANT LINES INSTALLATION (ULS) 282
FIGURE 4-33. COOLANT LINES INSTALLATION (LS) 284
FIGURE 4-34. COOLER LINES INSTALLATION (90KW) 286
FIGURE 4-35. CAC LINES INSTALLATION (ULS) 288
FIGURE 4-36. CAC LINES INSTALLATION (LS) 290
FIGURE 4-37. SURGE TANK INSTALLATION 292
FIGURE 4-38. TANK EXPANSION 294
FIGURE 4-39. BULKHEAD INSTALLATION 296
FIGURE 4-40. DEF CONTROL MODULE INSTALLATION (ULS) 298
FIGURE 4-41. DEF TANK INSTALLATION (ULS) 300
FIGURE 4-42. DEF TANK ASSEMBLY (ULS) 302
FIGURE 4-43. DEF LINES INSTALLATION (ULS) 304
FIGURE 4-44. HYDRAULIC PUMP INSTALLATION (90KW) 306
FIGURE 4-45. HEATER LINES INSTALLATION (ULS) 308
FIGURE 4-46. HEATER LINES INSTALLATION (LS) 310
FIGURE 4-47. BLOCK HEATER INSTALLATION (230V - LS) 312
FIGURE 4-48. BLOCK HEATER INSTALLATION (120V - LS) 314
FIGURE 4-49. BLOCK HEATER (ULS) 316
FIGURE 4-50. BLOCK HEATER (LS) 318
FIGURE 4-51. A/C PUMP INSTALLATION 320
FIGURE 4-52. A/C LINES INSTALLATION 322

SECTION 5 - DRIVE TRAIN 325

FIGURE 5-1. DRIVETRAIN INSTALLATION 326
FIGURE 5-2. FRONT AXLE INSTALLATION 328
FIGURE 5-3. FRONT AXLE ASSEMBLY 330
FIGURE 5-4. FRONT AXLE - CENTRAL 332
FIGURE 5-5. FRONT AXLE- DIFFERENTIAL 334
FIGURE 5-6. FRONT AXLE - HUB REDUCTION 336
FIGURE 5-7. FRONT AXLE - BRAKES 338
FIGURE 5-8. FRONT AXLE - STEERING 340
FIGURE 5-9. REAR AXLE INSTALLATION 342
FIGURE 5-10. REAR AXLE ASSEMBLY 344
FIGURE 5-11. REAR AXLE - CENTRAL HOUSING 346
FIGURE 5-12. REAR AXLE - DIFFERENTIAL 348
FIGURE 5-13. REAR AXLE - HUB REDUCTION 350
FIGURE 5-14. REAR AXLE - BRAKES 352
FIGURE 5-15. REAR AXLE - STEERING 354
FIGURE 5-16. DIFFERENTIAL KIT (FRONT AXLE) 356
FIGURE 5-17. DIFFERENTIAL KIT (REAR AXLE) 358
FIGURE 5-18. REDUCTION BUSHING KIT (FRONT & REAR AXLES) 360
FIGURE 5-19. PLANET GEAR CARRIER KIT (FRONT & REAR AXLES) 362
FIGURE 5-20. STEERING CASE KIT, (LF, RR) 364
FIGURE 5-21. STEERING CASE KIT, (RF, LR) 366
FIGURE 5-22. STEERING ADJUST BOLT KIT 368
FIGURE 5-23. RING GEAR SUPPORT KIT (REAR AXLE) 370
FIGURE 5-24. PISTON KIT (LH) 372
FIGURE 5-25. PISTON KIT (RH) 374
FIGURE 5-26. PISTON KIT 376
FIGURE 5-27. TRUNION KIT 378
FIGURE 5-28. DRIVE SHAFTS INSTALLATION 380
FIGURE 5-29. REMOTE GREASE SYSTEM INSTALLATION 382
FIGURE 5-30. AXLE SHIM INSTALLATION 384
FIGURE 5-31. TRANSMISSION INSTALLATION (6 SPD - 90KW) 386
FIGURE 5-32. TRANSMISSION INSTALLATION (6 SPD - 97KW) 388
FIGURE 5-33. TRANSMISSION (6 SPD - 90KW) 390
FIGURE 5-34. TRANSMISSION (6 SPD - HHP - 97KW) 392
FIGURE 5-35. PLANETARY CASE AND PARTS GROUP 394
FIGURE 5-36. TORQUE CONVERTER GROUP 396

MidWestTech | JLG 925 Telehandler Parts Manual | Publication 31211474 Order the manual at mid-west-tech.com >

FIGURE 6-44. HEATER AND A/C INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001201338	Ref	Heater and A/C Installation	C
1	0700614	2	Bolt, M6X30	
2	0760810	6	Bolt, M8X20	
3	3290601	1	Nut, M6X1	
4	4811700	3	Washer, M6	
5	4811900	4	Washer, M8	
6	4811902	2	Washer, M8	
7	4831900	6	Washer, Lock M8	
8	1001145539	2	Support, Pipe	
10	1001159925	1	Switch, HVAC Recycle	
11	1001160326	1	Switch, HVAC On/Off	
13	1001162953	1	Assembly, Cab Condenser (See Separate Breakdown in this Section)	
14	1001168327	1	Hose	
15	1001168330	1	Hose	
16	1001168331	1	Tube	
17	1001168456	1	Tube	
18	1001169151	1	Harness, A/C Option (See Separate Breakdown in ELECTRICAL Section)	
19	1001172546	1	Filter, HVAC Fresh Air	
20	1001172553	1	Filter, HVAC Air Recirculation	
21	1001178170	1	Bracket	
22	1001201497	1	Assembly, Heater and A/C (See Separate Breakdown in this Section)	
23	1001172547	1	Switch, HVAC Rotary 3 Speed	
24	1001172550	2	Knob, HVAC Control	
25	1001172552	1	Cable, HVAC	

MidWestTech | JLG 925 Telehandler Parts Manual | Publication 31211474 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
106	4460466	3	Plug	
107	4460933	1	Connector	
108	80604016	1	Lock, Connector	
109	4460465	7	Terminal	
110	4460466	5	Plug	
111	1001117110	1	Ring, Terminal	
112	1001117109	1	Ring, Terminal	
113	1001117110	1	Ring, Terminal	
114	1001117110	1	Ring, Terminal	
115	4460891	1	Connector	
116	80604018	1	Lock, Connector	
117	4460465	2	Terminal	
118	4460891	1	Connector	
119	80604018	1	Lock, Connector	
120	4460465	2	Terminal	
121	4460891	1	Connector	
122	80604018	1	Lock, Connector	
123	4460465	2	Terminal	
124	4460891	1	Connector	
125	80604018	1	Lock, Connector	
126	4460465	2	Terminal	
127	4460891	1	Connector	
128	80604018	1	Lock, Connector	
129	4460465	2	Terminal	
130	4460891	1	Connector	
131	80604018	1	Lock, Connector	
132	4460465	2	Terminal	
133	4460891	1	Connector	
134	80604018	1	Lock, Connector	
135	4460465	2	Terminal	
136	4460891	1	Connector	
137	80604018	1	Lock, Connector	
138	4460465	2	Terminal	
139	4460891	1	Connector	
140	80604018	1	Lock, Connector	
141	4460465	2	Terminal	
142	4460891	1	Connector	
143	80604018	1	Lock, Connector	
144	4460465	2	Terminal	
145	4460891	1	Connector	
146	80604018	1	Lock, Connector	
147	4460465	2	Terminal	
148	1001116950	1	Connector	
149	4460465	2	Terminal	
150	4460891	1	Connector	
151	80604018	1	Lock, Connector	
152	4460465	2	Terminal	
153	4461018	1	Connector	
154	4460509	2	Belgium Built Machines - Use Terminal	
155	4460247	1	Terminal, Ring	
156	1001133714	1	Connector	

MidWestTech | JLG 925 Telehandler Parts Manual | Publication 31211474 Order the manual at mid-west-tech.com >

FIGURE 11-1. DECALS INSTALLATION (ANSI)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001201869	Ref	Decals Installation (ULS)	F
1	1001227287	1	Decal, Manual Location	
3	1706098	1	Decal, Ether Warning	
4	1706296	1	Decal, Battery Warning (ANSI)	
5	1001102750	1	Decal, No Standing On Forks	
6	1706299	1	Decal, Contacting Power Lines Warning	
7	1706301	1	Decal, Keep Clear Of Rotating Parts Warning	
8	1706306	1	Decal, Tip Over Warning	
9	1706302	2	Decal, Pinch Point Boom Holes	
10	1001100957	2	Decal, Lift/Tie Down Point	
13	8006612	2	Decal, Stay Clear of Swing Area	
15	1001094708	1	Decal, Hydraulic Oil	
17	1001009178	4	Tack, Metal	
18	1706850	1	Decal, Crush Hazard Warning	
19	1706768	1	Decal, Vehicle Roll Away	
20	1707078	1	Decal, Warning/Danger	
22	1001130323	1	Decal, Oil Level	
23	1001174911	1	Decal, Nameplate Serial Number	
24	1001125387	1	Decal, Ultra Low Sulfur Diesel	
27	1001172035	1	Decal, No Weld or Drill	
30	1001214206	1	Decal, Park Brake	
31	1001184632	1	Decal, Battery Positive	
33	1001191229	1	Decal, Fuse Panel	
35	1001195855	1	Decal, Battery Disconnect	
36	1001196806	1	Decal, Diesel Exhaust Fluid	
37	AU2105	1	Decal, No Karcher	
38	8005616	2	Decal, Lifting Point	
39	8005870	1	Decal, Emergency Exit	
40	1001008540	1	Plate, Battery	
42	4109801	2	Decal, Tie Down Point	

MidWestTech | JLG 925 Telehandler Parts Manual | Publication 31211474 Order the manual at mid-west-tech.com >