Illustrated Parts Manual

Models
EC600SJ/EC600SJP
H600SJ/H600SJP

PVC
2001
2007

P/N
31215029

June 15, 2020 - Rev B

ANSI

AS/NZS

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 11

FIGURE 1-1. AXLE INSTALLATION - FIXED (2WD) 12
FIGURE 1-2. AXLE INSTALLATION - FIXED (4WD) 14
FIGURE 1-3. AXLE INSTALLATION - OSCILLATING WITHOUT TOW PACKAGE (2WD) 16
FIGURE 1-4. AXLE INSTALLATION - OSCILLATING WITH TOW PACKAGE (2WD) 18
FIGURE 1-5. AXLE INSTALLATION - OSCILLATING (4WD) 20
FIGURE 1-6. AXLE LOCKOUT VALVE ASSEMBLY 22
FIGURE 1-7. STEER INSTALLATION - WITHOUT TOW PACKAGE (2WD/2WS) 24
FIGURE 1-8. STEER INSTALLATION - WITH TOW PACKAGE (2WD/2WS) 26
FIGURE 1-9. STEER INSTALLATION - (4WD/2WS) (EC600SJ/H600SJ) 28
FIGURE 1-10. STEER INSTALLATION - (4WD/2WS) (EC600SJP/H600SJP) 32
FIGURE 1-11. WHEEL DRIVE INSTALLATION (NON UL SPECS) 34
FIGURE 1-12. WHEEL DRIVE INSTALLATION (UL SPECS) 36
FIGURE 1-13. NON-DRIVE HUB ASSEMBLY - LH (2WD FRONT) 40
FIGURE 1-14. NON-DRIVE HUB ASSEMBLY - RH (2WD FRONT) 42
FIGURE 1-15. DRIVE HUB ASSEMBLY (REAR) 44
FIGURE 1-16. DRIVE MOTOR ASSEMBLY (4WD FRONT) 48
FIGURE 1-17. DRIVE MOTOR ASSEMBLY (REAR) 50
FIGURE 1-18. DRIVE VALVE ASSEMBLY (4WD ONLY) 52
FIGURE 1-19. AC DRIVE ELECTRICAL PLATE ASSEMBLY (NON UL SPECS) 54
FIGURE 1-20. AC DRIVE ELECTRICAL PLATE ASSEMBLY (UL SPECS) 56
FIGURE 1-21. DRIVE MODULE PLATE ASSEMBLY 58
FIGURE 1-22. TIRE AND WHEEL INSTALLATION - 36/14LL X 22.5 FOAM-FILLED NON-MARKING 60
FIGURE 1-23. FRAME SHIELDS INSTALLATION 62
FIGURE 1-24. TOW PACKAGE INSTALLATION WITHOUT NATO EYE 64
FIGURE 1-25. TOW PACKAGE INSTALLATION WITH NATO EYE 66

SECTION 2 - TURNTABLE 69

FIGURE 2-1. MAIN CONTROL INSTALLATION - EC600SJ & H600SJ 70
FIGURE 2-2. MAIN CONTROL INSTALLATION - EC600SJP & H600SJP 72
FIGURE 2-3. MAIN CONTROL VALVE ASSEMBLY 74
FIGURE 2-4. SWING DRIVE INSTALLATION 78
FIGURE 2-5. SWING MOTOR ASSEMBLY 80
FIGURE 2-6. TURNTABLE BEARING, STOP AND LUBE INSTALLATION 84
FIGURE 2-7. TURNTABLE LOCK INSTALLATION 86
FIGURE 2-8. DRIVE ORIENTATION INSTALLATION 88
FIGURE 2-9. HYDRAULIC TANK AND PUMP/MOTOR INSTALLATION (NON-UL SPECS) 90
FIGURE 2-10. HYDRAULIC TANK AND PUMP/MOTOR INSTALLATION (UL SPECS) 92
FIGURE 2-11. ELECTRIC MOTOR ASSEMBLY 94
FIGURE 2-12. FUEL TANK AND ENGINE MODULE INSTALLATION - WITH STANDARD BATTERIES (H600SJ & H600SJP) 96
FIGURE 2-13. FUEL TANK AND ENGINE MODULE INSTALLATION - WITH AGM BATTERIES (H600SJ & H600SJP) 98
FIGURE 2-14. BATTERY CHARGER INSTALLATION - 110V/60HZ (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) (PVC 2001) 100
FIGURE 2-15. BATTERY CHARGER INSTALLATION - 110V/60HZ (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) (PVC 2007) 102
FIGURE 2-16. BATTERY CHARGER INSTALLATION - 120V-230V/45-65HZ (ALL SPECS EXCEPT UL SPECS) (PVC 2001) 104
FIGURE 2-17. BATTERY CHARGER INSTALLATION - 120V-230V/45-65HZ (ALL SPECS EXCEPT UL SPECS) (PVC 2007) 106
FIGURE 2-18. BATTERY CHARGER INSTALLATION - 120-240V/50-60HZ (ANSI, ANSI EXPORT, CHINA AND CSA SPECS) 108
FIGURE 2-19. BATTERY CHARGER INSTALLATION - 120-240V/50-60HZ (CE SPECS) (PVC 2001) 110
FIGURE 2-20. BATTERY CHARGER INSTALLATION - 120-240V/50-60HZ (CE SPECS) (PVC 2007) 112
FIGURE 2-21. BATTERY CHARGER INSTALLATION - 250V/50HZ (ANSI EXPORT, AUSTRALIAN AND CHINA SPECS) (PVC 2001) 114
FIGURE 2-22. BATTERY CHARGER INSTALLATION - 250V/50HZ (ANSI EXPORT, AUSTRALIAN AND CHINA SPECS) (PVC 2007) 116
FIGURE 2-23. BATTERY BOX INSTALLATION - STANDARD BATTERIES 118
FIGURE 2-24. BATTERY BOX INSTALLATION - AGM BATTERIES 120
FIGURE 2-25. BATTERY BOX INSTALLATION (UL SPECS) 122
FIGURE 2-26. GROUND CONTROL ELECTRICAL SYSTEM INSTALLATION 124
FIGURE 2-27. GROUND CONTROL PANEL INSTALLATION (EC600SJ/H600SJ) (ALL SPECS EXCEPT CE SPECS) 126
FIGURE 2-28. GROUND CONTROL PANEL INSTALLATION (EC600SJ/H600SJ) (CE SPECS) 128
FIGURE 2-29. GROUND CONTROL PANEL INSTALLATION (EC600SJP/H600SJP) (ALL SPECS EXCEPT CE SPECS) 130
FIGURE 2-30. GROUND CONTROL PANEL INSTALLATION (EC600SJP/H600SJP) (CE SPECS) 132
FIGURE 2-31. ENGINE CONTROLS INSTALLATION - STANDARD BATTERIES (H600SJ/H600SJP) 134

MidWestTech | JLG EC600SJ, EC600SJP, H600SJ, H600SJP Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-32. ENGINE CONTROLS INSTALLATION - AGM BATTERIES (H600SJ/H600SJP) 136
FIGURE 2-33. LIMIT SWITCH INSTALLATION 138
FIGURE 2-34. ALARM INSTALLATION 140
FIGURE 2-35. WHITE NOISE ALARM INSTALLATION 142
FIGURE 2-36. BEACON LIGHT INSTALLATION - AMBER 144
FIGURE 2-37. BEACON LIGHT INSTALLATION - BLUE 146
FIGURE 2-38. BEACON LIGHT INSTALLATION - RED 148
FIGURE 2-39. INVERTER INSTALLATION - 110V (OPTIONAL) 150
FIGURE 2-40. INVERTER INSTALLATION - 220V (OPTIONAL) 152
FIGURE 2-41. HOODS INSTALLATION 154

SECTION 3 - ENGINE 157

FIGURE 3-1. ENGINE AND GENERATOR INSTALLATION - WITH STANDARD BATTERIES (H600SJ/H600SJP ONLY) 158
FIGURE 3-2. ENGINE AND GENERATOR INSTALLATION - WITH AGM BATTERIES (H600SJ/H600SJP ONLY) 160
FIGURE 3-3. KUBOTA ENGINE ASSEMBLY (H600SJ/H600JP ONLY) 162
FIGURE 3-4. KUBOTA ENGINE COMPONENTS (H600SJ/H600JP ONLY) 164
FIGURE 3-5. EXHAUST STACK AND HOOD BAFFLES INSTALLATION - STANDARD BATTERIES (H600SJ/H600SJP) 168
FIGURE 3-6. EXHAUST STACK AND HOOD BAFFLES INSTALLATION - AGM BATTERIES (H600SJ/H600SJP) 170

SECTION 4 - BOOM 173

FIGURE 4-1. BOOM INSTALLATION (EC600SJ/H600SJ) 174
FIGURE 4-2. BOOM INSTALLATION (EC600SJP/H600SJP) 178
FIGURE 4-3. MAIN BOOM ASSEMBLY (EC600SJ/H600SJ) 182
FIGURE 4-4. MAIN BOOM ASSEMBLY (EC600SJP/H600SJP) 184
FIGURE 4-5. ROTATOR ASSEMBLY (EC600SJ/H600SJ) 186
FIGURE 4-6. PLATFORM SUPPORT INSTALLATION 188
FIGURE 4-7. BOOM VALVE INSTALLATION (EC600SJ/H600SJ) 190
FIGURE 4-8. BOOM VALVE INSTALLATION (EC600SJP/H600SJP) 192
FIGURE 4-9. BOOM VALVE ASSEMBLY (EC600SJ/H600SJ) 194
FIGURE 4-10. BOOM VALVE ASSEMBLY (EC600SJP/H600SJP) 196

SECTION 5 - PLATFORM 199

FIGURE 5-1. PLATFORM ASSEMBLY - 30IN X 3FT (76CM X 91.5CM) - WITH DROP BAR 200
FIGURE 5-2. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) - SIDE GATE ENTRY 202
FIGURE 5-3. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) - WITH DROP BAR 204
FIGURE 5-4. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) - SIDE GATE ENTRY 206
FIGURE 5-5. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) - WITH DROP BAR 208
FIGURE 5-6. PLATFORM ASSEMBLY - 30IN X 6FT (0.9M X 1.83M) (FALL ARREST PLATFORM) 210
FIGURE 5-7. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH SWING GATE 212
FIGURE 5-8. PLATFORM ASSEMBLY - 3FT X 6FT (91.5CM X 1.83M) - TRI-ENTRY - 1 SWING GATE/2 DROP BARS 214
FIGURE 5-9. PLATFORM ASSEMBLY - 3FT X 6FT (91.5CM X 1.83M) - TRI-ENTRY - 3 DROP BARS 216
FIGURE 5-10. PLATFORM ASSEMBLY - 3F X 6FT (91.5CM X 1.83M) (FALL ARREST PLATFORM) 218
FIGURE 5-11. PLATFORM ASSEMBLY - 3FT X 8FT (91.5CM X 2.44M) WITH SWING GATE 220
FIGURE 5-12. PLATFORM CONSOLE INSTALLATION - 2WD (ALL SPECS EXCEPT UL SPECS) 222
FIGURE 5-13. PLATFORM CONSOLE INSTALLATION - 2WD (UL SPECS) 224
FIGURE 5-14. PLATFORM CONSOLE INSTALLATION - 4WD (ALL SPECS EXCEPT UL SPECS) 226
FIGURE 5-15. PLATFORM CONSOLE INSTALLATION - 4WD (UL SPECS) 228
FIGURE 5-16. PLATFORM CONSOLE ASSEMBLY - 2WD (ALLSPECS EXCEPT UL SPECS) 230
FIGURE 5-17. PLATFORM CONSOLE ASSEMBLY - 2WD (UL SPECS) 234
FIGURE 5-18. PLATFORM CONSOLE ASSEMBLY - 4WD (ALLSPECS EXCEPT UL SPECS) 238
FIGURE 5-19. PLATFORM CONSOLE ASSEMBLY - 4WD (UL SPECS) 242
FIGURE 5-20. CONTROLLER ASSEMBLY - DRIVE AND STEER 246
FIGURE 5-21. CONTROLLER ASSEMBLY - LIFT AND SWING 248
FIGURE 5-22. FOOTSWITCH ASSEMBLY 252
FIGURE 5-23. ENGINE CONTROLS INSTALLATION - STANDARD BATTERIES (H600SJ/H600SJP) 254
FIGURE 5-24. ENGINE CONTROLS INSTALLATION - AGM BATTERIES (H600SJ/H600SJP) 256
FIGURE 5-25. JIB ROTATE SWITCH INSTALLATION (EC600SJP/H600SJP) 258
FIGURE 5-26. LIGHT PANEL INSTALLATION 260
FIGURE 5-27. TRAY ASSEMBLY 262
FIGURE 5-28. SKYEYE INSTALLATION 264
FIGURE 5-29. SKYGUARD BAR INSTALLATION 266
FIGURE 5-30. SKYLINE INSTALLATION 268
FIGURE 5-31. SOFT TOUCH INSTALLATION (SIDE ENTRY PLATFORM) (OPTIONAL) 270
FIGURE 5-32. SOFT TOUCH INSTALLATION - WITH FALL ARREST (SIDE ENTRY PLATFORM) (OPTIONAL) 272

MidWestTech | JLG EC600SJ, EC600SJP, H600SJ, H600SJP Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

FIGURE 5-33. SKYGLAZIER INSTALLATION (ANSI AND CSA SPECS) 274
FIGURE 5-34. SKYGLAZIER INSTALLATION (ANSI EXPORT SPECS) (SPANISH/PORTUGUESE) 276
FIGURE 5-35. SKYGLAZIER INSTALLATION (ANSI EXPORT SPECS) (ENGLISH/SPANISH) 278
FIGURE 5-36. FALL ARREST INSTALLATION (BOLT-ON EXTERNAL) (6FT/1.82M PLATFORM) 280
FIGURE 5-37. FALL ARREST INSTALLATION (BOLT-ON EXTERNAL) (6FT/1.82M TRI-ENTRY PLATFORM) 282
FIGURE 5-38. FALL ARREST INSTALLATION (BOLT-ON EXTERNAL) (8FT/2.4M PLATFORM) 284

SECTION 6 - CYLINDERS 287

FIGURE 6-1. AXLE LOCKOUT CYLINDER ASSEMBLY 288
FIGURE 6-2. LEVEL CYLINDER ASSEMBLY - PLATFORM SLAVE 290
FIGURE 6-3. LIFT CYLINDER ASSEMBLY - JIB 292
FIGURE 6-4. LIFT CYLINDER ASSEMBLY - MAIN (PRIOR TO PVC 2001) 294
FIGURE 6-5. LIFT CYLINDER ASSEMBLY - MAIN (PVC 2001) 296
FIGURE 6-6. MASTER CYLINDER ASSEMBLY 298
FIGURE 6-7. STEER CYLINDER ASSEMBLY 300
FIGURE 6-8. TELESCOPE CYLINDER ASSEMBLY 302

SECTION 7 - HYDRAULIC 305

FIGURE 7-1. HYDRAULIC DIAGRAM - AXLE (FIXED) 306
FIGURE 7-2. HYDRAULIC DIAGRAM - AXLE (OSCILLATING) 308
FIGURE 7-3. HYDRAULIC DIAGRAM - DRIVE (2WD) 310
FIGURE 7-4. HYDRAULIC DIAGRAM - DRIVE (4WD) 312
FIGURE 7-5. HYDRAULIC DIAGRAM - STANDARD (EC600SJ/H600SJ) (PRIOR TO PVC 2001) 314
FIGURE 7-6. HYDRAULIC DIAGRAM - STANDARD (EC600SJ/H600SJ) (PVC 2001) 318
FIGURE 7-7. HYDRAULIC DIAGRAM - STANDARD (EC600SJP/H600SJP) (PRIOR TO PVC 2001) 322
FIGURE 7-8. HYDRAULIC DIAGRAM - STANDARD (EC600SJP/H600SJP) (PVC 2001) 326
FIGURE 7-9. HYDRAULIC DIAGRAM - TOW 330

SECTION 8 - ELECTRICAL 333

FIGURE 8-1. AC BOX AT PLATFORM - LOCALLY SUPPLIED COMPONENTS 334
FIGURE 8-2. AC BOX AT PLATFORM INSTALLATION - 110V (ALL SPECS EXCEPT AUSTRALIAN & CE SPECS) 336
FIGURE 8-3. AC BOX AT PLATFORM INSTALLATION - 110V IEC YELLOW (CE SPEC) 338
FIGURE 8-4. AC BOX AT PLATFORM INSTALLATION - 220V IEC BLUE (CE SPEC) 340
FIGURE 8-5. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 POST GROUND WITH 2IN X 4IN BOX (CE SPEC) 342
FIGURE 8-6. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 SIDE GROUND WITH 2IN X 4IN BOX (CE SPEC) 344
FIGURE 8-7. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT 107 KEYED GROUND WITH 2IN X 4IN BOX 346
FIGURE 8-8. AC BOX AT PLATFORM INSTALLATION - 220V (ANSI, CSA & JAPANESE SPECS 348
FIGURE 8-9. BATTERY BOX CABLE ASSEMBLY (RH SIDE BOX) (STANDARD BATTERIES) 350
FIGURE 8-10. BATTERY BOX CABLE ASSEMBLY (LH SIDE BOX) (STANDARD BATTERIES) 352
FIGURE 8-11. BATTERY BOX CABLE ASSEMBLY (AGM BATTERIES) 354
FIGURE 8-12. BATTERY CHARGER ASSEMBLY 356
FIGURE 8-13. BEACON LIGHT HARNESS (AMBER BEACON ONLY) 358
FIGURE 8-14. BEACON LIGHT HARNESS (BLUE & RED BEACON ONLY) 360
FIGURE 8-15. BOOM TRANSPORT HARNESS (CE SPECS ONLY) 362
FIGURE 8-16. BOOM CABLE - LOWER 364
FIGURE 8-17. BOOM CABLE - UPPER (EC600SJ/H600SJ) 366
FIGURE 8-18. BOOM CABLE - UPPER (EC600SJP/H600SJP) 368
FIGURE 8-19. BREAKER BOX KIT WITH ONE BREAKER - CE SPEC 370
FIGURE 8-20. BREAKER BOX KIT WITH TWO BREAKERS - CE SPEC 372
FIGURE 8-21. CABLES AND CLAMPS INSTALLATION (EC600SJ/H600SJ) (ALL SPECS EXCEPT AUSTRALIAN & CE SPECS) 374
FIGURE 8-22. CABLES AND CLAMPS INSTALLATION (EC600SJ/H600SJ) (CE SPECS) 376
FIGURE 8-23. CABLES AND CLAMPS INSTALLATION (EC600SJP/H600SJP) (ALL SPECS EXCEPT AUSTRALIAN & CE SPECS) 378
FIGURE 8-24. CABLES AND CLAMPS INSTALLATION - SINGLE AC BOX (EC600SJP/H600SJP) (AUSTRALIAN & CE SPECS) 380
FIGURE 8-25. CABLES AND CLAMPS INSTALLATION - DUAL AC BOXES (EC600SJP/H600SJP) (CE SPECS) 382
FIGURE 8-26. CHARGER CORD PLUG INSTALLATION - 110V - IEC YELLOW (CE SPEC) 384
FIGURE 8-27. CHARGER CORD PLUG INSTALLATION - 220V - IEC BLUE (CE SPEC) 386
FIGURE 8-28. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 POST GROUND (CE SPEC) 388
FIGURE 8-29. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 SIDE GROUND (CE SPEC) 390
FIGURE 8-30. CHARGER CORD PLUG INSTALLATION - 220V - AFSINT 107 KEYED GROUND (CE SPEC) 392
FIGURE 8-31. CHARGER CORD PLUG INSTALLATION (CHINA SPEC) 394
FIGURE 8-32. DRIVE CABLE KIT (ALL SPECS EXCPET UL SPECS) 396

MidWestTech | JLG EC600SJ, EC600SJP, H600SJ, H600SJP Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

FIGURE 5-20. CONTROLLER ASSEMBLY - DRIVE AND STEER

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001166538	Ref	CONTROLLER ASSEMBLY (DRIVE AND STEER)	G
		Ref	Note: Original Equipment Controller May Have Been Replaced with Service Replacement Controller. Visually Identify Controller Before Ordering Parts.	
		Ref	Note: Use p/n 1001212415 Kit as Replacement.	
7	70004738	2	Washer	
10	70004739	1	Roller	
11	70004740	1	Boot, Switch	
14	70004741	2	Half, Handle	
17	70004742	1	Enclosure	
18	70004743	4	Nut	
19	70004744	NLA	Boot, Controller (Note: Use Item 200)	
20	70004745	NLA	Tube, Locking (Note: Use Item 200)	
21	70004746	NLA	Disc, Locking (Note: Use Item 200)	
25	70004747	2	Seal, Rope	
26	70004748	1	Screw M3 x 6	
28	70004749	2	Screw M5 x 20	
29	70004750	1	Pin, Dowel	
30	70004751	4	Screw M3 x 16	
101	4460265	1	Connector - 9 Position	
101	4460226	7	Socket, Female	
200	70005230	1	Boot Kit (Includes Items 19-21)	

MidWestTech | JLG EC600SJ, EC600SJP, H600SJ, H600SJP Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

FIGURE 6-8. TELESCOPE CYLINDER ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001228017	Ref	TELESCOPE CYLINDER ASSEMBLY	A
1	0100011	AR	Locking, Compound	
2	0100038	AR	Primer, Locking	
4	0630535	3	Bolt 1/4 x 1-1/8	
5	0641606	4	Bolt 3/8 x 3/4	
6	0961902	1	Bushing, Tapered	
7	See Note	NSS	Barrel (Note: Use Item 100)	
8	70006709	1	Rod	
9	70006710	1	Head	
10	2220885	2	Plug, O-Ring	
12	3340880	2	Pad, Support	
13	70006711	1	Piston	
14	3572040	1	Plate, Support	
15	See Note	NSS	Ring, Wear (Note: Use Item 100)	
16	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
17	See Note	NSS	Ring, Wear (Note: Use Item 100)	
18	See Note	NSS	O-Ring (Note: Use Item 100)	
19	See Note	NSS	O-Ring (Note: Use Item 100)	
20	See Note	NSS	O-Ring (Note: Use Item 100)	
21	3931448	4	Capscrew 1/4 x 3	
22	3931528	8	Bolt 5/16 x 1-3/4	
23	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
24	See Note	NSS	Wiper (Note: Use Item 100)	
25	See Note	NSS	Seal (Note: Use Item 100)	
26	See Note	NSS	Seal, Rod (Note: Use Item 100)	
27	70006712	1	Spacer	
28	4641179	1	Valve Assembly (Note: No Serviceable Parts - Purchase Complete Valve)	
28A	7026616	1	Seal Kit - 4641179 Valve	
100	2902019	1	Seal Kit (Includes Items 7, 15-20 & 23-26)	

MidWestTech | JLG EC600SJ, EC600SJP, H600SJ, H600SJP Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >

FIGURE 9-7. DECAL INSTALLATION - KOREAN SPECS (KOREAN LANGUAGE)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001248328	Ref	DECAL INSTALLATION	B
	1001249148	Ref	DECAL INSTALLATION - REFERENCE CHART	C
1	1703927	1	Decal - Danger/Warning (Platform)	
2	1704668	1	Decal - Danger/Warning (MTB)	
3	1703939	4	Decal - Electrocution	
4	1703951	3	Decal - Crushing	
12	1704277	3	Decal - Attach Lanyard	
13	1001253924	1	Decal - Warning/ Capacity	
14	1001253925	1	Decal - Warning/ Capacity	
16	1701502	1	Decal - Hydraulic Oil Level High	
17	1701503	1	Decal - Hydraulic Oil Level Low	
18	1701504	1	Decal - Hydraulic Oil	
20	See Note	NSS	Decal - Bar Code (Note: Not Available for Purchase)	
23	1701509	1	Decal - Manual	
24	1702300	6	Decal - Tie Down	
25	1701500	4	Decal - Lift	
26	1701529	2	Decal - Arrow	
28	0860520	1	Box, Manual Storage	
31	1703945	3	Decal - Warning/Crushing	
33	3820001	2	Rivet	
34	1703981	1	Nameplate - Footswitch	
35	1704708	4	Decal - Maximum Tire Load	
36	1701644	1	Decal - Charger	
37	1704705	1	Decal - Manual Descent	
38	1704120	1	Decal - Instructions Inside	
40	1701501	2	Decal - Arrow	
41	1704332	1	Decal - Battery Charger Instructions	
42	1702155	2	Decal - Battery Disconnect	
43	1704412	1	Decal - Oil Chart	
48	3311405	4	Nut 1/4	
49	4751400	4	Washer 1/4	
51	1704343	2	Decal - Warning Battery Ventilation	
52	1706377	1	Decal - Lift Diagram	
54	1001209679	1	Decal - Cable Routing	
62	1701499	2	Decal - No Lift	
63	1701517	2	Decal - Warning Hand Crushing	
64	1704670	2	Decal - Tip Over (Battery Weight)	
66	1704885	1	Decal - Website	
67	0641406	4	Bolt 1/4 x 3/4 (Not Shown)	
69	1705427	1	Decal - Drive/Steer Instructions	
73	1001224048	1	Decal - Yearly Inspection	

MidWestTech | JLG EC600SJ, EC600SJP, H600SJ, H600SJP Boom Lift Parts Manual | Pu... Order the manual at mid-west-tech.com >