An Oshkosh Corporation Company

Service and Maintenance Manual

Model H800AJ

PVC 2001


31215043

November 4, 2019 - Rev A

ANSI

CE

AS/NZS



Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		
A	General	A-1
B	Hydraulic System Safety	A-1
C	Maintenance	A-2
SECTION 1 - SPECIFICATIONS		
1.1	Operating Specifications	1-1
1.2	Tires	1-1
1.3	Capacities	1-1
1.4	Engine Data	1-1
1.5	Hydraulic Oil	1-2
1.6	Critical Stability Weights	1-3
1.7	Maintenance and Lubrication	1-5
1.8	ThreadLocking Compound	1-8
1.9	Torque Charts	1-9
	SAE Fastener Torque Chart	1-9
	Metric Fastener Torque Chart	1-15
SECTION 2 - GENERAL		
2.1	Machine Preparation, Inspection, and Maintenance	2-1
	General	2-1
	Preparation, Inspection, and Maintenance	2-1
	Pre-Start Inspection	2-1
	Pre-Delivery Inspection and Frequent Inspection	2-1
	Annual Machine Inspection	2-1
	Preventive Maintenance	2-1
2.2	Service and Guidelines	2-2
	General	2-2
	Safety and Workmanship	2-2
	Cleanliness	2-2
	Components Removal and Installation	2-2
	Component Disassembly and Reassembly	2-3
	Pressure-Fit Parts	2-3
	Bearings	2-3
	Gaskets	2-3
	Bolt Usage and Torque Application	2-3
	Hydraulic Lines and Electrical Wiring	2-3
	Hydraulic System	2-3
	Lubrication	2-4
	Battery	2-4
	Lubrication and Servicing	2-4
2.3	Lubrication and Information	2-4
	Hydraulic System	2-4
	Hydraulic Oil	2-4
	Changing Hydraulic Oil	2-4
	Lubrication Specifications	2-4
2.4	Cylinder Drift	2-5
	Theory	2-5
	Cylinder Leakage Test	2-5
	Cylinder Thermal Drift	2-5
2.5	Pins and Composite Bearing Repair Guidelines	2-6
2.6	Welding on JLG Equipment	2-6
	Do the Following When Welding on JLG Equipment	2-6
	DO NOT Do the Following When Welding on JLG Equipment	2-6

MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >

SECTION NO. **TITLE** **PAGE NO.**

SECTION 3 - CHASSIS & TURNTABLE

3.1 Tires & Wheels 3-1
Tire Damage 3-1
Tire Replacement 3-1
Wheel Replacement 3-1
Wheel Installation 3-1
3.2 Powertrain Operating Modes 3-2
Hybrid Mode 3-2
Electric Mode 3-2
Switching Between Modes on the Fly 3-2
Idle Reduction Stop Start 3-3
3.3 Drive Orientation System 3-4
3.4 Oscillating Axle System 3-4
3.5 Lockout Cylinder Bleeding 3-5
3.6 Oscillating Axle Lockout Test 3-8
3.7 Drive System 3-10
3.8 Drive Hub (Torque) 3-11
Removal 3-11
Installation 3-11
3.9 Drive Hub 3-12
Assembly/Disassembly 3-12
3.10 Drive brake 3-12
3.11 Drive Motor 3-12
Removal 3-12
Installation 3-12
Description 3-13
Shaft Seal Replacement 3-13
Loop Flushing Valve 3-14
Troubleshooting 3-15
Disassembly 3-16
Inspection 3-20
Assembly 3-22
Initial Start-up Procedures 3-27
3.12 Swing Drive 3-30
Roll, Leak And Brake Testing 3-30
Tightening and Torquing Bolts 3-31
Motor Control Valve Disassembly 3-32
Motor and Brake Disassembly 3-33
Main Drive Disassembly 3-34
Hub-Shaft Disassembly 3-35
Carrier Disassembly 3-36
Hub-Shaft Assembly 3-37
Carrier Assembly 3-37
Main Drive Assembly 3-38
Motor and Brake Assembly 3-39
Motor Control Valve Assembly 3-40
3.13 Swing Motor 3-47
Disassembly and inspection 3-47
Assembly 3-54
One Piece Stator Construction 3-62
3.14 Swing Hub Installation 3-63
Procedure For Setting Swing Gear Backlash 3-63
Swing Drive Lubrication 3-64
3.15 Swing Hub Removal 3-64

MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
3.16	Swing Bearing	3-65
	Turntable Bearing Mounting Bolt Condition Check	3-65
	Wear Tolerance	3-68
	Swing Bearing Replacement	3-68
	Swing Bearing Torque Values	3-69
3.17	Chassis Tilt Indicator System	3-71
3.18	Rotary Coupling	3-72
3.19	Generator	3-78
	Maintenance Schedule	3-78
	Overload Protection	3-79
	Inspecting Brushes, Replacing Brushes, and Cleaning Slip Rings	3-79
	Troubleshooting	3-81
	Generator Disassembly and Assembly	3-82
	Lead Connection List for Generator	3-90
3.20	Cold Start System	3-96
	Engine Warmup	3-96
3.21	Clutch Adapter Plate Installation	3-96
3.22	Clutch Kit & Release Shaft Installation	3-97
	Clutch Kit	3-97
	Release Shaft	3-98
3.23	Clutch Installation	3-99
3.24	Clutch Linear Actuator/Throwout Bearing Positioning installation Procedure	3-99
3.25	Counterweight	3-102
SECTION 4 - BOOM & PLATFORM		
4.1	Boom Systems	4-1
	Switch Systems	4-1
	Above Elevation (Above Horizontal) Cutout System	4-1
	Beyond Transport Position - Drive Speed Cutback System	4-1
	Drive/Steer – Boom Function Interlock System (CE Only)	4-1
	Transport Position Interlock System (CE only)	4-1
	Platform Control Enable System	4-1
	Function Speed Control System	4-1
	Platform	4-2
	Main Lift End Stroke Dampening System	4-2
	QuikStick Lift System	4-2
	Tower Boom Sequence Valve System	4-2
	Upright Level Override System	4-2
	Ground Control Keyswitch System	4-2
4.2	Main Boom Assembly	4-6
	Removal	4-6
	Disassembly	4-7
	Inspection	4-7
	Assembly	4-7
	Installation	4-8
4.3	Upright	4-9
	Removal	4-9
	Installation	4-10
4.4	Tower Boom Assembly	4-12
	Removal	4-12
	Inspection	4-12
	Assembly	4-13
	Installation	4-13
	Tower Out of Sync	4-14

MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >

4. Fuel Filter/Water Separator



Lube Point(s) - Replaceable Element
Interval - Drain water daily; Change every year or 600hours of operation.

5. Fuel Strainer




Lube Point(s) - Replaceable Element
Interval - Change every year or 600 hours of operation.

6. Radiator



Lube Point(s) - Fill Cap
Lube - Anti-Freeze Coolant (Fleet Charge A/F 50/50 or equivalent)
Capacity - 6 qt. (5.7 L)
Interval - Check coolant level daily. Ensure it is between the "FULL" and "LOW" lines. If coolant level is low, allow fluid to cool, then add as required.

7. Swing Drive Hub



Lube Point(s) - Level/Fill Plug
Capacity - 43 oz. (1.3 L)
Lube - 90w80 Gear Oil
Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation.

MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >

Fault- logic Trouble Shooting

Match the transmission symptoms with the problem statements and follow the action steps shown in the box diagrams. This will give expedient aid in correcting minor problems eliminating unnecessary machine down time.

Following the fault - logic diagrams are diagram action comments of the action steps shown in the diagrams. Where applicable, the comment number of the statement appears in the action block of the diagrams.

RECOMMENDED GAUGE LOCATIONS

Gauges Recommended

Inlet vacuum gauge: 30 PSI to 14.8 PSI (2 bar to 1 bar)

System pressure gauge: 10,000 PSI (700 bar)

Charge pressure gauge: 0 to 600 PSI (0 to 50 bar)

Case pressure gauge: 0 to 300 PSI (0 to 25 bar)




Figure 5-121. Gauge Locations

MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >




Figure 7-110. Skyguard Harness


MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >


5. Install the pin into the center hole, then slide the washer over the pin. Install the snap ring into the groove in the pin.





NOTE: *When installing snap rings make sure they are seated in the pin groove and closed properly.*





MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >

WH245 ENG FAN					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	BLK	0-14-9	10AWG	GXL	X247(1)
2	WHT	49-26 ENG FAN	10AWG	GXL	X466(1)

SN215 ENG SPD SNSR					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	YEL	2-16-1	18AWG	TXL	X465(R)
2	WHT	48-21 ENG SPD SNSR	18AWG	TXL	X465(S)
3	BLK	0-16	18AWG	TXL	X465(T)

X223 PROP FUEL RACK ACT					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	WHT	60-5 THROTTLE RTN	18AWG	GXL	X465(N)
2	WHT	48-13 THR ACT	18AWG	GXL	X465(P)

X247 TO GROUND					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	BLK	0-14-9	10AWG	GXL	WH245(1)

X327 TO GROUND					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	BLK	0-27	16AWG	GXL	X465(O)

EC193 GLOW PLUGS					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	WHT	48-23GLOW	10AWG	GXL	X466(3)

SW196 OIL PRS SNSR					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	WHT	48-20 OIL PRS	18AWG	GXL	X465(V)

EC194 ALTERNATOR					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1					
2	WHT	48-16 ALT EXC	18AWG	GXL	X465(Q)
3					

SN197 COOL TEMP SNSR					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	WHT	48-19 TEMP SNSR	18AWG	GXL	X465(W)
2	BLK	0-19	18AWG	GXL	X465(X)

HV325 DRV FWD					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	WHT	25-1 DRV FWD	18AWG	GXL	X465(C)
2	WHT	60-4-1 DRIVE RTN	18AWG	GXL	S214(1)

HV326 DRV REV					
CONN POS	WIRE COLOR	WIRE LABEL	GAUGE	JACKET	TO
1	WHT	25-2DRVREV	18AWG	GXL	X465(B)
2	WHT	60-4-2DRIVERTN	18AWG	GXL	S214(1)

MidWestTech | JLG H800AJ Boom Lift Service Manual | Publication 31215043 Order the manual at mid-west-tech.com >